# **SIEMENS**



Operating Instructions

# **SINAMICS**

**SINAMICS G120 und G120P** 

Low voltage converters Built-in and wall mounting units with CU230P-2 Control Units

Edition 02/2023

# **SIEMENS**

# Changes in the current edition

edition	
Fundamental safety instructions	1
Introduction	2
Description	3
Installing	4
Commissioning	5
Uploading the converter settings	6
Protecting the converter settings	7
Advanced commissioning	8
Alarms, faults and system messages	9
Corrective maintenance	10
Technical data	11

**Appendix** 

**SINAMICS** 

SINAMICS G120, G120P Converter with CU230P-2 Control Units

**Operating Instructions** 

Edition 02/2023, Firmware V4.7 SP14

#### Legal information

#### Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

#### **DANGER**

indicates that death or severe personal injury will result if proper precautions are not taken.



#### WARNING

indicates that death or severe personal injury may result if proper precautions are not taken.



#### CAUTION

indicates that minor personal injury can result if proper precautions are not taken.

#### NOTICE

indicates that property damage can result if proper precautions are not taken.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

#### **Qualified Personnel**

The product/system described in this documentation may be operated only by personnel qualified for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

#### **Proper use of Siemens products**

Note the following:



#### WARNING

Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

#### **Trademarks**

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

#### **Disclaimer of Liability**

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

# Changes in the current edition

### Essential changes with respect to Edition 10/2020

#### **New functions**

SINAMICS G115D converter now supports the extended function 'Safety Limited Speed (SLS)' with the firmware version V4.7 SP14.

Overview of new and modified function in firmware V4.7 SP14:



# **Table of contents**

	Changes	in the current edition	3
1	Fundame	ental safety instructions	13
	1.1	General safety instructions	13
	1.2	Equipment damage due to electric fields or electrostatic discharge	20
	1.3	Warranty and liability for application examples	21
	1.4	Security information	22
	1.5	Residual risks of power drive systems	23
2	Introduct	tion	25
	2.1	About the Manual	25
	2.2	Guide through the manual	26
3	Description	on	29
	3.1	Intended use	
	3.2	OpenSSL	30
	3.3	Transferring OpenOSS license terms to a PC	31
	3.4	Identifying the converter	32
	3.5	Directives and standards	33
	3.6	Control Units	35
	3.7 3.7.1 3.7.2	Power Module	37
	3.7.2	Components for the Power Modules	
	3.8.1	Accessories for shielding	
	3.8.2	Line filter	
	3.8.3 3.8.4	Line reactor	
	3.8.5	((dv/dt filter plus VPL PM240-2))	
	3.8.6	Sine-wave filter	
	3.8.7	dv/dt filter	
	3.8.8	Braking Module and braking resistor	
	3.8.9	Control Unit Adapter Kit CUA20	
	3.9	Motors and multi-motor drives that can be operated	61
4	Installing	]	63
	4.1	Installing the label for the North American market	63
	4.2	EMC-compliant setup of the machine or plant	
	4.2.1	Control cabinet	65

4.2.2 4.2.3	Cables Electromechanical components	
4.3	Installing reactors, filters and braking resistors	70
4.4 4.4.1 4.4.2 4.4.3 4.4.4 4.4.5 4.4.6 4.4.7 4.4.8	Installing Power Modules	71 71 72 74 77 79 80
4.5 4.5.1.1 4.5.1.2 4.5.1.3 4.5.2 4.5.3 4.5.4 4.5.5 4.5.6 4.5.7 4.5.8 4.5.9	Connecting the line supply and motor  Permissible line supplies  TN line system  IT system  Requirements for the protective conductor  Connecting the converter with the PM230 Power Module IP55  Connecting the converter with the PM230 Power Module  Connecting the converter with the PM330 Power Module  Connecting the converter with the PM240P-2 Power Module  Connecting a converter with the PM240P-2 Power Module  Connecting the converter with the PM240P-2 Power Module  Connecting the converter with the PM250 Power Module  Connecting the motor to the converter in a star or delta connection	90 91 93 94 95 102 104 105 117
4.6 4.6.1 4.6.2 4.6.3 4.6.4 4.6.5 4.6.6 4.6.7 4.6.8 4.6.9 4.6.10 4.6.11 4.6.12 4.6.13 4.6.13.1 4.6.13.2 4.6.13.3 4.6.13.4	Connecting the interfaces for the converter control Plugging the Control Unit onto the Power Module Overview of the interfaces Fieldbus interface allocation  Terminal strips Factory interface settings Default setting of the interfaces Additional digital inputs and outputs on PM330 Power Modules Safe Torque Off (STO) safety function Application examples for "Safe Torque Off" Wiring terminal strips Connecting the temperature contact of the braking resistor Fieldbus interfaces Connecting the converter to PROFINET Communication via PROFINET IO and Ethernet Connecting the PROFINET cable to the converter What do you have to set for communication via PROFINET? Installing GSDML	115 119 120 124 144 146 153 157 157 159
4.6.14 4.6.14.1 4.6.14.2 4.6.14.3 4.6.14.4	Connecting the converter to PROFIBUS  Connecting the PROFIBUS cable to the converter	160 161 161 162

5	Commissi	ioning	165
	5.1	Commissioning guidelines	165
	5.2	Tools to commission the converter	166
	5.3	Preparing for commissioning	168
	5.3.1	Collecting motor data	168
	5.3.2	Forming DC link capacitors	
	5.3.3	Converter factory setting	172
	5.4	Quick commissioning using the BOP-2 operator panel	
	5.4.1	Inserting the BOP-2	
	5.4.2	Starting quick commissioning	
	5.4.3	Quick commissioning with application classes	
	5.4.3.1	Overview	
	5.4.3.2 5.4.3.3	Select the application class	
	5.4.3.4	Standard Drive Control	
	5.4.3.5	Expert	
	5.4.3.3 5.4.4	Identifying the motor data and optimizing the closed-loop control	
		·	
	5.5	Quick commissioning with a PC	
	5.5.1	Creating a project	
	5.5.2	Transfer converters connected via USB into the project	196
	5.5.3	Go online and start the commissioning Wizard	
	5.5.4 5.5.5	Commissioning wizard	
	5.5.6	Dynamic Drive Control	
	5.5.7	Expert	
	5.5.8	Identify motor data	
	5.6	Restoring the factory settings	
	5.7	Series commissioning	211
	5.8	Handling the BOP 2 operator panel	212
	5.8.1	Switching the motor on and off	
	5.8.2	Changing parameter values	
	5.8.3	Changing indexed parameters	
	5.8.4	Entering the parameter number directly	216
	5.8.5	Entering the parameter value directly	217
	5.8.6	Why can a parameter value not be changed?	218
6	Uploading	g the converter settings	219
	6.1	Uploading to the memory card	220
	6.1.1	Recommended memory cards	220
	6.1.2	Automatic upload	
	6.1.3	Message for a memory card that is not inserted	
	6.1.4	Manual upload with Startdrive	
	6.1.5	Manual upload with BOP-2	
	6.1.6	Safely removing a memory card using the BOP-2	
	6.1.7	Safely remove the memory card with Startdrive	225
	6.2	Uploading to the BOP-2	227
	6.3	Upload to a PC using Startdrive	228

	6.4	More options for the upload	229
7	Protectin	ng the converter settings	231
	7.1	Write protection	231
	7.2	Know-how protection	233
	7.2.1	Know-how protection	233
	7.2.2	Extending the exception list for know-how protection	237
	7.2.3	Activating and deactivating know-how protection	238
8	Advance	ed commissioning	241
	8.1	Overview of the converter functions	241
	8.2	Brief description of the parameters	244
	8.3	Sequence control when switching the motor on and off	245
	8.4	Adapt the default setting of the terminal strip	248
	8.4.1	Digital inputs	
	8.4.2	Analog inputs as digital inputs	
	8.4.3	Digital outputs	252
	8.4.4	Analog inputs	254
	8.4.5	Adjusting characteristics for analog input	
	8.4.6	Setting the deadband	
	8.4.7	Analog outputs	
	8.4.8	Adjusting characteristics for analog output	260
	8.5	Safe Torque Off (STO) safety function	
	8.5.1	Safe Torque Off (STO) safety function	
	8.5.2	Setting the feedback signal for Safe Torque Off	
	8.6	Controlling clockwise and counter-clockwise rotation via digital inputs	
	8.6.1	Two-wire control, ON/reverse	
	8.6.2	Two-wire control, clockwise/counterclockwise rotation 1	
	8.6.3	Two-wire control, clockwise/counterclockwise rotation 2	
	8.6.4	Three-wire control, enable/clockwise/counterclockwise rotation	
	8.6.5	Three-wire control, enable/ON/reverse	276
	8.7	Drive control via PROFIBUS or PROFINET	
	8.7.1	Receive data and send data	
	8.7.2	Telegrams	
	8.7.3	Parameter channel	
	8.7.4	Examples	
	8.7.5	Expanding or freely interconnecting telegrams	
	8.7.6	Device-to-device communication	
	8.7.7	Acyclically reading and writing converter parameters	
	8.8	Drive control via USS	
	8.9	Drive control via Modbus RTU	
	8.10	Drive control via Ethernet/IP	
	8.11	Drive control via BACnet MS/TP	307
	8.12	Drive control via P1	
	8.13	Jogging	311

8.14	Switching over the drive control (command data set)	313
8.15 8.15.1	Free function blocksOverview	
8.16 8.16.1 8.16.2 8.16.3 8.16.4	Physical units  Motor standard  Unit system  Technological unit of the technology controller  Setting the system of units and technology unit	317 317 319
8.17 8.17.1 8.17.2 8.17.3 8.17.4	Setpoints	323 324 325
8.18 8.18.1 8.18.2 8.18.3 8.18.4 8.18.5 8.18.6	Setpoint processing Overview Invert setpoint Enable direction of rotation Skip frequency bands and minimum speed. Speed limitation Ramp-function generator	
8.19 8.19.1 8.19.2	PID technology controller Autotuning the PID technology controller Adapting Kp and Tn	347
8.20	Free technology controllers	352
8.21	Multi-zone control	354
8.22	Cascade control	357
8.23	Real time clock (RTC)	361
8.24	Time switch (DTC)	363
8.24	Motor control	
8.25.1 8.25.2 8.25.2.1 8.25.2.2 8.25.2.3 8.25.2.4 8.25.3 8.25.3.1 8.25.3.2	Reactor, filter and cable resistance at the converter output	
8.26 8.26.1 8.26.2 8.26.3 8.26.4 8.26.5	Electrically braking the motor  Electrical braking  DC braking  Compound braking  Dynamic braking  Braking with regenerative feedback to the line	
8 27	Overcurrent protection	307

	8.28	Converter protection using temperature monitoring	393
	8.29	Motor protection with temperature sensor	396
	8.30	Motor protection by calculating the temperature	398
	8.31	How do I achieve a motor overload protection in accordance with IEC/UL 61800-5-1?	400
	8.32	Motor and converter protection by limiting the voltage	401
	8.33 8.33.1 8.33.2 8.33.3 8.33.4 8.33.5 8.33.6	Monitoring the driven load	404 404 405 406 408
	8.34	Flying restart – switching on while the motor is running	412
	8.35	Automatic restart	414
	8.36	Kinetic buffering (Vdc min control)	417
	8.37	Essential service mode	419
	8.38	Efficiency optimization	423
	8.39	Bypass	426
	8.40	Hibernation mode	430
	8.41	Line contactor control	434
	8.42	Calculating the energy saving for fluid flow machines	436
	8.43	Switchover between different settings	438
9	Alarms, fau	ults and system messages	441
	9.1	Operating states indicated via LEDs	442
	9.2	System runtime	445
	9.3	Identification & maintenance data (I&M)	446
	9.4	Alarms, alarm buffer, and alarm history	447
	9.5	Faults, alarm buffer and alarm history	450
	9.6	List of alarms and faults	453
10	Corrective	maintenance	461
	10.1	Replace Control Unit	463
	10.2 10.2.1 10.2.2 10.2.3 10.2.4 10.2.5 10.2.6 10.2.7	Downloading the converter settings	465 465 466 467 470
	10.2.7	Dominous month the reading startaine minimum.	175

10	).3	Replacing a Power Module	476
10	).4	PROFINET device name	478
10 10 10	0.5 0.5.1 0.5.2 0.5.3 0.5.4 0.5.5	Firmware upgrade and downgrade  Overview  Preparing the memory card  Upgrading the firmware  Firmware downgrade  Correcting an unsuccessful firmware upgrade or downgrade	479 480 481 483
10	).6	If the converter no longer responds	486
11 Te	chnical da	ıta	489
11	.1	Technical data, CU230P-2 Control Unit	489
11	.2	Overload capability of the converter	492
11 11 11 11		Technical data, PM230 Power Module  Ambient conditions	493 495 496 500 501
11 11 11 11 11	.4 .4.1 .4.2 .4.3 .4.4 .4.5 .4.6 .4.7	Technical Data, PM240P-2 Power Module  Ambient conditions  General technical data, 400 V converters  Specific technical data, 400 V converters  Current derating depending on the pulse frequency, 400 V converters  General technical data, 690 V converters  Specific technical data, 690 V converters  Current derating depending on the pulse frequency, 690 V converters	507 509 510 512 513 514
	.5 .5.1 .5.2	Technical data, PM330 Power Module	518
11 11 11 11 11 11		Technical data, PM240-2 Power Module  Ambient conditions	529 531 532 539 540 541 549 550 551
11 11		Technical data, PM250 Power Module	555 557

	11.8	Data regarding the power loss in partial load operation	561
	11.9 11.9.1	Restrictions for special ambient conditions  Permissible line supplies dependent on the installation altitude	
	11.10	Protecting persons from electromagnetic fields	564
Α	Appendix	<b></b>	565
	A.1	New and extended functions	565
	A.1.1	Firmware version 4.7 SP14	565
	A.1.2	Firmware version 4.7 SP13	565
	A.1.3	Firmware version 4.7 SP10	566
	A.1.4	Firmware version 4.7 SP9	568
	A.1.5	Firmware version 4.7 SP6	570
	A.1.6	Firmware version 4.7 SP3	571
	A.1.7	Firmware version 4.7	573
	A.1.8	Firmware version 4.6 SP6	
	A.1.9	Firmware version 4.6	575
	A.1.10	Firmware version 4.5	576
	A.2	Interconnecting signals in the converter	577
	A.2.1	Fundamentals	577
	A.2.2	Application example	579
	A.3	Manuals and technical support	581
	A.3.1	Overview of the manuals	581
	A.3.2	Configuring support	584
	A.3.3	Product Support	
	Indov		F07

**Fundamental safety instructions** 

#### 1.1 **General safety instructions**



#### WARNING

#### Electric shock and danger to life due to other energy sources

Touching live components can result in death or severe injury.

- Only work on electrical devices when you are qualified for this job.
- Always observe the country-specific safety rules.

Generally, the following steps apply when establishing safety:

- 1. Prepare for disconnection. Notify all those who will be affected by the procedure.
- 2. Isolate the drive system from the power supply and take measures to prevent it being switched back on again.
- 3. Wait until the discharge time specified on the warning labels has elapsed.
- 4. Check that there is no voltage between any of the power connections, and between any of the power connections and the protective conductor connection.
- 5. Check whether the existing auxiliary supply circuits are de-energized.
- 6. Ensure that the motors cannot move.
- 7. Identify all other dangerous energy sources, e.g. compressed air, hydraulic systems, or water. Switch the energy sources to a safe state.
- 8. Check that the correct drive system is completely locked.

After you have completed the work, restore the operational readiness in the inverse sequence.



#### **▲** WARNING

#### Risk of electric shock and fire from supply networks with an excessively high impedance

Excessively low short-circuit currents can lead to the protective devices not tripping or tripping too late, and thus causing electric shock or a fire.

- In the case of a conductor-conductor or conductor-ground short-circuit, ensure that the short-circuit current at the point where the converter is connected to the line supply at least meets the minimum requirements for the response of the protective device used.
- You must use an additional residual-current device (RCD) if a conductor-ground short circuit does not reach the short-circuit current required for the protective device to respond. The required short-circuit current can be too low, especially for TT supply systems.

#### 1.1 General safety instructions





#### **▲** WARNING

#### Risk of electric shock and fire from supply networks with an excessively low impedance

Excessively high short-circuit currents can lead to the protective devices not being able to interrupt these short-circuit currents and being destroyed, and thus causing electric shock or a fire.

Ensure that the prospective short-circuit current at the line terminal of the converter does not exceed the breaking capacity (SCCR or Icc) of the protective device used.





#### WARNING

#### Electric shock if there is no ground connection

For missing or incorrectly implemented protective conductor connection for devices with protection class I, high voltages can be present at open, exposed parts, which when touched, can result in death or severe injury.

Ground the device in compliance with the applicable regulations.





#### WARNING

#### Electric shock due to connection to an unsuitable power supply

When equipment is connected to an unsuitable power supply, exposed components may carry a hazardous voltage. Contact with hazardous voltage can result in severe injury or death.

Only use power supplies that provide SELV (Safety Extra Low Voltage) or PELV- (Protective Extra Low Voltage) output voltages for all connections and terminals of the electronics modules.





#### **WARNING**

#### Electric shock due to equipment damage

Improper handling may cause damage to equipment. For damaged devices, hazardous voltages can be present at the enclosure or at exposed components; if touched, this can result in death or severe injury.

- Ensure compliance with the limit values specified in the technical data during transport, storage and operation.
- Do not use any damaged devices.





#### ♠ WARNING

#### Electric shock due to unconnected cable shield

Hazardous touch voltages can occur through capacitive cross-coupling due to unconnected cable shields.

• As a minimum, connect cable shields and the conductors of power cables that are not used (e.g. brake cores) at one end at the grounded housing potential.





#### **WARNING**

### Arcing when a plug connection is opened during operation

Opening a plug connection when a system is operation can result in arcing that may cause serious injury or death.

• Only open plug connections when the equipment is in a voltage-free state, unless it has been explicitly stated that they can be opened in operation.





#### ♠ WARNING

#### Electric shock due to residual charges in power components

Because of the capacitors, a hazardous voltage is present for up to 5 minutes after the power supply has been switched off. Contact with live parts can result in death or serious injury.

• Wait for 5 minutes before you check that the unit really is in a no-voltage condition and start work.

#### **NOTICE**

#### Damage to equipment due to unsuitable tightening tools.

Unsuitable tightening tools or fastening methods can damage the screws of the equipment.

- Only use screw inserts that exactly match the screw head.
- Tighten the screws with the torque specified in the technical documentation.
- Use a torque wrench or a mechanical precision nut runner with a dynamic torque sensor and speed limitation system.
- Adjust the tools used regularly.

#### **NOTICE**

#### Property damage due to loose power connections

Insufficient tightening torques or vibration can result in loose power connections. This can result in damage due to fire, device defects or malfunctions.

- Tighten all power connections to the prescribed torque.
- Check all power connections at regular intervals, particularly after equipment has been transported.

#### 1.1 General safety instructions



#### WARNING

#### Electromagnetic interference due to inadequate shield support

A lack of adequate shield support for the power cables can cause malfunctions and impermissibly high levels of interference.

- Use the shield connection plates supplied or recommended.
- Use the shield connection clips recommended.



#### **WARNING**

#### Spread of fire from built-in devices

Built-in devices can cause a fire and a pressure wave in the event of a fault. Fire and smoke can escape from the control cabinet and cause serious personal injury and property damage.

- Install built-in appliances in a robust metal control cabinet that is suitable for protecting people from fire and smoke.
- Only operate built-in devices with the control cabinet doors closed.
- Ensure that smoke can only escape via controlled and monitored paths.



#### **WARNING**

#### Active implant malfunctions due to electromagnetic fields

Converters generate electromagnetic fields (EMF) in operation. Electromagnetic fields may interfere with active implants, e.g. pacemakers. People with active implants in the immediate vicinity of an converter are at risk.

- As the operator of an EMF-emitting installation, assess the individual risks of persons with active implants.
- Observe the data on EMF emission provided in the product documentation.



#### CAUTION

#### Symptomatic respiratory and skin reaction to chemicals

A newly purchased product might contain traces of substances that are identified as sensitizers.

Sensitizers are substances which can cause sensitization in the lungs and skin after exposure to them.

Once sensitized, individuals can have severe reactions to further exposure, even in small amounts. In the most extreme cases, individuals might develop asthma or dermatitis respectively.

If the product has a strong smell, keep it in a well-ventilated area for 14 days.

#### **▲** WARNING

#### Unexpected machine movement caused by radio devices or mobile phones

Using radio devices, cellphones, or mobile WLAN devices in the immediate vicinity of the components can result in equipment malfunction. Malfunctions may impair the functional safety of machines and can therefore put people in danger or lead to property damage.

- Therefore, if you move closer than 20 cm to the components, be sure to switch off radio devices, cellphones or WLAN devices.
- Use the "SIEMENS Industry Online Support app" only on equipment that has already been switched off.

#### NOTICE

#### Damage to motor insulation due to excessive voltages

When operated on systems with grounded line conductors or in the event of a ground fault in the IT system, the motor insulation can be damaged by the higher voltage against ground. If you use motors that have insulation that is not designed for operation with grounded line conductors, you must perform the following measures:

- IT system: Use a ground fault monitor and eliminate the fault as quickly as possible.
- TN or TT systems with grounded line conductor: Use an isolating transformer on the line side.



#### WARNING

#### Fire due to inadequate ventilation clearances

Inadequate ventilation clearances can cause overheating of components with subsequent fire and smoke. This can cause severe injury or even death. This can also result in increased downtime and reduced service lives for devices/systems.

Ensure compliance with the specified minimum clearance as ventilation clearance for the respective component.

#### **NOTICE**

#### Overheating due to inadmissible mounting position

The device may overheat and therefore be damaged if mounted in an inadmissible position.

Only operate the device in admissible mounting positions.

#### 1.1 General safety instructions

#### WARNING

#### Unrecognized dangers due to missing or illegible warning labels

Dangers might not be recognized if warning labels are missing or illegible. Unrecognized dangers may cause accidents resulting in serious injury or death.

- Check that the warning labels are complete based on the documentation.
- Attach any missing warning labels to the components, where necessary in the national language.
- Replace illegible warning labels.

#### NOTICE

#### Device damage caused by incorrect voltage/insulation tests

Incorrect voltage/insulation tests can damage the device.

 Before carrying out a voltage/insulation check of the system/machine, disconnect the devices as all converters and motors have been subject to a high voltage test by the manufacturer, and therefore it is not necessary to perform an additional test within the system/machine.



#### WARNING

#### Unexpected movement of machines caused by inactive safety functions

Inactive or non-adapted safety functions can trigger unexpected machine movements that may result in serious injury or death.

- Observe the information in the appropriate product documentation before commissioning.
- Carry out a safety inspection for functions relevant to safety on the entire system, including all safety-related components.
- Ensure that the safety functions used in your drives and automation tasks are adjusted and activated through appropriate parameterizing.
- Perform a function test.
- Only put your plant into live operation once you have guaranteed that the functions relevant to safety are running correctly.

#### Note

### Important Safety instructions for Safety Integrated

If you want to use Safety Integrated functions, you must observe the Safety instructions in the Safety Integrated documentation.

## **MARNING**

#### Malfunctions of the machine as a result of incorrect or changed parameter settings

As a result of incorrect or changed parameterization, machines can malfunction, which in turn can lead to injuries or death.

- Protect the parameterization against unauthorized access.
- Handle possible malfunctions by taking suitable measures, e.g. emergency stop or emergency off.

1.2 Equipment damage due to electric fields or electrostatic discharge

# 1.2 Equipment damage due to electric fields or electrostatic discharge

Electrostatic sensitive devices (ESD) are individual components, integrated circuits, modules or devices that may be damaged by either electric fields or electrostatic discharge.



#### NOTICE

#### Equipment damage due to electric fields or electrostatic discharge

Electric fields or electrostatic discharge can cause malfunctions through damaged individual components, integrated circuits, modules or devices.

- Only pack, store, transport and send electronic components, modules or devices in their original packaging or in other suitable materials, e.g conductive foam rubber of aluminum foil.
- Only touch components, modules and devices when you are grounded by one of the following methods:
  - Wearing an ESD wrist strap
  - Wearing ESD shoes or ESD grounding straps in ESD areas with conductive flooring
- Only place electronic components, modules or devices on conductive surfaces (table with ESD surface, conductive ESD foam, ESD packaging, ESD transport container).

## 1.3 Warranty and liability for application examples

Application examples are not binding and do not claim to be complete regarding configuration, equipment or any eventuality which may arise. Application examples do not represent specific customer solutions, but are only intended to provide support for typical tasks.

As the user you yourself are responsible for ensuring that the products described are operated correctly. Application examples do not relieve you of your responsibility for safe handling when using, installing, operating and maintaining the equipment.

#### 1.4 Security information

#### Security information 1.4

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, systems, machines and networks.

In order to protect plants, systems, machines and networks against cyber threats, it is necessary to implement – and continuously maintain – a holistic, state-of-the-art industrial security concept. Siemens' products and solutions constitute one element of such a concept.

Customers are responsible for preventing unauthorized access to their plants, systems, machines and networks. Such systems, machines and components should only be connected to an enterprise network or the internet if and to the extent such a connection is necessary and only when appropriate security measures (e.g. firewalls and/or network segmentation) are in place.

For additional information on industrial security measures that may be implemented, please

https://www.siemens.com/industrialsecurity.

Siemens' products and solutions undergo continuous development to make them more secure. Siemens strongly recommends that product updates are applied as soon as they are available and that the latest product versions are used. Use of product versions that are no longer supported, and failure to apply the latest updates may increase customer's exposure to cyber threats.

To stay informed about product updates, subscribe to the Siemens Industrial Security RSS Feed under

https://www.siemens.com/cert.

Further information is provided on the Internet:

Industrial Security Configuration Manual (https://support.industry.siemens.com/cs/ww/en/ view/108862708)



#### **▲** WARNING

#### Unsafe operating states resulting from software manipulation

Software manipulations, e.g. viruses, Trojans, or worms, can cause unsafe operating states in your system that may lead to death, serious injury, and property damage.

- Keep the software up to date.
- Incorporate the automation and drive components into a holistic, state-of-the-art industrial security concept for the installation or machine.
- Make sure that you include all installed products into the holistic industrial security concept.
- Protect files stored on exchangeable storage media from malicious software by with suitable protection measures, e.g. virus scanners.
- On completion of commissioning, check all security-related settings.

## 1.5 Residual risks of power drive systems

When assessing the machine or system-related risk in accordance with the respective local regulations (e.g. EC Machinery Directive), the machine manufacturer or system integrator must take into account the following residual risks emanating from the control and drive components of a drive system:

- 1. Unintentional movements of driven machine or system components during commissioning, operation, maintenance, and repairs caused by, for example,
  - Hardware faults and/or software errors in the sensors, control system, actuators, and connections
  - Response times of the control system and of the drive
  - Operation and/or environmental conditions outside the specification
  - Condensation/conductive contamination
  - Parameterization, programming, cabling, and installation errors
  - Use of wireless devices/mobile phones in the immediate vicinity of electronic components
  - External influences/damage
  - X-ray, ionizing radiation and cosmic radiation
- 2. Unusually high temperatures, including open flames, as well as emissions of light, noise, particles, gases, etc., can occur inside and outside the components under fault conditions caused by, for example:
  - Component failure
  - Software errors
  - Operation and/or environmental conditions outside the specification
  - External influences/damage
- 3. Hazardous shock voltages caused by, for example:
  - Component failure
  - Influence during electrostatic charging
  - Induction of voltages in moving motors
  - Operation and/or environmental conditions outside the specification
  - Condensation/conductive contamination
  - External influences/damage
- 4. Electrical, magnetic and electromagnetic fields generated in operation that can pose a risk to people with a pacemaker, implants or metal replacement joints, etc., if they are too close
- 5. Release of environmental pollutants or emissions as a result of improper operation of the system and/or failure to dispose of components safely and correctly

#### 1.5 Residual risks of power drive systems

- 6. Influence of network-connected communication systems, e.g. ripple-control transmitters or data communication via the network
- 7. Motors for use in potentially explosive areas:
  When moving components such as bearings become worn, this can cause enclosure components to exhibit unexpectedly high temperatures during operation, creating a hazard in areas with a potentially explosive atmosphere.

For more information about the residual risks of the drive system components, see the relevant sections in the technical user documentation.

Introduction

#### 2.1 About the Manual

#### Who requires the operating instructions and what for?

These operating instructions primarily address fitters, commissioning engineers and machine operators. The operating instructions describe the devices and device components and enable the target groups being addressed to install, connect-up, set, and commission the converters safely and in the correct manner.

#### What is described in the operating instructions?

These operating instructions provide a summary of all of the information required to operate the converter under normal, safe conditions.

The information provided in the operating instructions has been compiled in such a way that it is sufficient for all standard applications and enables drives to be commissioned as efficiently as possible. Where it appears useful, additional information for entry level personnel has been added.

The operating instructions also contain information about special applications. Since it is assumed that readers already have a sound technical knowledge of how to configure and parameterize these applications, the relevant information is summarized accordingly. This relates, e.g. to operation with fieldbus systems.

#### What is the meaning of the symbols in the manual?

Reference to further information in the manual

Download from the Internet

DVD that can be ordered

End of a handling instruction.





Examples of converter function symbols

# 2.2 Guide through the manual

Chapter	In this section you will find answers to the following questions:
Description (Page 29)	How is the converter marked?
	Which components make up the converter?
	Which optional components are available for the converter?
	What is the purpose of the optional components?
	Which motors can be fed from the converter?
	Which commissioning tools are there?
Installing (Page 63)	Which sequence is recommended when installing the converter?
	What does EMC-compliant installation actually mean?
	Which options are available to install optional components below the converter?
	What are the converter dimensions?
	Which mounting and installation materials are required when installing the converter?
	To which line supplies can the converter be connected?
	How is the converter connected to the line supply?
	How is the braking resistor connected to the converter?
	Which terminals and fieldbus interfaces does the converter have?
	What are the interface functions?
Commissioning (Page 165)	Which motor data is required for commissioning
	How is the converter set in the factory?
	What is the commissioning procedure?
	How do you restore the converter factory settings?
Uploading the converter set-	Why is it necessary to back up the converter settings?
tings (Page 219)	Which options are available to back up the settings?
	How does the data backup function?
	How do you prevent the converter settings from being changed?
	How do you prevent the converter settings from being read out?
Protecting the converter set-	How do I protect the converter settings against manipulation?
tings (Page 231)	How do I protect my know-how, which is embedded in the converter settings, so that it cannot be copied by unauthorized persons?
Advanced commissioning	Which functions are included in the converter firmware?
(Page 241)	How are the functions set?
Corrective maintenance	What is the meaning of the LEDs provided on the converter?
(Page 461)	How does the system runtime respond?
	How does the converter save alarms and faults?
	What do the converter alarms and faults mean?
	How are converter faults resolved?
	Which I&M data is saved in the converter?

Chapter	In this section you will find answers to the following questions:
Alarms, faults and system	How are converter components replaced?
messages (Page 441)	How is the firmware version of the converter changed?
	What must be done after a converter replacement if the safety functions of the converter are active?
Technical data (Page 489)	What is the converter technical data?
	What do "High Overload" and "Low Overload" mean?
	What effect do the installation altitude or ambient temperature have on the converter, for example?
Appendix (Page 565)	What are the new functions of the current firmware?
	How is the converter operated using the BOP-2 Operator Panel?
	How can signal interconnections be changed in the converter firmware?
	What does "BiCo technology" mean?
	Where can I find additional information about the converter?

2.2 Guide through the manual

Description

#### 3.1 Intended use

#### Use for the intended purpose

The converter described in this manual is a device to control a three-phase motor. The converter is designed for installation in electrical installations or machines.

It has been approved for industrial and commercial use on industrial networks. Additional measures have to be taken when connected to public grids.

The technical specifications and information about connection conditions are indicated on the rating plate and in the operating instructions.

#### Use of third-party products

This document contains recommendations relating to third-party products. Siemens accepts the fundamental suitability of these third-party products.

You can use equivalent products from other manufacturers.

Siemens does not accept any warranty for the properties of third-party products.

## 3.2 OpenSSL

#### 3.2 **OpenSSL**

### **Use of OpenSSL**

This product contains software developed in the OpenSSL project for use within the OpenSSL toolkit.

This product contains cryptographic software created by Eric Young.

This product contains software developed by Eric Young.

Further information is provided on the Internet:



OpenSSL (https://www.openssl.org/)



Cryptsoft (mailto:eay@cryptsoft.com)

## 3.3 Transferring OpenOSS license terms to a PC

#### Requirement

You have an empty memory card and a reader for the memory card.

#### **Procedure**

#### **Procedure**

To transfer OpenOSS license terms to a PC, proceed as follows:

- 1. Switch off the converter power supply.
- 2. Insert an empty memory card into the card slot of the converter.

  Overview of the interfaces (Page 118)
- 3. Switch on the converter power supply.
- 4. The converter writes file "Read\_OSS.ZIP" to the memory card within approximately 30 seconds.
- 5. Switch off the converter power supply.
- 6. Withdraw the memory card from the converter.
- 7. Insert the memory card into the card reader of a PC.
- 8. Please read the license terms.


3.4 Identifying the converter

## 3.4 Identifying the converter

#### Main components of the converter

Each SINAMICS G120 converter comprises a Control Unit and a Power Module.

- The Control Unit controls and monitors the connected motor.
- The Power Module provides the connections for line supply and motor.



The following data is provided on the Power Module type plate (1):

- Designation, e.g. PM240-2 Power Module
- Technical specifications: voltage and current
- Article number, e.g. 6SL3210-1PE21-1UL0
- Version, e.g. A02

The following data can be found on the Control Unit type plate (2):

- Designation, e.g. Control Unit CU240E-2 DP-F
- Article number, e.g. 6SL3244-0BB13-1PA0
- Version, e.g. A02 (hardware), 4.7 (firmware)

#### **Further converter components**

The following components are available so that you can adapt the converter to different applications and ambient conditions:

- Line filter (Page 44)
- Line reactor (Page 46)
- Cutput reactor (Page 48)
- Sine-wave filter (Page 55)
- dv/dt filter (Page 57)
- Praking Module and braking resistor (Page 58)
- Control Unit Adapter Kit CUA20 (Page 60)

#### 3.5 Directives and standards

#### Description

The following directives and standards are relevant for the converters:



#### **European Low Voltage Directive**

The converters fulfill the requirements stipulated in the Low-Voltage Directive 2014/35/EU, if they are covered by the application area of this directive.

#### **European Machinery Directive**

The converters fulfill the requirements stipulated in the Machinery Directive 2006/42/EC, if they are covered by the application area of this directive.

However, the use of the converters in a typical machine application has been fully assessed for compliance with the main regulations in this directive concerning health and safety.

#### Directive 2011/65/EU

The converter fulfills the requirements of Directive 2011/65/EU relating to the restriction of the use of certain hazardous substances in electrical and electronic devices (RoHS).

#### **European EMC Directive**

The compliance of the converter with the regulations of the Directive 2014/30/EU has been verified through full compliance with IEC/EN 61800-3.



#### **Underwriters Laboratories (North American market)**

Converters provided with one of the test symbols displayed fulfill the requirements stipulated for the North American market as a component of drive applications, and are appropriately listed.







#### **EMC requirements for South Korea**

The converters with the KC marking on the rating plate satisfy the EMC requirements for South Korea.



#### **Eurasian conformity**

The converters comply with the requirements of the Russia/Belarus/Kazakhstan customs union (EAC).



#### Australia and New Zealand (RCM formerly C-Tick)

The converters showing the test symbols fulfill the EMC requirements for Australia and New Zealand.

#### 3.5 Directives and standards

#### Immunity to voltage drop of semiconductor process equipment.

The converters comply with the requirements of standard SEMI F47-0706.

#### **DNV-GL**

The SINAMICS CUA20 Control Unit Adapter Kit facilitates DNV-GL-certified cabinet designs.

#### China RoHS

The converters comply with the China-RoHs directive. Further information is provided on the Internet:



China RoHS (https://support.industry.siemens.com/cs/ww/en/view/109738656)

#### **Quality systems**

Siemens AG employs a quality management system that meets the requirements of ISO 9001 and ISO 14001.

#### **Further information**

#### Certificates for download

- EC Declaration of Conformity: (https://support.industry.siemens.com/cs/ww/en/view/ 58275445)
- Certificates for the relevant directives, prototype test certificates, manufacturers declarations and test certificates for functions relating to functional safety ("Safety Integrated"): (http://support.automation.siemens.com/WW/view/en/22339653/134200)
- Certificates for products that were certified by UL: (http://database.ul.com/cgi-bin/XYV/ template/LISEXT/1FRAME/index.html)
- Certificates for products that were certified by TÜV SÜD: (https://www.tuev-sued.de/ industrie konsumprodukte/zertifikatsdatenbank)

#### Standards that are not relevant



The converters do not fall in the area of validity of the China Compulsory Certification (CCC).

## 3.6 Control Units



The Control Units differ with regard to the type of fieldbus.

Designation	Article number	Fieldbus
CU230P-2 HVAC	6SL3243-0BB30-1HA3	USS, Modbus RTU, BACnet MS/TP, P1
CU230P-2 DP	6SL3243-0BB30-1PA3	PROFIBUS DP
CU230P-2 PN	6SL3243-0BB30-1FA0	PROFINET IO, EtherNet/IP
CU230P-2 BT 1)	6SL3243-6BB30-1HA3	USS, Modbus RTU, BACnet MS/TP, P1

<sup>1)</sup> Exclusive version for Siemens IC BT

## Shield connection kit for the Control Unit

The shield connection kit is an optional component. The shield connection kit comprises the following components:

- Shield plate
- Elements for optimum shield support and strain relief of the signal and communication cables

Table 3-1 Article Nos.

Shield connection kit 1 for the CU230P-2 Control Units with all fieldbus interfaces except for PROFINET.	6SL3264-1EA00-0FA0
Shield connection kit 3 for the CU230P-2 and CU240E-2 Control Units with PROFINET interface.	6SL3264-1EA00-0HB0

### 3.7 Power Module

## 3.7 Power Module

Important data on the Power Modules is provided in this section. Further information is contained in the Hardware Installation Manual of the Power Module.

Overview of the manuals (Page 581)

All power data refers to rated values or to power for operation with low overload (LO).

### Which Power Module can I use with the Control Unit?

Power module for the SINAMICS G120P

PM230
 PM240P-2
 PM330

Power module for the SINAMICS G120

PM240-2
 PM250

## 3.7.1 Power module for the SINAMICS G120P



Figure 3-1 PM230, 3-phase 400 VAC, degree of protection IP55 / UL Type 12

## PM230 for pumps and fan applications

The PM230 Power Module is suitable for cabinet-free installation.

Table 3-2 3-phase 380 VAC ... 480 VAC, article number 6SL3223-0DE...

Frame size		FSA	FSB	FSC	FSD	FSE	FSF
Power (kW)	Filter Class A	0.37 3	4 7.5	11 18.5	22 30	37 45	55 90
	Filter Class B	0.37 3	4 7.5	11 15	18.5 30	37 45	55 90

### 3.7 Power Module



Figure 3-2 Examples of Power Modules with IP20 degree of protection

## PM230, 3-phase 400 VAC in IP20 degree of protection for pump and fan applications

The PM230 Power Module in IP20 degree of protection is available without a filter or with an integrated class A line filter.

Table 3-3 3-phase 380 VAC ... 480 VAC, article numbers: 6SL3210-1NE...

Frame size	FSA	FSB	FSC	FSD	FSE	FSF
Power (kW)	0.37 3	4 7.5	11 18.5	22 37	45 55	75 90

## PM240P-2 for pump and fan applications

The PM240P-2 Power Module is available without a filter or with an integrated class A line filter.

Table 3-4 3-phase 380 VAC ... 480 VAC, article number 6SL3210-1RE...

Frame size	FSD	FSE	FSF
Power (kW)	22 37	45 55	75 132

Table 3-5 3-phase 500 VAC ... 690 VAC, article number 6SL3210-1RH...

Frame size	FSD	FSE	FSE
Power (kW)	11 37	45 55	75 132

## PM330 for pump, fan and compressor applications



Figure 3-3 PM330 for pump and fan applications

The PM330 Power Module is available as an unfiltered device. External line filters are available as an option, see Section

Table 3-6 3-phase 380 VAC ... 480 VAC, article numbers: 6SL3310-1PE...

Frame size	GX	НХ	JX
Power (kW)	160 250	315 400	450 560

Table 3-7 3-phase 500 VAC ... 690 VAC, article numbers: 6SL3310-1PG...

Frame size	НХ	JX
Power (kW)	315 450	500 630

### 3.7 Power Module



Figure 3-4 Examples of Power Modules with Push-Through technology FSA  $\dots$  FSC

## PM230 in Push-Through technology for pump and fan applications

The PM230 Power Module is available without a filter or with integrated class A line filter.

Table 3-8 3-phase 380 VAC ... 480 VAC, article number 6SL3211-1NE...

Frame size	FSA	FSB	FSC
Power (kW)	3	7.5	18.5

### 3.7.2 Power module for the SINAMICS G120

## PM240-2 for standard applications

The PM240-2 Power Module is available without a filter or with an integrated class A line filter. The PM240-2 permits dynamic braking via an external braking resistor.

Table 3-9 1-phase/3-phase 200 VAC ... 240 VAC, article number 6SL3210-1PB... and 6SL3210-1PC...

Frame size	FSA	FSB	FSC	FSD	FSE	FSF
Power (kW)	0.55 0.75	1.1 2.2	3.0 4.0	11 18.5	22 30	37 55

Table 3-10 3-phase 380 VAC ... 480 VAC, article number 6SL3210-1PE...

Frame size	FSA	FSB	FSC	FSD	FSE	FSF	FSG
Power (kW)	0.55 3.0	4.0 7.5	11 15	18.5 37	45 55	75 132	160 250

Table 3-11 3-phase 500 VAC ... 690 VAC, article number 6SL3210-1PH...

Frame size	FSD	FSE	FSF	FSG
Power (kW)	11 37	45 55	75 132	160 250

## PM240-2 with Push-Through technology for standard applications

The PM240-2 Power Module is available with Push-Through technology without a filter or with an integrated class A line filter. The PM240-2 allows dynamic braking using an external braking resistor.

Table 3-12 1-phase/3-phase 200 VAC ... 240 VAC, article number 6SL3211-1PB...

Frame size	FSA	FSB	FSC	FSD	FSE	FSF
Power (kW)	0.75	2.2	4.0	18.5	30	55

Table 3-13 3-phase 380 VAC ... 480 VAC, article number 6SL3211-1PE...

Frame size	FSA	FSB	FSC	FSD	FSE	FSF
Power (kW)	3.0	7.5	15	37	55	132

Table 3-14 3 AC 500 V ... 690 V, Article No. 6SL3211-1PH...

Frame size	FSD	FSE	FSF
Power (kW)	37	55	132

### 3.7 Power Module

## PM250 for standard applications with energy recovery

The PM250 Power Module is available without a filter or with integrated class A line filter. The PM250 permits dynamic braking with energy recovery into the line supply.

Table 3-15 3-phase 380 VAC ... 480 VAC, article number 6SL3225-0BE...

Frame size	FSC	FSD	FSE	FSF
Power (kW)	7.5 15	18.5 30	37 45	55 90

## 3.8.1 Accessories for shielding

### Shield connection kit

Establish the shield and strain relief for the power connections using the shield connection kit.

The shield connection kit comprises a shield plate and serrated strips with screws.




Table 3-16 Article numbers for the shield connection kit

Frame size	PM250 Power Module	PM230, PM240-2	PM240P-2
FSA	6SL3262-1AA00-0BA0	The shield connection kit is	
FSB	6SL3262-1AB00-0DA0	included in the scope of de-	
FSC	6SL3262-1AC00-0DA0	livery	
FSD	6SL3262-1AD00-0DA0		The lower shield connec-
FSE	6SL3262-1AD00-0DA0		tion kit is included in the
FSF	6SL3262-1AF00-0DA0		scope of delivery

## 3.8.2 Line filter

With a line filter, the converter can achieve a higher radio interference class.

### NOTICE

### Overloading the line filter when connected to line supplies that are not permissible

The line filter is only suitable for operation on TN or TT line supplies with a grounded neutral point. If operated on other line supplies, the line filter will be thermally overloaded and will be damaged.

• For converters equipped with line filter, only connect to TN or TT line supplies with a grounded neutral point.

## External line filters for PM230, 380 V ... 480 V (IP20)

Power	Module	Power	Line filter according to EN 61800-3 Category C1	
FSA	6SL3210-1NE11-3UG1, 6SL3210-1NE11-7UG1, 6SL3210-1NE12-2UG1, 6SL3210-1NE13-1UG1, 6SL3210-1NE14-1UG1, 6SL3210-1NE15-8UG1, 6SL3211NE17-7UG1 .	0.37 kW 3 kW	6SL3203-0BE17-7BA0	
FSB	6SL3210-1NE21-0UG1, 6SL3210-1NE21-3UG1, 6SL3211NE21-8UG1	4 kW 7.5 kW	6SL3203-0BE21-8BA0	
FSC	6SL3210-1NE22-6UG1, 6SL3210-1NE23-2UG1, 6SL3211NE23-8UG1	11 kW 18.5 kW	6SL3203-0BE23-8BA0	
FSD	6SL3210-1NE24-5UL0, 6SL3210-1NE26-0UL0	22 kW 30 kW	6SL3203-0BE27-5BA0	
FSE	6SL3210- 1NE27-5UL0, 6SL3210- 1NE28-8UL0	37 kW 45 kW	6SL3203-0BE31-1BA0	
FSF	6SL3210-1NE31-1UL0, 6SL3210-1NE31-5UL0	55 kW 75 kW	6SL3203-0BE31-8BA0	

## External line filters for PM330, 380 V ... 480 V

Powe	r Module	Power	Line filter according to EN 61800-3 Category C2
GX	6SL3310-1PE33-0AA0, 6SL3310-1PE33-7AA0	160 kW 200 kW	6SL3000-0BE33-1AA0
	6SL3310-1PE34-6AA0	250 kW	6SL3000-0BE35-0AA0

Power N	<i>l</i> odule	Power	Line filter according to EN 61800-3 Category C2
HX	6SL3310-1PE35-8AA0, 6SL3310-1PE36-6AA0, 6SL3310-1PE37-4AA0	315 kW 400 kW	6SL3760-0MR00-0AA0
JX	6SL3310-1PE38-4AA0, 6SL3310-1PE38-8AA0, 6SL3310-1PE41-0AA0	450 kW 560 kW	

## External line filters for the PM330 Power Module, 500 V $\dots$ 690 V

Power N	<i>l</i> odule	Power	Line filter according to EN 61800-3 Category C2
HX	6SL3310-1PG33-7AA0, 6SL3310-1PG34-0AA0, 6SL3310-1PG34-5AA0, 6SL3310-1PG35-2AA0	315 kW 450 kW	6SL3760-0MS00-0AA0
JX	6SL3310-1PG35-8AA0, 6SL3310-1PG36-5AA0, 6SL3310-1PG37-2AA0	500 kW 630 kW	6SL3760-0MS00-0AA0

## **External line filters for PM250**

Power N	<i>l</i> odule	Power	Class B line filter according to EN55011: 2009
FSC	6SL3225-0BE25-5AA0, 6SL3225-0BE27-5AA0, 6SL3225-0BE31-1AA0	7.5 kW 15.0 kW	6SL3203-0BD23-8SA0

#### 3.8.3 Line reactor

The line reactor supports the overvoltage protection, smoothes the harmonics in the line supply and bridges commutation dips. For the Power Modules subsequently listed, a line reactor is suitable in order to dampen the specified effects.

The figure on the right-hand side shows as example the line reactors for the PM240-2 Power Modules, FSB.



The line requirements for deployment of a line reactor depends on the Power Module:



Technical data (Page 489)

### Line reactors for PM330, 380 V ... 480 V

Power	Module	Power	Line reactor
GX	6SL3310-1PE33-0AA0	160 kW	6SL3000-0CE33-3AA0
	6SL3310-1PE33-7AA0	200 kW	6SL3000-0CE35-1AA0
	6SL3310-1PE34-6AA0	250 kW	
HX	6SL3310-1PE35-8AA0	315 kW	6SL3000-0CE36-3AA0
	6SL3310-1PE36-6AA0	355 kW	6SL3000-0CE37-7AA0
	6SL3310-1PE37-4AA0	400 kW	
JX	6SL3310-1PE38-4AA0	450 kW	6SL3000-0CE38-7AA0
	6SL3310-1PE38-8AA0, 6SL3310-1PE41-0AA0	500 kW 560 kW	6SL3000-0CE41-0AA0

### Line reactors for PM330 Power Modules, 500 V ... 690 V

Power	Module	Power	Line reactor
HX	6SL3310-1PG33-7AA0, 6SL3310-1PG34-0AA0, 6SL3310-1PG34-5AA0	315 kW 400 kW	6SL3000-0CH34-8AA0
	6SL3310-1PG35-2AA0	450 kW	6SL3000-0CH36-0AA0
JX	6SL3310-1PG35-8AA0	500 kW	6SL3000-0CH36-0AA0
	6SL3310-1PG36-5AA0, 6SL3310-1PG37-2AA0	560 kW 630 kW	6SL3000-0CH38-4AA0

#### Line reactors for PM240-2 Power Modules

A line reactor is not required.

## Line reactors for PM240-2, 380 V ... 480 V

Power	Module	Power	Line reactor
FSA	6SL3210-1PE11-8 . L1, 6SL3210-1PE12-3 . L1, 6SL3210-1PE13-2 . L1	0.55 kW 1.1 kW	6SL3203-0CE13-2AA0
FSB	6SL3210-1PE14-3 . L1, 6SL3211PE16-1 . L1, 6SL3211PE18-0 . L1	1.5 kW 3 kW	6SL3203-0CE21-0AA0
FSC	6SL3210-1PE21-1 . L0, 6SL3210-1PE21-4 . L0, 6SL3211PE21-8 . L0	4 kW 7.5 kW	6SL3203-0CE21-8AA0
	6SL3210-1PE22-7 . LO, 6SL3211PE23-3 . LO	11 kW 15 kW	6SL3203-0CE23-8AA0

FSD ... FSG: A line reactor is not required.

# Line reactors for PM240-2 Power Module, 500 V $\dots$ 690 V

A line reactor is not required.

## Line reactors for PM240-2, 200 V ... 240 V

Power	Module	Power	Line reactor
FSA	6SL3210-1PB13-0 . L0, 6SL3210-1PB13-8 . L0	0.55 kW 0.75 kW	6SL3203-0CE13-2AA0
FSB	6SL3210-1PB15-5 . L0, 6SL3210-1PB17-4 . L0, 6SL3211PB21-0 . L0	1.1 kW 2.2 kW	6SL3203-0CE21-0AA0
FSC	6SL3210-1PB21-4 . LO, 6SL3211PB21-8 . LO	3 kW 4 kW	6SL3203-0CE21-8AA0
	6SL3211PC22-2 . L0, 6SL3210-1PC22-8 . L0	5.5 kW 7.5 kW	6SL3203-0CE23-8AA0

FSD ... FSF: A line reactor is not required.

## 3.8.4 Output reactor

Output reactors reduce the voltage stress on the motor windings and the load placed on the converter as a result of capacitive recharging currents in the cables.

An output reactor is required for the following motor cable lengths:

- For PM330 Power Module:
  - > 100 m shielded
  - ≥ 200 m unshielded
- All other Power Modules:
  - ≥ 50 m shielded
  - ≥ 100 m unshielded

The figure on the right-hand side shows as example the output reactors for PM240-2 Power Modules, FSB and FSC.



### NOTICE

### The output reactor is damaged if the converter pulse frequency is too high

The output reactors are designed for a specific pulse frequency. The output reactor can overheat if the converter is operated with excessive pulse frequencies. Excessively high temperatures damage the output reactor.

- Operate the converter only with an output reactor with the permissible pulse frequencies:
  - PM330 Power Modules HX and JX: Pulse frequency ≤ 2.5 kHz
  - All other Power Modules: Pulse frequency ≤ 4 kHz

### Output reactors for PM230 Power Modules (IP55/UL Type 12)

Power	Module	Power	Output reactor
FSA	6SL3223-0DE13-7 . A0, 6SL3223-0DE15-5 . A0, 6SL3223-0DE17-5 . A0, 6SL3223-0DE21-1 . A0, 6SL3223-0DE21-5 . A0, 6SL3223-0DE22-2 . A0	0.37 kW 2.2 kW	6SL3202-0AE16-1CA0
	6SL3223-0DE23-0 . A0	3.0 kW	6SL3202-0AE18-8CA0
FSB	6SL3223-0DE24-0 . A0, 6SL3223-0DE25-5 . A0, 6SL3223-0DE27-5 . A0,	4.0 kW 7.5 kW	6SL3202-0AE21-8CA0
FSC	6SL3223-0DE31-1 . A0, 6SL3223-0DE31-5 . A0, 6SL3223-0DE31-8 . A0	11.0 kW 18.5 kW	6SL3202-0AE23-8CA0
FSD	6SL3223-0DE32-2 . A0	22 kW	6SE6400-3TC03-8DD0
	6SL3223-0DE33-0 . A0	30 kW	6SE6400-3TC05-4DD0
FSE	6SL3223-0DE33-7 . A0	37 kW	6SE6400-3TC08-0ED0
	6SL3223-0DE34-5 . A0	45 kW	6SE6400-3TC07-5ED0

Power	Module	Power	Output reactor
FSF	6SL3223-0DE35-5 . A0	55 kW	6SE6400-3TC14-5FD0
	6SL3223-0DE37-5 . A0	75 kW	6SE6400-3TC15-4FD0
	6SL3223-0DE38-8 . A0	90 kW	6SE6400-3TC14-5FD0

## Output reactors for PM230 Power Modules (IP20)

Power N	Module	Power	Output reactor
FSA	6SL3210-1NE11-3 . G1 6SL3210-1NE11-7 . G1 6SL3210-1NE12-2 . G1 6SL3210-1NE13-1 . G1 6SL3210-1NE14-1 . G1 6SL3210-1NE15-8 . G1	0.37 kW 2.2 kW	6SL3202-0AE16-1CA0
	6SL3210-1NE17-7 . G1	3.0 kW	6SL3202-0AE18-8CA0
FSB	6SL3210-1NE21-0 . G1 6SL3210-1NE21-3 . G1 6SL3210-1NE21-8 . G1	4.0 kW 7.5 kW	6SL3202-0AE21-8CA0
FSC	6SL3210-1NE22-6 . G1 6SL3210-1NE23-2 . G1 6SL3210-1NE23-8 . G1	11.0 kW 18.5 kW	6SL3202-0AE23-8CA0
FSD	6SL3210-1NE24-5 . L0	22 kW	6SE6400-3TC03-8DD0
	6SL3210-1NE26-0 . L0	30 kW	6SE6400-3TC05-4DD0
FSE	6SL3210-1NE27-5 . L0	37 kW	6SE6400-3TC08-0ED0
	6SL3210-1NE28-8 . L0	45 kW	6SE6400-3TC07-5ED0
FSF	6SL3210-1NE31-1 . L0	55 kW	6SE6400-3TC14-5FD0
	6SL3210-1NE31-5 . L0	75 kW	6SE6400-3TC15-4FD0

## Output reactors for PM230 push-through Power Modules

Power M	/lodule	Power	Output reactor
FSA	6SL3211-1NE17-7 . G1	3.0 kW	6SL3202-0AE18-8CA0
FSB	6SL3211-1NE21-8 . G1	7.5 kW	6SL3202-0AE21-8CA0
FSC	6SL3211-1NE23-8 . G1	18.5 kW	6SL3202-0AE23-8CA0

## Output reactors for PM240-2 Power Modules, 380 V ... 480 V

Power I	Module	Power	Output reactor
FSA	6SL3210-1PE11-8 . L1, 6SL3210-1PE12-3 . L1, 6SL3210-1PE13-2 . L1, 6SL3210-1PE14-3 . L1, 6SL3210-1PE16-1 . L1	0.55 kW 2.2 kW	6SL3202-0AE16-1CA0
	6SL3211PE18-0 . L1	3 kW	6SL3202-0AE18-8CA0

Power	Module	Power	Output reactor
FSB	6SL3210-1PE21-1 . LO, 6SL3210-1PE21-4 . LO, 6SL3211PE21-8 . LO	4 kW 7.5 kW	6SL3202-0AE21-8CA0
FSC	6SL3210-1PE22-7 . L0, 6SL3211PE23-3 . L0	11 kW 15 kW	6SL3202-0AE23-8CA0
FSD	6SL3210-1PE23-8 . L0 6SL3210-1PE24-5 . L0 6SL3210-1PE26-0 . L0 6SL3211PE27-5 . L0	18.5 kW 37 kW	6SE6400-3TC07-5ED0
FSE	6SL3210-1PE28-8 . L0, 6SL3211PE31-1 . L0	45 kW 55 kW	6SE6400-3TC14-5FD0
FSF	6SL3210-1PE31-5 . L0	75 kW	
	6SL3210-1PE31-8 . L0	90 kW	
	6SL3210-1PE32-1 . L0	110 kW	6SL3000-2BE32-1AA0
	6SL3211PE32-5 . LO	132 kW	6SL3000-2BE32-6AA0
FSG	6SL3210-1PE33-0 . L0	160 kW	6SL3000-2BE33-2AA0
	6SL3210-1PE33-7 . L0	200 kW	6SL3000-2BE33-8AA0
	6SL3210-1PE34-8 . L0	250 kW	6SL3000-2BE35-0AA0

## Output reactors for PM240-2 Power Modules, 500 V ... 690 V

Power N	Module	Power	Output reactor
FSF	6SL3210-1PH28-0 . L0, 6SL3210-1PH31-0 . L0	75 kW 90 kW	6SL3000-2AH31-0AA0
	6SL3210-1PH31-2 . L0, 6SL3210-1PH31-4 . L0	110 kW 132 kW	6SL3000-2AH31-5AA0
FSG	6SL3210-1PH31-7CL0	160 kW	6SL3000-2AH31-8AA0
	6SL3210-1PH32-1CL0	200 kW	6SL3000-2AH32-4AA0
	6SL3210-1PH32-5CL0	250 kW	6SL3000-2AH32-6AA0

## Output reactors for PM240-2 Power Modules, 200 V $\dots$ 240 V

Power N	1odule	Power	Output reactor
FSA	6SL3210-1PB13-0 . LO, 6SL3211PB13-8 . LO	0.55 kW 0.75 kW	6SL3202-0AE16-1CA0
FSB	6SL3210-1PB15-5 . LO	1.1 kW	
	6SL3210-1PB17-4 . LO	1.5 kW	6SL3202-0AE18-8CA0
FSB	6SL3211PB21-0 . L0	2.2 kW	6SL3202-0AE21-8CA0
FSC	6SL3210-1PB21-4 . LO, 6SL3211PB21-8 . LO	3 kW 4 kW	
	6SL3211PC22-2 . L0, 6SL3210-1PC22-8 . L0	5.5 kw 7.5 kW	6SL3202-0AE23-8CA0
FSD	6SL3210-1PC24-2UL0, 6SL3210-1PC25-4UL0, 6SL3210-1PC26-8UL0	11 kW 18.5 kW	6SE6400-3TC07-5ED0

Power N	/lodule	Power	Output reactor
FSE	6SL3210-1PC28-0UL0, 6SL3210-1PC31-1UL0	22 kW 55 kW	6SE6400-3TC14-5FD0
FSF	6SL3210-1PC31-3UL0, 6SL3210-1PC31-6UL0, 6SL3210-1PC31-8UL0		

## Output reactors for PM330 Power Modules, 380 V ... 480 V

Power N	Module	Power	Output reactor
GX	6SL3310-1PE33-0AA0	160 kW	6SL3000-2BE33-2AA0
	6SL3310-1PE33-7AA0	200 kW	6SL3000-2BE33-8AA0
	6SL3310-1PE34-6AA0	250 kW	6SL3000-2BE35-0AA0
HX	6SL3310-1PE35-8AA0	315 kW	6SL3000-2AE36-1AA0
	6SL3310-1PE36-6AA0	355 kW	6SL3000-2AE38-4AA0
	6SL3310-1PE37-4AA0	400 kW	
JX	6SL3310-1PE38-4AA0, 6SL3310-1PE38-8AA0	450 kW 500 kW	6SL3000-2AE41-0AA0
	6SL3310-1PE41-0AA0	560 kW	6SL3000-2AE41-4AA0

## Output reactors for PM330 Power Modules, 500 V ... 690 V

Power I	Module	Power	Output reactors
JX	6SL3310-1PG35-8AA0,	500 kW 630 kW	6SL3000-2AE41-0AA0
	6SL3310-1PG36-5AA0,		
	6SL3310-1PG37-2AA0		

## Output reactors for PM240P-2 Power Modules, 380 V ... 480 V

Power Module		Power	Output reactor
FSD	6SL3210-1RE24-5 . L0	22 kW	6SE6400-3TC03-8DD0
	6SL3210-1RE26-0 . L0	30 kW	6SE6400-3TC07-5ED0
	6SL3210-1RE27-5 . L0	37 kW	
FSE	6SL3210-1RE28-8 . L0	45 kW	
	6SL3210-1RE31-1 . L0	55 KW	6SE6400-3TC14-5FD0
FSF	6SL3210-1RE31-5 . L0	75 kW	
	6SL3210-1RE31-8 . L0	90 kW	
	6SL3210-1RE32-1 . L0	110 kW	6SL3000-2BE32-1AA0
	6SL3210-1RE32-5 . L0	132 kW	6SL3000-2BE32-6AA0

## Output reactors for PM250 Power Module

Power N	Module	Power	Output reactor
FSC	6SL3225-0BE25-5 . A0, 6SL3225-0BE27-5 . A0, 6SL3225-0BE31-1 . A0	7.5 kW 15.0 kW	6SL3202-0AJ23-2CA0
FSD	6SL3225-0BE31-5 . A0	18.5 kW	6SE6400-3TC05-4DD0
	6SL3225-0BE31-8 . A0	22 kW	6SE6400-3TC03-8DD0
	6SL3225-0BE32-2 . A0	30 kW	6SE6400-3TC05-4DD0
FSE	6SL3225-0BE33-0 . A0	37 kW	6SE6400-3TC08-0ED0
	6SL3225-0BE33-7 . A0	45 kW	6SE6400-3TC07-5ED0
FSF	6SL3225-0BE34-5 . A0	55 kW	6SE6400-3TC14-5FD0
	6SL3225-0BE35-5 . A0	75 kW	6SE6400-3TC15-4FD0
	6SL3225-0BE37-5 . A0	90 kW	6SE6400-3TC14-5FD0

## 3.8.5 ((dv/dt filter plus VPL PM240-2))

A combination of dv/dt filter and a voltage peak limiter (VPL) – dv/dt filter plus VPL – is available to suppress voltage peaks.

When using a dv/dt filter plus VPL, observe the following restrictions:

- The output frequency must not exceed 150 Hz.
- The pulse frequency must not exceed 4 kHz.



#### NOTICE

## Damage to the dv/dt filter plus VPL if it is not activated during commissioning

The dv/dt filter plus VPL may be damaged if it is not activated during commissioning.

- Activate the dv/dt filter plus VPL during commissioning via parameter p0230.
- Activate the dv/dt filter plus VPL during commissioning according to the electric specifications.

#### NOTICE

#### Damage to the dv/dt filter plus VPL if the connection to the capacitor is not removed

The dv/dt filter plus VPL may be damaged if the connection to the capacitor of the common mode filter is not removed when the dv/dt filter plus VPL operates in the IT line system.

Further information is provided on the Internet:

• FAQ of dv/dt filter plus VPL (<a href="https://support.industry.siemens.com/cs/ww/en/ps/13224/faq">https://support.industry.siemens.com/cs/ww/en/ps/13224/faq</a>)

For applications in the USA and Canada, you can also use the dv/dt filters plus VPL recommended by Siemens Product Partner for Drive Options. For more information, see the link below:

Voltage limiter and dv/dt filter (<a href="https://www.mdexx.com/wp-content/uploads/2019/11/">https://www.mdexx.com/wp-content/uploads/2019/11/</a> BAF-18-001-76 Instruction manual.pdf)

### dv/dt filters plus VPL for PM240-2 Power Modules, 3 AC 400 V

Power	Power Module		dv/dt filter plus VPL
			Manufacturer: mdexx Magnetronic Devices s.r.o
FSD	6SL3210-1PE23-8 .L0	18.5 kW	JTA:TEF1203-0HB
	6SL3210-1PE24-5 .L0 6SL3210-1PE26-0 .L0	22 kW 30 kW	JTA:TEF1203-0JB
FSD FSE	6SL3211PE27-5 .L0 6SL3210-1PE28-8 .L0	37 kW 45 kW	JTA:TEF1203-0KB

Power Module		Power	dv/dt filter plus VPL Manufacturer: mdexx Mag- netronic Devices s.r.o
FSE FSF	6SL3211PE31-1 .L0 6SL3210-1PE31-5 .L0	55 kW 75 kW	JTA:TEF1203-0LB
FSF	6SL3210-1PE31-8 .L0 6SL3210-1PE32-1 .L0 6SL3211PE32-5 .L0	90 kW 110 kW 132 kW	JTA:TEF1203-0MB

## dv/dt filters plus VPL for PM240-2 Power Modules, 3 AC 690 V

Power N	<i>l</i> odule	Power	dv/dt filter plus VPL Manufacturer: mdexx Mag- netronic Devices s.r.o
FSD	6SL3210-1PH21-4 .L0 6SL3210-1PH22-0 .L0 6SL3210-1PH22-3 .L0	11 kW 15 kW 18.5 kW	JTA:TEF1203-0GB
	6SL3210-1PH22-7 .L0 6SL3210-1PH23-5 .L0 6SL3210-1PH24-2 .L0	22 kW 30 kW 37 kW	JTA:TEF1203-0HB
FSE	6SL3210-1PH25-2 .L0 6SL3210-1PH26-2 .L0	45 kW 55 kW	JTA:TEF1203-0JB
FSF	6SL3210-1PH28-0 .L0 6SL3210-1PH31-0 .L0	75 kW 90 kW	JTA:TEF1203-0KB
	6SL3210-1PH31-2 .L0 6SL3210-1PH31-4 .L0	110 kW 132 kW	JTA:TEF1203-0LB
FSG	6SL3210-1PH31-7CL0 6SL3210-1PH32-1CL0 6SL3210-1PH32-5CL0	160 kW 200 kW 250 kW	JTA:TEF1203-0MB

### 3.8.6 Sine-wave filter

The sine-wave filter at the converter output limits the voltage rate-ofrise and the peak voltages at the motor winding. The maximum permissible length of motor feeder cables is increased to 300 m.

The following applies when using a sine-wave filter:

- Operation is only permissible with pulse frequencies from 4 kHz to 8 kHz.
  - From 110 kW power rating of the Power Modules (according to the type plate) only 4 kHz is permissible.
- The converter power is reduced by 5%.
- The maximum output frequency of the converter is 150 Hz at 380 V to 480 V.
- Operation and commissioning may only be performed with the motor connected, as the sine-wave filter is not no-load proof.
- An output reactor is superfluous.

### Sine-wave filter for PM240-2 Power Module, 380 V ... 480 V

Power Module		Power	Sine-wave filter
FSD	6SL3210-1PE23-8 . L0, 6SL3210-1PE24-5 . L0	18.5 kW 22 kW	6SL3202-0AE24-6SA0
	6SL3210-1PE26-0 . L0	30 kW	6SL3202-0AE26-2SA0
	6SL3211PE27-5 . L0	37 kW	6SL3202-0AE28-8SA0
FSE	6SL3210-1PE28-8 . L0	45 kW	
	6SL3211PE31-1 . LO	55 kW	6SL3202-0AE31-5SA0
FSF	6SL3210-1PE31-5 . L0	75 kW	
	6SL3210-1PE31-8 . L0	90 kW	6SL3202-0AE31-8SA0
	6SL3210-1PE32-1 . L0, 6SL3211PE32-5 . L0	110 kW 132 kW	6SL3000-2CE32-3AA0
FSG	6SL3210-1PE33-0 . L0	160 kW	6SL3000-2CE32-8AA0
	6SL3210-1PE33-7 . LO	200 kW	6SL3000-2CE33-3AA0
	6SL3210-1PE34-8 . L0	250 kW	6SL3000-2CE34-1AA0

### Sine-wave filter for PM240-2 Power Module, 200 V ... 240 V

Power Module		Power	Sine-wave filter
FSD	6SL3210-1PC24-2UL0	11 kW	6SL3202-0AE24-6SA0
	6SL3210-1PC25-4UL0	15 kW	6SL3202-0AE26-2SA0
	6SL3211PC26-8UL0	18.5 kW	6SL3202-0AE28-8SA0
FSE	6SL3210-1PC28-0UL0	22 kW	
	6SL3211PC31-1UL0	30 kW	6SL3202-0AE31-5SA0
FSF	6SL3210-1PC31-3UL0	37 kW	
	6SL3210-1PC31-6UL0, 6SL3211PC31-8UL0	45 kW 55 kW	6SL3202-0AE31-8SA0

## Sine-wave filter for PM250 Power Module

Power I	Module	Power	Sine-wave filter
FSC	6SL3225-0BE25-5 . A0	7.5 kW	6SL3202-0AE22-0SA0
	6SL3225-0BE27-5 . A0, 6SL3225-0BE31-1 . A0	11.0 kW 15.0 kW	6SL3202-0AE23-3SA0
FSD	6SL3225-0BE31-5 . A0, 6SL3225-0BE31-8 . A0	18.5 kW 22 kW	6SL3202-0AE24-6SA0
	6SL3225-0BE32-2 . A0	30 kW	6SL3202-0AE26-2SA0
FSE	6SL3225-0BE33-0 . A0, 6SL3225-0BE33-7 . A0	37 kW 45 kW	6SL3202-0AE28-8SA0
FSF	6SL3225-0BE34-5 . A0, 6SL3225-0BE35-5 . A0	55 kW 75 kW	6SL3202-0AE31-5SA0
	6SL3225-0BE37-5 . A0	90 kW	6SL3202-0AE31-8SA0

## Sine-wave filter for PM240P-2 Power Module, 380 V ... 480 V

Power Module		Power	Sine-wave filter
FSD	6SL3210-1RE24-5 . L0	22 kW	6SL3202-0AE26-2SA0
	6SL3210-1RE26-0 . L0	30 kW	6SL3202-0AE28-8SA0
	6SL3210-1RE27-5 . LO	37 kW	
FSE	6SL3210-1RE28-8 . LO	45 kW	6SL3202-0AE31-5SA0
	6SL3210-1RE31-1 . LO	55 KW	
FSF	6SL3210-1RE31-5 . LO	75 kW	6SL3202-0AE31-8SA0
	6SL3210-1RE31-8 . LO	90 kW	6SL3000-2CE32-3AA0
	6SL3210-1RE32-1 . LO	110 kW	
	6SL3210-1RE32-5 . L0	132 kW	6SL3000-2CE32-8AA0

## 3.8.7 dv/dt filter

## du/dt filters for the PM330 Power Module, 380 V ... 480 V

A du/dt filter plus VPL (Voltage Peak Limiter) limits the voltage rate of rise du/dt and the voltage peaks at the motor. A du/dt filter plus VPL allows standard motors with standard insulation and without insulated bearings to be operated at the converter.

Power M	odule	Power	du/dt filter plus VPL	du/dt filter compact plus VPL
GX	6SL3310-1PE33-0AA0, 6SL3310-1PE33-7AA0, 6SL3310-1PE34-6AA0	160 kW 250 kW	6SL3000-2DE35-0AA0	6SL3000-2DE35-0EA0
HX	6SL3310-1PE35-8AA0, 6SL3310-1PE36-6AA0, 6SL3310-1PE37-4AA0	315 kW 400 kW	6SL3000-2DE38-4AA0	6SL3000-2DE38-4EA0
JX	6SL3310-1PE38-4AA0, 6SL3310-1PE38-8AA0, 6SL3310-1PE41-0AA0	450 kW 560 kW	6SL3000-2DE41-4AA0	6SL3000-2DE41-4EA0

## du/dt filters for the PM330 Power Module, 500 V ... 690 V

Power M	odule	Power	du/dt filter plus VPL	du/dt filter compact plus VPL
JX	6SL3310-1PG35-8AA0,	500 kW	6SL3000-2DH38-1AA0	6SL3000-2DG38-1EA0
	6SL3310-1PG36-5AA0, 6SL3310-1PG37-2AA0	630 kW		

## 3.8.8 Braking Module and braking resistor

The braking resistor allows loads with a high moment of inertia to be quickly braked. Inverters with power up to 132 kW have an integrated Braking Module that controls the braking resistor.

A Braking Module is available as option for inverters with more power.

An example for a braking resistor is shown at the side.



## **Braking Modules and braking resistors for PM330**

Powe	er Module	Power	Braking Module	Power	Braking resistor
GX	6SL3310-1PE33-0AA0, 6SL3310-1PE33-7AA0, 6SL3310-1PE34-6AA0	160 kW 250 kW	6SL3760- 1AE32-6AA0	50 kW	6SE7032- 5FS87-2DC0
НХ	6SL3310-1PE35-8AA0, 6SL3310-1PE36-6AA0, 6SL3310-1PE37-4AA0	315 kW 400 kW			
JX	6SL3310-1PE38-4AA0, 6SL3310-1PE38-8AA0, 6SL3310-1PE41-0AA0	450 kW 560 kW			

### Braking resistors for PM240-2, 380 V ... 480 V

Power N	Module (	Power	Braking resistor
FSA	6SL3210-1PE11-8 . L1, 6SL3210-1PE12-3 . L1, 6SL3210-1PE13-2 . L1, 6SL3210-1PE14-3 . L1	0.55 kW 1.5 kW	6SL3201-0BE14-3AA0
	6SL3211PE16-1 . L1, 6SL3211PE18-0 . L1	2.2 kW 3.0 kW	6SL3201-0BE21-0AA0
FSB	6SL3210-1PE21-1 . LO, 6SL3210-1PE21-4 . LO, 6SL3211PE21-8 . LO	4 kW 7.5 kW	6SL3201-0BE21-8AA0
FSC	6SL3210-1PE22-7 . L0, 6SL3211PE23-3 . L0	11 kW 15 kW	6SL3201-0BE23-8AA0
FSD	6SL3210-1PE23-8 . L0, 6SL3210-1PE24-5 . L0	18.5 kW 22 kW	JJY:023422620001
	6SL3210-1PE26-0 . L0, 6SL3210-1PE27-5 . L0	30 kW 37 kW	JJY:023424020001
FSE	6SL3210-1PE28-8 . L0, 6SL3210-1PE31-1 . L0	45 kW 55 kW	JJY:023434020001

Power N	/lodule	Power	Braking resistor
FSF	6SL3210-1PE31-5 . L0, 6SL3210-1PE31-8 . L0,	75 kW 90 kW	JJY:023454020001
	6SL3210-1PE32-1 . L0, 6SL3210-1PE32-5 . L0	90 kW 132 kW	JJY:023464020001
FSG	6SL3210-1PE33-0AL0, 6SL3210-1PE33-7AL0, 6SL3210-1PE34-8AL0	160 kW 250 kW	6SL3000-1BE32-5AA0

## Braking resistors for PM240-2, 500 V ... 690 V

Power N	/lodule	Power	Braking resistor
FSD	6SL3210-1PH21-4 . L0, 6SL3210-1PH22-0 . L0, 6SL3210-1PH22-3 . L0, 6SL3210-1PH22-7 . L0, 6SL3210-1PH23-5 . L0, 6SL3210-1PH24-2 . L0	11 kW 37 kW	JJY:023424020002
FSE	6SL3210-1PH25-2 . L0, 6SL3210-1PH26-2 . L0	45 kW 55 kW	JJY:023434020002
FSF	6SL3210-1PH28-0 . L0, 6SL3210-1PH31-0 . L0,	75 kW 90 kW	JJY:023464020002
	6SL3210-1PH31-2 . L0, 6SL3210-1PH31-4 . L0	110 kW 132 kW	JJY:023464020002
FSG	6SL3210-1PH31-7CL0, 6SL3210-1PH32-1CL0, 6SL3210-1PH32-5CL0	160 kW 250 kW	6SL3000-1BH32-5AA0

## Braking resistors for PM240-2, 200 V ... 240 V

Power Module		Power	Braking resistor
FSA	6SL3210-1PB13-0 . LO, 6SL3211PB13-8 . LO	0.55 kW 0.75 kW	JJY:023146720008
FSB	6SL3210-1PB15-5 . L0, 6SL3210-1PB17-4 . L0, 6SL3211PB21-0 . L0	1.1 kW 2.2 kW	JJY:023151720007
FSC	6SL3210-1PB21-4 . LO, 6SL3211PB21-8 . LO	3 kW 4 kW	JJY:02 3163720018
	6SL3210-1PC22-2 . L0, 6SL3210-1PC22-8 . L0	5.5 kW 7.5 kW	JJY:023433720001
FSD	6SL3210-1PC24-2UL0, 6SL3210-1PC25-4UL0, 6SL3210-1PC26-8UL0	11 kW 18.5 kW	JJY:023422620002
FSE	6SL3210-1PC28-0UL0, 6SL3210-1PC31-1UL0	22 kW 30 kW	JJY:023423320001
FSF	6SL3210-1PC31-3UL0, 6SL3210-1PC31-6UL0, 6SL3210-1PC31-8UL0	37 kW 55 kW	JJY:023434020003

## 3.8.9 Control Unit Adapter Kit CUA20

### Overview

When using the CUA20 Control Unit Adapter Kit, the Control Unit can be installed next to the PM240-2 Power Module.

Article No: 6SL3255-0BW01-0NA0




Figure 3-5 Control Unit Adapter Kit CUA20

The SINAMICS CUA20 Control Unit Adapter Kit comprises the following components:

- Adapter which is snapped onto the Power Module
- · Adapter for the Control Unit
- Prefabricated cable to connect the two adapters

#### 3.9 Motors and multi-motor drives that can be operated

### Siemens motors that can be operated

You can connect standard induction motors to the converter.

You can find information on further motors on the Internet:

Motors that can be operated (https://support.industry.siemens.com/cs/ww/en/view/ 100426622)

### Third-party motors that can be operated

You can operate standard asynchronous motors from other manufacturers with the converter:

### NOTICE

### Insulation failure due to unsuitable third-party motor

A higher load occurs on the motor insulation in converter mode than with line operation. Damage to the motor winding may occur as a result.

Please observe the notes in the System Manual "Requirements for third-party motors"

Further information is provided on the Internet:

Requirements for third-party motors (https://support.industry.siemens.com/cs/ww/en/ view/79690594)

### Multi-motor operation

Multi-motor operation involves simultaneously operating several identical motors on one converter. For standard induction motors, multi-motor operation is generally permissible.

Additional preconditions and restrictions relating to multi-motor operation are available on the Internet:



Multi-motor drive (http://support.automation.siemens.com/WW/view/en/84049346)

3.9 Motors and multi-motor drives that can be operated

Installing

## 4.1 Installing the label for the North American market

## Description

DANGER - Risk of electrical shock. Discharge time of DC capacitors to a level below 50V is 5 minutes.

WARNING -The opening of the branch-circuit protective device may be an indication that a fault has been interrupted. To reduce the risk of fire or electrical shock, current carrying parts and other components of the controller should be examined and replaced if damaged. If burnout of the current elements of an overload relay occurs, the complete overload relay must be replaced.

The supply circuit's maximum short circuit current capability and voltage rating depends on type and rating of the overcurrent protection device.

Refer to the user manual for details.

Integral solid state short circuit protection does not provide branch circuit protection. Branch circuit protection must be provided in accordance with the National Electrical Code, the Canadian Electrical Code, Part1, respectively, additional local Codes and the Manufacturer's Instructions.

Integral motor overload protection included. Refer to user manual for initial setting and adjustments.

DANGER - Risque de choc électrique. Une tension dangereuse peut être présentée jusqu'à 5 minutes après avoir coupé l'alimentation.

ATTENTION - Le déclenchement du dispositif de protection du circuit de dérivation peut être dû à une coupure qui résulte d'un courant de défaut. Pour limiter le risque d'incendie ou de choc électrique, examiner les pièces porteuses de courant et les autres éléments du contrôleur et les remplacer s'ils sont endommagés. En cas de grillages de l'élément traversé par le courant dans un relais de surcharge, le relais tout entier doit être remplacé.

Le courant nominal de court-circuit du circuit d'alimentation et sa tension assignée dépendent du type et des caractéristiques assignées du dispositif de protection contre les surcharges. Pour plus de détails, voir manuel

La protection intégrée contre les courts-circuits n'assure pas la protection de la dérivation. La protection de la dérivation doit être exécutée conformément au le National Electrical Code (NEC) ou le Code Canadien de L'électricité, première partie, et dans le respect des prescriptions locales et des instructions du fabricant.

Protection de surcharge moteur incluse. Voir manuel pour les paramètres d'origine et les réglages.

Figure 4-1 Adhesive label with danger and warning notes for North America

The converter is supplied with an adhesive label with danger and warning notes for the North American market.

Attach the adhesive label in the required language to the inside of the control cabinet where it is clearly visible at all times.

## 4.2 EMC-compliant setup of the machine or plant

The converter is designed for operation in industrial environments where strong electromagnetic fields are to be expected.

Reliable and disturbance-free operation is only ensured for EMC-compliant installation.

To achieve this, subdivide the control cabinet and the machine or system into EMC zones:

#### **EMC** zones




Figure 4-2 Example of the EMC zones of a plant or machine

#### Inside the control cabinet

- Zone A: Line supply connection
- Zone B: Power electronics

  Devices in Zone B generate energy-rich electromagnetic fields.
- Zone C: Control and sensors
   Devices in Zone C do not generate any energy-rich electromagnetic fields themselves, but their functions can be impaired by electromagnetic fields.

#### Outside the control cabinet

Zone D: Motors, braking resistors
 Devices in Zone D generate electromagnetic fields with a significant amount of energy

#### 4.2.1 Control cabinet

- Assign the various devices to zones in the control cabinet.
- Electromagnetically uncouple the zones from each other by means of one of the following actions:
  - Side clearance ≥ 25 cm
  - Separate metal enclosure
  - Large-area partition plates
- Route cables of various zones in separate cable harnesses or cable ducts.
- Install filters or isolation amplifiers at the interfaces of the zones.

### Control cabinet assembly

- Connect the door, side panels, top and base plate of the control cabinet with the control cabinet frame using one of the following methods:
  - Electrical contact surface of several cm<sup>2</sup> for each contact location
  - Several screw connections
  - Short, finely stranded, braided copper wires with cross-sections
     ≥ 95 mm² / 000 (3/0) (-2) AWG
- Install a shield support for shielded cables that are routed out of the control cabinet.
- Connect the PE bar and the shield support to the control cabinet frame through a large surface area to establish a good electrical connection.
- Mount the control cabinet components on a bare metal mounting plate.
- Connect the mounting plate to the control cabinet frame and PE bar and shield support through a large surface area to establish a good electrical connection.
- For screw connections onto painted or anodized surfaces, establish a good conductive contact using one of the following methods:
  - Use special (serrated) contact washers that cut through the painted or anodized surface.
  - Remove the insulating coating at the contact locations.

## Measures required for several control cabinets

- Install equipotential bonding for all control cabinets.
- Screw the frames of the control cabinets together at several locations through a large surface area using serrated washers to establish a good electrical connection.
- In plants and systems where the control cabinets are lined up next to one another, and which are installed in two groups back to back, connect the PE bars of the two cabinet groups at as many locations as possible.

### 4.2 EMC-compliant setup of the machine or plant




Figure 4-3 Grounding and high-frequency equipotential bonding measures in the control cabinet and in the plant/system

### **Further information**

Additional information about EMC-compliant installation is available in the Internet:

EMC installation guideline (<a href="http://support.automation.siemens.com/WW/view/en/60612658">http://support.automation.siemens.com/WW/view/en/60612658</a>)

### 4.2.2 **Cables**

Cables with a high level of interference and cables with a low level of interference are connected to the converter:

- Cables with a high level of interference:
  - Cable between the line filter and converter
  - Motor cable
  - Cable at the converter DC link connection
  - Cable between the converter and braking resistor
- Cables with a low level of interference:
  - Cable between the line and line filter
  - Signal and data cables

### Cable routing inside the cabinet

- Route the power cables with a high level of interference so that there is a minimum clearance of 25 cm to cables with a low level of interference.
   If the minimum clearance of 25 cm is not possible, insert separating metal sheets between the cables with a high level of interference and cables with a low level of interference.
   Connect these separating metal sheets to the mounting plate to establish a good electrical connection.
- Cables with a high level of interference and cables with a low level of interference may only cross over at right angles:
- Keep all of the cables as short as possible.
- Route all of the cables close to the mounting plates or cabinet frames.
- Route signal and data cables as well as the associated equipotential bonding cables parallel
  and close to one another.
- Twist incoming and outgoing unshielded individual conductors.
   Alternatively, you can route incoming and outgoing conductors in parallel, but close to one another.
- Ground any unused conductors of signal and data cables at both ends.
- Signal and data cables must only enter the cabinet from one side, e.g. from below.
- Use shielded cables for the following connections:
  - Cable between the converter and line filter
  - Cable between the converter and output reactor or sine-wave filter




Figure 4-4 Routing converter cables inside and outside a control cabinet

4.2 EMC-compliant setup of the machine or plant

## Routing cables outside the control cabinet

- Maintain a minimum clearance of 25 cm between cables with a high level of interference and cables with a low level of interference.
- Use shielded cables for the following connections:
  - Converter motor cable
  - Cable between the converter and braking resistor
  - Signal and data cables
- Connect the motor cable shield to the motor enclosure using a PG gland that establishes a good electrical connection.

### Requirements relating to shielded cables

- Use cables with finely-stranded, braided shields.
- Connect the shield to at least one end of the cable.




Figure 4-5 Examples for EMC-compliant shield support

- Attach the shield to the shield support directly after the cable enters the cabinet.
- Do not interrupt the shield.
- Only use metallic or metallized plug connectors for shielded data cables.

## 4.2.3 Electromechanical components

## Surge voltage protection circuit

- Connect surge voltage protection circuits to the following components:
  - Coils of contactors
  - Relays
  - Solenoid valves
  - Motor holding brakes
- Connect the surge voltage protection circuit directly at the coil.
- Use RC elements or varistors for AC-operated coils and freewheeling diodes or varistors for DC-operated coils.

4.3 Installing reactors, filters and braking resistors

# 4.3 Installing reactors, filters and braking resistors

## Installing reactors, filters and braking resistors

The following supplementary components may be required depending on the Power Modules and the particular application:

- Line reactors
- Filter
- Braking resistors
- Brake Relay

Installing these components is described in the documentation provided.

## 4.4.1 Basic installation rules for built-in units

## Protection against the spread of fire

The built-in units may be operated only in closed housings or in higher-level control cabinets with closed protective covers, and when all of the protective devices are used. The installation of the built-in units in a metal control cabinet or protection with another equivalent measure must prevent the spread of fire and emissions outside the control cabinet.

Wall mounting units may be operated outside the control cabinet.

## Protection against condensation or electrically conductive contamination

Protect the converter, e.g. by installing it in a control cabinet with degree of protection IP54 according to IEC 60529 or NEMA 12. Further measures may be necessary for particularly critical operating conditions.


If condensation or conductive pollution can be excluded at the installation site, a lower degree of control cabinet protection may be permitted.

## Installing

Rules for admissible mounting:

• Only mount the Power Module in a vertical position with the motor connectors at the bottom.





- Maintain the minimum clearances to other components.
- Use the specified installation parts and components.
- · Comply with the specified torques.

# 4.4.2 Dimension drawings, drilling dimensions for the PM230 Power Module, IP55

The following dimension drawings are not to scale.

## Frame sizes FSA ... FSC




Figure 4-6 Dimension drawing, PM230 Power Module IP55, FSA ... FSC

Table 4-1 Dimensions

Frame size	Width	Heigh	Depth [mm]			
	[mm]	t[mm]	Without operator panel	With BOP-2, IOP-2 operator panel or blanking cover		
FSA	154	460	249	256		
FSB	180	540	249	256		
FSC	230	620	249	256		

Table 4-2 Drilling dimensions, cooling clearances and fixing

Frame size	Drilling dimensions [mm]			Cooling a	ir clearan	Screws/torque [Nm]	
	b	h	С	Тор	Bottom	Lateral	
FSA	132	445	11	100	100	0 1)	4 x M4 / 2.5
FSB	158	524	11	100	100	0 1)	4 x M4 / 2.5
FSC	208	604	11	125	125	0 1)	4 x M5 / 3.0

<sup>1)</sup> You can mount the Power Modules without any lateral cooling air clearance. For tolerance reasons, we recommend a lateral clearance of approx. 1 mm.

## Frame sizes FSD ... FSF




Figure 4-7 Dimension drawing, PM230 Power Module IP55 FSD ... FSF

Table 4-3 Dimensions

Frame size	Width	Heigh	Depth [mm]			
	[mm] t [mm] Without operator panel			With BOP-2, IOP-2 operator panel or blanking cover		
FSD	320	640	329	336		
FSE	320	751	329	336		
FSF	410	915	416	423		

Table 4-4 Drilling dimensions, cooling clearances and fixing

Frame size	Drilling dimensions [mm]			Cooling a	air clearan	Screws/torque [Nm]	
	b	h	С	Тор	Bottom	Lateral	
FSD	285	600	17.5	300	300	50	4 x M8 / 13
FSE	285	710	17.5	300	300	50	4 x M8 / 13
FSF	370	870	17.5	350	350	50	4 x M8 / 13

# 4.4.3 Dimension drawings, drilling dimensions for the PM230 Power Module, IP20

The following dimension drawings and drilling patterns are not to scale.

## Frame sizes FSA ... FSC




Table 4-5 Dimensions depend on the operator panel (OP) that is inserted

Frame size	Width [mm]	Heigh	t [mm]	Mounting depth in the cabinet with Control Unit (CU) [mm] 2)		
		without shield plate	with shield plate	without OP	with OP 1)	
FSA	73	196	276	224	235	
FSB	100	292	370	224	235	
FSC	140	355	432	224	235	

<sup>1)</sup> BOP-2, IOP-2 or blanking cover


Table 4-6 Drilling dimensions, cooling clearances and fixing

Frame size	Drilling dimensions [mm]			Cooling a	air clearan	Fixing/torque [Nm]	
	b	h	С	Тор	Bottom	Front	
FSA	62.3	186	6	80	100		2 x M4 / 2.5
FSB	80	281	6	80	100		4 x M4 / 2.5
FSC	120	343	6	80	100		4 x M5 / 3.0

<sup>1)</sup> You can mount the Power Modules without any lateral cooling air clearance. For tolerance reasons, we recommend a lateral clearance of approx. 1 mm.

<sup>&</sup>lt;sup>2)</sup> Power Module depth without Control Unit: 165 mm

## Frame sizes FSD ... FSF






Table 4-7 Dimensions depend on the operator panel (OP) that is inserted 1)

Frame size	Width [mm]	Heigh	t [mm]	Mounting depth in the cabinet with Control Unit (CU) [mm] 2)			
		without shield plate	with shield plate	without OP	with OP 1)		
FSD with- out filter	275	419	542	263	274		
FSD with filter	275	512	635	263	274		
FSE with- out filter	275	499	622	263	274		
FSE with filter	275	635	758	263	274		
FSF with- out filter	350	634	792	375	386		
FSF with filter	350	934	1092	375	386		

<sup>1)</sup> BOP-2, IOP-2 or blanking cover

<sup>&</sup>lt;sup>2)</sup> Power Module depth without Control Unit: FSD, FSE 237 mm, FSF 357 mm

Table 4-8 Drilling dimensions, cooling clearances and fixing


Frame size	Drilling dimensions [mm]			Cooling a	nir clearan	Fixing/torque [Nm]	
	b	h	С	Тор	Bottom	Front	
FSD without filter	235	325	11	300	300	100	4 x M6 / 6.0
FSD with filter	235	419	11	300	300	100	4 x M6 / 6.0
FSE without filter	235	405	11	300	300	100	4 x M6 / 10
FSE with filter	235	451	11	300	300	100	4 x M6 / 10
FSF without filter	300	598	11	350	350	100	4 x M8 / 13
FSF with filter	300	899	11	350	350	100	4 x M8 / 13

<sup>1)</sup> You can mount the Power Modules without any lateral cooling air clearance. For tolerance reasons, we recommend a lateral clearance of approx. 1 mm.

# 4.4.4 Dimension drawings, drilling dimensions for PM240P-2 Power Modules, IP20

The following dimension drawings and drilling patterns are not to scale.

## Frame sizes FSD ... FSF






Table 4-9 Dimensions depend on the operator panel (OP) that is inserted 1)

Frame size	Width [mm]	Heigh	t [mm]	Mounting depth in the cabinet with Control Unit (CU) [mm] <sup>2)</sup>		
		without shield with shield plate plate		without OP	with OP 1)	
FSD	200	472	624	253	264	
FSE	275	551	728	253	264	
FSF	305	709 965		373	384	

<sup>1)</sup> BOP-2, IOP-2 or blanking cover

<sup>&</sup>lt;sup>2)</sup> Power Module depth without Control Unit: FSD, FSE 237 mm, FSF 357 mm

Table 4-10 Drilling dimensions, cooling clearances and fixing

Frame	Drilling	dimensio	ns [mm]	Cooling a	air clearance	Fixing/torque [Nm]	
size	h	b	С	Тор	Top Bottom Front		
FSD	430	170	7	300	350	100	4 x M5 / 6.0
FSE	509	230	8.5	300	350	100	4 x M6 / 10
FSF	680	270	13	300	350	100	4 x M8 / 25

The Power Module is designed for mounting without any lateral cooling air clearance. For tolerance reasons, we recommend a lateral clearance of approx. 1 mm.

# 4.4.5 Dimension drawings, drilling dimensions for the Power Module PM330, IP20

The following dimension drawings and drilling patterns are not to scale.




Table 4-11 Dimensions, cooling air clearances [mm] and fastening [Nm]

Frame size	Dimensions			C	ooling air	·S	Mounting	
	Depth	Height	Width	th Top Bottom Lateral Front				Screws/torque
GX	328	1402	452	200	200	30	30	5 x M8 / 25
HX	393	1660	548	200	250	30	100	7 x M8 / 25
JX	393	1579	801	200	250	30	100	7 x M8 / 25

# 4.4.6 Dimensioned drawings, drilling dimensions for the PM240-2 Power Module, IP20

The following dimension drawings and drilling patterns are not to scale.

## Frame sizes FSA ... FSC




Table 4-12 Dimensions

Frame size	Width [mm]	Heigh	t [mm]	Mounting dep net with Cont [mr		Mount- ing depth with
		without shield plate	with shield plate	without OP	with OP 1)	CUA20 <sup>2)</sup> [mm]
FSA	73	196	276	224	235	194
FSB	100	292	370	224	235	194
FSC	140	355	432	224	235	194

<sup>1)</sup> BOP-2, IOP-2 or blanking cover

Table 4-13 Drilling dimensions, cooling clearances and fixing


Frame	Drilling	dimensio	ns [mm]	Cooling a	ir clearance	Fixing/torque [Nm]	
size	h	b	С	Тор	Bottom	Front	
FSA	186	62.3	6	80	100	100	3 x M4 / 2.5
FSB	281	80	6	80	100	100	4 x M4 / 2.5
FSC	343	120	6	80	100	100	4 x M5 / 3.5

The Power Module is designed for mounting without any lateral cooling air clearance. For tolerance reasons, we recommend a lateral clearance of approx. 1 mm

<sup>&</sup>lt;sup>2)</sup> Control Unit Adapter Kit CUA20

<sup>&</sup>lt;sup>3)</sup> Depth of Power Module without Control Unit: 165 mm

## Frame sizes FSD ... FSF






Table 4-14 Dimensions

Frame size	Width [mm]	Height [mm]		Mounting dep net with Con [mr	Mounting depth with	
		without shield plate	with shield plate	without OP	with OP 1)	CUA20 <sup>2)</sup> [mm]
FSD	200	472	624	253	264	237
FSE	275	551	728	253	264	237
FSF	305	709	965	373	384	357
FSG	305	1000	1286	373	384	357

<sup>&</sup>lt;sup>1)</sup> BOP-2, IOP-2 or blanking cover

Table 4-15 Drilling dimensions, cooling clearances and fixing

Frame	Drilling	dimensio	ns [mm]	Cooling a	air clearance	Fixing/torque [Nm]	
size	h	b	С	Top <sup>2)</sup>	Bottom 2)		
FSD	430	170	7	300	350	100	4 x M5 / 6.0
FSE	509	230	8.5	300	350	100	4 x M6 / 10

<sup>2)</sup> Control Unit Adapter Kit CUA20

<sup>&</sup>lt;sup>3)</sup> Depth of Power Module without Control Unit: FSD, FSE 237 mm, FSF, FSG 357 mm

Frame	Drilling (	dimensio	ns [mm]	Cooling a	air clearance	Fixing/torque [Nm]	
size	h	b	С	Top 2)	Bottom 2)		
FSF	680	270	13	300	350	100	4 x M8 / 25
FSG	970.5	265	15	300	350	100	4 x M8 / 25

The Power Module is designed for mounting without any lateral cooling air clearance. For tolerance reasons, we recommend a lateral clearance of approx. 1 mm

<sup>&</sup>lt;sup>2)</sup> The top and bottom cooling air clearances refer to the Power Module without shield plate

# 4.4.7 Dimensioned drawings, drilling dimensions for the PM250 Power Module

The following dimension drawings and drilling patterns are not to scale.

## Frame size FSC




Table 4-16 Dimensions depend on the operator panel (OP) that is inserted

Frame	Mounting depth in the cabine	t with Control Unit (CU) [mm]					
size	without OP	without OP with OP 1)					
FSC	224	235					


<sup>1)</sup> BOP-2, IOP-2 or blanking cover

Table 4-17 Cooling air clearances and fastening

Frame	Cooling	air clearances	[mm] <sup>1)</sup>	Fixing/torque [Nm]	
size	Тор	Top Bottom Front			
FSC	125	125	65	4 x M5 / 3	

You can mount the Power Modules without any lateral cooling air clearance. For tolerance reasons, we recommend a lateral clearance of approx. 1 mm.

## Frame sizes FSD ... FSF






Table 4-18 Dimensions depend on the operator panel (OP) that is inserted 1)

Frame size	Width [mm]	Height [mm]		Mounting depth in Control Unit	the cabinet with (CU) [mm] 2)
		without shield plate	with shield plate	without OP	with OP 1)
FSD with- out filter	275	419	542	263	274
FSD with filter	275	512	635	263	274
FSE with- out filter	275	499	622	263	274
FSE with filter	275	635	758	263	274
FSF with- out filter	350	634	792	375	386
FSF with filter	350	934	1092	375	386

<sup>1)</sup> BOP-2, IOP-2 or blanking cover

<sup>2)</sup> Power Module depth without Control Unit: FSD, FSE 204 mm, FSF 316 mm

Table 4-19 Drilling dimensions, cooling clearances and fixing

Frame size	Drillin	g dimen [mm]	sions	Cooling air clearances [mm] <sup>1)</sup>			Fixing/torque [Nm]
	b	h	С	Тор	Bottom	Front	
FSD without filter	235	325	11	300	300	65	4 x M6 / 6
FSD with filter	235	419	11	300	300	65	4 x M6 / 6
FSE without filter	235	405	11	300	300	65	4 x M6 / 6
FSE with filter	235	541	11	300	300	65	4 x M6 / 6
FSF without filter	300	598	11	350	350	65	4 x M8 / 13
FSF with filter	300	898	11	350	350	65	4 x M8 / 13

You can mount the Power Modules without any lateral cooling air clearance. For tolerance reasons, we recommend a lateral clearance of approx. 1 mm.

# 4.4.8 Dimension drawings, drilling dimensions for PM230 and PM240-2 Power Modules utilizing push-through technology

The following dimension drawings and drilling patterns are not to scale.

## Frame sizes FSA ... FSC

Panel thickness of the control cabinet ≤ 3.5 mm




Figure 4-8 Dimension drawing and drilling dimensions for frame sizes FSA ... FSC

Table 4-20 Dimensions depend on the operator panel (OP) that is inserted

Frame size	Width [mm]	Heigh	t [mm]		n in the cabinet with Init (CU) [mm]
		without shield plate	with shield plate	without OP	with OP 1)
FSA	126	238	322	177	188
FSB	154	345	430	177	188
FSC	200	411	500	177	188

<sup>1)</sup> BOP-2, IOP-2 or blanking cover

Table 4-21 Cooling air clearances and additional dimensions

Frame	Power Module depth [mm]	T1	T2	Cooling a	air clearance	es [mm] <sup>1)</sup>
size				Тор	Bottom	Front
FSA FSC	171	118	53	80	100	100

<sup>&</sup>lt;sup>1)</sup> The Power Module is designed for mounting without any lateral cooling air clearance. For tolerance reasons, we recommend a lateral clearance of 1 mm.

Table 4-22 Electrical cabinet cutout and mounting holes

Frame Control cabinet cutout [mm]				out [mm] Fixing/torque [Nm		
size	a	b	С	d	е	
FSA	103	106	27	198	88	8 × M5 / 3.5
FSB	148	134	34.5	304	116	8 × M5 / 3.5
FSC	123	174	30.5	365	156	10 × M5 / 3.5

## Frame sizes FSD ... FSF

Panel thickness of the control cabinet ≤ 3.5 mm

Cutouts of the control cabinet and mounting holes




Figure 4-9 Dimension drawing and drilling dimensions for frame sizes FSD ... FSF

Table 4-23 Dimensions depend on the operator panel (OP) that is inserted 1)

Frame size	Width [mm]	Heigh	t [mm]		n in the cabinet with Init (CU) [mm]
		without shield plate	with shield plate	without OP	with OP 1)
FSD	276	517	650	155	166
FSE	355	615	722	155	166
FSF	385	754	1021	193	204

<sup>1)</sup> BOP-2, IOP-2 or blanking cover

Table 4-24 Cooling air clearances and additional dimensions

Frame	Power Module depth [mm]	T1	T2	Cooling air clearances [mm]		
size				Тор	Bottom	Front
FSD, FSE	237	141	97.5	350	350	29
FSF	358	177.5	180.5	80	100	100

Table 4-25 Mounting

Frame size	Fixing/torque [Nm]
FSD, FSE	10 × M5 / 3.5
FSF	12 × M6 / 5.9

#### Connecting the line supply and motor 4.5





### WARNING

## Electric shock when the motor terminal box is open

As soon as the converter is connected to the line supply, the motor connections of the converter may carry dangerous voltages. When the motor is connected to the converter, there is danger to life through contact with the motor terminals if the motor terminal box is open.

Close the motor terminal box before connecting the converter to the line supply.

#### Note

## Fault protection when insulation fails in the motor circuit at the output side

In case of insulation failure in the motor circuit, the overcurrent trip of the converter meets the requirements of IEC 60364-4-41:2005/AMD1:2017 Section 411 and Annex D for protection against electric shock.

- Observe the installation specifications for this converter.
- Ensure the continuity of the protective conductor.
- Observe the applicable installation standards.

#### 4.5.1 Permissible line supplies

## Restrictions for installation altitudes above 2000 m

Above an installation altitude of 2000 m, the permissible line supplies are restricted.



Restrictions for special ambient conditions (Page 562)

## Screw for functional grounding on the converter, frame size FSG

If you wish to use the converters with integrated C3 line filter, please note the information in the sections "TN line system", "TT line system" and "IT system" below.



Figure 4-10 Remove screw for functional grounding


## 4.5.1.1 TN line system

A TN system transfers the PE protective conductor to the installed plant or system using a cable.

Generally, in a TN system the neutral point is grounded. There are versions of a TN system with a grounded line conductor, e.g. with grounded L1.

A TN system can transfer the neutral conductor N and the PE protective conductor either separately or combined.

Example: Separate transfer of N and PE, grounded neutral point




## Converter connected to a TN system

- Converters with integrated line filter:
  - Operation on TN line systems with grounded neutral point permissible.
  - Operation on TN line systems with grounded line conductor not permissible.

#### Note

## Special feature of FSG converters

FSG converters with integrated C3 line filter can be operated in TN line systems  $\leq$  600 V with a grounded line conductor if you remove the screw for functional grounding.



If you remove the screw for functional grounding, the EMC properties deteriorate and the requirements of Class C3 are no longer met.


- Converters with external line filter:
  - Operation on TN line systems with grounded neutral point permissible.
  - Operation on TN line systems with grounded line conductor not permissible.
- · Converters without line filter:
  - Operation on all TN line systems ≤ 600 V permissible
  - Operation on TN line systems > 600 V and grounded neutral point permissible.
  - Operation on TN line systems > 600 V and grounded line conductor not permissible.

Example: Transfer of N, grounded neutral

## 4.5.1.2 TT line system

In a TT line system, the transformer grounding and the installation grounding are independent of one another.

There are TT line supplies where the neutral conductor N is either transferred – or not.



#### Note

## Operation in IEC or UL systems

For installations in compliance with IEC, operation on TT line systems is permissible. For installations in compliance with UL, operation on TT line systems is not permissible.


## Converters connected to a TT system

- Converters with integrated line filter:
  - Operation on TT line systems with grounded neutral point permissible.
  - Operation on TT line systems without grounded neutral point not permissible.

#### Note

## Special feature of FSG converters

FSG converters with integrated C3 line filter can be operated in TT line systems without a grounded neutral point if you remove the screw for functional grounding.



If you remove the screw for functional grounding, the EMC properties deteriorate and the requirements of Class C3 are no longer met.


- Converters with external line filter:
  - Operation on TT line systems with grounded neutral point permissible.
  - Operation on TT line systems without grounded neutral point not permissible.
- Converters without line filter:
  - Operation on all TT line systems permissible.

## 4.5.1.3 IT system

In an IT line system, all of the conductors are insulated with respect to the PE protective conductor – or connected to the PE protective conductor through an impedance.

There are IT systems with and without transfer of the neutral conductor N.

Example: Transfer of N, impedance with respect to PE protective conductor



## Converter connected to an IT line system - FSA ... FSF

- Converters with integrated line filter:
  - Operation on IT line systems not permissible.
- Converter without line filter:
  - Operation on all IT line systems permissible.

#### Note

## 690 V converters: Output reactors for frame sizes FSD and FSE

An output reactor is required for 690 V converters in frame sizes FSD and FSE.

## Converter with PM330 Power Module operated on an IT line system


When connected to an IT line supply, you must open the connection to the basic interference suppression board of the Power Module.

Further information is provided on the Internet:

Hardware installation manual for PM330 Power Modules (<a href="https://support.industry.siemens.com/cs/ww/en/view/109742506">https://support.industry.siemens.com/cs/ww/en/view/109742506</a>)

## Converter with PM240-2 FSG Power Module operated on an IT line system

The converters have an integrated C3 line filter. Operation on IT line systems is only permissible if you remove the grounding screw at the converter.



## Behavior of the converter when a ground fault occurs

You must install an output reactor if the converter is to remain operational even when a ground fault occurs at the converter output. This output reactor prevents an overcurrent trip or damage to the converter.

## 4.5.2 Requirements for the protective conductor



## **MARNING**


## Electric shock due to interrupted protective conductor

The drive components conduct a high leakage current via the protective conductor. Touching conductive parts when the protective conductor is interrupted can result in death or serious injury.

• Dimension the protective conductor as stipulated in the appropriate regulations.


## Dimensioning the protective conductor

Observe the local regulations for protective conductors subject to an increased leakage current at the site of operation.



- 1) Protective conductor for line feeder cables
- 2 Protective conductor for converter line feeder cables
- (3) Protective conductor between PE and the control cabinet
- 4) Protective conductor for motor feeder cables

Figure 4-11 Protective conductors for converters with IP20 degree of protection



- (1) Protective conductor for line feeder cables
- (2) Protective conductor for converter line feeder cables
- 3 Protective conductor between PE and the control cabinet
- (4) Protective conductor for motor feeder cables

Figure 4-12 Protective conductors for converters with IP55 degree of protection

The minimum cross-section of the protective conductor ① ... ④ depends on the cross-section of the line or motor feeder cable:

- Line or motor feeder cable ≤ 16 mm<sup>2</sup>
   ⇒ Minimum cross-section of the protective conductor = cross-section of the line or motor feeder cable
- 16 mm<sup>2</sup> < line or motor feeder cable ≤ 35 mm<sup>2</sup>
   ⇒ Minimum cross-section of the protective conductor = 16 mm<sup>2</sup>
- Line or motor feeder cable > 35 mm<sup>2</sup>
   ⇒ Minimum cross-section of the protective conductor = ½ cross-section of the line or motor feeder cable

Additional requirements placed on the protective conductor (1) according to IEC 60204-1:

- For permanent connection, the protective conductor must fulfill at least one of the following conditions:
  - The protective conductor is routed so that it is protected against damage along its complete length.
     Cables routed inside switch cabinets or enclosed machine housings are considered to be adequately protected against mechanical damage.
  - As a conductor of a multi-conductor cable, the protective conductor has a cross-section ≥ 2.5 mm<sup>2</sup> Cu.
  - For an individual conductor, the protective conductor has a cross-section ≥ 10 mm² Cu.
  - The protective conductor consists of two individual conductors with the same crosssection.
- When connecting a multi-conductor cable using an industrial plug connector according to EN 60309, the protective conductor must have a cross-section of ≥ 2.5 mm² Cu.

## 4.5.3 Connecting the converter with the PM230 Power Module IP55




Figure 4-13 PM230 Power Module IP55 connection overview

Table 4-26 Connection types, maximum conductor cross-sections and tightening torques

converters	Connection	Cross-section / tightening torque		
FSA	Terminal	1 2.5 mm <sup>2</sup> / 0.5 Nm	18 14 AWG / 4.4 lbf in	
FSB	Terminal	2.5 6 mm <sup>2</sup> / 0.6 Nm	14 10 AWG, 5.3 lbf in	
FSC	Terminal	616 mm <sup>2</sup> / 1.5 Nm	10 5 AWG / 13.3 lbf in	
FSD	Cable lug	10 35 mm <sup>2</sup> / 6 Nm	5 2 AWG / 53 lbf in	
FSE	Cable lug	25 50 mm <sup>2</sup> / 6 Nm	3 2 AWG / 53 lbf in	
FSF	Cable lug	35 120 mm² / 13 Nm	2 4/0 AWG, 115 lbf in	

## **EMC** cable glands

To meet the requirements of degree of protection IP55/UL, type 12, and to fulfill EMC requirements, adhere to the following:

- Use EMC cable glands for the control cables.
- Make sure that the cable glands match the drill holes in the plate.




Figure 4-14 Example of an EMC cable gland (Blueglobe)

The EMC cable glands are not included in the scope of supply of the converter. Rubber sleeves for unused drill holes in the cable cover plate are included in the scope of supply.


# Connecting the mains supply and motor, frame sizes FSA ... FSC

## **Procedure**

1. Remove the front cover of the Power Module.



2. Remove the gland plate from the bottom of the converter.



Diameter of the holes in the gland plate:

20.5 mm	Control cables
20.5 mm	Mains and motor cables, FSA
25.5 mm	Mains and motor cables, FSB
32.5 mm	Mains and motor cables, FSC

Converter Connection **Dimensions** Explanation C 1) D FSA Mains cable 10 mm 60 mm 90 mm Motor cable 10 mm 60 mm 10 mm 60 mm В FSB Mains cable 10 mm 60 mm 50 mm С 50 mm Motor cable 10 mm 10 mm 40 mm D FSC Mains cable 10 mm 50 mm 70 mm Motor cable 10 mm 50 mm 10 mm 40 mm

3. Prepare the mains and motor cables for connection in accordance with the table below.

- 1) Cable shield
- 1 Gland plate
- 4. Assemble the cable glands with the prepared cables and EMC cable glands for the control cables.
- 5. Seal any unused bushings with a rubber sleeve.
- 6. Secure the gland plate to the converter enclosure. Tightening torque: 2 Nm Make sure that the seal of the gland plate is not damaged.
- 7. Where necessary, fit the supplied ferrite ring onto the motor cable. Ferrite rings are required to be able to comply with the limit values of IEC 61800-3, Category C1 with reference to grid-bound interference voltages when using Power Modules with integrated line filters.

If you use cables > 25 m, the requirements of Category C1 are no longer satisfied.






Figure 4-15 Ferrite rings for the mains and motor cables





The Power Modules are equipped with removable plug connectors that cannot be inadvertently interchanged. To remove the connectors, press the red lever to release the interlock.

9. Fit the front cover of the Power Module.

Make sure that the seal of the front cover is not damaged.


Line supply and motor are connected to the FSA  $\dots$  FSC Power Modules.  $\square$ 


# Connecting the mains supply and motor, frame sizes FSD ... FSF

## **Procedure**

- 1. Open the door of the Power Module.
- 2. Remove the terminal cover.








3. Remove the gland plate from the bottom of the converter.

Diameter of the holes in the gland plate:

20.5 mm Control cables
 40.5 mm Mains and motor cables, FSD
 50.5 mm Mains and motor cables, FSE
 63.5 mm Mains and motor cables, FSF

- 4. Assemble the cable glands with the prepared cables and EMC cable glands for the control cables.
- 5. Seal any unused bushings with a rubber sleeve.
- 6. Secure the gland plate to the converter enclosure. Tightening torque 2 Nm. Make sure that the seal of the gland plate is not damaged.
- 7. Connect the mains supply and the motor.



Close the door of the Power Module.Make sure that the door seal of the Power Module is not damaged.

Line supply and motor are connected to the FSD ... FSF Power Modules.  $\hfill\Box$ 

Converter with CU230P-2 Control Units
Operating Instructions, 02/2023, FW 4.7 SP14, A5E34257946B AJ

# 4.5.4 Connecting the converter with the PM230 Power Module





Figure 4-16 PM230 Power Module connection overview

Table 4-27 Connection, cross-section and tightening torque for PM230 Power Modules

Converter	er Connection		Cross-section,	Stripped	
			Metric	Imperial	insula- tion length
FSA	Line supply, motor	Diece	1 2.5 mm <sup>2</sup> , 0.5 Nm	16 14 AWG, 4.5 lbf in	8 mm
FSB			1.5 6 mm <sup>2</sup> , 0.6 Nm	16 10 AWG, 5.5 lbf in	8 mm
FSC		Plug connector with screw terminals	616 mm <sup>2</sup> , 1.3 Nm	10 6 AWG, 12 lbf in	10 mm
FSD	Line supply, motor		10 35 mm², 6 Nm	7 2 AWG, 53 lbf in	
FSE		Cable lug	25 50 mm <sup>2</sup> , 6 Nm	3 1 AWG, 53 lbf in	
FSF		Cable lug	35 120 mm <sup>2</sup> , 13 Nm	2 4/0 AWG, 115 lbf in	

## Connections for frame sizes FSA ... FSC




The Power Modules are equipped with withdrawable plug connectors that cannot be inadvertently interchanged.

To remove a plug connector, you must release it by pressing on the red lever.

## Connections for frame sizes FSD ... FSF

The line and motor connections have covers to prevent them from being touched.



You must open the cover to connect the line and motor:

- 1. Release the catches on both sides of the covers using a screwdriver.
- 2. Swivel the covers upwards.

Close the covers once you have connected the line and motor.

# 4.5.5 Connecting the converter with the PM330 Power Module




Figure 4-17 Connecting the PM330 Power Module

You will find additional information about the PM330 Power Module in the Internet:

Hardware installation manual for PM330 Power Modules (<a href="https://support.industry.siemens.com/cs/ww/en/view/109742506">https://support.industry.siemens.com/cs/ww/en/view/109742506</a>)

# 4.5.6 Connecting the converter with the PM240P-2 Power Module





Figure 4-18 PM240P-2 Power Module connection overview

Table 4-28 Connection, cross-section and tightening torque for PM240P-2 Power Modules

Converter	Connection		Cross-section, tig	Stripped	
			Metric	Imperial	insula- tion length
FSD	Line supply,	Screw-type termi- nal	10 35 mm², 2.5 4.5 Nm	20 10 AWG, 22 lbf in	18 mm
	1110101	i i i i		8 2 AWG, 40 lbf in	
FSE			25 70 mm², 8 10 Nm	6 3/0 AWG, 88.5 lbf in	25 mm
FSF	Line supply, motor		35 2 × 120 mm <sup>2</sup> , 22 25 Nm	1 2 × 4/0 AWG, 210 lbf in	
		Cable lug according to SN71322			

## Connections, frame sizes FSD ... FSF

You must remove the covers from the connections in order to connect the line supply and motor cables to the converter.







Figure 4-19 Remove the connection covers

In addition, for frame sizes FSD and FSE, release the two terminal screws on the connections for the motor and remove the dummy plug.

For frame size FSF you must breakout the openings from the connection cover for the power connections. Use side cutters or a fine saw blade.






Figure 4-20 Line and motor connections

You must re-attach the connection covers in order to re-establish the touch protection of the converter after it has been connected up.

# 4.5.7 Connecting a converter with the PM240-2 Power Module




Figure 4-21 Connection of the PM240-2 Power Module, 3 AC, FSA ... FSC




Figure 4-22 Connection of the PM240-2 Power Module, 3 AC, FSD ... FSF




Figure 4-23 Connection of the PM240-2 Power Module, 1 AC 200 V, FSA ... FSC

# 4.5 Connecting the line supply and motor





Figure 4-24 Connection of the PM240-2 Power Module, 1 AC 200 V, FSD ... FSF

Table 4-29 Connection, cross-section and tightening torque for PM240-2 Power Modules

Converter	Connection		Cross-section and tightening torque		Stripped
			Metric	Imperial	insula- tion length
FSA	Line system, motor	II.	1.5 2.5 mm <sup>2</sup> , 0.5 Nm	16 14 AWG, 4.5 lbf in	8 mm
FSB	and braking resistor		1.5 6 mm <sup>2</sup> , 0.6 Nm	16 10 AWG, 5.5 lbf in	8 mm
FSC		Plug connector with screw termi- nals	616 mm², 1.3 Nm	10 6 AWG, 12 lbf in	10 mm
FSD	Line and motor	Screw-type termi- nal	10 35 mm², 2.5 4.5 Nm	8 2 AWG, 22 40 lbf in	18 mm
	Braking resistor		2.5 16 mm², 1.2 1.5 Nm	20 6 AWG, 10.5 13 lbf in	10 mm
FSE	Line and motor	Screw-type termi- nal	25 70 mm², 8 10 Nm	6 3/0 AWG, 71 88.5 lbf in	25 mm
	Braking resistor		10 35 mm², 2.5 4.5 Nm	8 2 AWG, 22 40 lbf in	18 mm
FSF	Line and motor	Cable lug according to SN71322 for M10 bolts	35 2 × 120 mm <sup>2</sup> , 22 25 Nm	1 AWG 2 × 4/0 AWG, 195 221 lbf.in	1
	Braking resistor	Screw-type termi- nal	25 <sup>1)</sup> 70 mm <sup>2</sup> , 8 10 Nm	6 3/0 AWG, 71 88.5 lbf in	25 mm
FSG	Line and motor	Cable lug according to SN71322 for M10 bolts	35 2 × 185 mm <sup>2</sup> , 22 25 Nm	1 AWG 2 × 350 MCM, 195 221 lbf.in	1
	Braking resistor	Screw-type termi- nal	25 70 mm², 8 10 Nm	6 3/0 AWG, 71 88.5 lbf in	25 mm

<sup>1) 16</sup> mm<sup>2</sup> allowed during short-time duty

#### Connections for frame sizes FSA ... FSC



The Power Modules are equipped with withdrawable plug connectors that cannot be inadvertently interchanged.


To remove a plug connector, you must release it by pressing on the red lever.

Release lever


#### Connections for frame sizes FSD ... FSG

You must remove the covers from the connections in order to connect the line supply, braking resistor and motor to the converter. In addition, for frame sizes FSD and FSE, release the two terminal screws on the connections for the motor and braking resistor, and remove the dummy plug.


For frame sizes FSF and FSG, you must breakout the openings from the connection cover for the power connections. Use side cutters or a fine saw blade.



FSD ... FSG: Remove the top covers



FSD, FSE: Remove the lower cover



FSF, FSG: Remove the lower cover

### 4.5 Connecting the line supply and motor




Figure 4-25 Connections for the line supply, motor and braking resistor

You must re-attach the connection covers in order to re-establish the touch protection of the converter after it has been connected up.

#### Additional information when connecting FSG converters

#### Note

#### Conductor cross-section 240 mm<sup>2</sup>

Cable lugs for M10 bolts according to SN71322 are suitable for cables with cross-sections of  $35 \text{ mm}^2 \dots 185 \text{ mm}^2$  (1 AWG ...  $2 \times 350 \text{ MCM}$ ).

If you wish to establish connections with cables of 240 mm<sup>2</sup> (500 MCM), you must use narrow cable lugs, e.g. Klauke 12SG10. Other cable lugs are not suitable due to the narrow design of the converter.

The maximum permissible width of the cable lugs is 37 mm (1.45 inches).

Remove the plastic insulating plate as shown below to gain better access to the terminals for the power connections.




#### **WARNING**

#### Damage to converter as a result of operation without insulating plates

Without the insulating plates, voltage flashovers may occur between the phases.

• Replace the insulating plates after connecting the cables.





# 4.5.8 Connecting the converter with the PM250 Power Module





Figure 4-26 Connecting the PM250 Power Module

Table 4-30 Connection, cross-section and tightening torque for PM250 Power Modules


Converter	Line supply and motor connection	Cross-section and tightening torque		Stripped
		Metric	Imperial	insula- tion length
FSC	Screw-type terminal	410 mm <sup>2</sup> , 2.3 Nm	12 8 AWG, 20 lbf in	10 mm
FSD		10 35 mm <sup>2</sup> , 6 Nm	7 2 AWG, 53 lbf in	
FSE	Cable lug	25 50 mm², 6 Nm	3 1/0 AWG, 53 lbf in	
FSF	Cable lug	35 120 mm <sup>2</sup> , 13 Nm	2 4/0 AWG, 115 lbf in	

### Connections for frame size FSC



#### Connections for frame sizes FSD ... FSF

The line and motor connections have covers to prevent them from being touched.



You must open the cover to connect the line and motor:

- 1. Release the catches on both sides of the covers using a screwdriver.
- 2. Swivel the covers upwards.

Close the covers once you have connected the line and motor.


### 4.5.9 Connecting the motor to the converter in a star or delta connection

#### Overview

Standard induction motors up to a rated power of approximately 3 kW are usually connected in star/delta connection (Y/ $\Delta$ ) at 400 V/230 V. For a 400-V line supply, you can connect the motor to the converter either in a star or in a delta connection.

### **Function description**

#### Operating the motor in a star connection




In a star connection, the motor can provide its rated torque  $M_N$  in the range 0 ... rated frequency  $f_N$ .

Rated voltage  $U_N = 400 \text{ V}$  is available at a rated frequency  $f_N = 50 \text{ Hz}$ .

The motor goes into field weakening above the rated frequency. In field weakening, the available motor torque decreases proportionally with 1/f. In field weakening, the available power remains constant.

#### Operating the motor in a delta connection with 87 Hz characteristic



In a delta connection, the motor is operated with a voltage and frequency above its rated values. As a consequence, the motor power is increased by a factor  $\sqrt{3} \approx 1.73$ .

In the range  $f = 0 \dots 87$  Hz, the motor can output its rated torque  $M_N$ .

The maximum voltage U = 400 V is available at a frequency of  $f = \sqrt{3} \times 50$  Hz  $\approx$  87 Hz.

The motor only goes into field weakening above 87 Hz.

The higher motor power when operated with an 87 Hz characteristic has the following disadvantages:

- The converter must supply approximately 1.73x current. Select a converter based on its rated current and not its rated power.
- The motor temperature increases more significantly than when operated with  $f \le 50$  Hz.
- The motor must have windings that are approved for a voltage > rated voltage U<sub>N</sub>.
- As the fan impeller rotates faster, the motor has a higher noise level than operation with f ≤ 50 Hz.

### 4.6.1 Plugging the Control Unit onto the Power Module

The Power Module has a holder for the Control Unit and a release mechanism.

There are different release mechanisms depending on the particular Power Module.

### **Inserting the Control Unit**

#### **Procedure**



- 1. Place the two catches of the Control Unit in the matching grooves of the Power Module.
- 2. Press the Control Unit onto the Power Module until you hear that it latches.

The Control Unit is plugged onto the Power Module.

### **Removing the Control Unit**


#### **Procedure**

Remove the Control Unit from the Power Module by pressing the release mechanism.

### Special features for the PM330 Power Module

To insert or detach the Control Unit, you must open the left-hand cover of the Power Module.

Close the cover before you commission the inverter.



### Special features for the PM230 Power Module IP55, FSA ... FSC

To insert or detach the Control Unit, you must release eight or ten fixing screws of the cover and then remove the cover.

The Power Module release mechanism is shown in the diagram.

Attach the cover again before you commission the converter. Do not damage the seal of the cover when attaching it.



### Installing the Control Unit, PM230 IP55 - FSD ... FSF

To insert or detach the Control Unit, you must open the front door of the Power Module.


Close the door before you commission the converter. Check to ensure that the seals are not damaged.



#### Operation with operator panel

To connect the operator panel to the Control Unit, you have to plug in the supplied connecting cable to the Control Unit and the operator panel.

Fasten the plug connector in the door with the supplied clamp.




Verbindungsleitung zum Operator Panel

#### Overview of the interfaces 4.6.2

#### Interfaces on the Control Unit

To access the interfaces at the front of the Control Unit, you must lift the Operator Panel (if one is being used) and open the front doors.



- 1 Memory card slot
- 2 Selecting the fieldbus address:
  - CU230P-2 DP
  - CU230P-2 HVAC
  - CU230P-2 BT

Bit 6 (64)
Bit 5 (32)
Bit 4 (16)
Bit 3 (8)
Bit 2 (4)
Bit 1 (2)
Bit 0 (1)
On Off

- 3 Terminal strips
- 4) Fieldbus interfaces at the lower side
- (5) Status LED



- (6) USB interface for connection to a PC
- (7) Switch for AI 0 and AI 1 (U/I)



- I 0/4 mA ... 20 mA
- U -10/0 V ... 10 V
- 8 Switch for Al 2 Current or temperature input



Connection to the operator panel

### Protection against unauthorized access via the USB interface



#### WARNING

### Unsafe operating states resulting from manipulation of the converter software

Manipulation of the converter software can cause unsafe operating states in your system that may lead to death, serious injury and property damage.

- Prevent unauthorized persons from accessing the converter's USB interface:
  - Do not route the USB interface outside the control cabinet.
  - Lock the control cabinet or the control room in which the converter is installed.

#### 4.6.3 Fieldbus interface allocation


#### Interfaces at the lower side of the CU230P-2 Control Unit



X150 X150 P1 P2

### Pin

- 1 RX+, receive data +
- 2 RX-, receive data -
- 3 TX+. Transmit data +
- 4 ---
- 5 ---
- 6 TX-, transmit data -
- 7 ---
- 8 ---



#### Pin

- 1 Shield, ground connection
- 2 --
- 3 RxD/TxD-P, receive and transmit (B/B')
- 4 CNTR-P, control signal
- 5 DGND, reference potential for data (C/C')
- 6 VP, supply voltage
- 7 ---
- 8 RxD/TxD-N, receive and transmit (A/A')
- 9 ---




#### Pin

- 1 0 V, reference potential
- 2 P+, RS485P, receive and transmit
- 3 N-, RS485N, receive and transmit
- 4 Cable shield
- 5 --

### 4.6.4 Terminal strips

#### Terminal strips with wiring example



<sup>1)</sup> The following applies to systems compliant with UL: Maximum current, 3 A 30 VDC or 2 A 250 VAC Figure 4-27 Wiring the digital inputs with p-switching contacts and an internal 24 V power supply (terminal 9)

GND

All terminals labelled with reference potential "GND" are connected internally in the converter.

DI COM

Reference potential "DI COM" is electrically isolated from "GND". The Control Unit is delivered with a jumper between terminals 28 and 69.

 $\rightarrow$  If, as shown above, you wish to use the 24-V supply from terminal 9 as supply for the digital inputs, then it is mandatory that this jumper is used.

31 +24 V IN 32 GND IN When an optional 24 V power supply is connected at terminals 31, 32, even when the Power Module is disconnected from the line supply, the Control Unit remains in operation. The Control Unit thus maintains fieldbus communication, for example.


- → for terminals 31, 32 only use a 24 VDC power supply with PELV (Protective Extra Low Voltage).
- $\rightarrow$  for applications in the USA and Canada: Use a 24 VDC power supply, NEC Class 2.

- → connect the 0 V of the power supply with the protective conductor.
- → if you also wish to use the power supply at terminals 31, 32 for the digital inputs, then you must connect "DI COM" and "GND IN" with one another at the terminals.

10	AI 1+	
11	AI 1-	
3	AI 0+	
4	AI 0-	


You may use the internal 10 V power supply or an external power supply for the analog inputs. → When you use the internal 10 V power supply, you must connect AI 0 or AI 1 with "GND".

#### Additional options for wiring the digital inputs



You must remove the jumper between terminals 28 and 69 if it is necessary to have electrical isolation between the external power supply and the internal converter power supply.

Connecting P-switching contacts with an external power supply



Remove the jumper between terminals 28 and 69.

Connecting M-switching contacts with an external power supply

#### Note


When a contact switching to M is connected, a ground fault at the digital input can lead to the input being unintentionally controlled.

### 4.6.5 Factory interface settings

The factory setting of the interfaces depends on the Control Unit.

#### Control Units with PROFIBUS or PROFINET interface

The function of the fieldbus interface and digital inputs DI 0, DI 1 depends on DI 3.




DO x: p073x AO 0: p0771[0] DI x: r0722.x

Speed setpoint (main setpoint): p1070[0] = 2050[1]

Figure 4-28 Factory setting of the CU230P-2 DP and CU230P-2 PN Control Units

#### Control Units with USS interface

The fieldbus interface is not active.




Speed setpoint (main setpoint): p1070[0] = 755[0]

Figure 4-29 Factory setting of CU230P-2 HVAC Control Units

### 4.6.6 Default setting of the interfaces

### Default setting 7: "Fieldbus with data set switchover"

Factory setting for inverters with PROFIBUS or PROFINET interface



DO 0: p0730, DO 1: p0731


AO 0: p0771[0], AO 1: p0771[1]

DI 0: r0722.0, ..., DI 3: r0722.3

Speed setpoint (main setpoint): p1070[0] = 2050[1] Jog 1 speed setpoint: p1058, factory setting: 150 rpm Jog 2 speed setpoint: p1059, factory setting: -150 rpm

Designation in the BOP-2: FB cdS


### Default setting 9: "Standard I/O with MOP"




# Designation in the BOP-2: Std MoP

Default setting 12: "Standard I/O with analog setpoint"

Factory setting for inverters with USS, Modbus, BACnet, MS/TP or P1 interface



### Default setting 14: "Process industry with fieldbus"



DO 0: p0730, DO 1: p0731

AO 0: p0771[0], AO 1: p0771[1]

DI 0: r0722.0, ..., DI 5: r0722.5


Motorized potentiometer setpoint after ramp-function generator: r1050

Speed setpoint (main setpoint): p1070[0] = 2050[1], p1070[1] = 1050

Switch controller via PZD01, bit 15: p0810 = r2090.15

Designation in the BOP-2: Proc Fb


### Default setting 15: "Process industry"




### Default setting 17: "2-wire (forw/backw1)"

────────────────────────────────────	
- 6DI1 ON /OFF counterclockwise	
7DI2 Acknowledge fault	
3 A  0+ Speed setpoint	
-⊗-18D0 0 Fault	
19	
[20]	
-⊗- <u>21</u> D0 1 Alarm	
22	
-O-12A0 0 Speed actual value	
-⊘-26A0 1 Current actual value	
DO 0: p0730, DO 1: AO 0: p0771[0], DI 0: r0722.0,, DI 2: r0722.2	AI 0: r0755[0]
· · · · · · · · · · · · · · · · · · ·	11 0.10735[0]
p0731 AO 1: p0771[1]	
Speed setpoint (main setpoint): p1070[0] = 755[0]	
Designation in the BOP-2: 2-wIrE 1	
•	


### Default setting 18: "2-wire (forw/backw2)"




### Default setting 19: "3-wire (enable/forw/backw)"




### Default setting 20: "3-wire (enable/on/reverse)"



# Default setting 21: "USS fieldbus"



### Default setting 101: "Universal application"




DO 0: p0730, ..., AO 0: p0771[0], AO 1: p0771[1] DI 0: r0722.0, ..., DI 5: r0722.5 AI 0: r0755[0] DO 2: p0732

#### Additional settings:

- Fixed speed setpoint 1: p1001 = 800 rpm
- Fixed speed setpoint 2: p1002 = 1000 rpm
- Fixed speed setpoint 3: p1003 = 1200 rpm
- If several of the DI 3 ... DI 5 = high, the inverter adds the corresponding fixed speeds.
- Fixed speed setpoint 15 for essential service mode (ESM): p1015 = 1500 rpm
- "Flying restart" is enabled: p1200 = 1
- Automatic restart is active. After a power failure, the inverter automatically acknowledges possible faults and switches on the motor: p1210 = 26

Designation in the BOP-2: P F 6PA

#### Default setting 103: "Pump pressure control"




DO 0: p0730, ..., DO 2: p0732 AO 0: p0771[0], AO 1: p0771[1] DI 0: r0722.0 Al 0: r0755[0] Additional settings:

- Differential pressure control using the technology controller
- Technological unit: p0595 = 1 (%), reference variable: p0596 = 1
- Default setting of the technology controller:
  - Enable: p2200 = 1
  - Fixed value 1: p2201 = 50 %
  - Ramp-up/down time for setpoint: p2257 = p2258 = 30 s
  - Ramp-up/down time for controller output: p2293 = 30 s
  - Upper and lower limits, actual value: p2267 = 120 %, p2268 = -10 %
  - Actual value filter time constant: p2265 = 10 s
  - Proportional gain  $K_P$ , integral time  $T_I$ , differentiation time constant  $T_D$ : p2280 ( $K_P$ ) = 1, p2285 ( $T_I$ ) = 30 s, p2274 ( $T_D$ ) = 0 s
- "Flying restart" is enabled: p1200 = 1
- Automatic restart is active. After a power failure, the inverter automatically acknowledges possible faults and switches on the motor: p1210 = 26

Designation in the BOP-2: P F dPc

### Default setting 104: "ESM stairwell pressure control"




DO 0: p0730, ..., DO 2: p0732 AO 0: p0771[0], AO 1: p0771[1] DI 0: r0722.0 Al 0: r0755[0] Additional settings:

- Pressure control using the technology controller
- Analog inputs smoothing time constant: p0753 = 500 ms
- Technological unit: p0595 = 1 (%), reference variable: p0596 = 1
- Default setting of the technology controller:
  - Enable: p2200 = 1
  - Fixed value 1: p2201 = 40 %
  - Ramp-up/down time for setpoint: p2257 = p2258 = 30 s
  - Ramp-up/down time for controller output: p2293 = 30 s
  - Upper and lower limits, actual value: p2267 = 120 %, p2268 = -10 %
  - Actual value filter time constant: p2265 = 10 s
  - Proportional gain  $K_p$ , integral time  $T_l$ , differentiation time constant  $T_D$ : p2280 ( $K_p$ ) = 1.2, p2285 ( $T_l$ ) = 25 s, p2274 ( $T_D$ ) = 0 s
  - Technology controller minimum limiting p2292 = 30 %
  - Technology controller output signal start value p2302 = 35 %
- "Flying restart" is enabled: p1200 = 1
- Automatic restart is active. After a power failure, the inverter automatically acknowledges possible faults and switches on the motor: p1210 = 26

Designation in the BOP-2: P\_F Stw

#### Default setting 105: "Fan pressure control + ESM with fixed setpoint"




DO 0: p0730, ..., AO 0: p0771[0], AO 1: p0771[1] DI 0: r0722.0, DI 1: r0722.1 AI 0: r0755[0] DO 2: p0732

#### Additional settings:

- Pressure control using the technology controller
- Analog inputs smoothing time constant: p0753 = 500 ms
- Technological unit: p0595 = 1 (%), reference variable: p0596 = 1
- Fixed speed setpoint 15 for essential service mode (ESM): p1015 = 1350 rpm
- Default setting of the technology controller:
  - Enable: p2200 = 1
  - Fixed value 1: p2201 = 40 %
  - Ramp-up/down time for setpoint: p2257 = p2258 = 30 s
  - Ramp-up/down time for controller output: p2293 = 30 s
  - Upper and lower limits, actual value: p2267 = 120 %, p2268 = -10 %
  - Actual value filter time constant: p2265 = 10 s
  - Proportional gain  $K_p$ , integral time  $T_l$ , differentiation time constant  $T_D$ : p2280 ( $K_p$ ) = 1.1, p2285 ( $T_l$ ) = 35 s, p2274 ( $T_D$ ) = 0 s
  - Technology controller minimum limiting p2292 = 20 %
  - Technology controller output signal start value p2302 = 50 %
- "Flying restart" is enabled: p1200 = 1
- Automatic restart is active. After a power failure, the inverter automatically acknowledges possible faults and switches on the motor: p1210 = 26

Designation in the BOP-2: P\_F Pc5

### Default setting 106: "Cooling tower with active sensor + hibernation"




DO 0: p0730, ..., DO 2: p0732 AO 0: p0771[0], AO 1: p0771[1] DI 0: r0722.0 AI 0: r0755[0] Additional settings:

- · Temperature control using the technology controller
- Analog inputs smoothing time constant: p0753 = 100 ms
- Technological unit: p0595 = 1 (%), reference variable: p0596 = 1
- Default setting of the technology controller:
  - Enable: p2200 = 1
  - Fixed value 1: p2201 = 26 %
  - Ramp-up/down time for setpoint: p2257 = p2258 = 30 s
  - Ramp-up/down time for controller output: p2293 = 30 s
  - Upper and lower limits, actual value: p2267 = 120 %, p2268 = -10 %
  - Actual value filter time constant: p2265 = 10 s
  - Proportional gain  $K_p$ , integral time  $T_l$ , differentiation time constant  $T_D$ : p2280 ( $K_p$ ) = 1.2, p2285 ( $T_l$ ) = 25 s, p2274 ( $T_D$ ) = 0 s
  - Technology controller system deviation inversion: p2306 = 1
- Default setting hibernation mode:
  - Activated: p2398 = 1
  - Start speed: p2390 = 50 rpm
  - Delay time: p2391 = 60 s
  - Restart value with technology controller: p2392 = 1 %
  - Restart speed relative w/o technology controller: p2393 = 100 rpm
- "Flying restart" is enabled: p1200 = 1
- Automatic restart is active. After a power failure, the inverter automatically acknowledges possible faults and switches on the motor: p1210 = 26

Designation in the BOP-2: P\_F ctF1

#### Default setting 107: "Cooling tower with LG-Ni1000 sensor + hibernation"




DO 0: p0730, ..., DO 2: p0732 AO 0: p0771[0], AO 1: p0771[1] DI 0: r0722.0 AI 3: r0755[3] Additional settings:


- · Temperature control using the technology controller
- Analog inputs smoothing time constant: p0753 = 100 ms
- Technological unit: p0595 = 1 (%), reference variable: p0596 = 1
- Default setting of the technology controller:
  - Enable: p2200 = 1
  - Fixed value 1: p2201 = 26 %
  - Ramp-up/down time for setpoint: p2257 = p2258 = 30 s
  - Ramp-up/down time for controller output: p2293 = 30 s
  - Upper and lower limits, actual value: p2267 = 120 %, p2268 = -100 %
  - Actual value filter time constant: p2265 = 10 s
  - Proportional gain  $K_p$ , integral time  $T_l$ , differentiation time constant  $T_D$ : p2280 ( $K_p$ ) = 1.2, p2285 ( $T_l$ ) = 25 s, p2274 ( $T_D$ ) = 0 s
  - Technology controller minimum limiting p2292 = 20 %
  - Technology controller system deviation inversion: p2306 = 1
- Default setting hibernation mode:
  - Activated: p2398 = 1
  - Start speed: p2390 = 50 rpm
  - Delay time: p2391 = 60 s
  - Restart value with technology controller: p2392 = 1 %
  - Restart speed relative w/o technology controller: p2393 = 100 rpm
- "Flying restart" is enabled: p1200 = 1
- Automatic restart is active. After a power failure, the inverter automatically acknowledges possible faults and switches on the motor: p1210 = 26

Designation in the BOP-2: P F ctF2


### Default setting 108: "USS fieldbus"




### Default setting 109: "Modbus RTU field"



### Default setting 110: "BACnet MS/TP fieldbus"



### Default setting 111: "Fixed setpoints"




DO 0: p0730, ..., DO 2: p0732 AO 0: p0771[0], AO 1: p0771[1] DI 0: r0722.0, ..., DI 3: r0722.3 Additional settings:

- Fixed speed setpoint 1: p1001 = 300 rpm
- Fixed speed setpoint 2: p1002 = 600 rpm
- Fixed speed setpoint 3: p1003 = 900 rpm
- Fixed speed setpoint 4: p1004 = 1200 rpm
- If several of the DI 0 ... DI 3 = high, the inverter adds the corresponding fixed speeds.
- "Flying restart" is enabled: p1200 = 1
- Automatic restart is active. After a power failure, the inverter automatically acknowledges possible faults and switches on the motor: p1210 = 26

Designation in the BOP-2: P\_F \_F55

### Default setting 112: "CO2 sensor, 2 PID setpoints"




#### Additional settings:

- CO<sub>2</sub> control using the technology controller
- Analog inputs smoothing time constant: p0753 = 500 ms
- Technological unit: p0595 = 1 (%), reference variable: p0596 = 1
- Default setting of the technology controller:
  - Enable: p2200 = 1
  - Fixed value 1: p2201 = 50 %
  - Fixed value 3: p2203 = 10 %
  - Technology controller setpoint 1: p2253 = r2224 (active fixed value)
  - Ramp-up/down time for setpoint: p2257 = p2258 = 30 s
  - Upper and lower limits, actual value: p2267 = 120 %, p2268 = -10 %
  - Actual value filter time constant: p2265 = 10 s
  - Technology controller system deviation inversion: p2306 = 1
- "Flying restart" is enabled: p1200 = 1
- Automatic restart is active. After a power failure, the inverter automatically acknowledges possible faults and switches on the motor: p1210 = 26

Designation in the BOP-2: P\_F\_CO2

#### Default setting 113: "Temperature-dependent pressure setpoint"




DO 0: p0730, ..., AO 0: p0771[0], AO 1: p0771[1] DI 0: r0722.0 AI 0: r0755[0], AI 2: r0755[2] DO 2: p0732

#### Additional settings:

- Temperature control using the technology controller
- Technological unit: p0595 = 1 (%), reference variable: p0596 = 1
- Default setting of the technology controller:
  - Enable: p2200 = 1
  - Upper and lower limits, setpoint: p20229 = 0.5, p20230 = 0.2
  - Ramp-up/down time for setpoint: p2257 = p2258 = 30 s
  - Ramp-up/down time for controller output: p2293 = 30 s
  - Upper and lower limits, actual value: p2267 = 120 %, p2268 = -10 %
  - Actual value filter time constant: p2265 = 10 s
  - Technology controller minimum limiting p2292 = 20 %
- "Flying restart" is enabled: p1200 = 1
- Automatic restart is active. After a power failure, the inverter automatically acknowledges possible faults and switches on the motor: p1210 = 26

Designation in the BOP-2: P\_F\_tP5

### Default setting 114: "P1 fieldbus"



#### Default setting 120: "PID settings for pumps and fans"

The default setting restores the function of the terminal strip to the factory setting.

Technology controller setting:

- Ramp-up/down time for setpoint: p2257 = p2258 = 30 s
- Ramp-up/down time for controller output: p2293 = 30 s
- Actual value upper limit: p2267 = 120%
- Actual value filter time constant: p2265 = 10 s

Designation in the BOP-2: P F PID

#### Default setting 200: "Option L13, main contactor"

The macro is intended for the G120P Cabinet with option L13 (main contactor).




DO 2: p0732

Designation in the BOP-2: L13

#### Default setting 201: "Option L57, L59, L60, Emergency Stop"

The macro is intended for the G120P Cabinet with options L57, L59 and L60 (Emergency Stop).



DI 4: r0722.4, DI 5: r0722.5

Designation in the BOP-2: L57\_60

### Default setting 202: "Option L83, L84, L86, ext. alarm/fault"

The macro is intended for the G120P Cabinet with options L83, L84 and L86 (external alarm or fault).

 7 DI 2	External alarm
 8 DI 3	External fault

DI 2: r0722.2, DI 3: r0722.3

Designation in the BOP-2: L83\_86

### Additional information on the default settings 200 ... 202

Additional information on the default settings 200 ... 202 is provided on the Internet.

G120P Cabinet operating instructions (<a href="https://support.industry.siemens.com/cs/ww/en/view/109749009">https://support.industry.siemens.com/cs/ww/en/view/109749009</a>)

# 4.6.7 Additional digital inputs and outputs on PM330 Power Modules

### Overview

The PM330 Power Module has 4 digital inputs and 2 digital outputs on terminal strip X9.





Figure 4-30 Terminal strip X9

### **Function description**



Connection cross-section: 0.2 mm<sup>2</sup> ... 2.5 mm<sup>2</sup>, tightening torque: 0.5 Nm (5 lb.in)

Use insulated end sleeves according to DIN 46228-4.

Terminals	Remark
1	You may either connect an external 24 V supply or use the internal 24 V supply.
3 6	The function of the digital inputs is shown in the factory setting.
	You can change the function of the digital inputs subsequently.
	The digital inputs are low-active in the factory setting. If you do not use one of the digital inputs, you must connect the digital input with 24 V.
8. 11. 12	The function of the digital outputs cannot be changed.

- 6, 11, 12 The function of the digital outputs cannot be changed.
- The digital output signals a fully charged DC link of the converter. A charged DC link is the precondition for the "operation" converter state.
- 11, 12 A device to protect against overload and short-circuit is required for the power supply to the line contactor control, e.g. a 4 A / 250 V fuse.

Connect the excitation coil of the line contactor to a surge suppressor, e.g. an RC element.

Figure 4-31 Terminal strip X9 with external 24 V supply




Figure 4-32 Terminal strip X9 with internal 24 V supply

# 4.6.8 Safe Torque Off (STO) safety function

#### Overview

You can implement safety function "Safe Torque Off" (STO) using the following Power Modules:

- PM240-2 Power Modules, FSD ... FSG
- PM240P-2 Power Modules, FSD ... FSF
- PM330 Power Module

### Requirement

The higher-level control system monitors the selection of STO and the feedback from the converter.

Application examples for "Safe Torque Off" (Page 146)

Setting the feedback signal for Safe Torque Off (Page 264)

### **Function description**


Use an SELV or PELV power supply with 24 V DC (20.4 V  $\dots$  28.8 V, maximum 60 V briefly).

Use a shielded cable with the following properties:

- Cable length ≤ 30 m
- Cross section 0.5 mm<sup>2</sup> ... + 1.5 mm<sup>2</sup> (20 ... 16 AWG)
- Insulated for 600 V
- Conductor end sleeves, stripping length 7 mm

Tightening torque: 0.2 Nm (2 lbf in)


#### Procedure for converters with PM240-2 and PM240P-2 Power Modules



Both switches = ON: STO is enabled Both switches = OFF: STO is locked Two switches different: not permissible

Figure 4-33 Terminals and switches for the "STO" function, PM240--2 and PM240P-2 Power Modules

1. Remove the Control Unit.




- 2. Connect the cable for selecting STO to terminals STO\_A and STO\_B.
- 3. Plug in the Control Unit.



- 4. Connect the cables for the STO feedback signal to 2 digital outputs of the Control Unit.
- 5. Attach the shield to the shield plate of the Control Unit through the largest possible surface

You have connected all cables for the STO safety function.

#### Procedure for converters with PM330 Power Modules



Both switches = ON: STO is enabled Both switches = OFF: STO is locked Two switches different: not permissible

Figure 4-34 Terminals and switches for the "STO" function

- 1. Connect the cable for selecting STO to terminals X41:STO\_A and X41:STO\_B.
- 2. Connect the cables for STO feedback to terminals X41:FB\_A and X41:FB\_B.
- 3. Attach the shield to the shield plate through the largest possible surface area.

You have connected all cables for the STO safety function.  $\ \ \square$ 

# 4.6.9 Application examples for "Safe Torque Off"


#### Overview

A higher-level control system is required to select the STO safety function.

#### Requirement

The following requirements apply:

- The converter signals that the STO safety function is being controlled to the higher-level control system using two digital outputs.
  - For converters with PM240-2 and PM240P-2 Power Modules, you must interconnect feedback signals "STO is active" with two digital outputs.



- For converters with PM330 Power Modules, you can use terminal strip -X41.
- The higher-level control system monitors the selection of the STO safety function and the feedback from the converter.
- Forced checking procedure (test stop):
  - The higher-level control system regularly selects the STO safety function and evaluates the converter feedback signal.
  - We recommend that you implement a time monitoring function in the higher-level control system, which issues an alarm if a test stop is overdue.
- Suitable higher-level controllers
  - SIRIUS 3SK1: Single-channel static feedback circuit
     Permissible for converters FSH and FSJ, not permissible for FSA ... FSG
  - SIRIUS 3SK2: Two-channel dynamic feedback circuit
  - MSS 3RK3: Two-channel dynamic feedback circuit
  - SIMATIC: Feedback circuit monitoring in the safety program
- Forced checking procedure (test stop) every 3 months

#### **Function description**

### SIRIUS 3SK1 safety relay

With a SIRIUS 3SK1 safety relay and FSA ... FSG converters, as a maximum, you can achieve SII 2/PI d

Using a SIRIUS 3SK1 safety relay, you can only achieve SIL 3/PL e using an FSGX, FSHX or FSJX converter.




Figure 4-35 Connection 3SK1 inside a control cabinet for FSGX, FSHX and FSJX

#### SIRIUS 3SK2 safety relay

The wiring examples are implemented using safety relays with relay enable circuits. Safety relays with semiconductor enable circuits can also be used.





Figure 4-36 Connection 3SK2 inside a control cabinet for FSD ... FSG



 $T_1 \ge 30 \text{ ms}$  In case of deviating feedback, the safety relay must select the STO function and indicate an error.

Figure 4-37 Dynamic monitoring of STO feedback signal for FSD ... FSG




Figure 4-38 Connection 3SK2 inside a control cabinet for FSGX, FSHX and FSJX

When starting, static monitoring of the STO feedback signal is sufficient for converters FSGX, FSHX and FSJX.

# **3RK3 Modular Safety System**

You can use the following outputs to control the failsafe digital inputs in the converter:

- The failsafe digital outputs in the central units of the 3RK3 modular safety system
- The failsafe digital outputs in the EM 2/4F-DI 2F-DO expansion module
- The failsafe digital outputs in the EM 4F-DO expansion module.
- The failsafe relay outputs in the EM 4/8F-RO expansion module
- 2 individual relay contacts of the EM 2/4F-DI 1/2F-RO expansion module





Figure 4-39 Connection 3RK3 inside a control cabinet for FSD ... FSG



 $T_1 \ge 30 \text{ ms}$  In case of deviating feedback, the Modular Safety System must select the STO  $T_2 \ge 20 \text{ ms}$  function and indicate an error.

Figure 4-40 Dynamic monitoring of STO feedback signal for FSD ... FSG




Figure 4-41 Connection 3RK3 inside a control cabinet for FSGX, FSHX and FSJX

When starting, static monitoring of the STO feedback signal is sufficient for converters FSGX, FSHX and FSJX.

#### SIMATIC I/O modules





Figure 4-42 Connecting the SIMATIC S7-1500 in a control cabinet for FSD ... FSG



 $T_1 \ge 30 \text{ ms}$  In case of deviating feedback, the SIMATIC must select the STO function and

 $T_2 \ge 20 \text{ ms}$  indicate an error.

Figure 4-43 Dynamic monitoring of STO feedback signal for FSD ... FSG




Figure 4-44 Connecting the SIMATIC S7-1500 in a control cabinet for FSGX, FSHX and FSJX

Static monitoring of the STO feedback signal when STO is selected is sufficient for converters FSGX, FSHX and FSJX.

#### **Further information**

Further information is provided on the Internet:

SIRIUS 3SK1 safety relays (<a href="https://support.industry.siemens.com/cs/ww/en/ps/16381/man">https://support.industry.siemens.com/cs/ww/en/ps/16381/man</a>)

SIRIUS 3SK2 Safety Relays (<a href="https://support.industry.siemens.com/cs/ww/en/view/109444336">https://support.industry.siemens.com/cs/ww/en/view/109444336</a>)

SIRIUS 3RK3 modular safety system manual (<a href="https://support.industry.siemens.com/cs/ww/en/view/26493228">https://support.industry.siemens.com/cs/ww/en/view/26493228</a>)



\$7-1500 (https://support.industry.siemens.com/cs/ww/en/view/86140384)



ET 200SP (https://support.industry.siemens.com/cs/ww/en/view/84133942)



ET 200pro (https://support.industry.siemens.com/cs/ww/en/view/22098524)

ET 200S (https://support.industry.siemens.com/cs/ww/en/view/12490437)

\$7-300 (https://support.industry.siemens.com/cs/ww/en/view/19026151)

#### 4.6.10 Wiring terminal strips





#### **WARNING**

### Electric shock due to unsuitable power supply

Death or serious injury can result when live parts are touched in the event of a fault.

For all connections and terminals of the electronic boards, only use power supplies that provide PELV (Protective Extra Low Voltage) or SELV (Safety Extra Low Voltage) output voltages.





#### **WARNING**

#### Electric shock due to unsuitable motor temperature evaluation system

Voltage flashovers to the electronics of the converter can occur in motors without safe electrical separation of the temperature sensors in accordance with IEC 61800-5-1 when the motor develops a fault.

- Install a temperature monitoring relay 3RS1... or 3RS2...
- Evaluate the temperature monitoring relay output using a digital input of the converter, e.g. using the "External fault" function.

You can find additional information about the temperature monitoring relay on the Internet:

Manual 3RS1 / 3RS2 temperature monitoring relays (https:// support.industry.siemens.com/cs/ww/en/view/54999309)

#### Note

# Malfunction caused by incorrect switching states as the result of diagnostic flows in the off state (logical state "0")

In contrast to mechanical switching contacts, e.g. emergency stop switches, diagnostic flows can also flow with semiconductor switches in the off state. If interconnection with digital inputs is faulty, the diagnostic flows can lead to incorrect switching states and thus to a malfunction of the drive.

- Observe the conditions for digital inputs and digital outputs specified in the relevant manufacturers documentation.
- Check the conditions of the digital inputs and digital outputs in regard to the flows in off state. If applicable, connect the digital inputs with suitably dimensioned, external resistors to protect against the reference potential of the digital inputs.

In order to install the converter in compliance with UL, you may only connect the DO 0 and DO 2 relay outputs of the Control Unit using copper wires approved for 75 °C.





#### WARNING

#### Electric shock due to damaged insulation

Damaged insulation of cables carrying hazardous voltages can cause a short circuit with cables carrying non-hazardous voltages. This can have the effect that parts of the converter or the installation carry an unexpectedly high voltage.

• Use only cables with double insulation for 230 V cables which you connect to the digital outputs of the converter.

#### **NOTICE**

#### Overvoltages for long signal cables

Using > 30 m long cables at the converter's digital inputs and 24 V power supply or inductive circuits at the digital inputs can lead to overvoltage. Overvoltages can damage the converter.

• Connect an overvoltage protection device between the terminal and the associated reference potential.

We recommend using the Weidmüller overvoltage protection terminal with designation MCZ OVP TAZ DIODE 24VDC.

Table 4-31 Permissible cables and wiring options

Solid or finely stranded conductor	Finely stranded conductor with non-insulated conductor end sleeve	Finely stranded conductor with partially insulated conductor end sleeve		
8 mm 0.5 1.5 mm <sup>2</sup> 0.5 mm <sup>2</sup> 0.5 mm <sup>2</sup>				
Cables with twin end sleeves are not permissible.				

# Wiring the terminal strip in compliance with EMC

• If you use shielded cables, then you must connect the shield to the mounting plate of the control cabinet or with the shield support of the converter through a good electrical connection and a large surface area.

Further information about EMC-compliant wiring is available on the Internet:

EMC installation guideline (<a href="http://support.automation.siemens.com/WW/view/en/60612658">http://support.automation.siemens.com/WW/view/en/60612658</a>)

• Use the right shield connection plate for shield support and strain relief.

Control Units (Page 35)

#### 4.6.11 Connecting the temperature contact of the braking resistor



#### WARNING

# Fire caused by an unsuitable or incorrectly installed braking resistor

Using an unsuitable or improperly installed braking resistor can cause fires and smoke to develop. Fire and smoke development can cause severe personal injury or material damage.

- Only use braking resistors that are approved for the converter.
- Install the braking resistor in accordance with regulations.
- Monitor the temperature of the braking resistor.

#### **Procedure**

1. Connect the temperature monitoring system of the braking resistor (terminals T1 and T2 on the braking resistor) to a free digital input on the inverter.




Figure 4-45 Example: Temperature monitoring of the braking resistor via digital input DI 3 on the **Control Unit** 

2. Define the function of the digital input used as an external fault with p2106. As an example with temperature monitoring via digital input DI 3: p2106 = 722.3.

The inverter monitors the braking resistor temperature.

#### 4.6.12 Fieldbus interfaces

#### Overview

The Control Units are available in different versions for communication with higher-level controls with the fieldbus interfaces listed as follows:

Fieldbus	Profiles		S7 communica-	Control Unit
	PROFIdrive	PROFlenergy 1)	tion 1)	
PROFINET	<b>✓ ✓</b>		✓	CU230P-2 PN
EtherNet/IP 1)				
PROFIBUS	<b>✓</b>		✓	CU230P-2 DP
USS 1)				CU230P-2 HVAC
Modbus RTU 1)				
BACnet MS/TP 1)				
P1 <sup>1)</sup>				

<sup>&</sup>lt;sup>1)</sup> Information about these fieldbuses, profiles and communication types can be found in the Fieldbus Function Manual.

Overview of the manuals (Page 581)

# 4.6.13 Connecting the converter to PROFINET

#### 4.6.13.1 Communication via PROFINET IO and Ethernet

You can either integrate the converter in a PROFINET network or communicate with the converter via Ethernet.

# The converter in PROFINET IO operation





Figure 4-46 The converter in PROFINET IO operation (examples)

The converter supports the following functions:

- RT
- IRT: The converter forwards the clock synchronism, but does not support clock synchronism.

- MRP: Media redundancy, impulsed with 200 ms. Precondition: Ring topology With MRP, you get an uninterrupted switchover if you set the failure monitoring time to a value > 200 ms.
- MRPD: Media redundancy, bumpless. Precondition: IRT and the ring topology created in the
- Diagnostic alarms in accordance with the error classes specified in the PROFIdrive profile.
- Device replacement without removable data storage medium: The replacement converter is assigned the device name from the IO controller, not from its memory card or from the programming device.
- Shared Device for converters that support PROFIsafe.

#### The converter as Ethernet node



The converter as Ethernet node (examples)

Further information on the operation as Ethernet nodes can be found in the Function Manual "Fieldbuses".



Overview of the manuals (Page 581)

#### **Further information on PROFINET**

Further information on PROFINET can be found on the Internet:

- PROFINET the Ethernet standard for automation (http://w3.siemens.com/mcms/ automation/en/industrial-communications/profinet/Pages/Default.aspx)
- PROFINET system description (https://support.industry.siemens.com/cs/ww/en/view/ 19292127)

#### 4.6.13.2 Connecting the PROFINET cable to the converter

#### **Procedure**

1. Integrate the converter in the bus system (e.g. ring topology) of the control using PROFINET cables and the two PROFINET sockets X150-P1 and X150-P2.

Overview of the interfaces (Page 118)

The maximum permitted cable length from the previous station and to the next one is 100 m.

2. Externally supply the converter with 24 VDC through terminals 31 and 32. The external 24 V supply is only required if communications with the control should also run when the line voltage is switched off.

You have connected the converter to the control system via PROFINET.

#### Communication with the control system even if the line voltage is switched off

You must supply the converter with 24 V DC at terminals 31 and 32 if you wish to maintain communication with the control system when the line voltage is switched off.

In the case of brief interruptions of the 24 V power supply, the converter may signal a fault without communications with the control system being interrupted.

#### 4.6.13.3 What do you have to set for communication via PROFINET?

### Configuring PROFINET communication in the I/O controller

You require the appropriate engineering system to configure PROFINET communication in the IO controller.

If required, load the GSDML file of the converter into the engineering system.



Installing GSDML (Page 160)

#### **Device** name

In addition to the MAC address and IP address, PROFINET also uses the device name to identify PROFINET devices (Device name). The device name must be unique across the PROFINET network.

To assign the device name, you need an engineering software, e.g. HW-Config.

The converter saves the device name on the inserted memory card.

#### IP address

In addition to the device name, PROFINET also uses an IP address.

You have the following options to specify the IP address of the converter:

- You specify the IP address using engineering software, e.g. via HW Config.
- The IO Controller assigns an IP address to the converter.

#### **Telegram**

Set the same telegram in the converter as in the IO Controller. Interconnect the telegrams in the control program of the IO Controller with the signals of your choosing.



Drive control via PROFIBUS or PROFINET (Page 278)

### **Application examples**

You can find application examples for PROFINET communication on the Internet:


Controlling the speed of a SINAMICS G110M/G120/G120C/G120D with S7-300/400F via PROFINET or PROFIBUS, with Safety Integrated (via terminal) and HMI (https:// support.industry.siemens.com/cs/ww/en/view/60441457)

Controlling the speed of a SINAMICS G110M / G120 (Startdrive) with S7-1500 (TO) via PROFINET or PROFIBUS, with Safety Integrated (via terminal) and HMI (https:// support.industry.siemens.com/cs/ww/en/view/78788716)

#### 4.6.13.4 Installing GSDML

#### **Procedure**

- 1. Save the GSDML to your PC.
  - With Internet access:



GSDML (https://support.industry.siemens.com/cs/ww/en/view/26641490)

– Without Internet access:

Insert a memory card into the converter.


Set p0804 = 12.

The converter writes the GSDML as a zipped file (\*.zip) into directory /SIEMENS/SINAMICS/ DATA/CFG on the memory card.

- 2. Unzip the GSDML file on your computer.
- 3. Import the GSDML into the engineering system of the controller.

You have now installed the GSDML in the engineering system of the controller.

#### 4.6.14 Connecting the converter to PROFIBUS



The PROFIBUS DP interface has the following functions:

- Cyclic communication
- Acyclic communication
- · Diagnostic alarms

General information on PROFIBUS DP can be found in the Internet:

- Information about PROFIBUS DP (<a href="http://www.automation.siemens.com/net/html\_76/support/printkatalog.htm">http://www.automation.siemens.com/net/html\_76/support/printkatalog.htm</a>)
- PROFIBUS user organization (<a href="http://www.profibus.com/downloads/installation-quide/">http://www.profibus.com/downloads/installation-quide/</a>)

### 4.6.14.1 Connecting the PROFIBUS cable to the converter

#### **Procedure**

- 1. Connect the converter to socket X126 via a PROFIBUS cable with the higher-level control.

  Overview of the interfaces (Page 118)

  The maximum permitted cable length to the previous station or the subsequent one is 100 m at a baud rate of 12 Mbit/s.
- 2. If necessary, connect a 24 V supply voltage to terminals 31 and 32. The external 24 V supply is only required if communication with the control may not be interrupted even if the line voltage is switched off.

You connected the converter with the control via PROFIBUS.

#### Communication with the control system even if the line voltage is switched off

You must supply the converter with 24 V DC at terminals 31 and 32 if you wish to maintain communication with the control system when the line voltage is switched off.

In the case of brief interruptions of the 24 V power supply, the converter may signal a fault without communications with the control system being interrupted.

### 4.6.14.2 What do you have to set for communication via PROFIBUS?

#### **Configuring PROFIBUS communication**

You require the appropriate engineering system to configure PROFIBUS communication in the PROFIBUS master.

If required, load the GSD file of the converter into the engineering system.

Installing the GSD (Page 162)

#### Setting the address

Set the address of the PROFIBUS device.

Set the PROFIBUS address (Page 162)

### Setting the telegram

Set the same telegram in the converter as in the PROFIBUS master. Interconnect the telegrams in the control program of the PROFIBUS master with the signals of your choosing.



Drive control via PROFIBUS or PROFINET (Page 278)

### **Application examples**

You can find application examples for PROFIBUS communication on the Internet:

Controlling the speed of a SINAMICS G110M/G120/G120C/G120D with S7-300/400F via PROFINET or PROFIBUS, with Safety Integrated (via terminal) and HMI (https:// support.industry.siemens.com/cs/ww/en/view/60441457)

Controlling the speed of a SINAMICS G110M / G120 (Startdrive) with S7-1500 (TO) via PROFINET or PROFIBUS, with Safety Integrated (via terminal) and HMI (https:// support.industry.siemens.com/cs/ww/en/view/78788716)

#### 4.6.14.3 Installing the GSD

#### **Procedure**

- 1. Save the GSD on your PC using one of the following methods.
  - With Internet access:
    - GSD (http://support.automation.siemens.com/WW/view/en/22339653/133100)
  - Without Internet access: Insert a memory card into the converter. Set p0804 = 12.

The converter writes the GSD as zipped file (\*.zip) into directory /SIEMENS/SINAMICS/ DATA/CFG on the memory card.

- 2. Unzip the GSD file on your computer.
- 3. Import the GSD in the engineering system of the controller.

You have now installed the GSD file in the engineering system of the controller.

#### 4.6.14.4 Set the PROFIBUS address.

Valid address area: 1 ... 125

You have the following options for setting the address:

• Using the address switch on the Control Unit:





Figure 4-48 Address switch with example for bus address 10

The address switch has priority over the other settings.

• With a commissioning tool, e.g. an operator panel, via parameter p0918 (factory setting: p0918 = 126).

It is only possible to change p0918 if an invalid address is set in the address switch.



# Setting the bus address

#### **Procedure**


- 1. Set the address using one of the subsequently listed options:
  - Via the address switch
  - With a commissioning tool via p0918
- 2. Switch off the converter power supply.
- 3. Wait until all LEDs on the converter are dark.
- 4. Switch on the converter power supply again. Your settings become effective after switching on.

The PROFIBUS address is set.

Commissioning

#### Commissioning guidelines 5.1

#### Overview



- 1. Define the requirements to be met by the drive for your application.
  - (Page 168)
- 2. Restore the factory settings of the converter if necessary.
  - (Page 209)
- 3. Check if the factory setting of the converter is sufficient for your application. (Page 172)
- 4. Set the following for quick commissioning of the drive:
  - The closed-loop motor control
    - The inputs and outputs
    - The fieldbus interface
  - (Page 174)
- 5. Check if additional converter functions are required for the application.
  - (Page 241)
- 6. If necessary, adapt the drive.
  - (Page 241)
- 7. Save your settings. (Page 219)

# 5.2 Tools to commission the converter

#### Operator panel

An operator panel is used to commission, troubleshoot and control the converter, as well as to back up and transfer the converter settings.



The Intelligent Operator Panel (IOP-2) can either be snapped onto a converter, or is available as handheld device with a connecting cable to the converter. The graphics-capable plain text display of the IOP-2 enables intuitive converter operation.


Additional information on the IOP-2 is available in the Internet:





The **Operator Panel BOP-2** for snapping onto the converter has a two-line display for diagnostics and operating the converter.

Operating Instructions of the BOP-2 and IOP-2 operator panels:



#### **Smart Access**



Smart Access is snapped onto a converter, and is a web server-based operating unit with wireless connection to a PC, tablet or smartphone. Smart Access is used to commission and maintain the converter.

You can find additional information about Smart Access on the Internet:


SINAMICS G120 Smart Access Operating Instructions (<a href="https://support.industry.siemens.com/cs/ww/en/view/109758122">https://support.industry.siemens.com/cs/ww/en/view/109758122</a>)

#### PC tools



**STARTER** and **Startdrive** are PC tools that are used to commission, troubleshoot and control the converter, as well as to back up and transfer the converter settings. You can connect the PC with the converter via USB or via the PROFIBUS / PROFINET fieldbus.

Connecting cable (3 m) between PC and converter: Article number 6SL3255-0AA00-2CA0



Startdrive, system requirements and download (<a href="https://support.industry.siemens.com/cs/ww/en/view/109760844">https://support.industry.siemens.com/cs/ww/en/view/109760844</a>)

Startdrive tutorial (<a href="http://support.automation.siemens.com/WW/view/en/73598459">http://support.automation.siemens.com/WW/view/en/73598459</a>)

STARTER, system requirements and download (<a href="http://support.automation.siemens.com/WW/view/en/26233208">http://support.automation.siemens.com/WW/view/en/26233208</a>)



Siemens respects the principles of data protection, in particular the data minimization rules (privacy by design).

Operating Instructions, 02/2023, FW 4.7 SP14, A5E34257946B AJ

5.2 Tools to commission the converter

For this product, this means:

The product does not process neither store any person-related data, only technical function data (e.g. time stamps). If the user links these data with other data (e.g. shift plans) or if he stores person-related data on the same data medium (e.g. hard disk), thus personalizing these data, he has to ensure compliance with the applicable data protection stipulations.

# 5.3 Preparing for commissioning

# 5.3.1 Collecting motor data

#### Data for a standard induction motor

Before starting commissioning, you must know the following data:

#### • Which motor is connected to the converter?

Note down the Article No. of the motor and the motor's nameplate data. If available, note down the motor code on the motor's nameplate.




Figure 5-1 Example of the rating plate for a standard induction motor

#### In which region of the world is the motor to be used?

- Europe IEC: 50 Hz [kW]
- North America NEMA: 60 Hz [hp] or 60 Hz [kW]

# • How is the motor connected?

Pay attention to the connection of the motor (star connection [Y] or delta connection  $[\Delta]$ ). Note the appropriate motor data for connecting.

# Data for a synchronous reluctance motor

Before starting commissioning, you must know the following data:

• Which motor is connected to the converter?

Note down the motor code on the type plate of the motor.




Figure 5-2 Example of a type plate for a reluctance motor

- In which region of the world is the motor to be used?
  - Europe IEC: 50 Hz [kW]
  - North America NEMA: 60 Hz [hp] or 60 Hz [kW]
- · How is the motor connected?

Pay attention to the connection of the motor (star connection [Y] or delta connection  $[\Delta]$ ). Note the appropriate motor data for connecting.

#### 5.3 Preparing for commissioning

### 5.3.2 Forming DC link capacitors

#### Description

You may have to reform the DC link capacitors if the Power Module has been stored for more than one year. When the converter is operational, DC link capacitors that have not been formed can be damaged.

Table 5-1 The forming duration depends on how long the converter was stored for

Storage time from the date of manufacture	Recommended forming duration
1 – 2 years	1 hour
2 – 3 years	2 hours
> 3 years	8 hours

The production date of the Power Module is coded in the 3rd and 4th digit of the serial number on the rating plate: "S X -- 3 4 X X X..."

Table 5-2 Production year and month

Digit ③	Year of manufacture	Digit 4	Month of manufacture
D	2013	1 9	January September
E	2014	0	October
F	2015	N	November
Н	2016	D	December
J	2017		
K	2018		
L	2019		
М	2020		

### Form DC Link of the PM330 power module

The "Forming the DC link" firmware function is only possible for the PM330 power module.

#### **Procedure**

- 1. Set p0010 = 2.
- 2. Set the forming duration p3380. For p3380 > 0, with alarm A07391, the converter signals that at the next on command, DC link forming starts.
- 3. Switch on the motor, e.g. from an inserted operator panel.
- 4. Wait for the forming time to elapse. r3381 indicates the remaining time.

  If the line voltage is switched off before forming has been completed, then you must again form the DC link.
- 5. The converter sets p3380 = 0.
- 6. Set p0010 = 0.

You have formed the DC link.

#### **Parameter**

Parameter	Descr	iption		
p0010	Drive	e commissioning parameter filter (factory setting: 0)		
	0: Rea	dy		
	2: Pov	ver unit commissioning		
p3380	DC lir	nk forming, forming duration (factory setting: 0 h)		
	p3380	0 = 0 deactivates the function.		
	I .	forming duration is changed while forming, then forming restarts with the modi-		
r3381	DC lir	ink forming, remaining time [h]		
	Rema	maining forming time.		
r3382	DC link forming, status word			
	.00	1 signal: Forming activated		
.01 1 signal: Forming active		1 signal: Forming active		
.02 1 signal: Forming completed		1 signal: Forming completed		
	.03 1 signal: Forming faulty			
The converter signals fault F07390				

# Forming the DC link of PM240-2 and PM240P-2 Power Modules

You form the DC link capacitors by supplying the converter with a line voltage of  $\leq$  100 % of the rated voltage for a defined time.




Figure 5-3 Forming the DC-link capacitors

# Form DC Link of other power modules

Formation of the DC link capacitors is not required for the following power modules even after a lengthy period of storage.

- PM230
- PM250

#### 5.3.3 Converter factory setting

#### Motor

In the factory, the converter is set for an induction motor matching the rated power of the Power Module.

#### Converter interfaces

The inputs and outputs and the fieldbus interface of the converter have specific functions when set to the factory settings.




Factory interface settings (Page 122)

### Switching the motor on and off

The converter is set in the factory as follows:

- After the ON command, the motor accelerates within the ramp-up time (referred to 1500 rpm) to its speed setpoint.
- After the OFF1 command, the motor brakes down to standstill with the ramp-down time.
- The negative direction of rotation is inhibited



With PM330 Power Modules: 20 s Ramp-up time: •

For all other Power Modules: 10 s

Ramp-down With PM230 and PM330 Power Modules: 30 s

time: For all other Power Modules: 10 s

Figure 5-4 Switching on, switching off and reversing the motor in the factory setting

The ramp-up and ramp-down times define the maximum motor acceleration when the speed setpoint changes. The ramp-up and ramp-down times are derived from the time between motor standstill and the maximum speed, or between the maximum speed and motor standstill.

### Traverse the motor in the jog mode

For a converter with PROFIBUS or PROFINET interface, operation can be switched over using digital input DI 3. The motor is either switched on and off via the fieldbus – or operated in the jog mode via its digital inputs.

For a control command at the respective digital input, the motor rotates with  $\pm 150$  rpm. The same ramp-up and ramp-down times as described above apply.




Figure 5-5 Jogging the motor in the factory setting

# Minimum and maximum speed

- Minimum speed factory setting 0 [rpm]
   After the selection of a motor, during the quick commissioning, the converter sets the minimum speed to 20% of the rated speed.
   The minimum speed is the lowest speed of the motor independent of the speed setpoint.
- Maximum speed factory setting 1500 [rpm]
   The converter limits the motor speed to this value.

### Operate the motor in the factory setting

We recommend that you execute quick commissioning. For quick commissioning, you must adapt the converter to the connected motor by setting the motor data in the converter.

For basic applications, you can try to operate the drive with a rated power < 18.5 kW without any other commissioning steps. Check whether the control quality of the drive without commissioning is adequate for the requirements of the application.

5.4 Quick commissioning using the BOP-2 operator panel

# 5.4 Quick commissioning using the BOP-2 operator panel

# 5.4.1 Inserting the BOP-2

# Plugging on an operator panel

#### Procedure



- 1. Locate the lower edge of the Operator Panel into the matching recess of the Control Unit.
- 2. Plug the Operator Panel onto the converter until the latch audibly engages.

The operator panel is plugged onto the Control Unit.

The operator panel is ready for operation when you connect the converter to the power supply.

# 5.4.2 Starting quick commissioning

#### Overview




Figure 5-6 Quick commissioning using the BOP-2 operator panel

### Requirement

The following requirements apply:



- The supply voltage is switched on.
- The operator panel displays setpoints and actual values.

5.4 Quick commissioning using the BOP-2 operator panel

#### **Function description**

#### **Procedure**



Press the ESC key.



Press one of the arrow keys until the BOP-2 displays menu SETHP.



To start quick commissioning, press the OK key in menus F !!!P.



We recommend resetting the converter to the factory setting before commencing quick commissioning.

Should you wish to change the default setting of the interfaces, the converter must be reset to the factory settings now.

Proceed as follows:

- 1. Press the OK key.
- 2. Switch over the display using an arrow key: ¬□□→ЧӺҔ
- 3. Press the OK key.



Whether the converter offers the selection of the application class, depends on the Power Module being used:

- PM230 or PM250 Power Module: The converter skips the step ∄₽₽↓.
- PM240-2, PM240P-2 or PM330 Power Modules:
   select the application class:
   Quick commissioning with application classes (Page 181)




Select the motor standard:

- KW 50HZIEC
- 片户 50 H 7 NEMA, US units
- 岩川 長日日7NEMA, SI units



Specify the overload capability of the converter:

- 景音景 景景 Duty cycle with "high overload"
- | []|| | Duty cycle with "low overload"





Set the converter supply voltage.



Select the motor type. If a 5-digit motor code is stamped on the motor rating plate, select the corresponding motor type with motor code.

Motors without motor code stamped on the rating plate:

- ; N ] [ ] Third-party induction motor
- !! | N | 1LE1, 1LG6, 1LA7, 1LA9 induction motors

Motors with motor code stamped on the rating plate:

- \P[ \ \N] 1PC1 induction motor
- \FP \ Reluctance motor

Depending on the converter, the motor list in BOP-2 can deviate from the list shown above.



If you have selected a motor type with motor code, you must now enter the motor code. The converter assigns the following motor data corresponding to the motor code.

If you do not know the motor code, then you must set the motor code = 0, and enter motor data from p0304 and higher from the rating plate.



87 Hz motor operation The BOP-2 only indicates this step if you selected IEC as the motor standard (P100 = 4 Hz 5 GHz).



Rated motor voltage



Rated motor current



Rated motor power



Rated motor frequency



Rated motor speed



Motor cooling:

- SF! F: Natural cooling
- F□R[E]: Forced-air cooling
- [ | [] [ ] : Liquid cooling
- N∏ FBN: Without fan



Select the appropriate application:

- "FF 577 In all applications that do not fit the other setting options.
- P!!MP FRN Applications involving pumps and fans
- 5117 Applications with short ramp-up and ramp-down times.

#### 5.4 Quick commissioning using the BOP-2 operator panel

- PUMP []H 7 Applications involving pumps and fans with optimized efficiency. The setting only makes sense for steady-state operation with slow speed changes. We recommend setting [ [ 5 7 ]] if load surges during operation cannot be ruled out.
- 1/ | [] [] Applications with high break loose torque

The selection option depends on the Power Module being used. There is no selection option for PM230 Power Modules.



### Select the control mode:


- #F | | W: U/f control with linear characteristic
- #F | | F: Flux current control (FCC)
- #F NIIR T: U/f control with square-law characteristic

Flux current control (FCC)  * Typical settling time after a speed change: 100 ms 200 ms  * Typical settling time after a load surge: 500 ms  * Typical settling time after a load surge: 500 ms  * Typical settling time after a load surge: 200 ms  * Typical settling time after a load surge: 200 ms  * Typical settling time after a load surge: 200 ms  * Typical settling time after a load surge: 200 ms  * Typical settling time after a load surge: 200 ms  * Typical settling time after a load surge: 200 ms  * Typical settling time after a speed change: 200 ms  * Typical settling time after a load surge: 200 ms  * Typical settling time after a speed change: 200 ms  * Typical settling time after a speed change: 200 ms  * Typical settling time after a speed change: 200 ms  * Typical settling time after a speed change: 200 ms  * Typical settling time after a speed change: 200 ms  * Typical settling time after a speed change: 200 ms  * Typical settling time after a speed change: 200 ms  * Typical settling time after a speed change: 200 ms  * Typical settling time after a speed change: 200 ms  * Typical settling time after a speed change: 200 ms  * Typical settling time after a load surge: 200 ms  * Typical settling time after a speed change: 200 ms  * Typical settling time after a load surge: 200 ms  * Typical settling time after a load surge: 200 ms  * Typical settling time after a load surge: 200 ms  * The vector control controls and limits the moto torque 200 ms  * The vector control controls and limits the moto torque 200 ms  * The vector control controls and limits the motor dorque 200 ms  * The vector control controls and limits the motor torque 200 ms  * The vector control controls and limits the motor torque 200 ms  * The vector control controls and limits the motor torque 200 ms  * The vector control controls and limits the motor torque 200 ms  * The vector control controls and limits the motor torque 200 ms  * The vector control controls and limits the motor torque 200 ms  * The vector control controls and li			
Typical settling time after a speed change: 100 ms 200 ms Typical settling time after a load surge: 500 ms Typical settling time after a load surge: 200 ms Typical settling time after a load surge: 200 ms Typical settling time after a load surge: 200 ms Typical settling time after a load surge: 200 ms  Typical settling time after a load surge: 200 ms  Typical settling time after a speed change: 100 ms Typical settling time after a speed change: 100 ms Typical settling time after a speed change: 100 ms Typical settling time after a speed change: 100 ms Typical settling time after a speed change: 100 ms Typical settling time after a speed change: 100 ms Typical settling time after a speed change: 100 ms Typical settling time after a speed change: 100 ms Typical settling time after a speed change: 100 ms Typical settling time after a speed change: 100 ms Typical settling time after a speed change: 100 ms Typical settling time after a speed change: 100 ms Typical settling time after a load surge: 200 ms Typical settling time after a load surge: 200 ms Typical settling time after a load surge: 200 ms  Typical settling time after a load surge: 200 ms  Typical settling time after a load surge: 200 ms  Typical settling time after a load surge: 200 ms  Typical settling time after a load surge: 200 ms  Typical settling time after a load surge: 200 ms  Typical settling time after a load surge: 200 ms  Typical settling time after a load surge: 200 ms  Typical settling time after a load surge: 200 ms  Typical settling time after a load surge: 200 ms  Typical settling time after a load surge: 200 ms  Typical settling time after a load surge: 200 ms  Typical settling time after a load surge: 200 ms  Typical settling time after a load surge: 200 ms  Typical settling time after a load surge: 200 ms  Typical settling time after a load surge: 200 ms  Typical settling time after a load surge: 200 ms  Torque accuracy that can be achieved: ± 5 % for 15 % 100 % of the rated speed  We recommend vector control for the followin	Control mode	istic	Sensorless vector control
The control mode is suitable to address the following requirements:  Motor power ratings < 45 kW  Ramp-up time 0 → rated speed (depending on the motor power rating): 1 s (0.1 kW) 10 s (45 kW)  Applications with steady load torque without load surges  The control mode is insensitive with respect to imprecise setting of the motor data  The vector control controls and limits the motor torque  Torque accuracy that can be achieved: ± 5 % for 15 % 100 % of the rated speed  We recommend vector control for the following applications:  Motor power ratings > 45 kW  Application with steady load torque without load surges  The control mode is insensitive with respect to imprecise setting of the motor data  Pumps, fans, and compressors with flow characteristic  Motors that can  Pumps, fans, and compressors with flow characteristic  Induction motors  Induction, synchronous and reluctance motors		Flux current control (FCC)	
ples         acteristic         chines           Motors that can         Induction motors         Induction, synchronous and reluctance motors	Closed-loop control characteristics	<ul> <li>Typical settling time after a load surge: 500 ms</li> <li>Load</li></ul>	<ul> <li>Typical settling time after a load surge: 200 ms</li> <li>Load Speed Speed</li></ul>
, , , , , , , , , , , , , , , , , , ,	Application examples	·	
	Motors that can be operated	Induction motors	Induction, synchronous and reluctance motors

Control mode	U/f control with linear or square-law character- istic	Sensorless vector control
	Flux current control (FCC)	
Power Modules that can be oper- ated	No restrictions	
Max. output frequency	550 Hz	240 Hz 150 Hz with PM330 Power Module
Commissioning	Contrary to vector control, no speed controller has to be set	



Select the default setting for the interfaces of the converter that is suitable for your application.








Figure 5-7 Minimum and maximum motor frequency

# Δ

# CAUTION

# Material damage caused by unexpected acceleration of the motor

Depending on the Power Module, the converter sets the minimum frequency p1080 to 20 % of the maximum frequency. Also for setpoint = 0, the motor accelerates for p1080 > 0 to the minimum frequency after switching on the motor. An unexpected acceleration of the motor can cause material damage.

• If the application requires a minimum frequency = 0, then set p1080 = 0.



Scaling of analog input 0






Figure 5-8 Ramp-up and ramp-down time of the motor



Ramp-down time for the OFF3 command



Motor data identification: Select the method which the converter uses to measure the data of the connected motor:

- ∏FF: Motor data is not measured.
- 5 7 12 Part: Recommended setting: Measure the motor data at standstill and with the motor rotating. The converter switches off the motor after the motor data identification has been completed.
- 57; L: Measure the motor data at standstill. The converter switches off the motor after the motor data identification has been completed.

  Select this setting if one of the following cases is applicable:

  - You have selected U/f control as control mode, e.g.¦; F | ; Nor¦; F ∏; R ∏
- Ray: Measure the motor data while the motor is rotating. The converter switches off the motor after the motor data identification has been completed.

FINISH

Complete the data entry for quick commissioning as follows:

- 2. Press the OK key.

You have entered all of the data that is necessary for the quick commissioning of the converter.

# 5.4.3 Quick commissioning with application classes

#### 5.4.3.1 Overview




Figure 5-9 Quick commissioning using the BOP-2 operator panel

# 5.4.3.2 Select the application class

#### Overview

When selecting an application class, the converter assigns the appropriate settings to the motor control.

If you do not set the application class, but instead setting "Expert", then you must define the appropriate closed-loop motor control setting.

# Requirement

You are using one of the following Power Modules:

- PM240-2
- PM240P-2
- PM330

If you are using a different Power Module, then BOP-2 does not show step ### #PPL. Perform commissioning without application class.

Starting quick commissioning (Page 175)

### **Function description**



Select one of the application classes or setting "Expert":

- 5↑AN 🤄 RP 🖟 Standard Drive Control (Page 184)
- 기식사무M; [ Dynamic Drive Control (Page 186)
- EXPERT ☐ Expert (Page 189)

Application class	Standard Drive Control	Dynamic Drive Control
Properties	<ul> <li>Typical settling time after a speed change: 100 ms 200 ms</li> <li>Typical settling time after a load surge: 500 ms</li> <li>Load</li></ul>	<ul> <li>Typical settling time after a speed change:     &lt; 100 ms</li> <li>Typical settling time after a load surge: 200 ms</li> <li>Load</li></ul>
Application examples	Pumps, fans, and compressors with flow characteristic	Pumps and compressors with displacement ma- chines
Power Modules that can be oper- ated	PM240-2, PM240P-2	PM240-2, PM240P-2 PM330
Max. output frequency	550 Hz	240 Hz 150 Hz
Motors that can be operated	Induction motors	Induction, synchronous and reluctance motors
Commissioning	<ul> <li>Unlike "Dynamic Drive Control," no speed controller needs to be set</li> <li>When compared to "Expert":         <ul> <li>Simplified commissioning using predefined motor data</li> <li>Reduced number of parameters</li> </ul> </li> <li>"Standard Drive Control" is preset for Power Modules, frame size A frame size C</li> </ul>	<ul> <li>Reduced amount of parameters when compared to "Expert"</li> <li>"Dynamic Drive Control" is preset for Power Modules frame size D frame size JX</li> </ul>

#### 5.4.3.3 Standard Drive Control

# **Function description**



Select the motor standard:

- KW SOHZIEC
- HP 50H7 NEMA, US units
- 片片 日日日7 NEMA, SI units



Set the converter supply voltage.



Select the motor type. If a 5-digit motor code is stamped on the motor rating plate, select the corresponding motor type with motor code.

Motors without motor code stamped on the rating plate:

- // / / ILE1, 1LG6, 1LA7, 1LA9 induction motors

Motors with motor code stamped on the rating plate:

- ILE | | N ] | | 100 1LE1 induction motor . 9
- \P[ \ \N] 1PC1 induction motor
- ╎P ႘ 뮤 ː ː ː ː 1 PH8 induction motor
- <code> !FP ! Reluctance motor</code>

Depending on the converter, the motor list in BOP-2 can deviate from the list shown above.



If you have selected a motor type with motor code, you must now enter the motor code. The converter assigns the following motor data corresponding to the motor code.

If you do not know the motor code, then you must set the motor code = 0, and enter motor data from p0304 and higher from the rating plate.



87 Hz motor operation The BOP-2 only indicates this step if you selected IEC as the motor standard (P100 = 4 M - 5 GHz).



Rated motor voltage



Rated motor current



Rated motor power



Rated motor frequency



Rated motor speed



Motor cooling:

- SF! F Natural cooling
- FNRFF Therced-air cooling
- | | []]|| | | Liquid cooling
- N☐ FRN Without fan



Select the basic setting for the motor control:

- #FF 577 Constant load
- PIIMP FAN Speed-dependent load



Select the default setting for the interfaces of the converter that is suitable for your application.



Default setting of the interfaces (Page 124)





# **CAUTION**

# Material damage caused by unexpected acceleration of the motor

Depending on the Power Module, the converter sets the minimum frequency p1080 to 20 % of the maximum frequency. Also for setpoint = 0, the motor accelerates for p1080 > 0 to the minimum frequency after switching on the motor. An unexpected acceleration of the motor can cause material damage.

If the application requires a minimum frequency = 0, then set p1080 = 0.




Figure 5-10 Minimum/maximum frequency of the motor



Scaling of analog input 0






Figure 5-11 Ramp-up and ramp-down time of the motor



Ramp-down time after the OFF3 command



Motor data identification: Select the method which the converter uses to measure the data of the connected motor:

- ## F No motor data identification
- 5 7 11 Ray Measure the motor data at standstill and with the motor rotating.
  The converter switches off the motor after the motor data identification has been completed.
- 57 11 Recommended setting: Measure the motor data at standstill.

  The converter switches off the motor after the motor data identification has been completed.

  Select this setting if the motor cannot rotate freely.
- Rag 7 Measure the motor data while the motor is rotating.
  The converter switches off the motor after the motor data identification has been completed.
- 5 T RT @P Setting the same as 5 T L R @ T After the motor data identification, the motor accelerates to the current setpoint.



Complete the data entry for quick commissioning as follows:

- 1. Switch over the display using an arrow key:  $\Pi_{i} \rightarrow Y \in S$
- 2. Press the OK key.

You have entered all of the data that is necessary for the quick commissioning of the converter.

#### 5.4.3.4 Dynamic Drive Control

# **Function description**



Select the motor standard:

- KW 50H7: IEC
- 片戶 后门片 ?: NEMA, US units
- 呂景 등급유 7: NEMA, SI units



Set the converter supply voltage.



Select the motor type. If a 5-digit motor code is stamped on the motor rating plate, select the corresponding motor type with motor code.

Motors without motor code stamped on the rating plate:

- # ##: 1LE1, 1LG6, 1LA7, 1LA9 induction motors

Motors with motor code stamped on the rating plate:

- ILE | | N ] | | | 1LE1 induction motor . 9
- IP[ | | N]] 1PC1 induction motor
- \FP \ Reluctance motor

Depending on the converter, the motor list in BOP-2 can deviate from the list shown above.



If you have selected a motor type with motor code, you must now enter the motor code. The converter assigns the following motor data corresponding to the motor code.

If you do not know the motor code, then you must set the motor code = 0, and enter motor data from p0304 and higher from the rating plate.



87 Hz motor operation The BOP-2 only indicates this step if you selected IEC as the motor standard (P100 =  $KW = S\Pi H T$ ).



Rated motor voltage



Rated motor current



Rated motor power



Rated motor frequency



Rated motor speed



Motor cooling:

- SF! F: Natural cooling
- F□R[E]: Forced-air cooling
- | | []|| ]: Liquid cooling
- N∏ FBN: Without fan



Select the basic setting for the motor control:

- [L L ]] P: Recommended setting for applications with short ramp-up and ramp-down times.

The BOP-2 does not display this step for a PM330 Power Module.



Select the default setting for the interfaces of the converter that is suitable for your application.

Default setting of the interfaces (Page 124)





# **CAUTION**

#### Material damage caused by unexpected acceleration of the motor

Depending on the Power Module, the converter sets the minimum frequency p1080 to 20 % of the maximum frequency. Also for setpoint = 0, the motor accelerates for p1080 > 0 to the minimum frequency after switching on the motor. An unexpected acceleration of the motor can cause material damage.

• If the application requires a minimum frequency = 0, then set p1080 = 0.




Figure 5-12 Minimum/maximum frequency of the motor



Scaling of analog input 0






Figure 5-13 Ramp-up and ramp-down time of the motor



Ramp-down time for the OFF3 command



Motor data identification: Select the method which the converter uses to measure the data of the connected motor:

- ∏FF: Motor data is not measured

The converter switches off the motor after the motor data identification has been completed.

• 5 7 1 L: Default setting: Measure the motor data at standstill.

The converter switches off the motor after the motor data identification has been completed.

Select this setting if the motor cannot rotate freely.

- Rar: Measure the motor data while the motor is rotating.
  The converter switches off the motor after the motor data identification has been completed.
- 5 T PT []P: Setting the same as 5 T T P[] T After the motor data identification, the motor accelerates to the current setpoint.



Complete the data entry for quick commissioning as follows:

- 1. Switch over the display using an arrow key:  $\Box 
  \Omega$
- 2. Press the OK key.

You have entered all of the data that is necessary for the quick commissioning of the converter.

### 5.4.3.5 **Expert**

### **Function description**



Select the motor standard:

- KW 50H7IEC
- 片户 片门片 7 NEMA, US units
- 岩景 長日日7 NEMA, SI units



Specify the overload capability of the converter:

- 뭐! [ [ ] L' | Duty cycle with "high overload"
- [[], [], Duty cycle with "low overload"

Overload capability of the converter (Page 492)



Set the converter supply voltage.



Select the motor type. If a 5-digit motor code is stamped on the motor rating plate, select the corresponding motor type with motor code.

Motors without motor code stamped on the rating plate:

- ; N THIE T Third-party induction motor
- # # # 1LE1, 1LG6, 1LA7, 1LA9 induction motors

Motors with motor code stamped on the rating plate:

- ILE | | N ] | | 100 1LE1 induction motor . 9
- \P[ | |N∏ 1PC1 induction motor
- !F₽!Reluctance motor

Depending on the converter, the motor list in BOP-2 can deviate from the list shown above.



If you have selected a motor type with motor code, you must now enter the motor code. The converter assigns the following motor data corresponding to the motor code.

If you do not know the motor code, then you must set the motor code = 0, and enter motor data from p0304 and higher from the rating plate.



87 Hz motor operation The BOP-2 only indicates this step if you selected IEC as the motor standard (P100 =  $\frac{1}{12}$   $\frac$ 



Rated motor voltage



Rated motor current



Rated motor power



Rated motor frequency



Rated motor speed



Motor cooling:

- SF! F: Natural cooling
- FMRFF 7: Forced-air cooling
- | | []]] | ]: Liquid cooling
- N∏ FRN: Without fan



Select the appropriate application:

- #FF 577 In all applications that do not fit the other setting options.
- P!!MP FRN Applications involving pumps and fans
- 51 1/ [ ] H 7 Applications with short ramp-up and ramp-down times.
- # L [ ] Applications with high break loose torque



Select the control mode:

- #F | | W: U/f control with linear characteristic
- #F | | | F: Flux current control (FCC)
- 5₽1 N FN: Sensorless vector control

Control mode	U/f control with linear or square-law character- istic	Sensorless vector control
	Flux current control (FCC)	
Closed-loop control characteristics	<ul> <li>Typical settling time after a speed change: 100 ms 200 ms</li> <li>Typical settling time after a load surge: 500 ms</li> <li>Load</li></ul>	<ul> <li>Typical settling time after a speed change:     &lt; 100 ms</li> <li>Typical settling time after a load surge: 200 ms</li> <li>Load</li></ul>
Application examples	Pumps, fans, and compressors with flow characteristic	Pumps and compressors with displacement ma- chines
Motors that can be operated	Induction motors	Induction, synchronous and reluctance motors
Power Modules that can be oper- ated	No res	strictions
Max. output frequency	550 Hz	240 Hz 150 Hz with PM330 Power Module
Commissioning	Contrary to vector control, no speed controller has to be set	
	1	



Select the default setting for the interfaces of the converter that is suitable for your application.

Default setting of the interfaces (Page 124)






Figure 5-14 Minimum and maximum motor frequency



# CAUTION

#### Material damage caused by unexpected acceleration of the motor

Depending on the Power Module, the converter sets the minimum frequency p1080 to 20 % of the maximum frequency. Also for setpoint = 0, the motor accelerates for p1080 > 0 to the minimum frequency after switching on the motor. An unexpected acceleration of the motor can cause material damage.

• If the application requires a minimum frequency = 0, then set p1080 = 0.



Scaling of analog input 0






Figure 5-15 Ramp-up and ramp-down time of the motor



Ramp-down time for the OFF3 command



Motor data identification: Select the method which the converter uses to measure the data of the connected motor:

- \[
   \int F: Motor data is not measured.
   \]
   \[
   \]
- 5711 PDT: Recommended setting: Measure the motor data at standstill and with the motor rotating. The converter switches off the motor after the motor data identification has been completed.
- 5 7 1 1 1: Measure the motor data at standstill. The converter switches off the motor after the motor data identification has been completed.

  Select this setting if one of the following cases is applicable:

  - You have selected U/f control as control mode, e.g., F | | | Nor, F |
- Part: Measure the motor data while the motor is rotating. The converter switches off the motor after the motor data identification has been completed.

FINISH

Complete the data entry for quick commissioning as follows:

- 1. Switch over the display using an arrow key:  $\Box \Box \rightarrow 
  \Box$
- 2. Press the OK key.

You have entered all of the data that is necessary for the quick commissioning of the converter.

# 5.4.4 Identifying the motor data and optimizing the closed-loop control


#### Overview

Using the motor data identification, the converter measures the data of the stationary motor. In addition, based on the response of the rotating motor, the converter can determine a suitable setting for the vector control.

To start the motor data identification routine, you must switch-on the motor via the terminal strip, fieldbus or from the operator panel.

### Identifying the motor data and optimizing the closed-loop control

#### Requirements





• The motor has cooled down to the ambient temperature.

An excessively high motor temperature falsifies the motor data identification results.



# Unexpected machine motion while the motor data identification is in progress

For the stationary measurement, the motor can make several rotations. The rotating measurement accelerates the motor up to the rated speed. Secure dangerous machine parts before starting motor data identification:

- Before switching on, ensure that nobody is working on the machine or located within its working area.
- Secure the machine's work area against unintended access.
- Lower suspended loads to the floor.

#### **Procedure**

Enable the control priority via the operator panel.



The BOP-2 displays the symbol indicating manual operation.

Switch on the motor.



During motor data identification  $M \square \uparrow - \uparrow \square$  flashes on the BOP-2.



If the converter again outputs alarm A07991, then it waits for a new ON command to start the rotating measurement.

If the converter does not output alarm A07991, switch off the motor as described below, and switch over the converter control from HAND to AUTO.

Switch on the motor to start the rotating measurement.



During motor data identification Market 1 and flashes on the BOP-2.

The motor data identification can take up to 2 minutes depending on the rated motor power.

Depending on the setting, after motor data identification has been completed, the converter switches off the motor - or it accelerates it to the setpoint.

If required, switch off the motor.

Disable the control priority via the operator panel.

You have completed the motor data identification.

Quick commissioning has been completed once the motor data identification has been successfully completed.

# 5.5 Quick commissioning with a PC.

The screen forms that are shown in this manual show generally valid examples. The number of setting options available in screen forms depends on the particular converter type.

#### Overview

To be able to perform quick commissioning using a PC, you need to do the following:

- 1. Creating a project
- 2. Integrating the converter into the project
- 3. Go online and start the quick commissioning

# 5.5.1 Creating a project

# Creating a new project

#### **Procedure**

- 1. Start the Startdrive commissioning software.
- 2. In the menu, select "Project" → "New...".
- 3. Specify a name of your choice for the project.

You have created a new project.


# 5.5.2 Transfer converters connected via USB into the project

# Integrating the converter into the project


#### **Procedure**

- 1. Switch on the converter power supply.
- 2. First insert a USB cable into your PC and then into the converter.
- 3. The PC operating system installs the USB driver when you are connecting the converter and PC together for the first time.

4. Press the "Accessible nodes" button.



5. When the USB interface is appropriately set, then the "Accessible nodes" screen form shows the converters that can be accessed.



If you have not correctly set the USB interface, then the following "No additional nodes found" message is displayed. In this case, follow the description below.


6. Transfer the converter into the project using the menu: "Online - Upload device as new station (hardware and software)".

You have transferred a converter accessible via the USB interface into your project.

# 5.5.3 Go online and start the commissioning Wizard

#### **Procedure**

- 1. Select your project and go online: Select your project and go online:
- 2. In the following screen form, select the converter with which you wish to go online.
- 3. Once you are online, select "Commissioning" → "Commissioning Wizard":



You have started the commissioning Wizard of the converter.  $\ensuremath{\blacksquare}$ 

# 5.5.4 Commissioning wizard

# Select the application class

# **Procedure**



When selecting an application class, the converter assigns the motor control with the appropriate default settings:

- [1] Standard Drive Control (Page 200)
- [2] Dynamic Drive Control (Page 202)
- [0] Expert or if no application class is listed:

Application class	Standard Drive Control	Dynamic Drive Control
Properties	Typical settling time after a speed change: 100 ms 200 ms  Typical settling time after a load surge: 500 ms  Load Speed Motor torque  500 ms	Typical settling time after a speed change: < 100 ms  Typical settling time after a load surge: 200 ms  Load  Speed  Motor torque  200 ms
	<ul> <li>"Standard Drive Control" is suitable to address the following requirements:         <ul> <li>Motor power ratings &lt; 45 kW</li> <li>Ramp-up time 0 → rated speed (depending on the motor power rating):                 1 s (0.1 kW) 10 s (45 kW)</li> <li>Applications with increasing load torque without load surges</li> </ul> </li> <li>"Standard Drive Control" is insensitive with respect to imprecise setting of the motor data</li> </ul>	<ul> <li>"Dynamic Drive Control" controls and limits the motor torque</li> <li>Torque accuracy that can be achieved: ± 5% for 15% 100% of the rated speed</li> <li>We recommend "Dynamic Drive Control" for the following applications:         <ul> <li>Motor power ratings &gt; 11 kW</li> <li>For load surges 10% &gt;100% of the rated motor torque</li> </ul> </li> <li>"Dynamic Drive Control" is necessary for a rampup time 0 → rated speed (dependent on the rated motor power): &lt; 1 s (0.1 kW) &lt; 10 s (132 kW).</li> </ul>
Application examples	Pumps, fans, and compressors with flow characteristic	Pumps and compressors with displacement ma- chines
Power Modules that can be oper- ated	PM240-2, PM240P-2	PM240-2, PM240P-2 PM330
Max. output frequency	550 Hz	240 Hz 150 Hz
Motors that can be operated	Induction motors	Induction, synchronous and reluctance motors
Commissioning	<ul> <li>Unlike "Dynamic Drive Control," no speed controller needs to be set</li> <li>When compared to "Expert":         <ul> <li>Simplified commissioning using predefined motor data</li> <li>Reduced number of parameters</li> </ul> </li> <li>"Standard Drive Control" is preset for Power Modules, frame size A frame size C</li> </ul>	<ul> <li>Reduced amount of parameters when compared to "Expert"</li> <li>"Dynamic Drive Control" is preset for Power Modules frame size D frame size JX</li> </ul>

#### 5.5.5 Standard Drive Control

# Procedure for application class [1]: Standard Drive Control

Setpoint specification

Select whether the converter is connected to a higher-level control via the fieldbus.

Select whether the ramp-function generator for the speed setpoint is implemented in the higher-level control or in the converter.

Defaults of the setpoi...

Select the I/O configuration to preassign the converter interfaces.

Factory interface settings (Page 122)



Default setting of the interfaces (Page 124)

Drive setting

Drive options

Set the applicable motor standard and the converter supply voltage.

If an optional component is installed between converter and motor, the corresponding setting must be performed.

If a braking resistor is installed, you set the maximum braking power to which the braking resistor will be subjected.

Motor

Select your motor.

Enter the motor data according to the rating plate of your motor.

If you have selected a motor based on its article number, the data has already been entered.

Select the temperature sensor for monitoring of the motor temperature.

Important parameters

Set the most important parameters to suit your application.



#### **CAUTION**

### Material damage caused by unexpected acceleration of the motor

Depending on the Power Module, the converter sets the minimum frequency p1080 to 20% of the maximum frequency. Also for setpoint = 0, the motor accelerates for p1080 > 0 to the minimum frequency after switching on the motor. An unexpected acceleration of the motor can cause material damage.

If the application requires a minimum frequency = 0, then set p1080 = 0.

Drive functions

Select the application:

- [0] Constant load: Typical applications include conveyor drives
- [1] Speed-dependent load: Typical applications include pumps and fans


Motor data identification (not all the following settings may be visible in Startdrive):

- [0]: No motor data identification
- [2]: Recommended setting. Measure the motor data at standstill. The converter switches off the motor after the motor data identification has been completed. Select this setting if the motor cannot freely rotate, e.g. for a mechanically limited traversing range.
- [12]: The same setting as [2]. The motor accelerates to the currently set setpoint after the motor data identification.



Set the check mark for "RAM data to EEPROM (save data in the drive)" to save your data in the converter so that it is not lost if the power fails.

Press the "Finish" button.



You have entered all of the data that is necessary for the quick commissioning of the converter.

#### 5.5.6 **Dynamic Drive Control**

# Procedure for application class [2]: Dynamic Drive Control

Setpoint specification

Select whether the converter is connected to a higher-level control via the fieldbus.

Select whether the ramp-function generator for the speed setpoint is implemented in the higher-level control or in the converter.

Defaults of the setpoi...

Select the I/O configuration to preassign the converter interfaces.

Factory interface settings (Page 122)



Default setting of the interfaces (Page 124)



Drive options

Set the applicable motor standard and the converter supply voltage.

If an optional component is installed between converter and motor, the corresponding setting must be performed.

If a braking resistor is installed, you set the maximum braking power to which the braking resistor will be subjected.



Select your motor.

Enter the motor data according to the rating plate of your motor.

If you have selected a motor based on its article number, the data has already been entered.

Select the temperature sensor for monitoring of the motor temperature.



Set the most important parameters to suit your application.



#### **CAUTION**

### Material damage caused by unexpected acceleration of the motor

Depending on the Power Module, the converter sets the minimum frequency p1080 to 20% of the maximum frequency. Also for setpoint = 0, the motor accelerates for p1080 > 0 to the minimum frequency after switching on the motor. An unexpected acceleration of the motor can cause material damage.

If the application requires a minimum frequency = 0, then set p1080 = 0.



#### Application:

- [0]: Recommended setting for standard applications.
- [1]: Recommended setting for applications with ramp-up and ramp-down times < 10 s. This setting is not suitable for hoisting gear and cranes.
- [5] Recommended setting for applications with a high break loose torque.

Motor data identification:

- [0]: No motor data identification
- [1]: Recommended setting. Measure the motor data at standstill and with the motor rotating. The converter switches off the motor after the motor data identification has been completed.


- [2]: Measure the motor data at standstill. The converter switches off the motor after the motor data identification has been completed.

  Select this setting if the motor cannot freely rotate, e.g. for a mechanically limited traversing range.
- [3]: Measure the motor data while the motor is rotating. The converter switches off the motor after the motor data identification has been completed.
- [11]: The same setting as [1]. The motor accelerates to the currently set setpoint after the motor data identification.
- [12]: The same setting as [2]. The motor accelerates to the currently set setpoint after the motor data identification.



Set the check mark for "RAM data to EEPROM (save data in the drive)" to save your data in the converter so that it is not lost if the power fails.

Press the "Finish" button.



You have entered all of the data that is necessary for the quick commissioning of the converter.



#### 5.5.7 **Expert**

# Procedure without application class or for the application class [0]: Expert

Setpoint specification

Select whether the converter is connected to a higher-level control via the fieldbus.

Select whether the ramp-function generator for the speed setpoint is implemented in the higher-level control or in the converter.

Open-loop/closed-loop ..

Select the control mode.

Further information is provided at the end of the section.

Defaults of the setpoi...

Select the I/O configuration to preassign the converter interfaces.

Factory interface settings (Page 122)

Default setting of the interfaces (Page 124)

Drive setting

Set the applicable motor standard and the converter supply voltage.

#### Application:

- "[0] Load cycle with high overload for applications requiring a high dynamic performance, e.g. conveyor systems.
- "[1] Load cycle with low overload ..." for applications that do not require a high dynamic performance, e.g. pumps or fans.
- [6], [7]: Load cycles for applications with encoderless 1FK7 synchronous motors. The respective power module being used determines whether or not the selection is displayed by the commissioning wizard.

Drive options

If an optional component is installed between converter and motor, the corresponding setting must be performed.

If a braking resistor is installed, you set the maximum braking power to which the braking resistor will be subjected.

Motor 🏓

Select your motor.

Enter the motor data according to the rating plate of your motor.

If you have selected a motor based on its article number, the data has already been entered.

Select the temperature sensor for monitoring of the motor temperature.

Important parameters

Set the most important parameters to suit your application.



#### **CAUTION**

#### Material damage caused by unexpected acceleration of the motor

Depending on the Power Module, the converter sets the minimum frequency p1080 to 20% of the maximum frequency. Also for setpoint = 0, the motor accelerates for p1080 > 0 to the minimum frequency after switching on the motor. An unexpected acceleration of the motor can cause material damage.

If the application requires a minimum frequency = 0, then set p1080 = 0.

Drive functions

#### Application:

- [0]: In all applications that do not fall under [1] ... [3]
- [1]: Applications involving pumps and fans
- [2]: Applications with short ramp-up and ramp-down times. However, this setting is not suitable for hoisting gear and cranes/lifting gear.
- [3]: Setting only for steady-state operation with slow speed changes. We recommend setting [1] if load surges in operation cannot be ruled out.

#### Motor identification:

- [1]: Recommended setting. Measure the motor data at standstill and with the motor rotating. The converter switches off the motor after the motor data identification has been completed.
- [2]: Measure the motor data at standstill. The converter switches off the motor after the motor data identification has been completed.


  Recommended setting for the following cases:
  - You have selected "Speed control" as control mode, however the motor cannot freely rotate, e.g. for mechanically limited traversing sections.
  - You have set "U/f control" as control mode.
- [3]: Measure the motor data while the motor is rotating. The converter switches off the motor after the motor data identification has been completed.
- [11]: The same setting as [1]. The motor accelerates to the currently set setpoint after the motor data identification.
- [12]: The same setting as [2]. The motor accelerates to the currently set setpoint after the motor data identification.

Calculating the motor parameters: Select "Complete calculation".



Set the check mark for "RAM data to EEPROM (save data in the drive)" to save your data in the converter so that it is not lost if the power fails.

Press the "Finish" button.



You have entered all of the data that is necessary for the quick commissioning of the converter.



# Select a suitable control mode

Control mode	U/f control with linear or square-law character-	Encoderless vector control
Control mode	istic	Encoderiess vector control
	Flux current control (FCC)	
Closed-loop control characteristics	<ul> <li>Typical settling time after a speed change: 100 ms 200 ms</li> <li>Typical settling time after a load surge: 500 ms</li> <li>Load</li></ul>	<ul> <li>Typical settling time after a speed change:     &lt; 100 ms</li> <li>Typical settling time after a load surge: 200 ms</li> <li>Load</li></ul>
Application examples	Pumps, fans, and compressors with flow characteristic	Pumps and compressors with displacement ma- chines
Motors that can be operated	Induction motors	Induction, synchronous and reluctance motors
Power Modules that can be oper- ated	No res	strictions
Max. output frequency	550 Hz	240 Hz 150 Hz with PM330 Power Module
Commissioning	Contrary to vector control, no speed controller has to be set	

# 5.5.8 Identify motor data

#### Overview

Using the motor data identification, the converter measures the data of the stationary motor. In addition, based on the response of the rotating motor, the converter can determine a suitable setting for the vector control.

To start the motor data identification routine, you must switch on the motor.

# Identifying the motor data and optimizing the closed-loop control

#### Requirements

- You have selected a method of motor data identification during quick commissioning, e.g. measurement of the motor data while the motor is stationary.

  When quick commissioning is complete, the converter issues alarm A07991.
- The motor has cooled down to the ambient temperature.
   An excessively high motor temperature falsifies the motor data identification results.
- The PC and converter are connected to each other online.




# WARNING

# Unexpected machine motion while the motor data identification is in progress

For the stationary measurement, the motor can make several rotations. The rotating measurement accelerates the motor up to the rated speed. Secure dangerous machine parts before starting motor data identification:

- Before switching on, ensure that nobody is working on the machine or located within its working area.
- Secure the machine's work area against unintended access.
- Lower suspended loads to the floor.

#### **Procedure**



- 1. Open the control panel.
- 2. Assume master control for the converter.
- 3. Set the "Drive enables"
- 4. Switch on the motor.

The converter starts the motor data identification. This measurement can take several minutes.

Depending on the setting, after motor data identification has been completed, the converter switches off the motor - or it accelerates it to the currently set setpoint.

- 5. If required, switch off the motor.
- 6. Relinquish the master control after the motor data identification.
- 7. Save the settings in the converter (RAM  $\rightarrow$  EEPROM):



You have completed the motor data identification.

# Self-optimization of the speed control

If you have not only selected motor data identification with the motor stationary, but also rotating measurement with self-optimization of the speed control, you must switch on the motor again as described above and wait for the optimization run to finish.

Quick commissioning has been completed once the motor data identification has been successfully completed.

#### Recommendations

Induction motors

When commissioning induction machines, you are advised to proceed as follows:

- Before connecting the load, a complete "rotating measurement" (p1900 = 3 or without encoder: p1960 = 1; with encoder: p1960 = 2) should be carried out. Since the induction machine is idling, you can expect highly accurate results for the saturation characteristic and the rated magnetizing current.
- When the load is connected, speed controller tuning should be repeated because the total moment of inertia has changed. This is realized by selecting parameter p1960 (without encoder: p1960 = 3; with encoder: p1960 = 4). During the speed optimization, the saturation characteristic recording is automatically deactivated in parameter p1959.
- Permanent-magnet synchronous motors
   When permanent-magnet synchronous motors are commissioned, the speed controller should be tuned (p1900 = 3 or p1960 > 0) when the load is connected.

# 5.6 Restoring the factory settings


# Why restore the factory settings?

Reset the converter to the factory settings in the following cases:

- You do not know the converter settings.
- The line voltage was interrupted during commissioning and you were not able to complete commissioning.

# Resetting to factory settings with Startdrive

#### **Procedure**



- 1. Go online.
- 2. Select "Commissioning".
- 3. Select "Back up/reset".
- 4. Select "All parameters will be reset".
- 5. Press the "Start" button.
- 6. Wait until the converter has been reset to the factory settings.

You have reset the converter to the factory settings.

# 5.6 Restoring the factory settings

# Resetting to factory setting with the BOP-2 operator panel

# **Procedure**

1. Select "Reset to factory settings"



2. Start the reset.



3. Wait until the converter has been reset to the factory setting.



You have reset the converter to the factory settings.

# 5.7 Series commissioning

#### Overview

Series commissioning is the commissioning of several identical converters. During series commissioning, it is sufficient to commission one of the converters and then transfer the settings of the first converter to additional converters.

#### Precondition

The following preconditions apply to the converters regarding series commissioning:

- All converters have the same article number
- The converters to which the settings are transferred have the same or a higher firmware version as the source converter with the original settings.


# **Function description**

#### **Procedure**

- 1. Commission the first converter.
- 2. Back up the settings of the first converter to an external storage medium. Uploading the converter settings (Page 219)
- 3. Transfer the settings from the first converter to another converter via the data storage medium.
  - Downloading the converter settings (Page 465)

# 5.8 Handling the BOP 2 operator panel

#### Overview



<sup>&</sup>lt;sup>1)</sup> Status display once the power supply for the converter has been switched on.

Figure 5-16 Menu of the BOP-2




Figure 5-17 Additional symbols of the BOP-2

# 5.8.1 Switching the motor on and off

#### Overview

The BOP-2 offers the option of switching the motor on and off using the control keys.

# **Function description**

#### **Procedure**

1. Enable the control priority via the operator panel.



2. Switch on the motor.



3. Switch off the motor.



4. Disable the control priority via the operator panel.



You switched the motor on and off again.

5.8 Handling the BOP 2 operator panel

# 5.8.2 Changing parameter values

#### Overview

You can modify the settings of the converter by changing the parameter values in the converter.

### Precondition

The converter only permits changes to write parameters. Write parameters begin with a "P", e.g. P45.

The value of a read-only parameter cannot be changed. Read-only parameters begin with an "r", for example: r2.

# **Function description**

#### **Procedure**

1. Select the menu to display and change parameter values.



2. Select the parameter filter.



- The converter only displays the most important parameters:



The converter displays all of the parameters to you:



3. When the parameter number flashes, select the desired parameter number.



4. When the parameter value flashes, change the parameter value.



You changed a parameter value.

#### **Additional information**

The converter immediately saves any changes so that they are protected against power failure.

# 5.8.3 Changing indexed parameters

### Overview

For indexed parameters, several parameter values are assigned to a parameter number. Each of the parameter values has its own index.

### Precondition

You are in the menu for displaying and changing parameter values.

The number of an indexed parameter flashes in the BOP-2 display.

# **Function description**

### **Procedure**

1. Set the parameter index.



2. Set the parameter value for the selected index.



You have now changed an indexed parameter.

5.8 Handling the BOP 2 operator panel

# 5.8.4 Entering the parameter number directly

### Overview

The BOP-2 offers the possibility of setting the parameter number digit by digit.

### Precondition

You are in the menu for displaying and changing parameter values.

The number of a given parameter flashes in the BOP-2 display.

## **Function description**

# **Procedure**

1. Press the OK button until the first digit of the parameter number flashes.



2. Change the parameter number digit-by-digit. If you press the OK button, the BOP-2 jumps to the next digit.



3. After you have entered all of the digits of the parameter number, press the OK button.

You set the parameter number directly.

# 5.8.5 Entering the parameter value directly

### Overview

The BOP-2 offers the option of setting the parameter value digit by digit.

### Precondition

You are in the menu for displaying and changing parameter values.

The parameter value flashes in the BOP-2 display.

# **Function description**

### **Procedure**

1. Press the OK button until the first digit of the parameter value flashes.



2. Change the parameter value digit-by-digit.



You set the parameter value directly.

5.8 Handling the BOP 2 operator panel

# 5.8.6 Why can a parameter value not be changed?

### Overview

Whether or not a parameter value can be changed depends on the type of parameter and the operating mode of the converter.

# **Function description**

The converter indicates why it currently does not permit a parameter to be changed:



### **Further information**

For each parameter, the parameter list contains the operating state in which the parameter can be changed.

# Uploading the converter settings

6

### Overview

After commissioning, your settings are permanently saved in the converter.

We recommend that you additionally back up the converter settings on an external storage medium by means of an upload. Without a backup, your settings could be lost should the converter develop a fault.

The following storage media options are available:

- Memory card
- Operator panel BOP-2
- Operator panel IOP-2
- SINAMICS G120 Smart Access
- PG/PC

# 6.1 Uploading to the memory card

# 6.1.1 Recommended memory cards

## **Function description**



Table 6-1 Memory cards to back up converter settings

Scope of delivery	Article number	
Memory card without firmware	6SL3054-4AG00-2AA0	
Memory card with firmware V4.7	6SL3054-7EH00-2BA0	
Memory card with firmware V4.7 SP3	6SL3054-7TB00-2BA0	
Memory card with firmware V4.7 SP6	6SL3054-7TD00-2BA0	
Memory card with firmware V4.7 SP9	6SL3054-7TE00-2BA0	
Memory card with firmware V4.7 SP10	6SL3054-7TF00-2BA0	
Memory card with firmware V4.7 SP14	6SL3054-7TG00-2BA0	

### **Further information**

### Using memory cards from other manufacturers

The converter only supports memory cards up to 2 GB. SDHC cards (SD High Capacity) and SDXC cards (SD Extended Capacity) are not permitted.

If you use a different SD memory card, then you must format it as follows:

- Insert the card into your PC's card reader.
- Command to format the card: format x: /fs:fat or format x: /fs:fat32 (x: Drive code of the memory card on your PC.)

### Functional restrictions with memory cards from other manufacturers

The following functions are either not possible – or only with some restrictions – when using memory cards from other manufacturers:

- Licensing functions is only possible using the recommended memory cards.
- Know-how protection is only possible with one of the recommended memory cards.
- In certain circumstances, memory cards from other manufacturers do not support writing or reading data from/to the converter.

# 6.1.2 Automatic upload

### Overview

We recommend that you insert the memory card before switching on the converter. The converter automatically backs up its settings on the inserted memory card and always keeps it up to date.

### Precondition

The converter power supply has been switched off.

# **Function description**

#### **Procedure**

1. Insert an empty memory card into the converter.

#### Note

### Accidental overwrite of the converter settings

When the supply voltage is switched on, the converter automatically accepts the settings already backed up on the memory card. If you use a memory card on which settings are already backed up, you will overwrite the settings of the converter.


• Use an empty memory card for the first automatic back-up of your settings.

#### Note

### Unintentional firmware update

If the memory card contains a converter firmware, the converter may perform a firmware update after the supply voltage has been switched on.

• Before inserting the memory card, ensure that it is empty.



2. Switch on the power supply for the converter.

After the power supply has been switched on, the converter copies its changed settings to the memory card.

# 6.1.3 Message for a memory card that is not inserted

# **Function description**

The converter identifies that a memory card is not inserted, and signals this state. The message is deactivated in the converter factory setting.

### Activate message

### **Procedure**

- 1. Set p2118[x] = 1101, x = 0, 1, ... 19
- 2. Set p2119[x] = 2

Message A01101 for a memory card that is not inserted is activated.

П

To cyclically signal to the higher-level control that a memory card is not inserted, connect parameter r9401 to the send data of the fieldbus interface.

### Deactivate message

#### **Procedure**

- 1. Set p2118[x] = 1101, x = 0, 1, ... 19
- 2. Set p2119[x] = 3

Message A01101 for a memory card that is not inserted is deactivated.

#### **Parameter**

Parameter	Explanation	Factory setting
p2118[019]	Change message type, message number	0
p2119[0 19]	Change message type, type	0
r9401	Safely remove memory card status	-

# 6.1.4 Manual upload with Startdrive

### Overview

If you insert the memory card into a converter that is already supplied with power, you must start the upload manually using a commissioning tool.


### Requirement

The following preconditions apply:

- The converter power supply has been switched on.
- The PC and converter are connected with one another via a USB cable or via the fieldbus.
- A memory card is inserted in the converter.

### **Function description**

#### **Procedure**



- 1. Go online.
- 2. Select "Online & diagnostics".
- 3. Select "Back up/reset".
- 4. Back up the settings to the EEPROM of the converter.
- 5. Set the number of your data backup. You can back up 99 different settings on the memory card.
- 6. Start data transfer
- 7. Wait until Startdrive signals that data backup has been completed.

You have backed up the converter settings to a memory card.  $\ \square$ 

### 6.1.5 Manual upload with BOP-2

### Overview

If you insert the memory card into a converter that is already supplied with power, you must start the upload manually using a commissioning tool.

6.1 Uploading to the memory card

#### Precondition

The converter power supply has been switched on.

A memory card is inserted in the converter.

# **Function description**

### **Procedure**

1. Select the upload.



2. Set the number of your data backup. You can back up 99 different settings on the memory card.



3. Start the upload.



4. Wait until the converter has backed up the settings to the memory card.



You have backed up the settings of the converter to the memory card.

# 6.1.6 Safely removing a memory card using the BOP-2

# **Function description**

#### **NOTICE**

### Data loss from improper handling of the memory card

If you remove the memory card when the converter is switched on without implementing the "safe removal" function you may destroy the file system on the memory card. The data on the memory card are lost. The memory card will only function again after formatting.

• Only remove the memory card using the "safe removal" function.

#### **Procedure**

1. Select the menu for changing parameter values.



2. If a memory card is inserted, p9400 = 1. Set p9400 = 2.



- 3. The converter indicates whether it is currently writing data to the memory card:
  - The converter sets p9400 = 100:



You must not remove the memory card. Wait for several seconds and then set p9400 = 2 again.

- The converter sets p9400 = 3:



Remove the memory card.

4. After removing the memory card, the converter sets p9400 = 0.



You have safely removed the memory card.

# 6.1.7 Safely remove the memory card with Startdrive

### **Function description**

### NOTICE


### Data loss from improper handling of the memory card

If you remove the memory card when the converter is switched on without implementing the "safe removal" function you may destroy the file system on the memory card. The data on the memory card are lost. The memory card will only function again after formatting.

• Only remove the memory card using the "safe removal" function.

### 6.1 Uploading to the memory card

#### **Procedure**



- 1. In the Drive Navigator select the following screen form:
- 2. Click on the button to safely remove the memory card. Startdrive will tell you whether you can remove the memory card from the converter.

You have now safely removed the memory card from the converter.

# 6.2 Uploading to the BOP-2

### Overview

You can back up the converter settings on the BOP-2 operator panel.


### Precondition

The converter power supply has been switched on.

# **Function description**

### Procedure

1. Select the upload to the operator panel.



2. Start the upload.



3. Wait until the upload is completed.



The upload from the converter to the BOP-2 is completed.

# 6.3 Upload to a PC using Startdrive

### Overview

You can backup the converter settings to a PC.

# Requirement

The following preconditions apply:

- The converter power supply has been switched on.
- The PC and converter are connected with one another via a USB cable or via the fieldbus.

# **Function description**

#### **Procedure**

- 1. Go online.
- 2. Select "Online" > "Upload device to PG/PC."
- 3. Back up the project with "Project" > "Save."
- 4. Wait until Startdrive signals that data backup has been completed.
- 5. Go offline.

You have backed up the settings.

#### 6.4 More options for the upload

# **Function description**

In addition to the default setting, the converter has an internal memory for backing up three other settings.

On the memory card, you can back up 99 other settings in addition to the default setting. Further information is provided on the Internet:



Memory options (http://support.automation.siemens.com/WW/view/en/43512514)

6.4 More options for the upload

**Protecting the converter settings** 

7

# 7.1 Write protection

### Overview

The write protection prevents unauthorized changing of the converter settings.

# **Function description**

Write protection is applicable for all user interfaces:

- Commissioning tool, e.g. operator panel or PC
- Parameter changes via fieldbus

No password is required for write protection.

# Activate and deactivate write protection

Parameter				
r7760	Write	Write protection/know-how protection status		
	.00	1 signal: Write protection active		
p7761	Write	Write protection (factory setting: 0)		
Deactivate write protection     Activate write protection		Deactivate write protection		
		Activate write protection		

### **Parameter**

Table 7-1 Parameters that can be changed with active write protection

Number	Name	
p0003	Access level / Acc_level	
p0010	Drive commissioning parameter filter / Drv comm par_filt	
p0124[0n]	CU detection using LED / CU detect LED	
p0970	Reset drive parameters / Drive par reset	
p0971	Save parameters / Sav par	
p0972	Drive unit reset / Drv_unit reset	
p2111	Alarm counter / Alarm counter	
p3950	Service parameter / Serv par	
p3981	Acknowledge drive object faults / Ackn DO faults	
p3985	Master control mode selection / PcCtrl mode select	
p7761	Write protection / Write protection	
p8805	Identification and Maintenance 4 Configuration / I&M 4 Config	

# 7.1 Write protection

Number	Name	
p8806[053]	Identification and Maintenance 1 / I&M 1	
p8807[015]	Identification and Maintenance 2 / I&M 2	
p8808[053]	Identification and Maintenance 3 / I&M 3	
p8809[053]	Identification and Maintenance 4 / I&M 4	
p9400	Safely remove memory card / Mem_card rem	
p9484	BICO interconnections search signal source / BICO S_src srch	

#### Note

# Write protection for multimaster fieldbus systems

Via multimaster fieldbus systems, e.g. BACnet or Modbus RTU, in spite of write protection being activated, parameters can still be changed. So that write protection is also active when accessing via these fieldbuses, you must additionally set p7762 to 1.

# 7.2 Know-how protection

# 7.2.1 Know-how protection

#### Overview

Know-how protection prevents unauthorized reading of the converter settings.

To protect your converter settings against unauthorized copying, in addition to know-how protection, you can also activate copy protection.

# Requirement

Know-how protection requires a password.

Combination of know-how protection and copy protection	Is a memory card necessary?	
Know-how protection without copy protection	The converter can be operated with or without memory card.	
Know-how protection with basic copy protection  Know-how protection with extended copy protection  tection	SIMATIC SIMATIC DEMONSTRATE SERVICES OF SE	The converter can only be operated with a SIEMENS memory card  Recommended memory cards (Page 220)

### **Function description**

The active know-how protection provides the following:

- With just a few exceptions, the values of all adjustable parameters p ... are invisible.
  - Several adjustable parameters can be read and changed when know-how protection is active.
    - In addition, you can define an exception list of adjustable parameters, which end users may change.
  - Several adjustable parameters can be read but not changed when know-how protection is active
- The values of monitoring parameters r ... remain visible.

### 7.2 Know-how protection

- Locked functions:
  - Downloading converter settings using a PC
  - Automatic controller optimization
  - Stationary or rotating measurement of the motor data identification
  - Deleting the alarm history and the fault history
  - Generating acceptance documents for safety functions
- Executable functions:
  - Restoring factory settings
  - Acknowledging faults
  - Displaying faults, alarms, fault history, and alarm history
  - Reading out the diagnostic buffer
  - Controlling a converter using a PC
  - Uploading adjustable parameters that can be changed or read when know-how protection is active.
  - Displaying acceptance documents for safety functions

When know-how protection is active, support can only be provided (from Technical Support) after prior agreement from the machine manufacturer (OEM).

### Know-how protection without copy protection

You can transfer the converter settings to another converter, e.g. using a memory card or an operator panel.

### Know-how protection with basic copy protection

After replacing a converter, to be able to operate the new converter with the settings of the replaced converter without knowing the password, the memory card must be inserted in the new converter.

### Know-how protection with extended copy protection

It is not possible to insert and use the memory card in another converter without knowing the password.

# Commissioning know-how protection

- 1. Check as to whether you must extend the exception list.
  - List of exceptions (Page 237)
- 2. Activate the know-how protection.
  - Know-how protection (Page 238)

### **Parameter**

Table 7-2 Parameters that can be changed with active know-how protection

Number	Name	
p0003	Access level / Acc_level	
p0010	Drive commissioning parameter filter / Drv comm par_filt	
p0124[0n]	CU detection using LED / CU detect LED	
p0791[01]	CO: Fieldbus analog outputs / Fieldbus AO	
p0970	Reset drive parameters / Drive par reset	
p0971	Save parameters / Sav par	
p0972	Drive unit reset / Drv_unit reset	
p2040	Fieldbus interface monitoring time / Fieldbus t_monit	
p2111	Alarm counter / Alarm counter	
p3950	Service parameter / Serv par	
p3981	Acknowledge drive object faults / Ackn DO faults	
p3985	Master control mode selection / PcCtrl mode select	
p7761	Write protection / Write protection	
p8402[08]	RTC daylight saving time setting / RTC DST	
p8805	Identification and Maintenance 4 Configuration / I&M 4 Config	
p8806[053]	Identification and Maintenance 1 / I&M 1	
p8807[015]	Identification and Maintenance 2 / I&M 2	
p8808[053]	Identification and Maintenance 3 / I&M 3	
p8809[053]	Identification and Maintenance 4 / I&M 4	
p8980	EtherNet/IP profile / Eth/IP profile	
p8981	EtherNet/IP ODVA STOP mode / Eth/IP ODVA STOP	
p8982	EtherNet/IP ODVA speed scaling / Eth/IP ODVA n scal	
p8983	EtherNet/IP ODVA torque scaling / Eth/IP ODVA M scal	
p9400	Safely remove memory card / Mem_card rem	
p9484	BICO interconnections search signal source / BICO S_src srch	

Table 7-3 Parameters that can be read with active know-how protection

Number	Name	
p0015	Macro drive unit / Macro drv unit	
p0100	IEC/NEMA Standards / IEC/NEMA Standards	
p0170	Number of Command Data Sets (CDS) / CDS count	
p0180	Number of Drive Data Sets (DDS) / DDS count	
p0300[0n]	Motor type selection / Mot type sel	
p0304[0n]	Rated motor voltage / Mot U_rated	
p0305[0n]	Rated motor current / Mot I_rated	
p0505	Selecting the system of units / Unit sys select	
p0595	Technological unit selection / Tech unit select	
p0730	BI: CU signal source for terminal DO 0 / CU S_src DO 0	

# 7.2 Know-how protection

Number	Name
p0731	BI: CU signal source for terminal DO 1 / CU S_src DO 1
p0732	BI: CU signal source for terminal DO 2 / CU S_src DO 2
p0806	BI: Inhibit master control / Inhibit PcCtrl
p0870	BI: Close main contactor / Close main cont
p0922	PROFIdrive PZD telegram selection / PZD telegr_sel
p1080[0n]	Minimum velocity / v_min
p1082[0n]	Maximum velocity / v_max
p1520[0n]	CO: Torque limit upper / M_max upper
p2000	Reference speed reference frequency / n_ref f_ref
p2001	Reference voltage / Reference voltage
p2002	Reference current / I_ref
p2003	Reference torque / M_ref
p2006	Reference temperature / Ref temp
p2030	Fieldbus interface protocol selection / Fieldbus protocol
p2038	PROFIdrive STW/ZSW interface mode / PD STW/ZSW IF mode
p2079	PROFIdrive PZD telegram selection extended / PZD telegr ext
p7763	KHP OEM exception list number of indices for p7764 / KHP OEM qty p7765
p7764[0n]	KHP OEM exception list / KHP OEM excep list
p11026	Free tec_ctrl 0 unit selection / Ftec0 unit sel
p11126	Free tec_ctrl 1 unit selection / Ftec1 unit sel
p11226	Free tec_ctrl 2 unit selection / Ftec2 unit sel

# 7.2.2 Extending the exception list for know-how protection

In the factory setting, the exception list only includes the password for know-how protection.

Before activating know-how protection, you can additionally enter the adjustable parameters in the exception list, which must still be able to be read and changed by end users – even if know-how protection has been activated.

You do not need to change the exception list, if, with exception of the password, you do not require additional adjustable parameters in the exception list.

# Absolute know-how protection

If you remove password p7766 from the exception list, it is no longer possible to enter or change the password for know-how protection.

You must reset the converter to the factory settings in order to be able to gain access to the converter adjustable parameters. When restoring the factory settings, you lose what you have configured in the converter, and you must recommission the converter.

### **Parameter**

Parameter	Description	Factory setting
p7763	KHP OEM exception list, number of indices for p7764	1
p7764[0p7763]	KHP OEM exception list	[0] 7766
p7766 is the password for know-how protection		[1499] 0

## 7.2.3 Activating and deactivating know-how protection

### Requirements

- The converter has now been commissioned.
- You have generated the exception list for know-how protection.
- To guarantee know-how protection, you must ensure that the project does not remain at the end user as a file.

### **Function description**

### Activating know-how protection

- 1. Enter a password of your choice in p7767. Each index of p7767 corresponds with a character in the ASCII format.
- 2. Complete entry of the password with p7767[29] = 0.
- 3. Enter the same password in p7768 as that for p7767.
- 4. Complete entry of the password with p7768[29] = 0.

The know-how protection for the converter is activated.

### **Deactivating know-how protection**

- 1. Enter the password for the know-how protection in p7766. Each index of p7766 corresponds with a character in the ASCII format.
- 2. Complete entry of the password with p7766[29] = 0.

The know-how protection for the converter is deactivated.  $\Box$ 

### **Parameter**

Parameter	Description	Factory setting
r7758[019]	KHP Control Unit serial number	
p7759[019]	KHP Control Unit reference serial number	
r7760	Write protection/know-how protection status	
p7765	KHP configuration	0000 bin
p7766[029]	KHP password, input	
p7767[029]	KHP password, new	
p7768[029]	KHP password, confirmation	
p7769[020]	KHP memory card reference serial number	
r7843[020]	Memory card serial number	

### **Further information**

### Preventing data reconstruction from the memory card

As soon as know-how protection has been activated, the converter only backs up encrypted data to the memory card.

In order to guarantee know-how protection, after activating know-how protection, we recommend that you insert a new, empty memory card. For memory cards that have already been written to, previously backed up data that was not encrypted can be reconstructed.

7.2 Know-how protection

Advanced commissioning

## 8.1 Overview of the converter functions

#### Overview




Figure 8-1 Overview of converter functions

#### **Drive control**



The converter receives its commands from the higher-level control via the terminal strip or the fieldbus interface of the Control Unit. The drive control defines how the converter responds to the commands.

Sequence control when switching the motor on and off (Page 245)

Adapt the default setting of the terminal strip (Page 248)

Controlling clockwise and counter-clockwise rotation via digital inputs (Page 266)

Drive control via PROFIBUS or PROFINET (Page 278)

Drive control via USS (Page 299)

Drive control via Modbus RTU (Page 302)

Drive control via Ethernet/IP (Page 305)

Drive control via BACnet MS/TP (Page 307)

Drive control via P1 (Page 310)

Jogging (Page 311)

The converter can switch between different settings of the drive control.

Switching over the drive control (command data set) (Page 313)

The free function blocks permit configurable signal processing within the converter.

#### 8.1 Overview of the converter functions

Free function blocks (Page 315)

You can select in which physical units the converter represents its associated values.


Physical units (Page 317)

### Setpoints and setpoint processing



The setpoint generally determines the motor speed.





The setpoint processing uses a ramp-function generator to prevent speed steps occurring and to limit the speed to a permissible maximum value.

Setpoint processing (Page 331)

### **Technology controller**



The technology controller controls process variables, e.g. pressure, temperature, level or flow. The closed-loop motor control receives the setpoint either from the higher-level control or from the technology controller.

PID technology controller (Page 340)

The converter has three additional technology controllers that operate independently of each other.

Free technology controllers (Page 352)

The multi-zone control offers various procedures to process multiple setpoints or actual values with only one technology controller.

Multi-zone control (Page 354)

The cascade control is ideal for applications in which, for example, significantly fluctuating pressures or flow rates are equalized.

Cascade control (Page 357)

The "time switch", together with the real-time clock, offers the option of controlling when signals are switched on and off.

Real time clock (RTC) (Page 361)

Time switch (DTC) (Page 363)

#### Motor control



The closed-loop motor control ensures that the motor follows the speed setpoint. You can choose between various control modes.

Motor control (Page 364)

The converter provides several methods to brake the motor electrically. During electrical braking, the motor develops a torque that reduces the speed down to standstill.

Electrically braking the motor (Page 378)

#### Protection of the drive and the driven load



The protection functions prevent damage to the motor, converter and driven load.

Overcurrent protection (Page 392)

Converter protection using temperature monitoring (Page 393)

Motor protection with temperature sensor (Page 396)

Motor protection by calculating the temperature (Page 398)

Motor and converter protection by limiting the voltage (Page 401)

The monitoring of the driven load prevents impermissible operating modes, e.g. dry-running of a pump.

Monitoring the driven load (Page 403)

### Increasing the drive availability



The kinetic buffering converts the kinetic energy of the load into electrical energy to buffer short-term power failures.

Flying restart – switching on while the motor is running (Page 412)

The "Flying restart" function permits the fault-free switching on of the motor while it is still turning.

Automatic restart (Page 414)

For active automatic restart, after a power failure, the converter attempts to automatically restart the motor and to acknowledge any faults that occur.

Kinetic buffering (Vdc min control) (Page 417)

In an emergency, the converter deactivates its protection functions in order to maintain drive operation as long as possible.

Essential service mode (Page 419)

#### **Energy saving**



For standard induction motors, the efficiency optimization reduces the motor losses in the partial load range.

Efficiency optimization (Page 423)

The "Bypass" function switches the motor between converter and line operation.

Bypass (Page 426)

If the plant/system conditions permit, the converter switches off the motor temporarily.

### **Energy saving**

Hibernation mode (Page 430)

If necessary, the main contactor control disconnects the converter from the power system and so reduces the converter losses.

Line contactor control (Page 434)

The converter calculates how much energy controlled converter operation saves when compared to mechanical flow control (e.g. throttle).

Calculating the energy saving for fluid flow machines (Page 436)

# 8.2 Brief description of the parameters

### Overview

The brief parameter description provides the most important information for all of the parameters that are assigned to a certain converter function.

If the number of parameter indices depends on the data sets, then the parameter index is shown in an abbreviated form.




Figure 8-2 Brief parameter description

# 8.3 Sequence control when switching the motor on and off

#### Overview



The sequence control defines the rules for switching the motor on and off.




Figure 8-3 Simplified representation of the sequence control

After switching the supply voltage on, the converter normally goes into the "ready to start" state. In this state, the converter waits for the command to switch on the motor.

The converter switches on the motor with the ON command. The converter changes to the "Operation" state.

After the OFF1 command, the converter brakes the motor down to standstill. The converter switches off the motor once standstill has been reached. The converter is again "ready to start".

# **Function description**




Figure 8-4 Sequence control of the converter when the motor is switched on and off

# 8.3 Sequence control when switching the motor on and off

Converter states S1 ... S5c are defined in the PROFIdrive profile. The sequence control defines the transition from one state to another.

Table 8-1 Converter states

The motor is switched off		The motor is switched on	
Current does not flow in the motor and the motor does not generate any torque		Current flows in the motor and the motor generates a torque	
S1	The ON command and an OFF command are active at the same time.	S4	The motor is switched on.
	In order for the converter to exit the state, you must deactivate OFF2 and OFF3 and activate the ON command again.		
S2 The converter waits for a new command to switch on the motor.		S5a, S5c	The motor is still switched on. The converter brakes the motor with the ramp-down time of the ramp-function generator.
S3 The converter waits for "Enable operation". The "Enable operation" command is always active in the converter factory setting.		S5b	The motor is still switched on. The converter brakes the motor with the OFF3 rampdown time.

Table 8-2 Commands for switching the motor on and off

ON	The converter switches the motor on.
Jogging 1	
Jogging 2	
Enable opera- tion	
OFF1, OFF3	1. The converter brakes the motor.
	2. The converter switches off the motor once it comes to a standstill.
	The converter identifies that the motor is at a standstill when at least one of the following conditions is satisfied:
	• The speed actual value falls below the threshold in p1226, and the time started in p1228 has expired.
	• The speed setpoint falls below the threshold in p1226, and the time subsequently started in p1227 has expired.
OFF2	The converter switches off the motor immediately without first braking it.
Inhibit opera- tion	

### **Parameters**

Number	Name	Factory setting
r0046.031	CO/BO: Missing enable signals	-
p0857	Power unit monitoring time	10000 ms
p0858[C]	BI: Unconditionally close holding brake	0
p0860	BI: Line contactor feedback signal	863.1

# 8.3 Sequence control when switching the motor on and off

Number	Name	Factory setting
p0861	Line contactor monitoring time	100 ms
p1226[D]	Speed threshold for standstill detection	20 rpm
p1227	Standstill detection monitoring time	300 s
p1228	Pulse suppression delay time	0.01 s

# 8.4 Adapt the default setting of the terminal strip


### Overview




In the converter, the input and output signals are interconnected with specific converter functions using special parameters. The following parameters are available to interconnect signals:

- Binectors BI and BO are parameters to interconnect binary signals.
- Connectors CI and CO are parameters to interconnect analog signals.

The following chapters describe how you adapt the function of individual converter inputs and outputs using binectors and connectors.




8.4 Adapt the default setting of the terminal strip



When using the PM330 Power Module, in addition to the terminals on the Control Unit, the converter has 4 digital inputs DI and 2 digital outputs DO on the Power Module.

# 8.4.1 Digital inputs

# **Function description**



<sup>1)</sup> When using the PM330 Power Module, the converter has 4 additional digital inputs.

To change the function of a digital input, you must interconnect the status parameter of the digital input with a binector input of your choice.

Binector inputs are designated in the parameter list with the "BI".

# Example

To acknowledge converter fault messages using digital input DI 1, you must interconnect DI 1 with the command to acknowledge faults (p2103).

Set p2103 = 722.1.

### **Parameter**

Parameter	Description	Factory setting
r0721	CU digital inputs, terminal actual value	-
r0722	CO/BO: CU digital inputs, status	-
r0723	CO/BO: CU digital inputs, status inverted	
p0724	CU digital inputs debounce time	4 ms
p0810	BI: Command data set selection CDS bit 0	0
p0840[C]	BI: ON/OFF (OFF1)	Dependent on the converter
p0844[C]	BI: No coast down/coast down (OFF2) signal source	Dependent on the converter
p0848[C]	BI: No quick stop/quick stop (OFF3) signal source 1	1
p0852[C]	BI: Enable operation/inhibit operation	Dependent on the converter
p1020[C]	BI: Fixed speed setpoint selection, bit 0	0
p1021[C]	BI: Fixed speed setpoint selection, bit 1	0
p1022[C]	BI: Fixed speed setpoint selection, bit 2	0

Parameter	Description	Factory setting
p1023[C]	BI: Fixed speed setpoint selection, bit 3	0
p1035[C]	BI: Motorized potentiometer setpoint higher	Dependent on the converter
p1036[C]	BI: Motorized potentiometer setpoint lower	Dependent on the converter
p1055[C]	BI: Jogging bit 0	Dependent on the converter
p1056[C]	BI: Jogging bit 1	Dependent on the converter
p1113[C]	BI: Setpoint inversion	Dependent on the converter
p2103[C]	BI: 1. Acknowledge faults	Dependent on the converter
p2106[C]	BI: External fault 1	1
p2112[C]	BI: External alarm 1	1


For additional binector inputs and additional information on parameters, please refer to the parameter list.



Overview of the manuals (Page 581)

#### 8.4.2 Analog inputs as digital inputs

## **Function description**



To use an analog input as additional digital input, you must interconnect the corresponding status parameter r0722.11 or r0722.12 with a binector input of your choice.

You may operate the analog input as a digital input with 10 V or with 24 V.

## NOTICE

## Defective analog input due to overcurrent


If the analog input switch is set to "Current input" (I), a 10 V or 24 V voltage source results in an overcurrent at the analog input. An overcurrent condition destroys the analog input.

If you use an analog input as a digital input, then you must set the analog input switch to "Voltage" (U).

8.4 Adapt the default setting of the terminal strip

## 8.4.3 Digital outputs

## **Function description**



To change the function of a digital output, you must interconnect the digital output with a binector output of your choice.

Binector outputs are designated in the parameter list with "BO".

<sup>1)</sup> When using the PM330 Power Module, the converter has 2 additional digital outputs. The function of the two additional digital outputs is fixed and cannot be modified:

- DO 0 (X9.8): Converter DC link is charged
- DO 1 (X9.11, X9.12): Close main contactor

## **Example**



To output converter fault messages via digital output DO 1, you must interconnect DO 1 with these fault messages.


Set p0731 = 52.3

## **Parameter**

Table 8-3 Frequently used binector outputs (BO) of the converter

Parameter	Description		Factory setting
r0052[015]	CO/BO: St	tatus word 1	-
	.00	1 signal: Ready for switching on	
	.01	1 signal: Ready for operation	
	.02	1 signal: Operation enabled	
	.03	1 signal: Fault active	
	.04	0 signal: OFF2 active	
	.05	0 signal: OFF3 active	
	.06	1 signal: Switching on inhibited active	
	.07	1 signal: Alarm active	
	.08	0 signal: Deviation, setpoint/actual speed	
	.09	1 signal: Control request	
	.10	1 signal: Maximum speed (p1082) reached	
	.11	0 signal: I, M, P limit reached	
	.13	0 signal: Alarm, motor overtemperature	
	.14	1 signal: Motor clockwise rotation	
	.15	0 signal: Alarm, converter overload	
r0053[011]	CO/BO: St	tatus word 2	-
	.00	1 signal: DC braking active	
	.02	1 signal: Speed > minimum speed (p1080)	
	.06	1 signal: Speed ≥ setpoint speed (r1119)	

You can find additional binector outputs in the parameter list.



## **Further information**


You can invert the signal of the digital output using parameter p0748.

Additional information is provided in the parameter list and the function diagrams 2230 ff.

Overview of the manuals (Page 581)

# 8.4.4 Analog inputs

# **Function description**



## Defining the analog input type

The parameter p0756[x] and the switch on the converter specify the analog input type.

Table 8-4 Default settings via parameter p0756

AI 0	Unipolar voltage input	0 V +10 V	p0756[0]	0
	Unipolar voltage input monitored	+2 V +10 V	=	1
	Unipolar current input	0 mA +20 mA		2
	Unipolar current input monitored	+4 mA +20 mA		3
	Bipolar voltage input (factory setting)	-10 V +10 V		4
Al 1	Unipolar voltage input	0 V +10 V	p0756[1]	0
	Unipolar voltage input monitored	+2 V +10 V	=	1
	Unipolar current input	0 mA +20 mA		2
	Unipolar current input monitored	+4 mA +20 mA		3
	Bipolar voltage input (factory setting)	-10 V +10 V		4
Al 2	Unipolar current input (factory setting)	0 mA +20 mA	p0756[2]	2
	Unipolar current input monitored	+4 mA +20 mA	=	3
	LG-Ni1000 temperature sensor			6
	Pt1000 temperature sensor			7
	No sensor connected			8
	DIN-Ni1000 temperature sensor (6180 ppm / K)			10
AI 3	3 LG-Ni1000 temperature sensor		p0756[3]	6
	Pt1000 temperature sensor			7
	No sensor connected (factory setting)			8
	DIN-Ni1000 temperature sensor (6180 ppm / K)			10

The switch that belongs to the analog input is located behind the front doors of the Control Unit.

• The switches for AI 0 and AI 1 (current/voltage) are located behind the lower front door of the Control Unit.



• The switch for AI 2 (temperature/current) is located behind the upper front door of the Control Unit.



#### Permissible measuring range of the temperature sensors

LG-Ni1000, DIN-Ni1000	– 88 °C 165 °C
Pt1000	− 88 °C 240 °C

For values outside the permissible measuring range, the converter outputs Alarm A03520 "Temperature sensor fault".

## Defining the function of an analog input

You define the analog input function by interconnecting a connector input of your choice with parameter p0755.

Parameter p0755 is assigned to the particular analog input via its index, e.g. parameter p0755[0] is assigned to analog input 0.

## Example

In order to enter the supplementary setpoint via analog input AI 0, you must interconnect AI 0 with the signal source for the supplementary setpoint.

Set p1075 = 755[0].

#### **Parameter**

Table 8-5 Frequently used connector inputs (CI) of the converter

Parameter	Description	Factory setting
p1070[C]	CI: Main setpoint	0
p1075[C]	CI: Supplementary setpoint	0
p2253[C]	CI: Technology controller setpoint 1	0
p2264[C]	CI: Technology controller actual value	0

You can find additional connector inputs in the parameter list.

Overview of the manuals (Page 581)

8.4 Adapt the default setting of the terminal strip

#### **Further information**

### Signal smoothing

When required, you can smooth the signal, which you read-in via an analog input, using parameter p0753.

Additional information is provided in the parameter list and in function diagram 2251.

Overview of the manuals (Page 581)

## Using an analog input as a digital input


An analog input can also be used as a digital input.


Digital inputs (Page 250)

## 8.4.5 Adjusting characteristics for analog input

## **Function description**

If you change the analog input type using p0756, then the converter automatically selects the appropriate scaling of the analog input. The linear scaling characteristic is defined using two points (p0757, p0758) and (p0759, p0760). Parameters p0757 ... p0760 are assigned to an analog input via their index, e.g. parameters p0757[0] ... p0760[0] belong to analog input 0.






You must define your own characteristic if none of the default types match your particular application.

## Example

The converter should convert a 6 mA ... 12 mA signal into the value range -100% ... 100% via analog input 0. The wire-break monitoring of the converter should respond when 6 mA is fallen below.



#### **Procedure**

1. Set the DIP switch for analog input 0 on the Control Unit to current input ("I").



2. set p0756[0] = 3
You have defined analog input 0 as a current input with wire-break monitoring.

3. Set p0757[0] = 6.0 (x1)

4. Set p0758[0] = -100.0 (y1)

5. Set p0759[0] = 12.0 (x2)

6. Set p0760[0] = 100.0 (y2)

7. Set p0761[0] = 6 An input current < 6 mA results in fault F03505.

The characteristic for the application example is set.  $\Box$ 

# Parameters


Parameter	Description	Factory setting
p0757[0n]	CU analog inputs characteristic value x1	0
p0758[0n]	CU analog inputs characteristic value y1	0%
p0759[0n]	CU analog inputs characteristic value x2	10
p0760[0n]	CU analog inputs characteristic value y2	100%
p0761[0n]	CU analog inputs wire-break monitoring, response threshold	2
p0762[0n]	CU analog inputs wire breakage monitoring time	100 ms

8.4 Adapt the default setting of the terminal strip

# 8.4.6 Setting the deadband

## **Function description**

With the control enabled, electromagnetic interference on the signal cable can cause the motor to slowly rotate in one direction, in spite of a speed setpoint = 0.




The deadband acts on the zero crossover of the analog input characteristic. Internally, the converter sets its speed setpoint = 0, even if the signal at the analog input terminals is slightly positive or negative. This prevents the converter from rotating the motor when the speed setpoint = 0.

#### **Parameter**

Parameter	Description	Factory setting
p0764[0]	Analog inputs deadband, AI 0	0
p0764[1]	Analog inputs deadband, AI 1	0

## 8.4.7 Analog outputs

## **Function description**



#### Defining the analog output type

Define the analog output type using parameter p0776.

AO 0	Current output (factory setting)	0 mA +20 mA	p0776[0] =	0
	Voltage output	0 V +10 V		1
	Current output	+4 mA +20 mA		2
AO 1	Current output (factory setting)	0 mA +20 mA	p0776[1] =	0
	Voltage output	0 V +10 V		1
	Current output	+4 mA +20 mA		2


## Defining the function of an analog output

You define the analog output function by interconnecting parameter p0771 with a connector output of your choice. Parameter p0771 is assigned to the specific analog output via its index, e.g. parameter p0771[0] is assigned to analog output 0.

Connector outputs are designated in the parameter list with "CO".

Overview of the manuals (Page 581)

## **Example**



To output the converter output current via analog output 0, you must interconnect AO 0 with the signal for the output current.

Set p0771 = 27.

#### **Parameter**

Table 8-6 Frequently used connector outputs (CO) of the converter

Parameter	Description	Factory setting
r0021	CO: Speed actual value, smoothed	- rpm
r0025	CO: Output voltage, smoothed	- Vrms

## 8.4 Adapt the default setting of the terminal strip

Parameter	Description	Factory setting
r0026	CO: DC link voltage, smoothed	- V
r0027	CO: Absolute actual current, smoothed	- Arms
r0063	CO: Speed actual value	- rpm


You can find additional connector outputs in the parameter list.


Overview of the manuals (Page 581)

#### 8.4.8 Adjusting characteristics for analog output

## **Function description**

If you change the analog output type, then the converter automatically selects the appropriate scaling of the analog output. The linear scaling characteristic is defined using two points (p0777, p0778) and (p0779, p0780).






Parameters p0777 ... p0780 are assigned to an analog output via their index, e.g. parameters p0777[0] ... p0770[0] belong to analog output 0.

You must define your own characteristic if none of the default types match your particular application.

## Example

Via analog output 0, the converter should convert a signal in the value range 0% ... 100% into an output signal 6 mA ... 12 mA.



## **Procedure**

- 1. Set p0776[0] = 2
  This defines analog output 0 as a current output.
- 2. Set p0777[0] = 0.0 (x1)
- 3. Set p0778[0] = 6.0 (y1)
- 4. Set p0779[0] = 100.0 (x2)
- 5. Set p0780[0] = 12.0 (y2)

The characteristic for the application example is set.

## **Parameters**

Table 8-7 Parameters for the scaling characteristic

Parameter	Description	Factory setting
p0777[01]	CU analog outputs characteristic value x1	-
p0778[01]	CU analog outputs characteristic value y1	0 V
p0779[01]	CU analog outputs characteristic value x2	100%
p0780[01]	CU analog outputs characteristic value y2	20 V

# 8.5 Safe Torque Off (STO) safety function

# 8.5.1 Safe Torque Off (STO) safety function

#### Overview



The converter with active STO function prevents energy supply to the motor. The motor can no longer generate torque on the motor shaft.

Consequently, the STO function prevents the starting of an electrically-driven machine component.

## The STO safety function conforms to IEC/EN 61800-5-2.

The STO function is defined in IEC/EN 61800-5-2:

"[...] [The converter] does not supply the motor with power that can generate a torque (or for a linear motor, a force)".

## Precondition

The machine manufacturer has already performed a risk assessment, e.g. in compliance with EN ISO 1050, "Safety of machinery - Principles of risk assessment".

## **Function description**

	Safe Torque Off (STO)	Standard converter functions linked with STO
1.	The converter detects that STO has been selected via the failsafe digital input.	
2.	The converter prevents the energy supply to the motor.	If you use a motor holding brake, the converter closes the motor holding brake.
		If you use a line contactor, the converter opens the line contactor.




Figure 8-5 Functionality of STO when the motor is at standstill (A) and rotating (B)

(A): When selecting STO, if the motor is already stationary (zero speed), then STO prevents the motor from starting.

(B): If the motor is still rotating (B) when STO is selected, it coasts down to standstill.

## **Example**

The STO function is suitable for applications where the motor is already at a standstill or will come to a standstill in a short, safe period of time through friction.

When STO is active, the converter can no longer electrically brake the motor, so that STO does not shorten the time that it takes for machine components to coast down to zero speed.

Application example	Possible solution	
When the EMERGENCY STOP button is pressed, it is not permissible for a stationary motor to inadvertently accelerate.	<ul> <li>Connect the EMERGENCY STOP pushbutton with the fail-safe converter digital input.</li> <li>Select STO via the failsafe digital input.</li> </ul>	

## More information

EN 60204-1 defines "EMERGENCY SWITCHING OFF" and "EMERGENCY STOP" as actions taken in an emergency. Further, it defines various stop categories for EMERGENCY STOP. "EMERGENCY SWITCHING OFF" and "EMERGENCY STOP" minimize different risks in the system or machine.

Table 8-8 The distinction between EMERGENCY OFF and EMERGENCY STOP

Action:	EMERGENCY SWITCHING OFF	EMERGENCY STOP	
		Stop Category 0 according to EN 60204-1	
Risk:			
	Electric shock	Unexpected movement	
Measure to minimize	Switch off	Prevent movement	
risk:	Either completely or partially switch off hazardous voltages.	Prevent hazardous movement.	

## 8.5 Safe Torque Off (STO) safety function

Action:	EMERGENCY SWITCHING OFF	EMERGENCY STOP
		Stop Category 0 according to EN 60204-1
Classic solution:	**************************************	Switch off the drive power supply
Solution with the STO	Not possible.	###
safety function inte- grated in the drive:	STO is not suitable for switching off a voltage.	
		Select STO
		It is not necessary to switch off the voltage to minimize risk.

# 8.5.2 Setting the feedback signal for Safe Torque Off

## Overview

The converter signals that the STO safety function is controlled to the higher-level control system using two digital outputs.

# **Function description**




Figure 8-6 Feedback signal "STO is active" via digital outputs

8.5 Safe Torque Off (STO) safety function

For converters equipped with PM240-2 (FSD...FSG) and PM240P-2 (FSD...FSF) Power Modules, you must interconnect the "STO is active" feedback signals with two digital outputs of the Control Unit.

### **Procedure**

- 1. Set p0730 = 1838.3
- 2. Set p0731 = 1838.4

You have interconnected the feedback signal for safety function STO with the digital outputs of the converter.



#### **Parameter**

Number	Name	Factory setting
p0730	BI: CU signal source for terminal DO 0	52.3
p0731	BI: CU signal source for terminal DO 1	52.7
r1838	CO/BO: Gating unit status word 1	
	.03 1 signal: Shutdown path STO_B is inactive	
	.04 1 signal: Shutdown path STO_A is inactive	

Further information is provided in the parameter list.



Overview of the manuals (Page 581)

#### Overview



The converter offers various methods to start and stop the motor and reverse its direction.


## Two-wire control, ON/reverse

ON/OFF1:

Switches the motor on or off

Reversing:

Reverses the motor direction of rotation




Two-wire control, clockwise/counterclockwise rotation 1 and clockwise/counterclockwise rotation 2

ON/OFF1 clockwise rotation:

Switches the motor on or off, clockwise rotation

ON/OFF1 counter-clockwise rotation:

Switches the motor on or off, counterclockwise rotation



# Three-wire control, enable/clock-wise/counterclockwise rotation

Enable/OFF1:


Enables the motor to be switched on or switched off

ON clockwise rotation:

Switches on the motor, clockwise rotation

ON counter-clockwise rotation:

Switches on the motor, counter-clockwise rotation



## Three-wire control, enable/ON/ reverse

Enable/OFF1:

Enables the motor to be switched on or switched off


ON:

Switches on the motor

Reversing:

Reverses the motor direction of rota-

tion



Reversing is disabled in the factory setting. To use the "Reverse" function, you must release the negative rotational direction.



Enable direction of rotation (Page 333)

# 8.6.1 Two-wire control, ON/reverse

# **Function description**




Figure 8-7 Two-wire control, ON/reverse

Command "ON/OFF1" switches the motor on and off. The "Reversing" command inverts the motor direction of rotation.

Table 8-9 Function table

ON/OFF1	Reversing	Function
0	0	The motor stops
0	1	
1	0	Clockwise motor rotation
1	1	Counter-clockwise motor rotation

# **Examples**

Table 8-10 Two-wire control and setting the assignment of the digital inputs

Parameter	Description	
p3334 = 0	2/3 wire control selection	
	0: Two-wire control, ON/reverse	
p0840[C] = 722.0	BI: ON/OFF (OFF1)	
	Command is received via digital input 0	
p1113[C] = 722.1	BI: Setpoint inversion (reversing)	
	Command is received via digital input 1	

Table 8-11 Set two-wire control, ON/reverse in quick commissioning

Parameter	Description	
p0015 = 12	Macro drive unit	
	Assigning digital inputs to the commands:	
	Digital input 0: ON/OFF1	
	Digital input 1: Reversing	
	Default setting of the interfaces (Page 124)	

## **Parameter**

Parameter	Description	Factory setting
p0840[C]	BI: ON/OFF (OFF1)	0
p1113[C]	BI: Setpoint inversion	0
r0722.0n	CO/BO: CU digital inputs, status	-
p3334	2/3 wire control selection	0
	0: Two-wire control, ON/reverse	

## 8.6.2 Two-wire control, clockwise/counterclockwise rotation 1

## **Function description**




Figure 8-8 Two-wire control, clockwise/counterclockwise rotation 1

Commands "ON/OFF1 clockwise rotation" and "ON/OFF1 counter-clockwise rotation" switch on the motor - and simultaneously select a direction of rotation. The converter only accepts a new command when the motor is at a standstill.

Table 8-12 Function table

ON/OFF1 clockwise rotation	ON/OFF1 counter-clock- wise rotation	Function
0	0	The motor stops.
1	0	Clockwise motor rotation.
0	1	Counter-clockwise motor rotation.
1	1	The motor direction of rotation is defined by the command that first reaches state "1".

## **Examples**

Table 8-13 Two-wire control and setting the assignment of the digital inputs

Parameter	Description	
p3334 = 1	2/3 wire control selection	
	1: Two-wire control, clockwise/counterclockwise rotation 1	
p3330[C] = 722.0	BI: 2/3 wire control command 1 (ON/OFF1 clockwise rotation)	
	Command is received via digital input 0	
p3331[C] = 722.1	BI: 2/3 wire control command 2 (ON/OFF1 counter-clockwise rotation)	
	Command is received via digital input 1	

Table 8-14 Set two-wire control, clockwise/counterclockwise rotation 1 in quick commissioning

Parameter	Description	
p0015 = 17	Macro drive unit	
	Assigning digital inputs to the commands:	
	Digital input 0: ON/OFF1 clockwise rotation	
	Digital input 1: ON/OFF1 counter-clockwise rotation	
	Default setting of the interfaces (Page 124)	

## **Parameter**

Parameter	Description	Factory setting
r0722.0n	CO/BO: CU digital inputs, status	-
p0840[C]	BI: ON/OFF (OFF1)	0
p1113[C]	BI: Setpoint inversion	0
p3330[C]	BI: 2/3 wire control command 1	0
p3331[C]	BI: 2/3 wire control command 2	0
r3333.0n	CO/BO: 2/3 wire control control word	-
p3334	2/3 wire control selection	0
	1: Two-wire control, clockwise/counterclockwise rotation 1	

# 8.6.3 Two-wire control, clockwise/counterclockwise rotation 2

## **Function description**




Figure 8-9 Two-wire control, clockwise/counterclockwise rotation 2

Commands "ON/OFF1 clockwise rotation" and "ON/OFF1 counter-clockwise rotation" switch on the motor - and simultaneously select a direction of rotation. The converter accepts a new command at any time, independent of the motor speed.

Table 8-15 Function table

ON/OFF1 clockwise rotation	ON/OFF1 counter-clock- wise rotation	Function
0	0	The motor stops.
1	0	Clockwise motor rotation.
0	1	Counter-clockwise motor rotation.
1	1	The motor stops.

## **Examples**

Table 8-16 Two-wire control and setting the assignment of the digital inputs

Parameter	Description	
p3334 = 2	2/3 wire control selection	
	2: Two-wire control, clockwise/counterclockwise rotation 2	
p3330[C] = 722.0	BI: 2/3 wire control command 1 (ON/OFF1 clockwise rotation)	
	Command is received via digital input 0 (DI 0)	
p3331[C] = 722.1	BI: 2/3 wire control command 2 (ON/OFF1 counter-clockwise rotation)	
	Command is received via digital input 1 (DI 1)	

Table 8-17 Set two-wire control, clockwise/counterclockwise rotation 2 in quick commissioning

Parameter	Description
p0015 = 18	Macro drive unit
	Assigning digital inputs to the commands:
	Digital input 0: ON/OFF1 clockwise rotation
	Digital input 1: ON/OFF1 counter-clockwise rotation
	Default setting of the interfaces (Page 124)

## **Parameter**

Parameter	Description	Factory setting
r0722.0n	CO/BO: CU digital inputs, status	-
p0840[C]	BI: ON/OFF (OFF1)	0
p1113[C]	BI: Setpoint inversion	0
p3330[C]	BI: 2/3 wire control command 1	0
p3331[C]	BI: 2/3 wire control command 2	0
r3333.0n	CO/BO: 2/3 wire control control word	-
p3334	2/3 wire control selection	0
	2: Two-wire control, clockwise/counterclockwise rotation 2	

## 8.6.4 Three-wire control, enable/clockwise/counterclockwise rotation

## **Function description**




Figure 8-10 Three-wire control, enable/clockwise/counterclockwise rotation

The "Enable" command is a precondition for switching on the motor. Commands "ON clockwise rotation" and "ON counter-clockwise rotation" switch on the motor - and simultaneously select a direction of rotation. Removing the enable switches the motor off (OFF1).

Table 8-18 Function table

Enable / OFF1	ON clockwise rota- tion	ON counter-clock- wise rotation	Function	
0	0 or 1	0 or 1	The motor stops.	
1	0 →1	0	Clockwise motor rotation.	
1	0	0 →1	Counter-clockwise motor rotation.	
1	1	1	The motor stops.	

## **Examples**

Table 8-19 Three-wire control and setting the assignment of the digital inputs

Parameter	Description
p3334 = 3	2/3 wire control selection
	3: Three-wire control enable/clockwise/counterclockwise rotation
p3330[C] = 722.0	BI: 2/3 wire control command 1 (enable/OFF1)
	Command is received via digital input 0
p3331[C] = 722.1	BI: 2/3 wire control command 2 (ON clockwise rotation)
	Command is received via digital input 0
p3332[C] = 722.2	BI: 2/3 wire control command 3 (ON counter-clockwise rotation)
	Command is received via digital input 0

Table 8-20 Set three-wire control, enable/clockwise/counterclockwise rotation in quick commissioning

Parameter	Description
p0015 = 19	Macro drive unit
	Assigning digital inputs to the commands:
	Digital input 0: Enable/OFF1
	Digital input 1: ON clockwise rotation
	Digital input 2: ON counter-clockwise rotation
	Default setting of the interfaces (Page 124)

## **Parameter**

Parameter	Description	Factory setting
r0722.0n	CO/BO: CU digital inputs, status	-
p0840[C]	BI: ON/OFF (OFF1)	0
p1113[C]	BI: Setpoint inversion	0
p3330[C]	BI: 2/3 wire control command 1	0
p3331[C]	BI: 2/3 wire control command 2	0
p3332[C]	BI: 2/3 wire control command 3	0
r3333.0n	CO/BO: 2/3 wire control control word	-
p3334	2/3 wire control selection	0
	3: Three-wire control enable/clockwise/counterclockwise rotation	

# 8.6.5 Three-wire control, enable/ON/reverse

## **Function description**

The "Enable" command is a precondition for switching on the motor. The "ON" command switches the motor on. The "Reversing" command inverts the motor direction of rotation. Removing the enable switches the motor off (OFF1).




Figure 8-11 Three-wire control, enable/ON/reverse

Table 8-21 Function table

Enable / OFF1	ON	Reversing	Function	
0	0 or 1	0 or 1	The motor stops.	
1	0→1	0	Clockwise motor rotation.	
1	0→1	1	Counter-clockwise motor rotation.	

## **Examples**

Table 8-22 Changing the assignment of the digital inputs

Parameter	Description
p3334 = 4	2/3 wire control selection
	4: Three-wire control enable/clockwise/counterclockwise rotation
p3330[C] = 722.0	BI: 2/3 wire control command 1 (enable/OFF1)
	Command is received via digital input 0
p3331[C] = 722.1	BI: 2/3 wire control command 2 (ON)
	Command is received via digital input 0
p3332[C] = 722.2	BI: 2/3 wire control command 3 (reversing)
	Command is received via digital input 0

Table 8-23 Set three-wire control, enable/ON/reverse in quick commissioning

Parameter	Description
p0015 = 20	Macro drive unit
	Assigning digital inputs to the commands:
	Digital input 0: Enable/OFF1
	Digital input 1: ON
	Digital input 2: Reversing
	Default setting of the interfaces (Page 124)

## **Parameter**

Parameter	Description	Factory setting
r0722.0n	CO/BO: CU digital inputs, status	-
p0840[C]	BI: ON/OFF (OFF1)	0
p1113[C]	BI: Setpoint inversion	0
p3330[C]	BI: 2/3 wire control command 1	0
p3331[C]	BI: 2/3 wire control command 2	0
p3332[C]	BI: 2/3 wire control command 3	0
r3333.0n	CO/BO: 2/3 wire control control word	-
p3334	2/3 wire control selection	0
	4: Three-wire control enable/ON/reverse	

## 8.7 Drive control via PROFIBUS or PROFINET

#### 8.7.1 Receive data and send data

#### Overview

#### Cyclic data exchange



The converter receives cyclic data from the higher-level control - and returns cyclic data to the control.




Figure 8-12 Cyclic data exchange

Converter and higher-level control system package their data in the form of telegrams.




Figure 8-13 Telegram structure

A telegram has the following structure:

- Header and trailer form the protocol frame.
- User data is located within the frame:
  - PKW: The control system can read or change the parameters in the converter via "PKW data".
    - Not every telegram has a "PKW range".
  - PZD: The converter receives control commands and setpoints from the higher-level control - and sends status messages and actual values via "PZD data".

## PROFIdrive and telegram numbers

For typical applications, certain telegrams are defined in the PROFIdrive profile and are assigned a fixed PROFIdrive telegram number. As a consequence, behind a PROFIdrive telegram number, there is a defined signal composition. As a consequence, a telegram number uniquely describes cyclic data exchange.


The telegrams are identical for PROFIBUS and PROFINET.

# 8.7.2 Telegrams

## Overview

The user data of the telegrams that are available are described in the following.

#### Telegram 1



16-bit speed setpoint

## Telegram 20

PZD01	PZD02	PZD03	PZD04	PZD05	PZD06
STW1	NSOLL_				
	l A				
70\\\/1	NIST_A	IAIST_	MIST_	PIST_	MELD_ NAMUR
23001	GLATT	GLATT	GLATT	GLATT	NAMUR

16-bit speed setpoint for VIK-Namur

#### Telegram 350

PZD01	PZD02	PZD03	PZD04
STW1	NSOLL _A	M_LIM	STW3
ZSW1	NIST_A GLATT	IAIST_ GLATT	ZSW3

<sup>16-</sup>bit speed setpoint with torque limiting

### Telegram 352

PZD01	PZD02	PZD03	PZD04	PZD05	PZD06
STW1	_A	Freely assignable			
ZSW1	NIST_A GLATT	IAIST_ GLATT	MIST_ GLATT	WARN_ CODE	FAULT_ CODE

<sup>16-</sup>bit speed setpoint for PCS7

## Telegram 353

	PZD01	PZD02
	STW1	NSOLL _A
\	ZSW1	NIST_A GLATT

16-bit speed setpoint with reading and writing to parameters

## Telegram 354

			PZD01	PZD02	PZD03	PZD04	PZD05	PZD06
	PK		STW1	NSOLL _A	Freely a	ssignable	)	
ſ		\	7SW1	NIST_A			WARN_	
L			23001	GLATT	GLATT	GLATT	CODE	CODE

16-bit speed setpoint for PCS7 with reading and writing to parameters

## 8.7 Drive control via PROFIBUS or PROFINET

## Telegram 999

PZD01	PZD02	PZD03	PZD04	PZD05	PZD06	PZD07	PZD08	PZD09	PZD10	PZD11	PZD12	PZD <sup>2</sup>	13	. PZ	D17
STW1	Telegra	m length	for the re	l ceive dat l	l ta I	l				 	l				
ZSW1	Telegra	m length	for the tra	l ansmit da I	l ita I	l I	l	l		l	l I	1 I 1 I	1	1	_

Unassigned interconnection and length

Table 8-24 Abbreviations

Abbreviation	Explanation	Abbreviation	Explanation
PZD	Process data	PKW	Parameter channel
STW	Control word	MIST_GLATT	Actual smoothed torque
ZSW	V Status word		Actual smoothed active power
NSOLL_A	Speed setpoint	M_LIM	Torque limiting value
NIST_A	Speed actual value	FAULT_CODE	Fault code
NIST_A_GLATT	Smoothed actual speed value	WARN_CODE	Alarm code
IAIST_GLATT	Smoothed current actual val-	MELD_NAMUR	Message according to the VIK-NA-
	ue		MUR definition

# **Function description**

# Control word 1 (STW1)

Bit	Significance		Explanation	Signal inter-		
	Telegram 20	All other tele- grams		connection in the con- verter		
0	0 = OFF1		The motor brakes with the ramp-down time p1121 of the ramp-function generator. The converter switches off the motor at standstill.	p0840[0] = r2090.0		
	0 → 1 = ON		$0 \rightarrow 1 = ON$		The converter goes into the "ready" state. If, in addition bit $3 = 1$ , then the converter switches on the motor.	
1	0 = OFF2		Switch off the motor immediately, the motor then coasts down to a standstill.			
	1 = No OFF2		The motor can be switched on (ON command).			
2	0 = Quick stop (0	OFF3)	Quick stop: The motor brakes to a standstill with the OFF3 ramp-down time p1135.	p0848[0] = r2090.2		
	1 = No quick stop (OFF3)		The motor can be switched on (ON command).			
3	0 = Inhibit operation		Immediately switch-off motor (cancel pulses).	p0852[0] =		
	1 = Enable operation		Switch-on motor (pulses can be enabled).	r2090.3		
4	0 = Disable RFG		The converter immediately sets its ramp-function generator output to 0.	p1140[0] = r2090.4		
	1 = Do not disab	le RFG	The ramp-function generator can be enabled.			

Bit	Significance		Explanation	Signal inter-
	Telegram 20	All other tele- grams		connection in the con- verter
5	0 = Stop RFG		The output of the ramp-function generator stops at the actual value.	p1141[0] = r2090.5
	1 = Enable RFG		The output of the ramp-function generator follows the setpoint.	
6	0 = Inhibit setpo	int	The converter brakes the motor with the rampdown time p1121 of the ramp-function generator.	p1142[0] = r2090.6
	1 = Enable setpo	int	Motor accelerates to the setpoint with the rampup time p1120.	
7	$0 \rightarrow 1 = Acknowledge faults$		Acknowledge fault. If the ON command is still active, the converter switches to the "switching on inhibited" state.	p2103[0] = r2090.7
8, 9	Reserved			
10	0 = No control v	ia PLC	Converter ignores the process data from the fieldbus.	p0854[0] = r2090.10
	1 = Control via P	LC	Control via fieldbus, converter accepts the process data from the fieldbus.	
11	1 = Direction reversal		Invert setpoint in the converter.	p1113[0] = r2090.11
12	Not used			
13	<sup>1)</sup> 1 = MOP up		Increase the setpoint saved in the motorized potentiometer.	p1035[0] = r2090.13
14	<sup>1)</sup> 1 = MOP down		Reduce the setpoint saved in the motorized potentiometer.	p1036[0] = r2090.14
15	CDS bit 0	Reserved	Changes over between settings for different operation interfaces (command data sets).	p0810 = r2090.15

<sup>&</sup>lt;sup>1)</sup> If you change over from another telegram to telegram 20, then the assignment of the previous telegram is kept.

# Status word 1 (ZSW1)

Bit	Significance		Remarks	Signal inter-
	Telegram 20	All other tele- grams		connection in the con- verter
0	1 = Ready for switching on		Power supply switched on; electronics initialized; pulses locked.	p2080[0] = r0899.0
1	1 = Ready		Motor is switched on (ON/OFF1 = 1), no fault is active. With the command "Enable operation" (STW1.3), the converter switches on the motor.	p2080[1] = r0899.1
2	1 = Operation enabled		Motor follows setpoint. See control word 1, bit 3.	p2080[2] = r0899.2
3	1 = Fault active		The converter has a fault. Acknowledge fault using STW1.7.	p2080[3] = r2139.3
4	1 = OFF2 inactive		Coast down to standstill is not active.	p2080[4] = r0899.4

## 8.7 Drive control via PROFIBUS or PROFINET

Bit	it Significance		Remarks	Signal inter-
	Telegram 20	All other tele- grams		connection in the con- verter
5	1 = OFF3 inactive		Quick stop is not active.	p2080[5] = r0899.5
6	1 = Switching on	inhibited active	It is only possible to switch on the motor after an OFF1 followed by ON.	p2080[6] = r0899.6
7	1 = Alarm active		Motor remains switched on; no acknowledgement is necessary.	p2080[7] = r2139.7
8	1 = Speed deviati erance range	on within the tol-	Setpoint / actual value deviation within the tolerance range.	p2080[8] = r2197.7
9	1 = Master contro	ol requested	The automation system is requested to accept the converter control.	p2080[9] = r0899.9
10	1 = Comparison s exceeded	peed reached or	Speed is greater than or equal to the corresponding maximum speed.	p2080[10] = r2199.1
11	1 = current or torque limit reached	1 = torque limit reached	Comparison value for current or torque has been reached or exceeded.	p2080[11] = r0056.13 / r1407.7
12	1)	1 = Holding brake open	Signal to open and close a motor holding brake.	p2080[12] = r0899.12
13	0 = Alarm, motor overtemperature			p2080[13] = r2135.14
14	1 = Motor rotates clockwise		Internal converter actual value > 0.	p2080[14]
	0 = Motor rotates counter-clock- wise		Internal converter actual value < 0.	= r2197.3
15	1 = CDS display	0 = Alarm, converter thermal overload		p2080[15] = r0836.0 / r2135.15

<sup>&</sup>lt;sup>1)</sup> If you change over from another telegram to telegram 20, then the assignment of the previous telegram is kept.

## Control word 3 (STW3)

Bit	Significance	Explanation	Signal interconnec-
	Telegram 350		tion in the converter 1)
0	1 = fixed setpoint bit 0	Selects up to 16 different fixed	p1020[0] = r2093.0
1	1 = fixed setpoint bit 1	setpoints.	p1021[0] = r2093.1
2	1 = fixed setpoint bit 2		p1022[0] = r2093.2
3	1 = fixed setpoint bit 3		p1023[0] = r2093.3
4	1 = DDS selection bit 0	Changes over between settings	p0820 = r2093.4
5	1 = DDS selection bit 1	for different motors (drive data sets).	p0821 = r2093.5
6	Not used		
7	Not used		
8	1 = technology controller enable		p2200[0] = r2093.8
9	1 = enable DC braking		p1230[0] = r2093.9
10	Not used		

Bit	Significance	Explanation	Signal interconnec-
	Telegram 350		tion in the converter 1)
11	Reserved		
12	1 = torque control active	Changes over the control mode	p1501[0] = r2093.12
	0 = speed control active	for vector control.	
13	1 = no external fault		p2106[0] = r2093.13
	0 = external fault is active (F07860)		
14	Not used		
15	1 = CDS bit 1	Changes over between settings for different operation interfaces (command data sets).	p0811[0] = r2093.15

<sup>&</sup>lt;sup>1)</sup> If you switch from telegram 350 to a different one, then the converter sets all interconnections p1020, ... to "0". Exception: p2106 = 1.

## Status word 3 (ZSW3)

Bit	Significance	Description	Signal intercon- nection in the converter
0	1 = DC braking active		p2051[3] = r0053
1	1 =  n_act   > p1226	Absolute current speed > stationary state detection	
2	1 =  n_act   > p1080	Absolute actual speed > minimum speed	
3	1 = i_act ≧ p2170	Actual current ≥ current threshold value	
4	1 =  n_act   > p2155	Absolute actual speed > speed threshold value 2	
5	1 =  n_act   ≤ p2155	Absolute actual speed < speed threshold value 2	
6	1 =  n_act   ≧ r1119	Speed setpoint reached	
7	1 = DC link voltage ≦ p2172	Actual DC link voltage ≤ threshold value	
8	1 = DC link voltage > p2172	Actual DC link voltage > threshold value	
9	1 = ramp-up or ramp-down completed	Ramp-function generator is not active.	
10	1 = technology controller output at the lower limit	Technology controller output ≦ p2292	
11	1 = technology controller output at the upper limit	Technology controller out- put > p2291	
12	Not used		
13	Not used		
14	Not used		
15	Not used		

# 8.7 Drive control via PROFIBUS or PROFINET

# Fault word according to the VIK-NAMUR definition (MELD\_NAMUR)

Bit	Significance	P no.
0	1 = Control Unit signals a fault	p2051[5] = r3113
1	1 = line fault: Phase failure or inadmissible voltage	
2	1 = DC link overvoltage	
3	1 = Power Module fault, e.g. overcurrent or overtemperature	
4	1 = converter overtemperature	
5	1 = ground fault/phase fault in the motor cable or in the motor	
6	1 = motor overload	
7	1 = communication error to the higher-level control system	
8	1 = fault in a safety-relevant monitoring channel	
10	1 = fault in the internal converter communication	
11	1 = line fault	
15	1 = other fault	

## 8.7.3 Parameter channel

## Overview

The parameter channel allows parameter values to be cyclically read and written to.

Parameter channel				
PKE (1st word)	IND (2nd word)		PWE (3rd and 4th words)	
1512:11: 10 0	15 8	7 0	15 0	15 0
AK S PNU	Subindex	Page index	PWE 1	PWE 2
Р				
M				

Structure of the parameter channel:

- PKE (1st word)
  - Type of task (read or write).
  - Bit 11 is reserved and is always assigned 0.
  - Parameter number
- IND (2nd word)
  - Parameter index
- PWE (3rd and 4th word)
  - Parameter value

## **Function description**

## AK: Request and response ID

Table 8-25 Request identifiers, control → converter

AK	Description	Response	Response identifier	
		positive	nega- tive	
0	No request	0	7/8	
1	Request parameter value	1/2	7/8	
2	Change parameter value (word)	1	7/8	
3	Change parameter value (double word)	2	7/8	
4	Request descriptive element 1)	3	7/8	
6 <sup>2)</sup>	Request parameter value (field) 1)	4/5	7/8	
7 2)	Change parameter value (field, word) 1)	4	7/8	
8 2)	Change parameter value (field, double word) 1)	5	7/8	
9	Request number of field elements	6	7/8	

<sup>&</sup>lt;sup>1)</sup> The required element of the parameter is specified in IND (2nd word).

The following request IDs are identical: 1 = 6, 2 = 7 and 3 = 8. We recommend that you use identifiers 6, 7 and 8.

## 8.7 Drive control via PROFIBUS or PROFINET

Table 8-26 Response identifiers, converter → control

AK	Description	
0	No response	
1	Transfer parameter value (word)	
2	Transfer parameter value (double word)	
3	Transfer descriptive element 1)	
4	Transfer parameter value (field, word) <sup>2)</sup>	
5	Transfer parameter value (field, double word) 2)	
6	Transfer number of field elements	
7	Converter cannot process the request. In the most significant word of the parameter channel, the converter sends an error number to the control, refer to the following table.	
8	No master controller status / no authorization to change parameters of the parameter channel interface	

<sup>&</sup>lt;sup>1)</sup> The required element of the parameter is specified in IND (2nd word).

Table 8-27 Error numbers for response identifier 7

No.	Description
00 hex	Illegal parameter number (access to a parameter that does not exist)
01 hex	Parameter value cannot be changed (change request for a parameter value that cannot be changed)
02 hex	Lower or upper value limit exceeded (change request with a value outside the value limits)
03 hex	Incorrect subindex (access to a subindex that does not exist)
04 hex	No array (access with a subindex to non-indexed parameters)
05 hex	<b>Incorrect data type</b> (change request with a value that does not match the data type of the parameter)
06 hex	<b>Setting not permitted, only resetting</b> (change request with a value not equal to 0 without permission)
07 hex	<b>Descriptive element cannot be changed</b> (change request to a descriptive element error value that cannot be changed)
0B hex	No master control (change request but with no master control, see also p0927)
0C hex	Keyword missing
11 hex	Request cannot be executed due to the operating state (access is not possible for temporary reasons that are not specified)
14 hex	<b>Inadmissible value</b> (change request with a value that is within the limits but which is illegal for other permanent reasons, i.e. a parameter with defined individual values)
65 hex	Parameter number is currently deactivated (depending on the mode of the converter)
66 hex	Channel width is insufficient (communication channel is too small for response)
68 hex	Illegal parameter value (parameter can only assume certain values)
6A hex	Request not included / task is not supported (the valid request identifications can be found in table "Request identifications controller → converter")
6B hex	No change access for a controller that is enabled. (The operating state of the converter prevents a parameter change)

<sup>&</sup>lt;sup>2)</sup> The required element of the indexed parameter is specified in IND (2nd word).

No.	Description
86 hex	Write access only for commissioning (p0010 = 15) (operating state of the converter prevents a parameter change)
87 hex	Know-how protection active, access locked
C8 hex	Change request below the currently valid limit (change request to a value that lies within the "absolute" limits, but is however below the currently valid lower limit)
C9 hex	<b>Change request above the currently valid limit</b> (example: a parameter value is too large for the converter power)
CC hex	Change request not permitted (change is not permitted as the access code is not available)

## PNU (parameter number) and page index

Parameter number	PNU	Page index
0000 1999	0000 1999	0 hex
2000 3999	0000 1999	80 hex
6000 7999	0000 1999	90 hex
8000 9999	0000 1999	20 hex
10000 11999	0000 1999	A0 hex
20000 21999	0000 1999	50 hex
30000 31999	0000 1999	F0 hex
60000 61999	0000 1999	74 hex

### Subindex

For indexed parameters, the parameter index is located in subindex as hexadecimal value.

### PWE: Parameter value or connector

Parameter values or connectors can be located in the PWE.

Table 8-28 Parameter value or connector

	PWE 1	PWE 2		
Parameter value	Bit 15 0	Bit 15 8	Bit 7 0	
	0	0	8-bit value	
	0	16-bit value		
	32-bit	t value		
Connector	Bit 15 0	Bit 15 0 Bit 15 10 Bit 9		
	Number of the connector	3F hex	The index or bit field number of the connector	

### **Examples**

### Read request: Read out serial number of the Power Module (r7841[2])

To obtain the value of indexed parameter r7841, you must fill the parameter channel with the following data:

- PKE, Bit 12 ... 15 (AK): = 6 (request parameter value (field))
- PKE, Bit 0 ... 10 (PNU): = 1841 (parameter number without offset)
   Parameter number = PNU + offset (page index)
   (7841 = 1841 + 6000)
- IND, bit 8 ... 15 (subindex): = 2 (index of parameter)
- IND, bit 0 ... 7 (page index): = 90 hex (offset 6000 corresponds to 90 hex)
- Because you want to read the parameter value, words 3 and 4 in the parameter channel for requesting the parameter value are irrelevant. They should be assigned a value of 0, for example.

	Parameter channel					
F	PKE, 1st word IND, 2nd word PWE1 - high, 3rd word PWE2 - low, 4th word					
1512 11	10 0	15 8	7 0	15 0	15 8	7 0
AK	Parameter number	Subindex	Page index	Parameter value	Parameter value	Parameter value
0 1 1 0 0	11100110001	00000010	10010000	0000000000000000000	0000000	00000000

Figure 8-14 Parameter channel for read request from r7841[2]

#### Write request: Change restart mode (p1210)

The restart mode is inhibited in the factory setting (p1210 = 0). In order to activate the automatic restart with "acknowledge all faults and restart for an ON command", p1210 must be set to 26:

- PKE, bit 12 ... 15 (AK): = 7 (change parameter value (field, word))
- PKE, bit 0 ... 10 (PNU): = 4BA hex (1210 = 4BA hex, no offset, as 1210 < 1999)
- IND, bit 8 ... 15 (subindex): = 0 hex (parameter is not indexed)
- IND, bit 0 ... 7 (page index): = 0 hex (offset 0 corresponds to 0 hex)
- PWE1, bit 0 ... 15: = 0 hex
- **PWE2, Bit 0 ... 15:** = **1A hex** (26 = 1A hex)

	Parameter channel				
F	PKE, 1st word IND, 2nd word PWE1 - high, 3rd word PWE2 - low, 4th word				
1512 11	10 0	15 8	7 0	15 0	15 0
AK	Parameter number	Subindex	Page index	Parameter value (bit 16 31)	Parameter value (bit 0 15)
0 1 1 1 0	10010111010	00000000	00000000	000000000000000000	00000000000011010

Figure 8-15 A parameter channel to activate the automatic restart with p1210 = 26

### Write request: Assign digital input 2 with the function ON/OFF1 (p0840[1] = 722.2)

In order to link digital input 2 with ON/OFF1, you must assign parameter p0840[1] (source, ON/OFF1) the value 722.2 (DI 2). To do this, you must fill the parameter channel as follows:

- PKE, bit 12 ... 15 (AK): = 7 hex (change parameter value (field, word))
- PKE, bit 0 ... 10 (PNU): = 348 hex (840 = 348 hex, no offset, as 840 < 1999)

- IND, bit 8 ... 15 (subindex): = 1 hex (CDS1 = Index 1)
- IND, bit 0 ... 7 (page index): = 0 hex (offset 0 corresponds to 0 hex)
- PWE1, Bit 0 ... 15: = 2D2 hex (722 = 2D2 hex)
- **PWE2, Bit 10 ... 15: = 3F hex** (drive object for SINAMICS G120, always 63 = 3f hex)
- PWE2, Bit 0 ... 9: = 2 hex (Index of Parameter (DI 2 = 2))

	Parameter channel						
	PKE, 1st word IND, 2nd word PWE1 - high, 3rd word PWE2 - low, 4th word						
1512	11	10 0	15 8	7 0	15 0	15 10	9 0
AK		Parameter number	Subindex	Page index	Parameter value	Drive Object	Index
0 1 1 1	0	0 1 1 0 1 0 0 1 0 0	00000001	00000000	0 0 0 0 0 0 1 0 1 1 0 1 0 0 1 0	1 1 1 1 1 1	00000000010

Figure 8-16 Parameter channel to assign digital input 2 with ON/OFF1

## **Function description**

### AK: Request and response ID

Table 8-29 Request identifiers, control → converter

AK	Description		eidentifier
		positive	nega- tive
0	No request	0	7/8
1	Request parameter value	1/2	7/8
2	Change parameter value (word)	1	7/8
3	Change parameter value (double word)	2	7/8
4	Request descriptive element 1)	3	7/8
6 <sup>2)</sup>	Request parameter value (field) 1)	4/5	7/8
7 2)	Change parameter value (field, word) 1)	4	7/8
8 2)	Change parameter value (field, double word) 1)	5	7/8
9	Request number of field elements	6	7/8

<sup>1)</sup> The required element of the parameter is specified in IND (2nd word).

Table 8-30 Response identifiers, converter → control

AK	Description
0	No response
1	Transfer parameter value (word)
2	Transfer parameter value (double word)
3	Transfer descriptive element 1)
4	Transfer parameter value (field, word) 2)
5	Transfer parameter value (field, double word) 2)
6	Transfer number of field elements

The following request IDs are identical: 1 = 6, 2 = 7 and 3 = 8. We recommend that you use identifiers 6, 7 and 8.

## 8.7 Drive control via PROFIBUS or PROFINET

AK	Description
7	Converter cannot process the request. In the most significant word of the parameter channel, the converter sends an error number to the control, refer to the following table.
8	No master controller status / no authorization to change parameters of the parameter channel interface

<sup>1)</sup> The required element of the parameter is specified in IND (2nd word).

Table 8-31 Error numbers for response identifier 7

No.	Description
00 hex	Illegal parameter number (access to a parameter that does not exist)
01 hex	Parameter value cannot be changed (change request for a parameter value that cannot be changed)
02 hex	Lower or upper value limit exceeded (change request with a value outside the value limits)
03 hex	Incorrect subindex (access to a subindex that does not exist)
04 hex	No array (access with a subindex to non-indexed parameters)
05 hex	<b>Incorrect data type</b> (change request with a value that does not match the data type of the parameter)
06 hex	<b>Setting not permitted, only resetting</b> (change request with a value not equal to 0 without permission)
07 hex	<b>Descriptive element cannot be changed</b> (change request to a descriptive element error value that cannot be changed)
0B hex	No master control (change request but with no master control, see also p0927.)
0C hex	Keyword missing
11 hex	<b>Request cannot be executed due to the operating state</b> (access is not possible for temporary reasons that are not specified)
14 hex	<b>Inadmissible value</b> (change request with a value that is within the limits but which is illegal for other permanent reasons, i.e. a parameter with defined individual values)
65 hex	Parameter number is currently deactivated (depending on the mode of the converter)
66 hex	Channel width is insufficient (communication channel is too small for response)
68 hex	Illegal parameter value (parameter can only assume certain values)
6A hex	Request not included / task is not supported (the valid request identifications can be found in table "Request identifications controller → converter")
6B hex	No change access for a controller that is enabled. (The operating state of the conerter prevents a parameter change)
86 hex	Write access only for commissioning (p0010 = 15) (operating state of the converter prevents a parameter change)
87 hex	Know-how protection active, access locked
C8 hex	Change request below the currently valid limit (change request to a value that lies within the "absolute" limits, but is however below the currently valid lower limit)
C9 hex	Change request above the currently valid limit (example: a parameter value is too large for the converter power)
CC hex	Change request not permitted (change is not permitted as the access code is not available)
	!

<sup>&</sup>lt;sup>2)</sup> The required element of the indexed parameter is specified in IND (2nd word).

### PNU (parameter number) and page index

Parameter number	PNU	Page index
0000 1999	0000 1999	0 hex
2000 3999	0000 1999	80 hex
6000 7999	0000 1999	90 hex
8000 9999	0000 1999	20 hex
10000 11999	0000 1999	A0 hex
20000 21999	0000 1999	50 hex
29000 29999	0000 1999	70 hex
30000 31999	0000 1999	F0 hex
60000 61999	0000 1999	74 hex

#### **Subindex**

For indexed parameters, the parameter index is located in subindex as hexadecimal value.

#### PWE: Parameter value or connector

Parameter values or connectors can be located in the PWE.

Table 8-32 Parameter value or connector

	PWE 1	PWE 2		
Parameter value	Bit 15 0	Bit 15 8	Bit 7 0	
	0	0	8-bit value	
	0	16-bit value		
	32-bit value			
Connector	Bit 15 0	Bit 15 10	Bit 9 0	
	Number of the connector	3F hex	The index or bit field number of the connec- tor	

## **Examples**

### Read request: Read out serial number of the Power Module (r7841[2])

To obtain the value of the indexed parameter r7841, you must fill the telegram of the parameter channel with the following data:

- PKE, Bit 12 ... 15 (AK): = 6 (request parameter value (field))
- PKE, Bit 0 ... 10 (PNU): = 1841 (parameter number without offset)
   Parameter number = PNU + offset (page index)
   (7841 = 1841 + 6000)
- IND, bit 8 ... 15 (page index): = 2 (index of parameter)

- IND, bit 0 ... 7 (subindex): = 90 hex (offset 6000 corresponds to 90 hex)
- Because you want to read the parameter value, words 3 and 4 in the parameter channel for requesting the parameter value are irrelevant. They should be assigned a value of 0, for example.

Γ	Parameter channel							
PKE, 1st word			KE, 1st word	IND, 2r	nd word	PWE1 - high, 3rd word	PWE2 - lov	v, 4th word
Γ	1512	11	10 0	15 8	7 0	15 0	15 8	7 0
Γ	AK		Parameter number	Page index	Subindex	Parameter value	Parameter value	Parameter value
(	0 1 1 0	0	1 1 1 0 0 1 1 0 0 0 1	00000010	10010000	0000000000000000000	0000000	00000000

Figure 8-17 Telegram for a read request from r7841[2]

### PNU (parameter number) and page index

Parameter number	PNU	Page index
0000 1999	0000 1999	0 hex
2000 3999	0000 1999	80 hex
6000 7999	0000 1999	90 hex
8000 9999	0000 1999	20 hex
10000 11999	0000 1999	A0 hex
20000 21999	0000 1999	50 hex
30000 31999	0000 1999	F0 hex
60000 61999	0000 1999	74 hex

#### **Subindex**

For indexed parameters, the parameter index is located in subindex as hexadecimal value.

### PWE: Parameter value or connector

Parameter values or connectors can be located in the PWE.

Table 8-33 Parameter value or connector

	PWE 1		PWE 2
Parameter value	Bit 15 0	Bit 15 8	Bit 7 0
	0	0	8-bit value
	0	16	-bit value
	32-bit	value	
Connector	Bit 15 0	Bit 15 10	Bit 9 0
	Number of the connector	3F hex	The index or bit field number of the connector

### 8.7.4 Examples

### Read request: Read out serial number of the Power Module (p7841[2])

To obtain the value of the indexed parameter p7841, you must fill the telegram of the parameter channel with the following data:

- PKE, Bit 12 ... 15 (AK): = 6 (request parameter value (field))
- PKE, Bit 0 ... 10 (PNU): = 1841 (parameter number without offset)
   Parameter number = PNU + offset (page index)
   (7841 = 1841 + 6000)
- IND, bit 8 ... 15 (subindex): = 2 (index of parameter)
- IND, bit 0 ... 7 (page index): = 90 hex (offset 6000 corresponds to 90 hex)
- Because you want to read the parameter value, words 3 and 4 in the parameter channel for requesting the parameter value are irrelevant. They should be assigned a value of 0, for example.

	Parameter channel						
PKE, 1st word		PKE, 1st word	IND, 2r	nd word	PWE1 - high, 3rd word	PWE2	- low, 4th word
1512	11	10 0	15 8	7 0	15 0	15 10	9 0
AK		Parameter number	Subindex	Page index	Parameter value	Drive object	Index
0 1 1 0	0	1 1 1 0 0 1 1 0 0 0 1	00000010	10010000	0000000000000000000	000000	00000000000

Figure 8-18 Telegram for a read request from p7841[2]

#### Write request: Change restart mode (p1210)

The restart mode is inhibited in the factory setting (p1210 = 0). In order to activate the automatic restart with "acknowledge all faults and restart for an ON command", p1210 must be set to 26:

- PKE, bit 12 ... 15 (AK): = 7 (change parameter value (field, word))
- PKE, bit 0 ... 10 (PNU): = 4BA hex (1210 = 4BA hex, no offset, as 1210 < 1999)
- IND, bit 8 ... 15 (subindex): = 0 hex (parameter is not indexed)
- IND, bit 0 ... 7 (page index): = 0 hex (offset 0 corresponds to 0 hex)
- PWE1, bit 0 ... 15: = 0 hex
- **PWE2, Bit 0 ... 15:** = **1A hex** (26 = 1A hex)

	Parameter channel					
PKE, 1st word		PKE, 1st word	IND, 2r	nd word	PWE1 - high, 3rd word	PWE2 - low, 4th word
1512	11	10 0	15 8	7 0	15 0	15 0
AK		Parameter number	Subindex	Page index	Parameter value (bit 16 31)	Parameter value (bit 0 15)
0 1 1 1	0	10010111010	00000000	0000000	0000000000000000000	00000000000011010

Figure 8-19 Telegram, to activate the automatic restart with p1210 = 26

## Write request: Assign digital input 2 with the function ON/OFF1 (p0840[1] = 722.2)

In order to link digital input 2 with ON/OFF1, you must assign parameter p0840[1] (source, ON/OFF1) the value 722.2 (DI 2). To do this, you must populate the telegram of the parameter channel as follows:

- PKE, bit 12 ... 15 (AK): = 7 hex (change parameter value (field, word))
- **PKE, bit 0 ... 10 (PNU): = 348 hex** (840 = 348 hex, no offset, as 840 < 1999)

## 8.7 Drive control via PROFIBUS or PROFINET

- IND, bit 8 ... 15 (subindex): = 1 hex (CDS1 = Index 1)
- IND, bit 0 ... 7 (page index): = 0 hex (offset 0 corresponds to 0 hex)
- **PWE1, Bit 0 ... 15**: = **2D2 hex** (722 = 2D2 hex)
- **PWE2, Bit 10 ... 15: = 3F hex** (drive object for SINAMICS G120, always 63 = 3f hex)
- **PWE2, Bit 0 ... 9: = 2 hex** (Index of Parameter (DI 2 = 2))

	Parameter channel						
PKE, 1st word			IND, 2r	nd word	PWE1 - high, 3rd word	PWE2	- low, 4th word
1512	11	10 0	15 8	7 0	15 0	15 10	9 0
AK		Parameter number	Subindex	Page index	Parameter value	Drive Object	Index
0 1 1 1 0 0 1 1 0 1 0 0 1 0 0		00000001	00000000	0 0 0 0 0 0 1 0 1 1 0 1 0 0 1 0	1 1 1 1 1 1	00000000010	

Figure 8-20 Telegram, to assign DI 2 with ON/OFF1

## 8.7.5 Expanding or freely interconnecting telegrams

#### Overview

When you have selected a telegram, the converter interconnects the corresponding signals with the fieldbus interface. Generally, these interconnections are locked so that they cannot be changed. However, with the appropriate setting in the converter, the telegram can be extended or even freely interconnected.

## **Function description**

#### Interconnection of send data and receive data




Figure 8-21 Interconnection of the send data

In the converter, the send data are available in the "Word" format (p2051) - and in the "Double word" format (p2061). If you set a specific telegram, or you change the telegram, the converter automatically interconnects parameters p2051 and p2061 with the appropriate signals.




Figure 8-22 Interconnection of the receive data

#### 8.7 Drive control via PROFIBUS or PROFINET

The converter saves the receive data as follows:

- "Word" format in r2050
- "Double word" format in r2060
- Bit-by-bit in r2090 ... r2093

### **Extending a telegram: Procedure**

- 1. Set p0922 = 999.
- 2. Set parameter p2079 to the value of the corresponding telegram.
- 3. Interconnect additional send words and receive words with signals of your choice via parameters r2050 and p2051.

You have extended a telegram.

### Freely interconnecting signals in the telegram: Procedure

- 1. Set p0922 = 999.
- 2. Set p2079 = 999.
- 3. Interconnect additional send words and receive words with signals of your choice via parameters r2050 and p2051.

You have freely interconnected a telegram.

## Example

You wish to extend telegram 1 to 6 send words and 6 receive words. You want to test the extension by initiating that the converter returns each receive word back to the higher-level control system.

### **Procedure**

- 1. p0922 = 999
- 2. p2079 = 1
- 3. p2051[2] = r2050[2]
- 4. ...
- 5. p2051[5] = r2050[5]
- 6. Test the telegram length for received and sent words:
  - r2067[0] = 6
  - r2067[1] = 6

You wish to extend telegram 1 to 6 send words and 6 receive words.

### **Parameter**

Number	Name	Factory setting
p0922	PROFIdrive PZD telegram selection	1
r2050[011]	CO: PROFIdrive PZD receive word	-
p2051[016]	CI: PROFIdrive PZD send word	0 or dependent on the converter
r2053[016]	PROFIdrive diagnostics send PZD word	-
r2060[010]	CO: PROFIdrive PZD receive double word	-
p2061[015]	CI: PROFIdrive PZD send double word	0
r2063[015]	PROFIdrive diagnostics PZD send double word	-
r2067	PZD maximum interconnected	-
	[0] Receive (r2050, r2060)	
	[1] Send (p2051, p2061)	
p2079	PROFIdrive PZD telegram selection extended	1
p2080[015]	BI: Binector-connector converter, status word 1	[0] 899
		[1] 899.1
		[2] 899.2
		[3] 2139.3
		[4] 899.4
		[5] 899.5
		[6] 899.6
		[7] 2139.7
		[8] 2197.7
		[9] 899.9
		[10] 2199.1
		[11] 1407.7
		[12] 0
		[13] 2135.14
		[14] 2197.3
		[15] 2135.15
r2090.015	BO: PROFIdrive receive PZD1 bit by bit	-
r2091.015	BO: PROFIdrive PZD2 receive bit-serial	-
r2092.015	BO: PROFIdrive PZD3 receive bit-serial	-
r2093.015	BO: PROFIdrive PZD4 receive bit-serial	-

## 8.7.6 Device-to-device communication

### Overview

"Direct data exchange" is sometimes called "device-to-device communication" or "data exchange broadcast". With direct data exchange, devices exchange data without any direct involvement of the master.

#### 8.7 Drive control via PROFIBLIS or PROFINET

### Additional information

Further information about the "Direct data exchange" function is provided in the Fieldbus function manual.

Overview of the manuals (Page 581)

#### 8.7.7 Acyclically reading and writing converter parameters

### Overview

The converter supports the writing and reading of parameters via acyclic communication:

- For PROFIBUS: Up to 240 bytes per write or read request via data set 47
- For PROFINET: Write or read requests via B02E hex and B02F hex

### Example

### Application example, "Read and write to parameters"

Further information is provided on the Internet:



Application examples (<a href="https://support.industry.siemens.com/cs/ww/en/view/29157692">https://support.industry.siemens.com/cs/ww/en/view/29157692</a>)

## **Further information**

Further information about acyclic communication is provided in the Fieldbus function manual.



Overview of the manuals (Page 581)

## 8.8 Drive control via USS

### Overview



USS is used to transfer cyclic process data and acyclic parameter data between precisely one master and up to 31 devices. The converter is always the device, and sends data when requested to do so by the master. Device-to-device communication is not possible.

## **Function description**

## Control word 1 (STW1)

Bit	Meaning	Explanation	Signal inter- connection in the con- verter
0	0 = OFF1	The motor brakes with the ramp-down time p1121 of the ramp-function generator. The converter switches off the motor at standstill.	p0840[0] = r2090.0
	$0 \rightarrow 1 = ON$	The converter goes into the "ready" state. If, in addition, bit $3 = 1$ , the converter switches on the motor.	
1	0 = OFF2	Switch off the motor immediately, the motor then coasts down to a standstill.	p0844[0] = r2090.1
	1 = No OFF2	The motor can be switched on (ON command).	
2	0 = Quick stop (OFF3)	Quick stop: The motor brakes with the OFF3 rampdown time p1135 down to standstill.	p0848[0] = r2090.2
	1 = No quick stop (OFF3)	The motor can be switched on (ON command).	
3	0 = Inhibit operation	Immediately switch-off motor (cancel pulses).	p0852[0] =
	1 = Enable operation	Switch-on motor (pulses can be enabled).	r2090.3
4	0 = Disable RFG	The converter immediately sets its ramp-function generator output to 0.	p1140[0] = r2090.4
	1 = Do not disable RFG	The ramp-function generator can be enabled.	
5	0 = Stop RFG	The output of the ramp-function generator stops at the actual value.	p1141[0] = r2090.5
	1 = Enable RFG	The output of the ramp-function generator follows the setpoint.	
6	0 = Inhibit setpoint	The converter brakes the motor with the ramp-down time p1121 of the ramp-function generator.	p1142[0] = r2090.6
	1 = Enable setpoint	Motor accelerates with the ramp-up time p1120 to the setpoint.	
7	$0 \rightarrow 1 = Acknowledge$ faults	Acknowledge fault. If the ON command is still active, the converter switches to the "switching on inhibited" state.	p2103[0] = r2090.7
8, 9	Reserved		
10	0 = No control via PLC	Converter ignores the process data from the fieldbus.	p0854[0] =
	1 = Control via PLC	Control via fieldbus, converter accepts the process data from the fieldbus.	r2090.10

## 8.8 Drive control via USS

Bit	Meaning	Explanation	Signal inter- connection in the con- verter
11	1 = Direction reversal	Invert setpoint in the converter.	p1113[0] = r2090.11
12	Reserved		
13	1 = MOP up	Increase the setpoint saved in the motorized potentiometer.	p1035[0] = r2090.13
14	1 = MOP down	Reduce the setpoint saved in the motorized potentiometer.	p1036[0] = r2090.14
15	Reserved		

## Status word 1 (ZSW1)

Bit	Meaning	Remarks	Signal inter- connection in the con- verter
0	1 = Ready for switching on	Power supply switched on; electronics initialized; pulses locked.	p2080[0] = r0899.0
1	1 = Ready	Motor is switched on (ON/OFF1 = 1), no fault is active. With the command "Enable operation" (STW1.3), the converter switches on the motor.	p2080[1] = r0899.1
2	1 = Operation enabled	Motor follows setpoint. See control word 1, bit 3.	p2080[2] = r0899.2
3	1 = Fault active	The converter has a fault. Acknowledge fault using STW1.7.	p2080[3] = r2139.3
4	1 = OFF2 inactive	Coast down to standstill is not active.	p2080[4] = r0899.4
5	1 = OFF3 inactive	Quick stop is not active.	p2080[5] = r0899.5
6	1 = Switching on inhibited active	It is only possible to switch on the motor after an OFF1 followed by ON.	p2080[6] = r0899.6
7	1 = Alarm active	Motor remains switched on; no acknowledgement is necessary.	p2080[7] = r2139.7
8	1 = Speed deviation with- in the tolerance range	Setpoint / actual value deviation within the tolerance range.	p2080[8] = r2197.7
9	1 = Master control requested	The automation system is requested to accept the converter control.	p2080[9] = r0899.9
10	1 = Comparison speed reached or exceeded	Speed is greater than or equal to the corresponding maximum speed.	p2080[10] = r2199.1
11	1 = Torque limit not reached	Comparison value for current or torque has been fallen below.	p2080[11] = r0056.13 / r1407.7
12	Reserved		p2080[12] = r0899.12
13	0 = Alarm, motor over- temperature		p2080[13] = r2135.14

Bit	Meaning	Remarks	Signal inter- connection in the con- verter
14	1 = Motor rotates clock- wise	Internal converter actual value > 0	p2080[14] = r2197.3
	0 = Motor rotates counter-clockwise	Internal converter actual value < 0	
15	0 = Alarm, converter thermal overload		p2080[15] = r2135.15

### **Parameter**

Parameter	Description	Factory setting
p2020	Fieldbus interface baud rate	8
p2021	Fieldbus interface address	0
p2022	Fieldbus interface USS PZD number	2
p2023	Fieldbus interface USS PKW number	127
p2024	Fieldbus interface times	[0] 1000 ms [1] 0 ms [2] 0 ms
r2029	Fieldbus interface error statistics	-
p2030	Fieldbus interface protocol selection	0
p2031	Fieldbus interface Modbus parity	2
p2040	Fieldbus interface monitoring time	100 ms

## **Further information**

Additional information about USS is provided in the "Fieldbus" function manual.



Overview of the manuals (Page 581)

## 8.9 Drive control via Modbus RTU

### Overview



Modbus RTU is used to transfer cyclic process data and acyclic parameter data between precisely one master and up to 247 slaves. The converter is always the slave, and sends data when requested to do so by the master. Slave-to-slave communication is not possible.

## **Function description**

## Control word 1 (STW1)

Bit	Meaning	Explanation	Signal inter- connection in the con- verter	
0	0 = OFF1	The motor brakes with the ramp-down time p1121 of the ramp-function generator. The converter switches off the motor at standstill.		
	$0 \rightarrow 1 = ON$	The converter goes into the "ready" state. If, in addition, bit $3 = 1$ , the converter switches on the motor.		
1	0 = OFF2	Switch off the motor immediately, the motor then coasts down to a standstill.	p0844[0] = r2090.1	
	1 = No OFF2	The motor can be switched on (ON command).		
2	0 = Quick stop (OFF3)	Quick stop: The motor brakes with the OFF3 rampdown time p1135 down to standstill.	p0848[0] = r2090.2	
	1 = No quick stop (OFF3)	The motor can be switched on (ON command).		
3	0 = Inhibit operation	Immediately switch-off motor (cancel pulses).	p0852[0] =	
	1 = Enable operation	Switch-on motor (pulses can be enabled).	r2090.3	
4	0 = Disable RFG	The converter immediately sets its ramp-function generator output to 0.	its ramp-function gen- r2090.4	
	1 = Do not disable RFG	The ramp-function generator can be enabled.		
5	0 = Stop RFG	The output of the ramp-function generator stops at the actual value.	p1141[0] = r2090.5	
	1 = Enable RFG	The output of the ramp-function generator follows the setpoint.		
6	0 = Inhibit setpoint	The converter brakes the motor with the ramp-down time p1121 of the ramp-function generator.	p1142[0] = r2090.6	
	1 = Enable setpoint	Motor accelerates with the ramp-up time p1120 to the setpoint.		
7	$0 \rightarrow 1 = Acknowledge$ faults	Acknowledge fault. If the ON command is still active, the converter switches to the "switching on inhibited" state.	p2103[0] = r2090.7	
8, 9	Reserved			
10	0 = No control via PLC	Converter ignores the process data from the fieldbus.	p0854[0] =	
	1 = Control via PLC	Control via fieldbus, converter accepts the process data from the fieldbus.	r2090.10	

Bit	Meaning	Explanation	Signal inter- connection in the con- verter		
11	1 = Direction reversal	Invert setpoint in the converter.	p1113[0] = r2090.11		
12	Reserved				
13	1 = MOP up	Increase the setpoint saved in the motorized potentiometer.	p1035[0] = r2090.13		
14	1 = MOP down	Reduce the setpoint saved in the motorized potentiometer.	p1036[0] = r2090.14		
15	Reserved				

## Status word 1 (ZSW1)

Bit	Meaning	Remarks	Signal intercon- nection in the converter
0	1 = Ready for switching on	Power supply switched on; electronics initialized; pulses locked.	p2080[0] = r0899.0
1	1 = Ready	Motor is switched on (ON/OFF1 = 1), no fault is active. With the command "Enable operation" (STW1.3), the converter switches on the motor.	p2080[1] = r0899.1
2	1 = Operation enabled	Motor follows setpoint. See control word 1, bit 3.	p2080[2] = r0899.2
3	1 = Fault active	The converter has a fault. Acknowledge fault using STW1.7.	p2080[3] = r2139.3
4	1 = OFF2 inactive	Coast down to standstill is not active.	p2080[4] = r0899.4
5	1 = OFF3 inactive	Quick stop is not active.	p2080[5] = r0899.5
6	1 = Switching on inhibited active	It is only possible to switch on the motor after an OFF1 followed by ON.	p2080[6] = r0899.6
7	1 = Alarm active	Motor remains switched on; no acknowledgement is necessary.	p2080[7] = r2139.7
8	1 = Speed deviation within the tolerance range	Setpoint / actual value deviation within the tolerance range.	p2080[8] = r2197.7
9	1 = Master control requested	The automation system is requested to accept the converter control.	p2080[9] = r0899.9
10	1 = Comparison speed reached or exceeded	Speed is greater than or equal to the corresponding maximum speed.	p2080[10] = r2199.1
11	1 = Torque limit not reached	Comparison value for current or torque has been fallen below.	p2080[11] = r0056.13 / r1407.7
12	Reserved		p2080[12] = r0899.12
13	0 = Alarm, motor overtemperature		p2080[13] = r2135.14

### 8.9 Drive control via Modbus RTU

Bit	Meaning	Remarks	Signal intercon- nection in the converter
14	1 = Motor rotates clockwise	Internal converter actual value > 0	p2080[14] =
	0 = Motor rotates counter- clockwise	Internal converter actual value < 0	r2197.3
15	0 = Alarm, converter thermal overload		p2080[15] = r2135.15

<sup>1)</sup> If you change over from another telegram to telegram 20, then the assignment of the previous telegram is kept.

### **Parameter**

Table 8-34 Settings for Modbus RTU

Parameter	Description	Factory setting
p2020	Fieldbus interface baud rate	8
p2021	Fieldbus interface address	0
p2024	Fieldbus interface times	[0] 1000 ms [1] 0 ms [2] 0 ms
r2029	Fieldbus interface error statistics	-
p2030	Fieldbus interface protocol selection	0
p2031	Fieldbus interface Modbus parity	2
p2040	Fieldbus interface monitoring time	100 ms

### **Further information**

Further informationAdditional information about Modbus RTU is provided in the "Fieldbus" function manual.

Overview of the manuals (Page 581)

# 8.10 Drive control via Ethernet/IP

### Overview



EtherNet/IP is an Ethernet-based fieldbus. EtherNet/IP is used to transfer cyclic process data as well as acyclic parameter data.

## **Function description**

Parameter	Description			
p2030 = 10	Fieldbus interface protocol selection: Ethernet/IP			
p8924	PN DHCP mode	0: DHCP off		
		2: DHCP on, identification b	ased on MAC address	
		3: DHCP on, identification b	ased on Name of Station	
p8925	PN interfaces configuration	0: No function		
		1: Reserved		
		2: Save the configuration and activate		
		3: Delete configuration		
p8980	Ethernet/IP profile		0: SINAMICS	
	A change only becomes active supply is switched off and swit		1: ODVA AC/DC	
p8982	Ethernet/IP ODVA speed scal	ing		
	A change only becomes active switched on again.	after the converter power su	upply is switched off and	
	123: 32	127: 2	131: 0.125	
	124: 16	128: 1	132: 0.0625	
	125: 8	129: 0.5	133: 0.03125	
	126: 4	130: 0.25		

### **Parameter**


## Settings for Ethernet/IP

Parameter	Description	Factory setting
p2030	Fieldbus interface protocol selection	0
p8920	PN Name of Station	-
p8921[03]	PN IP Address	0
p8922[03]	PN Default Gateway	0
p8923[03]	PN Subnet Mask	0
p8924	PN DHCP mode	0
p8925	Activate PN interface configuration	0
p8980	EtherNet/IP profile	0
p8982	EtherNet/IP ODVA speed scaling	128

## 8.10 Drive control via Ethernet/IP

## **Further information**

Additional information about USS is provided in the "Fieldbus" function manual.



## 8.11 Drive control via BACnet MS/TP

## **Settings for BACnet MS/TP**

Parameter	Explanation			
p2020	Fieldbus interface baudrate (Factory setting: 8)	6: 9600 baud 7: 19200 baud	8: 38400 baud 10: 76800 baud	
p2021	· ·			
p2024	Fieldbus interface times	[0] maximum permissible proce	essing time (APDU timeout)	
p2025	Fieldbus SS BACnet set- tings	et- [0] = device object instance number [1] = info maximum number frames [2] = APDU number of retries [3] = maximum manager address		
p2026	Fieldbus interface BACn Change in value at which and ConfirmedCOVNotific	point the converter sends and l	JnConfirmedCOVNotification or	
r2029	Fieldbus interface error statistics	[0] number of error-free telegrams [1] number of rejected telegrams [2] number of framing errors [3] number of overrun errors	<ul><li>[4] number of parity errors</li><li>[5] number of starting character errors</li><li>[6] number of checksum errors</li><li>[7] number of length errors</li></ul>	
p2030 = 5	Fieldbus interface protocol selection p0015 = 110 sets p2013 = 5 → BACnet MS/TP			
p2040	<b>Fieldbus interface monitoring time</b> (Factory setting: 10 s) p2040 = 0: Monitoring is deactivated			

## Control word 1 (STW1)

Bit	Meaning	Explanation	BACNet	Signal inter- connection in the converter
0	0 = OFF1	The motor brakes with the ramp-down time p1121 of the ramp-function generator. The converter switches off the motor at standstill.		p0840[0] = r2090.0
	0 → 1 = ON	The converter goes into the "ready" state. If, in addition, bit 3 = 1, the converter switches on the motor.		

## 8.11 Drive control via BACnet MS/TP

Bit	Meaning	Explanation	BACNet	Signal inter- connection in the converter
1	0 = OFF2	Switch off the motor immediately, the motor then coasts down to a standstill.	BV27	p0844[0] = r2090.1
	1 = No OFF2	The motor can be switched on (ON command).	·	
2	0 = Quick stop (OFF3)	Quick stop: The motor brakes with the OFF3 ramp-down time p1135 down to standstill.	BV28	p0848[0] = r2090.2
	1 = No quick stop (OFF3)	The motor can be switched on (ON command).		
3	0 = Inhibit operation	Immediately switch-off motor (cancel pulses).	BV26	p0852[0] = r2090.3
	1 = Enable operation	Switch-on motor (pulses can be enabled).		
4	0 = Disable RFG	The converter immediately sets its ramp-function generator output to 0.	BV26	p1140[0] = r2090.4
	1 = Do not disable RFG	The ramp-function generator can be enabled.		
5	0 = Stop RFG	The output of the ramp-function generator stops at the actual value.	BV26	p1141[0] = r2090.5
	1 = Enable RFG	The output of the ramp-function generator follows the setpoint.		
6	0 = Inhibit setpoint	The converter brakes the motor with the ramp-down time p1121 of the ramp-function generator.	BV26	p1142[0] = r2090.6
	1 = Enable setpoint	Motor accelerates with the ramp-up time p1120 to the setpoint.		
7	0 → 1 = Acknowledge faults	Acknowledge fault. If the ON command is still active, the converter switches to the "switching on inhibited" state.	BV22	p2103[0] = r2090.7
8, 9	Reserved		N/A	
10	0 = No control via PLC	Converter ignores the process data from the fieldbus.	BV93	p0854[0] = r2090.10
	1 = Control via PLC	Control via fieldbus, converter accepts the process data from the fieldbus.		
11	1 = Direction reversal	Invert setpoint in the converter.	BV21	p1113[0] = r2090.11
12	Reserved		N/A	
13	1 = MOP up	Increase the setpoint saved in the motorized potentiometer.	N/A	p1035[0] = r2090.13
14	1 = MOP down	Reduce the setpoint saved in the motorized potentiometer.	N/A	p1036[0] = r2090.14
15	Reserved		N/A	

## Status word 1 (ZSW1)

Bit	Meaning	Remarks	Signal interconnection in the converter
0	1 = Ready for switching on	Power supply switched on; electronics initialized; pulses locked.	p2080[0] = r0899.0
1	1 = Ready	Motor is switched on (ON/OFF1 = 1), no fault is active. With the command "Enable operation" (STW1.3), the converter switches on the motor.	p2080[1] = r0899.1
2	1 = Operation enabled	Motor follows setpoint. See control word 1, bit 3.	p2080[2] = r0899.2
3	1 = Fault active	The converter has a fault. Acknowledge fault using STW1.7.	p2080[3] = r2139.3
4	1 = OFF2 inactive	Coast down to standstill is not active.	p2080[4] = r0899.4
5	1 = OFF3 inactive	Quick stop is not active.	p2080[5] = r0899.5
6	1 = Switching on inhibited active	It is only possible to switch on the motor after an OFF1 followed by ON.	p2080[6] = r0899.6
7	1 = Alarm active	Motor remains switched on; no acknowledgement is necessary.	p2080[7] = r2139.7
8	1 = Speed deviation within the tolerance range	Setpoint / actual value deviation within the tolerance range.	p2080[8] = r2197.7
9	1 = Master control requested	The automation system is requested to accept the converter control.	p2080[9] = r0899.9
10	1 = Comparison speed reached or exceeded	Speed is greater than or equal to the corresponding maximum speed.	p2080[10] = r2199.1
11	1 = Torque limit not reached	Comparison value for current or torque has been fallen below.	p2080[11] = r0056.13 / r1407.7
12	Reserved		p2080[12] = r0899.12
13	0 = Alarm, motor overtemperature		p2080[13] = r2135.14
14	1 = Motor rotates clockwise	Internal converter actual value > 0	p2080[14] = r2197.3
	0 = Motor rotates counter-clock- wise	Internal converter actual value < 0	
15	0 = Alarm, converter thermal overload		p2080[15] = r2135.15

<sup>1)</sup> If you change over from another telegram to telegram 20, then the assignment of the previous telegram is kept.

### **Further information**

You can find additional information about BACnet MS/TP in the "Fieldbus" function manual:

Overview of the manuals (Page 581).

#### **Drive control via P1** 8.12

## **Settings for P1**

Parameter	Explanation				
p2020	Fieldbus interface baudrate	5: 4800 baud			
	(Factory setting: 5)	6: 9600 baud			
		7: 19200 baud			
p2021	Fieldbus interface address (F	actory setting: 99)			
	Valid addresses: 1 99.				
	The parameter is only active if address 0 is set at the Control Unit address switch.				
	A change only becomes active switched on again.	after the converter power su	upply is switched off and		
p2024	Fieldbus interface times	[0] Maximum permissible telegram processing time of			
	(Factory setting: [0] 1000 ms, [1] 0 ms, [2] 0 ms)	the Modbus device			
		[1] Character delay time			
		[2] Dead time between two	telegrams		
r2029	Fieldbus interface error sta-	[0] number of error-free	[4] number of parity errors		
	tistics	telegrams	[5] number of starting		
		[1] number of rejected telegrams	character errors		
		[2] number of framing er-	[6] number of checksum		
		rors	[7] number of length errors		
		[3] number of overrun er-	[/] number of length enois		
		rors			
p2030 = 8	Fieldbus interface protocol se	election: P1			
p2040 Fieldbus interface monitoring time (Factory setting: 100 ms)			ms)		
	p2040 = 0: Monitoring is deactivated				

## **Further information**

Additional information about P1 is provided in the "Fieldbus" function manual.



Overview of the manuals (Page 581).

## 8.13 Jogging

#### Overview




The "Jog" function is typically used to temporarily move a motor using local control commands.

### Requirement

The OFF1 command must be active. With an active ON command, the converter ignores the commands "Jogging 1" and "Jogging 2".

### **Function description**



Commands "Jog 1" or "Jog 2" switch the motor on and off.

The commands are only active when the converter is in the "Ready for switching on" state.




Figure 8-23 Behavior of the motor when "jogging"

After switching on, the motor accelerates to the setpoint, jog 1 or setpoint, jog 2. The two different setpoints can, for example, be assigned to motor clockwise and counter-clockwise rotation.

When jogging, the same ramp-function generator is active as for the ON/OFF1 command.

## Example

Parameter	Description
p1055 = 722.0	Jogging bit 0: Select jogging 1 via digital input 0
p1056 = 722.1	Jogging bit 1: Select jogging 2 via digital input 1

## 8.13 Jogging

## Parameter

Number	Name	Factory setting
p1055[C]	BI: Jogging bit 0	Depending on the converter
p1056[C]	BI: Jogging bit 1	Depending on the converter
p1058[D]	Jogging 1 speed setpoint	150 rpm
p1059[D]	Jogging 2 speed setpoint	-150 rpm
p1082[D]	Maximum speed	1500 rpm
p1110[C]	BI: Inhibit negative direction	Depending on the converter
p1111[C]	BI: Inhibit positive direction	0
p1113[C]	BI: Setpoint inversion	0
p1120[D]	Ramp-function generator ramp-up time	Depending on the converter
p1121[D]	Ramp-function generator ramp-down time	Depending on the converter

## 8.14 Switching over the drive control (command data set)

#### Overview



Several applications require the option of switching over the master control to operate the converter.




Figure 8-24 Converter control either via fieldbus or via terminal strip

## **Function description**

#### Command data set (CDS)

You can set the converter control in various ways and toggle between the settings.

The settings in the converter, which are assigned to a specific master control, are called the command data set.

You select the command data set using parameters p0810 and p0811. To do this, you must interconnect parameters p0810 and p0811 with control commands of your choice, e.g. a digital input.

#### Changing the number of command data sets

Up to 4 command data sets are possible.

- 1. Set p0010 = 15.
- 2. The number of command data sets is configured with p0170.
- 3. Set p0010 = 0.

You have changed the number of command data sets.


## Copying command data sets

- 1. Set p0809[0] to the number of the command data set whose settings you wish to copy (source).
- 2. Set p0809[1] to the number of the command data set into which you wish to copy the settings.
- 3. Set p0809[2] = 1
- 4. The converter sets p0809[2] = 0.

You have copied the settings of a command data set into another command data set.

8.14 Switching over the drive control (command data set)

## Example



The converter evaluates its control commands depending on digital input DI 3:

- Via a fieldbus from a central control system
- Via the converter digital inputs at the installation.

#### Note

The converter requires approx. 4 ms to switch over the command data set.

#### **Parameters**

Number	Name	Factory setting
p0010	Drive commissioning parameter filter	1
r0050	CO/BO: Command data set CDS effective	-
p0170	Number of command data sets (CDS)	2
p0809[0 2]	Copy command data set CDS	0
p0810	BI: Command data set selection CDS bit 0	Dependent on the converter
p0811	BI: Command data set selection CDS bit 1	0

## 8.15 Free function blocks

## 8.15.1 Overview

### Overview



The free function blocks permit configurable signal processing in the converter.

## **Function description**

The following free function blocks are available:

Table 8-35 Free function blocks

Logic blocks	AND 0	OR 0	XOR 0	NOT 0			
Logic blocks	AND 1	OR 1	XOR 1	NOT 1			
	AND 2	OR 2	XOR 2	NOT 2			
	AND 3	OR 3	XOR 2 XOR 3	NOT 3			
	AIND 3	OK 5	AUK 3	NOT 4			
				NOT 5			
		6.1.	N.A. 111 11		6	A1 1 .	D 1 11
Calculation blocks	Adder	Subtractor	Multiplier	Divider	Compara- tor	Absolute value	Polyline
	ADD 0	SUB 0	MUL 0	DIV 0	NCM 0	AVA 0	PLI 0
	ADD 1	SUB 1	MUL 1	DIV 1	NCM 1	AVA 1	PLI 1
	ADD 2						
Timer blocks	Pulse gen- erator	Pulse shorten-	ON delay	OFF delay	Pulse stretching		
		ing					
	MFP 0	PCL 0	PDE 0	PDF 0	PST 0		
	MFP 1	PCL 1	PDE 1	PDF 1	PST 1		
	MFP 2		PDE 2	PDF 2			
	MFP 3		PDE 3	PDF 3			
Memory block	RS flip-flop	D flip-flop					
	RSR 0	DFR 0					
	RSR 1	DFR 1					
	RSR 2	DFR 2					
Breaker block	Analog switch	Binary switch					
	NSW 0	BSW 0					
	NSW 1 BSW 1						
Control block	Limiter	Smooth- ing	Integrator	Differentiator			
	LIM 0	PT1 0	INT 0	DIF 0			
	LIM 1	PT1 1					

## 8.15 Free function blocks

Complex block	Limit monitor
	LVM 0
	LVM 1

You can only use a function block once. The converter has 3 adders for instance, ADD 0, ADD 1, and ADD 2. If you have already configured 3 adders, then no other adders are available.

## Application description for the free function blocks

Further information is provided on the Internet:



FAQ (http://support.automation.siemens.com/WW/view/en/85168215)

## 8.16 Physical units

#### 8.16.1 Motor standard

### Selection options and parameters involved



The converter represents the motor data corresponding to motor standard IEC or NEMA in different system units: SI units or US units.

Table 8-36 Parameters involved when selecting the motor standard

Parame-	Designation	Motor standard IEC/NEMA, p0100 =				
ter		O <sup>1)</sup>	1	2		
		IEC motor	NEMA motor	NEMA motor		
		50 Hz, SI units	60 Hz, US units	60 Hz, SI units		
r0206	Power Module rated power	kW	hp	kW		
p0219	Braking resistor braking power	kW	hp	kW		
p0307	Rated motor power	kW	hp	kW		
p0316	Motor torque constant	Nm/A	lbf ft/A	Nm/A		
r0333	Rated motor torque	Nm	lbf ft	Nm		
p0341	Motor moment of inertia	kgm²	lb ft²	kgm²		
p0344	Motor weight	kg	Lb	kg		
r0394	Rated motor power	kW	hp	kW		
r1493	Total moment of inertia, scaled	kgm²	lb ft²	kgm²		

<sup>1)</sup> Factory setting

It is only possible to change the motor standard during quick commissioning.

## 8.16.2 Unit system

Some physical units depend on the system of units selected (SI or US), for example the power [kW or hp] or the torque [Nm or lbf ft]. You can select in which system of units the converter represents its physical values.

## Options when selecting the system of units

The following options apply when selecting the system of units:

- p0505 = 1: System of units SI (factory setting)
   Torque [Nm], power [kW], temperature [°C or K]
- p0505 = 2: Referred system of units/SI Represented as [%]

#### 8.16 Physical units

- p0505 = 3: US system of units
   Torque [lbf ft], power [hp], temperature [°F]
- p0505 = 4: System of units, referred/US Represented as [%]

### **Special features**

The values for p0505 = 2 and for p0505 = 4 - represented in the converter - are identical. However, the reference to SI or US units is required for internal calculations and to output physical variables.

For variables, which cannot be represented as [%], then the following applies:

- p0505 = 1 corresponds to setting p0505 = 2
- p0505 = 3 corresponds to setting p0505 = 4

In the case of variables whose units are identical in the SI system and US system, and which can be displayed as a percentage, the following applies:

- p0505 = 1 corresponds to setting p0505 = 3
- p0505 = 2 corresponds to setting p0505 = 4

#### Reference variables

There is a reference variable in the converter for most parameters with physical units. When the referred representation [%] is set, then the converter scales the physical variables based on the particular reference variable.

When the reference variable changes, then the significance of the scaled value also changes. Example:

- Reference speed = 1500 rpm → fixed speed = 80 % corresponds to the speed = 1200 rpm
- Reference speed = 3000 rpm → fixed speed = 80 % corresponds to the speed = 2400 rpm

For each parameter you can find the associated reference variable for scaling in the parameter list. Example: r0065 is scaled with reference variable p2000.

If scaling is not specified in the parameter list, then the converter always shows/displays the parameter unscaled.

#### **Groups of units**

In the parameter list you will find the following information for parameters with changeable units:

- Unit group
   Designates the group to which the parameter belongs
- Unit selection
   Designates the parameter that changes over the unit

#### **Example:**

Unit group: 7 1, unit selection: p0505

The parameter belongs to the unit group 7 1 and p0505 changes over the unit.

Table 8-37 Unit group (p0100)

Unit group		Unit selection for p0100 =			
	0	1	2		
7_4	Nm	lbf ft	Nm		
14_6	kW	hp	kW		
25_1	kg m²	lbf ft²	kg m²		
27_1	kg	Ib	kg		
28_1	Nm/A	lbf ft/A	Nm/A		

Table 8-38 Unit group (p0505)

Unit group	Unit selection for p0505 =			Reference value for %	
	1	2	3	4	
2_1	Hz	%	Hz	%	p2000
3_1	rpm	%	rpm	%	p2000
5_1	Vrms	%	Vrms	%	P2001
5_2	V	%	V	%	p2001
5_3	V	%	V	%	p2001
6_2	Arms	%	Arms	%	p2002
6_5	А	%	Α	%	p2002
7_1	Nm	%	lbf ft	%	p2003
7_2	Nm	Nm	lbf ft	lbf ft	-
14_5	kW	%	hp	%	r2004
14_10	kW	kW	hp	hp	-
21_1	° C	°C	°F	°F	-
21_2	К	К	°F	°F	-
39_1	1/s²	%	1/s²	%	p2007

## 8.16.3 Technological unit of the technology controller

## Options when selecting the technological unit

p0595 defines in which technological unit the input and output variables of the technology controller are calculated, e.g. [bar], [m³/min] or [kg/h].

### Reference variable

p0596 defines the reference variable of the technological unit for the technology controller.

### 8.16 Physical units

### **Unit group**

Parameters involved with p0595 belong to unit group 9\_1.

The values that can be set and the technological units are shown in p0595.

### **Special features**

You must optimize the technology controller after changing p0595 or p0596.

## Additional technology controllers

You can set the technological unit for each additional technology controller.

	Technological unit	Reference variable for the technological unit	Unit group
Additional technology controller 0	p11026	p11027	9_2
Additional technology controller 1	p11126	p11127	9_3
Additional technology controller 2	p11226	p11227	9_4

## 8.16.4 Setting the system of units and technology unit


### **Setting using Startdrive**

### Requirement

You are offline with Startdrive.

#### **Procedure**

- 1. In the project, select "Parameter".
- 2. Select "Units".



- 3. Select the system of units.
- 4. Select the technological unit of the technology controller.
- 5. Save your settings.

6. Go online.

The converter signals that offline, other units and process variables are set than in the converter itself.

7. Accept these settings in the converter.

You have selected the motor standard and system of units.

## 8.17 Setpoints

### Overview



The converter receives its main setpoint from the setpoint source. The main setpoint generally specifies the motor speed.




Figure 8-25 Setpoint sources for the converter

You have the following options when selecting the source of the main setpoint:

- Converter fieldbus interface
- Analog input of the converter
- Motorized potentiometer emulated in the converter
- Fixed setpoints saved in the converter

You have the same selection options when selecting the source of the supplementary setpoint.

Under the following conditions, the converter switches from the main setpoint to other setpoints:

- When the technology controller is active and appropriately interconnected, its output specifies the motor speed.
- When jogging is active
- When controlled from an operator panel or a PC

# 8.17.1 Analog input as setpoint source

# **Function description**




Figure 8-26 Example: Analog input 0 as setpoint source

In the quick commissioning, you define the preassignment for the converter interfaces. Depending on what has been preassigned, after quick commissioning, the analog input can be interconnected with the main setpoint.

# Example

Setting with analog input 0 as setpoint source:

Parameter	Description	
p1070 = 755[0]	Interconnects main setpoint with analog input 0	
p1075 = 755[0]	Interconnects supplementary setpoint with analog input 0	

Number	Name	Factory setting
r0755[0 1]	CO: CU analog inputs, actual value in percent	- %
p1070[C]	CI: Main setpoint	Dependent on the converter
p1071[C]	CI: Main setpoint scaling	1
r1073	CO: Main setpoint active	- rpm
p1075[C]	CI: Supplementary setpoint	0
p1076[C]	CI: Supplementary setpoint scaling	1
r1077	CO: Supplementary setpoint effective	- rpm

# 8.17.2 Specifying the setpoint via the fieldbus

# **Function description**




Figure 8-27 Fieldbus as setpoint source

In the quick commissioning, you define the preassignment for the converter interfaces. Depending on what has been preassigned, after quick commissioning, the receive word PZD02 can be interconnected with the main setpoint.

# Example

Setting with receive word PZD02 as setpoint source:

Parameter	Description
p1070 = 2050[1]	Interconnects the main setpoint with the receive word PZD02 from the fieldbus.
p1075 = 2050[1]	Interconnects the supplementary setpoint with receive word PZD02 from the field-bus.

Number	Name	Factory setting
p1070[C]	CI: Main setpoint	Dependent on the converter
p1071[C]	CI: Main setpoint scaling	1
r1073	CO: Main setpoint active	- rpm
p1075[C]	CI: Supplementary setpoint	0
p1076[C]	CI: Supplementary setpoint scaling	1
r1077	CO: Supplementary setpoint effective	- rpm
r2050[011]	CO: PROFIdrive PZD receive word	-

# 8.17.3 Motorized potentiometer as setpoint source

# **Function description**

The "Motorized potentiometer" function emulates an electromechanical potentiometer. The output value of the motorized potentiometer can be set with the "higher" and "lower" control signals.




Figure 8-28 Motorized potentiometer as setpoint source




Figure 8-29 Function chart of the motorized potentiometer

### Example

Setting with the motorized potentiometer as setpoint source:

Parameter	Description
p1070 = 1050	Interconnects the main setpoint with the motorized potentiometer output.

# 8.17 Setpoints

Table 8-39 Basic setup of motorized potentiometer

Number	Name	Factory setting
p1035[C]	BI: Motorized potentiometer setpoint higher	0
p1036[C]	BI: Motorized potentiometer setpoint lower	Dependent on the converter
p1040[D]	Motorized potentiometer start value	0 rpm
p1047[D]	Motorized potentiometer, ramp-up time	10 s
p1048[D]	Motorized potentiometer, ramp-down time	10 s
r1050	Motorized potentiometer, setpoint after the ramp-function generator	- rpm
p1070[C]	CI: Main setpoint	Dependent on the converter
p1071[C]	CI: Main setpoint scaling	1
r1073	CO: Main setpoint active	- rpm
p1075[C]	CI: Supplementary setpoint	0
p1076[C]	CI: Supplementary setpoint scaling	1

Table 8-40 Extended setup of motorized potentiometer

Number	Name	Factory setting
p1030[D]	Motorized potentiometer configuration	0000 0110 bin
p1037[D]	Motorized potentiometer, maximum speed	0 rpm
p1038[D]	Motorized potentiometer, minimum speed	0 rpm
p1043[C]	BI: Motorized potentiometer, accept setting value	0
p1044[C]	CI: Motorized potentiometer, setting value	0

# 8.17.4 Fixed speed setpoint as setpoint source

# **Function description**




Figure 8-30 Fixed speed setpoint as setpoint source

The converter makes a distinction between two methods when selecting the fixed speed setpoints:

### Directly selecting a fixed speed setpoint




Figure 8-31 Direct selection of the fixed speed setpoint

Table 8-41 Resulting setpoint

p1020	p1021	p1022	p1023	Resulting setpoint
0	0	0	0	0
1	0	0	0	p1001
0	1	0	0	p1002
1	1	0	0	p1001 + p1002
0	0	1	0	p1003
1	0	1	0	p1001 + p1003
0	1	1	0	p1002 + p1003
1	1	1	0	p1001 + p1002 + p1003
0	0	0	1	p1004

### 8.17 Setpoints

p1020	p1021	p1022	p1023	Resulting setpoint
1	0	0	1	p1001 + p1004
0	1	0	1	p1002 + p1004
1	1	0	1	p1001 + p1002 + p1004
0	0	1	1	p1003 + p1004
1	0	1	1	p1001 + p1003 + p1004
0	1	1	1	p1002 + p1003 + p1004
1	1	1	1	p1001 + p1002 + p1003 + p1004

### Selecting the fixed speed setpoint, binary




Figure 8-32 Binary selection of the fixed speed setpoint

Table 8-42 Resulting setpoint

p1020	p1021	p1022	p1023	Resulting setpoint
0	0	0	0	0
1	0	0	0	p1001
0	1	0	0	p1002
1	1	0	0	p1003
0	0	1	0	p1004
1	0	1	0	p1005
0	1	1	0	p1006
1	1	1	0	p1007
0	0	0	1	p1008
1	0	0	1	p1009
0	1	0	1	p1010
1	1	0	1	p1011
0	0	1	1	p1012
1	0	1	1	p1013
0	1	1	1	p1014
1	1	1	1	p1015

# Example

After it has been switched on, a conveyor belt only runs with two different velocities. The motor should now operate with the following corresponding speeds:

- The signal at digital input 0 switches the motor on and accelerates it up to 300 rpm.
- The signal at digital input 1 accelerates the motor up to 2000 rpm.
- With signals at both digital inputs, the motor accelerates up to 2300 rpm.

Table 8-43 Settings for the application example

Parameter	Description
p1001[0] = 300.000	Fixed speed setpoint 1
p1002[0] = 2000.000	Fixed speed setpoint 2
p0840[0] = 722.0	ON/OFF1: Switches on the motor with digital input 0
p1070[0] = 1024	Main setpoint: Interconnects the main setpoint with a fixed speed setpoint.
p1020[0] = 722.0	Fixed speed setpoint selection bit 0: Interconnects fixed speed setpoint 1 with digital input 0 (DI 0).
p1021[0] = 722.1	Fixed speed setpoint selection bit 1: Interconnects fixed speed setpoint 2 with digital input 1 (DI 1).
p1016 = 1	Fixed speed setpoint mode: Directly selects fixed speed setpoints.

Table 8-44 Resulting fixed speed setpoints for the application example

Fixed speed setpoint selected via	Resulting setpoint
DI 0 = 0	Motor stops
DI 0 = 1 and DI 1 = 0	300 rpm
DI 0 = 1 and DI 1 = 1	2300 rpm

Parameter	Description	Factory setting
p1001[D]	CO: Fixed speed setpoint 1	0 rpm
p1002[D]	CO: Fixed speed setpoint 2	0 rpm
p1003[D]	CO: Fixed speed setpoint 3	0 rpm
p1004[D]	CO: Fixed speed setpoint 4	0 rpm
p1005[D]	CO: Fixed speed setpoint 5	0 rpm
p1006[D]	CO: Fixed speed setpoint 6	0 rpm
p1007[D]	CO: Fixed speed setpoint 7	0 rpm
p1008[D]	CO: Fixed speed setpoint 8	0 rpm
p1009[D]	CO: Fixed speed setpoint 9	0 rpm
p1010[D]	CO: Fixed speed setpoint 10	0 rpm
p1011[D]	CO: Fixed speed setpoint 11	0 rpm
p1012[D]	CO: Fixed speed setpoint 12	0 rpm

# 8.17 Setpoints

Parameter	Description	Factory setting
p1013[D]	CO: Fixed speed setpoint 13	0 rpm
p1014[D]	CO: Fixed speed setpoint 14	0 rpm
p1015[D]	CO: Fixed speed setpoint 15	0 rpm
p1016	Fixed speed setpoint selection mode	1
p1020[C]	Fixed speed setpoint selection, bit 0	0
p1021[C]	Fixed speed setpoint selection, bit 1	0
p1022[C]	Fixed speed setpoint selection, bit 2	0
p1023[C]	Fixed speed setpoint selection, bit 3	0
r1024	Fixed speed setpoint active	- rpm
r1025.0	Fixed speed setpoint status	-
p1070[C]	CI: Main setpoint	Dependent on the converter
p1071[C]	CI: Main setpoint scaling	1
r1073	CO: Main setpoint active	- rpm
p1075[C]	CI: Supplementary setpoint	0
p1076	CI: Supplementary setpoint scaling	1
r1077	CO: Supplementary setpoint effective	- rpm

# 8.18 Setpoint processing

#### 8.18.1 Overview

#### Overview



Setpoint processing influences the setpoint using the following functions:

- "Invert" inverts the motor direction of rotation.
- The "direction of rotation deactivate" function prevents the motor rotating in the incorrect direction.
- The "Skip frequency bands" prevent the motor from being continuously operated within these skip bands. This function avoids mechanical resonance effects by only permitting the motor to operate briefly at specific speeds.
- The "Speed limitation" function protects the motor and the driven load against excessively high speeds.
- The "Ramp-function generator" function prevents the setpoint from suddenly changing. As a consequence, the motor accelerates and brakes with a reduced torque.





Figure 8-33 Setpoint processing in the converter

# 8.18.2 Invert setpoint

# **Function description**



The function inverts the sign of the setpoint using a binary signal.

# Example

To invert the setpoint via an external signal, interconnect parameter p1113 with a binary signal of your choice.


Table 8-45 Application examples showing how a setpoint is inverted

Parameter	Description
p1113 = 722.1	Digital input 1 = 0: Setpoint remains unchanged. Digital input 1 = 1: Converter inverts the setpoint.
p1113 = 2090.11	Inverts the setpoint via the fieldbus (control word 1, bit 11).

Number	Name	Factory setting
p1113[C]	BI: Setpoint inversion	Dependent on the
		converter

# 8.18.3 Enable direction of rotation

# **Function description**



In the factory setting of the converter, the negative direction of rotation of the motor is inhibited.

Set parameter p1110 = 0 to permanently enable the negative direction of rotation.

Set parameter p1111 = 1 to permanently inhibit the positive direction of rotation.

Table 8-46 Application examples for inhibiting and enabling the direction of rotation

Number	Name	Factory setting
p1110	BI: Inhibit negative direction	1
p1111	BI: Inhibit positive direction	0

# 8.18.4 Skip frequency bands and minimum speed


#### Overview

The converter has a minimum speed and four skip frequency bands:

- The minimum speed prevents continuous motor operation at speeds less than the minimum speed.
- Each skip frequency band prevents continuous motor operation within a specific speed range.

# **Function description**

#### Minimum speed



Speeds where the absolute value is less than the minimum speed are only possible when the motor is accelerating or braking.

### Skip frequency bands

Additional information on the skip frequency bands is provided in the function diagram.

Table 8-47 Minimum speed

Number	Name	Factory setting
p1051[C]	CI: Speed limit of ramp-function generator, positive direction of rotation	9733
p1052[C]	CI: Speed limit of ramp-function generator, negative direction of rotation	1086
p1080[D]	Minimum speed	0 rpm
p1083[D]	CO: Speed limit in positive direction of rotation	210000 rpm
r1084	CO: Speed limit positive active	- rpm
p1085[C]	CI: Speed limit in positive direction of rotation	1083

Number	Name	Factory setting
p1091[D]	Skip speed 1	0 rpm
p1092[D]	Skip speed 2	0 rpm
p1093[D]	Skip speed 3	0 rpm
p1094[D]	Skip speed 4	0 rpm
p1098[C]	CI: Skip speed scaling	1
r1099	CO/BO: Skip frequency band of status word	-
p1101	Skip speed bandwidth	0 rpm
p1106	CI: Minimum speed signal source	0
r1112	CO: Speed setpoint according to minimum limit	- rpm
r1114	CO: Setpoint after direction limiting	- rpm
r1119	CO: Ramp-function generator setpoint at the input	- rpm
r1170	CO: Speed controller setpoint sum	- rpm

#### Note

In order that a stationary motor – after all of the enable signals have been switched on, can operate at the minimum

speed/minimum velocity once all of the enable signals are available, the direction must be entered using one of the

- following options:
- direction input via small setpoint.
- direction input by inhibiting the negative or positive direction (p1110, p1111).

#### NOTICE


#### Incorrect direction of motor rotation if the parameterization is not suitable

If you are using an analog input as speed setpoint source, then for a setpoint = 0 V, noise voltages can be superimposed on the analog input signal. After the on command, the motor accelerates up to the minimum frequency in the direction of the random polarity of the noise voltage. A motor rotating in the wrong direction can cause significant material damage to the machine or system.

• Inhibit the motor direction of rotation that is not permissible.

# 8.18.5 Speed limitation

The maximum speed limits the speed setpoint range for both directions of rotation.



The converter generates a message (fault or alarm) when the maximum speed is exceeded.

If you must limit the speed depending on the direction of rotation, then you can define speed limits for each direction.

Table 8-48 Parameters for the speed limitation

Number	Name	Factory setting
p1082[D]	Maximum speed	1500 rpm
p1083[D]	CO: Speed limit in positive direction of rotation	210000 rpm
p1085[C]	CI: Speed limit in positive direction of rotation	1083
p1086[D]	CO: Speed limit in negative direction of rotation	-210000 rpm
p1088[C]	CI: Speed limit in negative direction of rotation	1086


### 8.18.6 Ramp-function generator

The ramp-function generator in the setpoint channel limits the rate change of the speed setpoint (acceleration). A reduced acceleration reduces the accelerating torque of the motor. As a consequence, the motor reduces the stress on the mechanical system of the driven machine.

The extended ramp-function generator not only limits the acceleration, but by rounding the setpoint, also acceleration changes (jerk). This means that the motor does not suddenly generate a torque.

### **Extended ramp-function generator**

The ramp-up and ramp-down times of the extended ramp-function generator can be set independently of each other. The optimal times depend on the application, and can lie in the range from a few 100 ms to several minutes.



Initial and final rounding permit smooth, jerk-free acceleration and braking.

The ramp-up and ramp-down times of the motor are increased by the rounding times:

- Effective ramp-up time =  $p1120 + 0.5 \times (p1130 + p1131)$ .
- Effective ramp-down time =  $p1121 + 0.5 \times (p1130 + p1131)$ .

#### **Parameter**

Table 8-49 Additional parameters to set the extended ramp-function generator

Number	Name	Factory setting
p1120[D]	Ramp-function generator ramp-up time	Dependent on the converter
p1121[D]	Ramp-function generator ramp-down time	
p1130[D]	Ramp-function generator initial rounding time	
p1131[D]	Ramp-function generator final rounding time	
p1134[D]	Ramp-function generator rounding type	0 (continuous smoothing)
p1135[D]	OFF3 ramp-down time	Dependent on the
p1136[D]	OFF3 initial rounding time	converter
p1137[D]	OFF3 final rounding time	0 s
p1138[C]	CI: Ramp-function generator ramp-up time scaling	1
p1139[C]	CI: Ramp-function generator ramp-down time scaling	1
p1140[C]	BI: Enable ramp-function generator/disable ramp-function generator	Dependent on the converter
p1141[C]	BI: Continue ramp-function generator/freeze ramp-function generator	
p1142[C]	BI: Enable setpoint/inhibit setpoint	1
p1143[C]	BI: Accept ramp-function generator setting value	0
p1144[C]	CI: Ramp-function generator setting value	0
p1148[D]	Ramp-function generator tolerance for ramp-up and ramp-down active	19.8 rpm
r1149	CO: Ramp-function generator acceleration	-

# Setting the extended ramp-function generator

#### **Procedure**

- 1. Enter the highest possible speed setpoint.
- 2. Switch on the motor.
- 3. Evaluate your drive response.
  - If the motor accelerates too slowly, then reduce the ramp-up time.
     An excessively short ramp-up time means that the motor will reach its current limiting when accelerating, and will temporarily not be able to follow the speed setpoint. In this case, the drive exceeds the set time.
  - If the motor accelerates too fast, then extend the ramp-up time.
  - Increase the initial rounding if the acceleration is jerky.
  - In most applications, it is sufficient when the final rounding is set to the same value as the initial rounding.
- 4. Switch off the motor.

- 5. Evaluate your drive response.
  - If the motor decelerates too slowly, then reduce the ramp-down time.
     The minimum ramp-down time that makes sense depends on your particular application.
     Depending on the Power Module used, for an excessively short ramp-down time, the converter either reaches the motor current, or the DC link voltage in the converter becomes too high.
  - Extend the ramp-down time if the motor is braked too quickly or the converter goes into a fault condition when braking.
- 6. Repeat steps 1 ... 5 until the drive behavior meets the requirements of the machine or plant. You have set the extended ramp-function generator.

# 8.19 PID technology controller

#### Overview



The technology controller controls process variables, e.g. pressure, temperature, level or flow.




Figure 8-34 Example: Technology controller as a level controller


# Requirement

The U/f control or the vector control have been set.

# **Function description**

### **Function diagram**

The technology controller is implemented as a PID controller (controller with proportional, integral, and derivative action).



- 1 The converter uses the start value when all the following conditions are simultaneously satisfied:
  - The technology controller supplies the main setpoint (p2251 = 0).
  - The ramp-function generator output of the technology controller has not yet reached the start value.

Figure 8-35 Simplified representation of the technology controller

#### **Basic settings**

The settings required as a minimum are marked in gray in the function diagram:


- Interconnect setpoint and actual values with signals of your choice
- Set ramp-function generator and controller parameters K<sub>P</sub>, T<sub>I</sub> and T<sub>d</sub>.

#### Set controller parameters K<sub>P</sub>, T<sub>I</sub> and T<sub>d</sub>.

#### **Procedure**

- 1. Temporarily set the ramp-up and ramp-down times of the ramp-function generator (p2257 and p2258) to zero.
- 2. Enter a setpoint step and monitor the associated actual value.

  The slower the response of the process to be controlled, the longer you must monitor the controller response. Under certain circumstances (e.g. for a temperature control), you need to wait several minutes until you can evaluate the controller response.



3. Set the ramp-up and ramp-down times of the ramp-function generator back to their original value.

You have manually set the technology controller.  $\Box$ 

### Limiting the output of the technology controller

In the factory setting, the output of the technology controller is limited to  $\pm$  maximum speed. You must change this limit, depending on your particular application.

Example: The output of the technology controller supplies the speed setpoint for a pump. The pump should only run in the positive direction.

Table 8-50 Basic settings

Number	Name	Factory setting
r0046[031]	CO/BO: Missing enable signals	-
r0052[015]	CO/BO: Status word 1	-
r0056[015]	CO/BO: Status word, closed-loop control	-
r1084	CO: Speed limit positive active	-
r1087	CO: Speed limit negative active	- rpm
p2200[C]	BI: Technology controller enable	0
p2252	Technology controller configuration	See parameter list
p2253[C]	CI: Technology controller setpoint 1	0
p2254[C]	CI: Technology controller setpoint 2	0
p2255	Technology controller setpoint 1 scaling	100%
p2256	Technology controller setpoint 2 scaling	100%
p2257	Technology controller ramp-up time	1 s
p2258	Technology controller ramp-down time	1 s
r2260	CO: Technology controller setpoint after ramp-function generator	- %
p2261	Technology controller setpoint filter time constant	0 s
r2262	CO: Technology controller setpoint after filter	- %
p2263	Technology controller type	0
r2273	CO: Technology controller system deviation	- %
p2274	Technology controller differentiation time constant	0 s
p2280	Technology controller proportional gain	See parameter list
p2285	Technology controller integral time	See parameter list
p2286	BI: Hold technology controller integrator	56.13
p2289[C]	CI: Technology controller precontrol signal	0
p2306	Technology controller system deviation inversion	0
p2339	Technology controller threshold value for I proportion stop at skip speed	- S
r2344	CO: Technology controller last speed setpoint (smoothed)	- %
p2345	Technology controller fault response	0
r2349[013]	CO/BO: Technology controller status word	-
r3889[010]	CO/BO: ESM status word	-

Table 8-51 Limiting the output of the technology controller

Number	Name	Factory setting
p2290[C]	BI: Technology controller limitation enable	1
p2291	CO: Technology controller maximum limiting	100%
p2292	CO: Technology controller minimum limiting	0%
p2293	Technology controller ramp-up/ramp-down time	1 s

# 8.19 PID technology controller

Number	Name	Factory setting
r2294	CO: Technology controller output signal	- %
p2295	CO: Technology controller output scaling	100%
p2296[C]	CI: Technology controller output scaling	2295
p2297[C]	CI: Technology controller maximum limiting signal source	1084
p2298[C]	CI: Technology controller minimum limiting signal source	1087
p2299[C]	CI: Technology controller limitation offset	0
p2302	Technology controller output signal start value	0%

Table 8-52 Adapting the actual value of the technology controller

Number	Name	Factory setting
p2264[C]	CI: Technology controller actual value	0
p2265	Technology controller actual value filter time constant	0 s
p2266	CO: Technology controller actual value after filter	- %
p2267	Technology controller upper limit actual value	100%
p2268	Technology controller lower limit actual value	-100%
p2269	Technology controller gain actual value	100%
p2270	Technology controller actual value function	0
p2271	Technology controller actual value inversion	0
r2272	CO: Technology controller actual value scaled	- %

Table 8-53 PID technology controller, fixed values (binary selection)

Number	Name	Factory setting
p2201[D]	CO: Technology controller fixed value 1	10%
p2202[D]	CO: Technology controller fixed value 2	20%
p2203[D]	CO: Technology controller fixed value 3	30%
p2204[D]	CO: Technology controller fixed value 4	40%
p2205[D]	CO: Technology controller fixed value 5	50%
p2206[D]	CO: Technology controller fixed value 6	60%
p2207[D]	CO: Technology controller fixed value 7	70%
p2208[D]	CO: Technology controller fixed value 8	80%
p2209[D]	CO: Technology controller fixed value 9	90%
p2210[D]	CO: Technology controller fixed value 10	100%
p2211[D]	CO: Technology controller fixed value 11	110%
p2212[D]	CO: Technology controller fixed value 12	120%
p2213[D]	CO: Technology controller fixed value 13	130%
p2214[D]	CO: Technology controller fixed value 14	140%
p2215[D]	CO: Technology controller fixed value 15	150%
p2216[D]	Technology controller fixed value selection method	1
r2224	CO: Technology controller fixed value active	- %

Number	Name	Factory setting
r2225	CO/BO: Technology controller fixed value selection status word	- %
r2229	Technology controller number actual	-

Table 8-54 PID technology controller, fixed values (direct selection)

Number	Name	Factory setting
p2216[D]	Technology controller fixed value selection method	1
p2220[C]	BI: Technology controller fixed value selection bit 0	0
p2221[C]	BI: Technology controller fixed value selection bit 1	0
p2222[C]	BI: Technology controller fixed value selection bit 2	0
p2223[C]	BI: Technology controller fixed value selection bit 3	0
r2224	CO: Technology controller fixed value active	- %
r2225	CO/BO: Technology controller fixed value selection status word	- %
r2229	Technology controller number actual	-

Table 8-55 PID technology controller, motorized potentiometer

Number	Name	Factory setting
r2231	Technology controller motorized potentiometer setpoint memory	- %
p2235[C]	BI: Technology controller motorized potentiometer, setpoint, raise	0
p2236[C]	BI: Technology controller motorized potentiometer, setpoint, lower	0
p2237[D]	Technology controller motorized potentiometer maximum value	100%
p2238[D]	Technology controller motorized potentiometer minimum value	-100%
p2240[D]	Technology controller motorized potentiometer start value	0%
r2245	CO: Technology controller motorized potentiometer, setpoint before RFG	- %
p2247[D]	Technology controller motorized potentiometer ramp-up time	10 s
p2248[D]	Technology controller motorized potentiometer ramp-down time	10 s
r2250	CO: Technology controller motorized potentiometer, setpoint after RFG	- %

#### 8.19 PID technology controller

#### **Further information**

You will find additional information on the following PID controller components on the Internet at:

- Setpoint input: Analog value or fixed setpoint
- · Setpoint channel: Scaling, ramp-function generator and filter
- · Actual value channel: Filter, limiting and signal processing
- PID controller: Principle of operation of the D component, inhibiting the I component and the control sense
- Enable, limiting the controller output and fault response
- FAQ (http://support.automation.siemens.com/WW/view/en/92556266)

Additional information for setting the technology controller in certain applications is provided on the Internet:

- Closed-loop air intake control (<a href="https://support.industry.siemens.com/cs/ww/en/view/43296889">https://support.industry.siemens.com/cs/ww/en/view/43296889</a>)
- Closed-loop air discharge control (<a href="https://support.industry.siemens.com/cs/ww/en/view/77490904">https://support.industry.siemens.com/cs/ww/en/view/77490904</a>)
- Closed-loop fan control for a stairwell (<a href="https://support.industry.siemens.com/cs/ww/en/view/77491576">https://support.industry.siemens.com/cs/ww/en/view/77491576</a>)
- Closed-loop fan control for a parking garage or a tunnel (<a href="https://support.industry.siemens.com/cs/ww/en/view/77491575">https://support.industry.siemens.com/cs/ww/en/view/77491575</a>)
- Pressure-controlled pump (<a href="https://support.industry.siemens.com/cs/ww/en/view/43297279">https://support.industry.siemens.com/cs/ww/en/view/43297279</a>)
- Level-controlled pump (<a href="https://support.industry.siemens.com/cs/ww/en/view/43297280">https://support.industry.siemens.com/cs/ww/en/view/43297280</a>)
- Closed-loop control for the cooling circuit (<a href="https://">https://</a> support.industry.siemens.com/cs/ww/en/view/43297284)

### 8.19.1 Autotuning the PID technology controller

#### Overview

Autotuning is a converter function for the automatic optimization of the PID technology controller.

# Requirement

The following requirements apply:

- The motor closed-loop control is set
- The PID technology controller must be set the same as when used in subsequent operation:
  - The actual value is interconnected.
  - Scalings, filter and ramp-function generator have been set.
  - The PID technology controller is enabled (p2200 = 1 signal).

### **Function description**

For active autotuning, the converter interrupts the connection between the PID technology controller and the speed controller. Instead of the PID technology controller output, the autotuning function specifies the speed setpoint.




Figure 8-36 Autotuning using closed-loop level control as example

The speed setpoint results from the technology setpoint and a superimposed rectangular signal with amplitude p2355. If actual value = technology setpoint  $\pm$  p2355, the autotuning function switches the polarity of the superimposed signal. This causes the converter to excite the process variable for an oscillation.

#### 8.19 PID technology controller




Figure 8-37 Example for speed setpoint and actual process value for autotuning

The converter calculates the parameters of the PID controller from the determined oscillation frequency.

#### **Executing autotuning**

- 1. Select with p2350 the appropriate controller setting.
- 2. Switch on the motor. The converter signals Alarm A07444.
- 3. Wait until alarm A07444 goes away.
  The converter has recalculated parameters p2280, p2274 and p2285.
  If the converter signals fault F07445:
  - If possible, double p2354 and p2355.
  - Repeat the autotuning with the changed parameters.
- 4. Back up the calculated values so that they are protected against power failure, e.g. using the BOP-2: OPTIONS → RAM-ROM.

You have auto tuned the PID controller.

Number	Name	Factory setting
p2274	Technology controller differentiation time constant	0.0 s
p2280	Technology controller proportional gain	See parameter list
p2285	Technology controller integral time	See parameter list

Enable PID autotuning Automatic controller setting based on the "Ziegler Nichols" method.  After completion of the autotuning, the converter sets p2350 = 0.  0: No function 1: The process variable follows the setpoint after a sudden setpoint change (step function) relatively quickly, however with an overshoot.  2: Faster controller setting than for p2350 = 1 with larger overshoot of the controlled variable.  3: Slower controller setting than for p2350 = 1. Overshoot of the controlled variable is, to a large extent, avoided.  4: Controller setting after completion of the autotuning as for p2350 = 1. Optimize only the P and I action of the PID controller.	Number	Name	Factory setting
F t		Enable PID autotuning Automatic controller setting based on the "Ziegler Nichols" method.  After completion of the autotuning, the converter sets p2350 = 0.  0: No function  1: The process variable follows the setpoint after a sudden setpoint change (step function) relatively quickly, however with an overshoot.  2: Faster controller setting than for p2350 = 1 with larger overshoot of the controlled variable.  3: Slower controller setting than for p2350 = 1. Overshoot of the controlled variable is, to a large extent, avoided.  4: Controller setting after completion of the autotuning as for p2350 = 1. Optimize only the P and I action of the PID con-	-
p2354 PID autotuning monitoring time 240 s	p2354	PID autotuning monitoring time	240 s
	p2355	PID autotuning offset	5%

# 8.19.2 Adapting Kp and Tn

#### Overview

This function adapts the PID technology controller to the process, e.g. depending on the control deviation of the technology controller.

# **Function description**




Figure 8-38 Controller adaptation

Number	Name	Factory setting
p2252	Technology controller configuration	0000 0000 0000 0000 bin
p2280	Technology controller proportional gain	see parameter list
p2285	Technology controller integral time	see parameter list
p2310	CI: Technology controller Kp adaptation input value signal source	0
p2311	Technology controller, lower Kp adaptation value	1
p2312	Technology controller, upper Kp adaptation value	10
p2313	Technology controller lower Kp adaptation transition point	0%
p2314	Technology controller upper Kp adaptation transition point	100%
p2315	CI: Technology controller Kp adaptation scaling signal source	1
r2316	CO: Technology controller Kp adaptation output	-
p2317	CI: Technology controller Tn adaptation input value signal source	0
p2318	Technology controller, lower Tn adaptation value	3 s

# 8.19 PID technology controller

Number	Name	Factory setting
p2319	Technology controller, upper Tn adaptation value	10 s
p2320	Technology controller lower Tn adaptation transition point	0%
p2321	Technology controller upper Tn adaptation transition point	100%
r2322	CO: Technology controller Tn adaptation output	- S

#### Free technology controllers 8.20

#### Overview




The converter has three additional technology controllers.

The three "free technology controllers" have fewer setting options compared with the PID technology controller described above.



PID technology controller (Page 340)

### **Function description**



- n = 0 Free technology controller 0
- n = 1 Free technology controller 1
- n = 2 Free technology controller 2

Simplified function chart of the additional PID technology controllers, n = 0 ... 2

The additional technology controllers allow several process variables to be simultaneously controlled using one converter.

### Example

An HVAC system with heating and cooling valves to process the air:

- The main controller controls the speed of the fan drive.
- The additional technology controllers control the cooling and heating via the two analog outputs.

Table 8-56 Parameters for the free technology controller 0

Number	Name	Factory setting
p11000	BI: Free tec_ctrl 0 enable	0
p11026	Free tec_ctrl 0 unit selection	1 (%)
p11027	Free tec_ctrl 0 unit reference variable	1.00
p11028	Free tec_ctrl 0 sampling time	2 (256 ms)
r11049.011	CO/BO: Free tec_ctrl 0 status word	-

# 8.20 Free technology controllers

Number	Name	Factory setting
p11053	CI: Free tec_ctrl 0 setpoint signal source	0
p11057	Free tec_ctrl 0 setpoint ramp-up time	1 s
p11058	Free tec_ctrl 0 setpoint ramp-down time	1 s
p11063	Free tec_ctrl 0 error signal inversion	0
p11064	CI: Free tec_ctrl 0 actual value signal source	0
p11065	Free tec_ctrl 0 actual value smoothing time constant	0 s
p11067	Free tec_ctrl 0 actual value upper limit	100%
p11068	Free tec_ctrl 0 actual value lower limit	-100 %
p11071	Free tec_ctrl 0 actual value inversion	0
r11072	CO: Free tec_ctrl 0 actual value after limiter	-
r11073	CO: Free tec_ctrl 0 control deviation	-
p11074	Free tec_ctrl 0 differentiation time constant (T <sub>d</sub> )	0 s
p11080	Free tec_ctrl 0 proportional gain (K <sub>P</sub> )	1
p11085	Free tec_ctrl 0 integral time (T <sub>I</sub> )	30 s
p11091	CO: Free tec_ctrl 0 maximum limit	100%
p11092	CO: Free tec_ctrl 0 minimum limit	0%
p11093	Free tec_ctrl 0 ramp-up/ramp-down time limit	1 s
r11094	CO: Free tec_ctrl 0 output signal	-
p11097	CI: Free tec_ctrl 0 maximum limit signal source	11091[0]
p11098	CI: Free tec_ctrl 0 minimum limit signal source	11092[0]
p11099	CI: Free tec_ctrl 0 offset limit signal source	0

# See also

Overview of the manuals (Page 581)

### 8.21 Multi-zone control

#### Overview



Multi-zone control is used to control variables such as pressure or temperature via the technology setpoint deviation.

#### **Function description**

#### Configuration

p31021 specifies the configuration of multi-zone control:

- 1 setpoint and 1, 2 or 3 actual values
- Maximum value control (cooling)

The maximum value control compares 2 pairs of setpoint and actual value.

The converter controls the setpoint / actual value pair for which the actual value is greater than the associated setpoint.

If both actual values are greater than the associated setpoints, the converter controls the setpoint / actual value pair with the greater deviation. The converter only switches over to the other setpoint / actual value pair if the deviation of the controlled setpoint / actual value pair is more than two percent lower than the deviation of the uncontrolled value pair.

The control pauses if both actual values lie below the associated setpoints.

Minimum valve control (heating)

The minimum value control compares 2 pairs of setpoint and actual value.

The converter controls the setpoint / actual value pair for which the actual value is less than the associated setpoint.

If both actual values are smaller than the associated setpoints, the converter controls the setpoint / actual value pair with the greater deviation. The converter only switches over to the other setpoint / actual value pair if the deviation of the controlled setpoint / actual value pair is more than two percent lower than the deviation of the uncontrolled value pair.

The control pauses if both actual values lie above the associated setpoints.

#### Day to night mode

You have the following opportunities to switch from day to night mode:

- 1 signal at digital input 4
- Via p31025 with the aid of the free function blocks and the real-time clock

#### Activate multi-zone control

p31020 = 1 activates the multi-zone control and switches the analog inputs as sources for the setpoint and actual value:

```
p31023[0] = 755[0] (AI 0)
p31023[2] = 755[1] (AI 1)
p31026[0] = 755[2] (AI 2)
p31026[1] = 755[3] (AI 3)
p2253 = 31024 (setpoint output technology controller)
p2264 = 31027 (actual value output technology controller)
```

p31020 = 0 deactivates the multi-zone control and resets the interconnection of the analog inputs to the factory setting:

p31023[0] = 0 p31023[2] = 0 p31026[0] = 0 p31026[1] = 0 p2253 = 0 p2264 = 0

# Example

In an open plan office, temperature sensors (Lg-Ni1000) are installed in three different places. The converter receives the measured values and temperature setpoint via its analog inputs. Temperature setpoints between 8  $^{\circ}$ C ... 30  $^{\circ}$ C are permissible. Overnight, the average temperature should be 16 $^{\circ}$ C.

Parameter	Description
p2200[0] = 1	Technology controller enable
p2900[0] = 16	Temperature setpoint overnight as a fixed percentage value
p31020 = 1	Activate multi-zone control
p31021 = 0	Multi-zone control with one setpoint and three actual values
p31022 = 7	Three actual values, one setpoint. The actual value of the closed-loop control is the average value of three actual values.
p31023[0] = 755[0]	Temperature setpoint via analog input Al 0
p0756[0] = 0	Select analog input type (voltage input 0 10 V)
p0757[0] = 0	Lower value = $8^{\circ}$ C (0 V $\triangleq$ $8^{\circ}$ C)
p0758[0] = 8	
p0759[0] = 10	Upper value = $30^{\circ}$ C ( $10 \text{ V} \triangleq 30^{\circ}$ C)
p0760[0] = 30	
p31023[1] = 2900	Interconnect p31023[1] with the value from p2900 for the reduction overnight
p31026[0]= 755.2	Temperature actual value 1 via analog input 2 as a percentage value
p0756[2] = 6	Analog input type (temperature sensor LG-Ni1000)
p0757[2] = 0	Lower value of the scaling characteristic
p0758[2] = 0	
p31023[1] = 2900	Interconnect p31023[1] with the value from p2900 for the reduction overnight
p31026[0]= 755.2	Temperature actual value 1 via analog input 2 as a percentage value
p0756[2] = 6	Analog input type (temperature sensor LG-Ni1000)
p0757[2] = 0	Lower value of the scaling characteristic
p0758[2] = 0	
p0759[2] = 100	Upper value of the scaling characteristic
p0760[2] = 100	
p31026[1]=755[3]	Temperature actual value 2 via analog input Al 3 in %
p0756[3] = 6	Select analog input type (temperature sensor LG-Ni1000)
p0757[3] = 0	Lower value of the scaling characteristic
p0758[3] = 0	

# 8.21 Multi-zone control

Parameter	Description
p0759[3] = 100	Upper value of the scaling characteristic
p0760[3] = 100	
p31026[2] = 755[1]	Temperature actual value 3 via a temperature sensor with current output (0 mA 20 mA) via analog input Al 1
p0756[1] = 2	Analog input type (current input 0 20 mA)
p0757[1] = 0	Lower value of the scaling characteristic (0 mA $\triangleq$ 0 °C)
p0758[1] = 0	
p0759[1] = 20	Upper value of the scaling characteristic (20 mA ≜ 100%)
p0760[1] = 100	
p31025 = 722.4	Switch over from day to night via digital input 4

# **Parameters**

Number	Name	Factory setting
p2200	BI: Technology controller enable	0
p31020	Multi-zone control interconnection	0
p31021	Configuration of multi-zone control	0
	0: Setpoint 1 / multiple actual values	
	1: Two zones /maximum value setting	
	2: Two zones / minimum value setting	
p31022	Multi-zone control actual value processing	0
	0: Only actual value 1	
	1: Only actual value 2	
	2: Only actual value 3	
	3: Difference (actual value 1, 2)	
	4: Addition (actual value 1, 2)	
	5: Addition (actual value 1, 2 and 3)	
	6: Mean value (actual value 1, 2)	
	7: Mean value (actual value 1, 2 and 3)	
	8: Minimum (actual value 1, 2)	
	9: Minimum (actual value 1, 2 and 3)	
	10: Maximum (actual value 1, 2)	
	11: Maximum (actual value 1, 2 and 3)	
p31023[03]	CI: Multi-zone control setpoint input	0
r31024	CO: Multi-zone control setpoint output	-
p31025	BI: Multi-zone control day/night switchover	0
p31026[02]	CI: Multi-zone control actual value input	0
r31027	CO: Multi-zone control actual value output	-


You will find more information about this multi-zone control in the parameter list and in function diagram 7032 of the List Manual.

### 8.22 Cascade control

#### Overview



The cascade control is ideal for applications in which, for example, significantly fluctuating pressures or flow rates are equalized.



 $M_D$  Speed-controlled motor

M<sub>1</sub> ... M<sub>3</sub> Uncontrolled motors

B<sub>0</sub> Pressure sensor. Interconnect the signal of the pressure sensor with the actual value input of the technology controller.

Figure 8-40 Example: Cascade control for the pressure in a liquid pipe

Depending on the control deviation of the technology controller, the converter cascade control switches a maximum of three additional motors directly to the line supply via contactors.

#### Precondition

To deploy the cascade control, you must activate the technology controller.

### **Function description**

### Activate uncontrolled motors M<sub>1</sub> ... M<sub>3</sub>




Figure 8-41 Activate uncontrolled motors M<sub>1</sub> ... M<sub>3</sub>

Procedure for connecting an uncontrolled motor:

- 1. The speed-controlled motor turns with maximum speed p1082.
- 2. The control deviation of the technology controller is greater than p2373.
- 3. Time p2374 has expired.
  The converter brakes the speed-controlled motor with ramp-down time p1121 to the activation/deactivation speed p2378. Until the activation/deactivation speed p2378 is attained, the converter deactivates the technology controller temporarily.
- 4. After switch-on delay p2384, the converter connects an uncontrolled motor.

# Deactivate uncontrolled motors $M_1 \dots M_3$




Figure 8-42 Deactivate uncontrolled motors M<sub>1</sub> ... M<sub>3</sub>

Procedure for switching off an uncontrolled motor:

- 1. The speed-controlled motor turns with minimum speed p1080.
- 2. The control deviation of the technology controller is less than -p2373.
- 3. Time p2375 has expired.

  The converter accelerates the speed-controlled motor with ramp-up time p1120 to the activation/deactivation speed p2378. Until the activation/deactivation speed p2378 is attained, the converter deactivates the technology controller temporarily.
- 4. After shutdown delay p2386, the converter disconnects an uncontrolled motor.

## Sequence for activating and deactivating the M<sub>1</sub> ... M<sub>3</sub> motors

Table 8-57 p2371 specifies the sequence for activating and deactivating the motors

p2371	$\rightarrow$ $\rightarrow$ Sequence for activating motors $\rightarrow$ $\rightarrow$					Power of the activated M <sub>1</sub> M <sub>3</sub>			
	$\rightarrow$ $\rightarrow$ Sequence for deactivating motors $\rightarrow$ $\rightarrow$					motors compared with the speed- controlled DM motor			
	Stage 1	Stage 2	Stage 3	Stage 4	Stage 5	Stage 6	1 × M <sub>D</sub>	2 × M <sub>D</sub>	$3 \times M_D$
1	M <sub>1</sub>						M <sub>1</sub>		
2	M <sub>1</sub>	M <sub>1</sub> +M <sub>2</sub>					M <sub>1</sub> , M <sub>2</sub>		
3	M <sub>1</sub>	M <sub>2</sub>	M <sub>1</sub> +M <sub>2</sub>				M <sub>1</sub>	M <sub>2</sub>	
4	M <sub>1</sub>	M <sub>1</sub> +M <sub>2</sub>	$M_1 + M_2 + M_3$				$M_1, M_2, M_3$		
5	M <sub>1</sub>	M <sub>3</sub>	$M_1+M_3$	$M_1 + M_2 + M_3$			M <sub>1</sub> , M <sub>2</sub>	M <sub>3</sub>	
6	M <sub>1</sub>	M <sub>2</sub>	$M_1+M_2$	$M_2+M_3$	$M_1 + M_2 + M_3$		M <sub>1</sub>	M <sub>2</sub> , M <sub>3</sub>	
7	M <sub>1</sub>	M <sub>1</sub> +M <sub>2</sub>	M <sub>3</sub>	$M_1+M_3$	M <sub>1</sub> +M <sub>2</sub> +M <sub>3</sub>		M <sub>1</sub> , M <sub>2</sub>		$M_3$
8	M <sub>1</sub>	M <sub>2</sub>	M <sub>3</sub>	$M_1+M_3$	$M_2+M_3$	$M_1 + M_2 + M_3$	M <sub>1</sub>	M <sub>2</sub>	$M_3$

#### **Parameter**

Parameter	Description	Factory setting
p2200	Technology controller enable	0
p2251	Technology controller mode	0
p2370	Cascade control enable	0
p2371	Cascade control configuration	0
p2372	Cascade control motor selection mode	0
p2373	Cascade control activation threshold	20 %
p2374	Cascade control activation delay	30 s
p2375	Cascade control deactivation delay	30 s
p2376	Cascade control overload threshold	25 %
p2377	Cascade control interlock time	0 s
p2378	Cascade control activation/deactivation speed	50 %
r2379	Cascade control status word	
p2380	Cascade control operating hours	0 h
p2381	Cascade control maximum time for continuous mode	24 h
p2382	Cascade control absolute operating time limit	24 h
p2383	Cascade control deactivation sequence	0
p2384	Cascade control motor switch-on delay	0 s
p2385	Cascade control stop time activation speed	0 s
p2386	Cascade control motor switch-off delay	0 s
p2387	Cascade control stop time deactivation speed	0 s

Additional information is provided in the parameter list and in function diagram 7036.

## **Further information**

#### Interaction with the "Hibernation mode" function

In order that the "Cascade control" and "Hibernation mode" functions do not influence each other, you must make the following settings in the cascade control:

- p2392 < p2373
  - The restart value of the hibernation mode p2392 must be lower than the activation threshold for the cascade control p2373.
- p2373 < p2376
  - The activation threshold for the cascade control p2373 must be lower than the overload threshold for the cascade control p2376.
- The actual speed must be higher than the restart speed for hibernation mode  $(p1080 + p2390) \times 1.05$ .
- The value for the activation delay of the cascade control p2374 must be higher than the rampup time t<sub>v</sub> from hibernation mode.
  - $t_v = (p1080 + p2390) \times 1.05 \times p1120 \times p1139/p1082$

#### 8.23 Real time clock (RTC)



The real-time clock is the basis for time-dependent process controls, e.g.:

- To reduce the temperature of a heating control during the night
- To increase the pressure of a water supply at certain times during the day

## Accept the real-time clock in the alarm and fault buffer

Using the real-time clock, you can track the sequence of alarms and faults over time. When an appropriate message occurs, the converter converts the real-time clock into the UTC time format (Universal Time Coordinated):

Date, time  $\Rightarrow$  01.01.1970, 0:00 + d (days) + m (milliseconds)

The converter takes the number "d" of the days and the number "m" of the milliseconds in the alarm and fault times of the alarm and/or fault buffer.



Alarms, faults and system messages (Page 441)

## **Converting UTC to RTC**

An RTC can again be calculated in the UTC format from the saved fault or alarm time. In the Internet, you will find programs to convert from UTC to RTC, e.g.



UTC to RTC (http://unixtime-converter.com/)

#### **Example:**

Saved as alarm time in the alarm buffer:

r2123[0] = 2345 [ms]r2145[0] = 14580 [days]

Number of seconds =  $2345 / 1000 + 14580 \times 86400 = 1259712002$ Converting this number of seconds to RTC provides the date: 02.12.2009, 01:00:02.

The times specified for alarms and faults always refer to standard time.

# **Function and settings**

The real time clock starts as soon as the converter's power supply is switched on for the first time. The real-time clock comprises the time in a 24 hour format and the date in the "day, month, year" format.

After a power supply interruption, the real time clock continues to run for approx. five days.

If you wish to use the real-time clock, you must set the time and date once when commissioning.

If you restore the converter factory setting, the converter only resets parameters p8402 and p8405 of the real-time clock. P8400 and p8401 are not reset.

# 8.23 Real time clock (RTC)

# **Parameters**

Number	Name	Factory setting
p8400[0 2]	RTC time	0
p8401[0 2]	RTC date	1.1.1970
p8402[0 8]	RTC daylight saving time setting	0
r8403	RTC daylight saving time actual difference	-
r8404	RTC weekday	-
p8405	Activate/deactivate RTC alarm A01098	1

# 8.24 Time switch (DTC)



The "time switch" (DTC) function, along with the real-time clock in the converter, offers the option of controlling when signals are switched on and off.

#### **Examples:**

- Switching temperature control from day to night mode.
- Switching a process control from weekday to weekend.

# Principle of operation of the time switch (DTC)

The converter has three independently adjustable time switches. The time switch output can be interconnected with every binector input of your converter, e.g. with a digital output or a technology controller's enable signal.




Figure 8-43 Example of the response of the time switch.

#### Settings for the example with DTC1

- Enable parameterization of the DTC: p8409 = 0. As long as the parameterization of the DTC is enabled, the converter holds the output of all three DTC (r84x3, x = 1, 2, 3; r84x3.0 normal, r84x3.1 inverted status message) at LOW.
- Activate/deactivate the weekday
  - p8410[0] = 0 Monday
  - p8410[1] = 1 Tuesday
  - p8410[2] = 1 Wednesday
  - p8410[3] = 0 Thursday
  - p8410[4] = 1 Friday
  - -p8410[5] = 1 Saturday
  - -p8410[6] = 0 Sunday
- Setting switching times:
  - ON: p8411[0] = 20 (hh), p8411[1] = 0 (MM)
  - OFF: p8412[0] = 10 (hh), p4812[1] = 0 (MM)
- Enable the setting: p8409 = 1. The converter re-enables the DTC output.

## 8.25 Motor control

#### Overview



The converter has two alternative methods to ensure the motor speed follows the configured speed setpoint:

- U/f control
- Vector control

# 8.25.1 Reactor, filter and cable resistance at the converter output

#### Overview

Components between the converter and the motor influence the closed-loop control quality of the converter:

- Output reactor or sine-wave filter In the factory setting, for the motor data identification, the converter assumes that neither output reactor nor sine wave filter are connected at the converter output.
- Motor cable with unusually high cable resistance.
   For the motor data identification, the converter assumes a cable resistance = 20 % of the stator resistance of the cold motor.

## **Function description**

You must correctly set the components between the converter and motor to achieve an optimum closed-loop control quality

#### **Procedure**

- 1. Set p0010 = 2.
- 2. Set the cable resistance in p0352.
- 3. Set p0230 to the appropriate value.
- 4. Set p0235 to the appropriate value.
- 5. Set p0010 = 0.
- 6. Carry out the guick commissioning and the motor identification again.
  - Commissioning (Page 165)

You have set the reactor, filter and cable resistance between the converter and motor.

#### **Parameter**


Number	Name	Factory setting
p0010	Drive commissioning parameter filter	1
p0230	Drive filter type, motor side	0
p0235	Number of motor reactors in series	1
p0350[M]	Motor stator resistance, cold	0 Ω
p0352[M]	Cable resistance	0 Ω

For further information on parameters, please refer to the parameter list.

## 8.25.2 U/f control

## 8.25.2.1 U/f control

## Overview



In the "Flux Current Control (FCC)" U/f version, the converter controls the motor current (starting current) at low speeds.

Figure 8-44 Simplified function diagram of the U/f control

The U/f control is a speed feedforward control with the following properties:


- The converter sets the output voltage on the basis of the U/f characteristic.
- The output frequency is essentially calculated from the speed setpoint and the number of pole pairs of the motor.
- The slip compensation corrects the output frequency depending on the load and thus increases the speed accuracy.
- The omission of a control loop means that the U/f control is stable in all cases.
- In applications with higher speed accuracy requirements, a load-dependent voltage boost can be selected (flux current control, FCC)

For operation of the motor with U/f control, you must set at least the following subfunctions appropriate for your application:

- U/f characteristic
- · Voltage boost

## **Function description**

The converter has different U/f characteristics.



- 1 The voltage boost of the characteristic optimizes motor start-up
- ② With flux current control (FCC), the converter compensates the voltage drop across the stator resistance of the motor

Figure 8-45 U/f characteristics of the converter

With increasing speed or output frequency, the converter increases its output voltage U. The maximum possible output voltage of the converter depends on the line voltage.

The converter can increase the output frequency even at the maximum output voltage. The motor is then operated with field weakening.

The value of the output voltage at the rated motor frequency also depends on the following variables:

The value of the output voltage at the rated motor frequency p0310 also depends on the following variables:

- Ratio between the converter size and the motor size
- Line voltage
- Line impedance
- · Actual motor torque

The maximum possible output voltage as a function of the input voltage is provided in the technical data.




Table 8-58 Linear and parabolic characteristics

Requirement	Application examples	Remark	Characteristic	Parameter
The required tor-	Eccentric-worm pump,	-	Linear	p1300 = 0
que is independ- ent of the speed	compressor	drops across the stator resistance. Recom-	Linear with Flux Current Control (FCC)	p1300 = 1
		Precondition: The motor data has been set according to the rating plate and the motor has been identified after the basic commissioning.		
The required torque increases with the speed	Centrifugal pumps, radial fans, axial fans, compressors	Lower losses in the motor and converter than for a linear characteristic.	Parabolic	p1300 = 2

Table 8-59 Characteristics for special applications

Requirement	Application examples	Remark	Characteristic	Parameter
Applications with a low dynamic response and constant speed	Centrifugal pumps, radial fans, axial fans	The ECO mode saves more energy than the parabolic characteristic.  If the speed setpoint is reached and remains unchanged for 5 seconds, the converter reduces its output voltage again.	ECO mode	p1300 = 4 (linear characteristic ECO) or p1300 = 7 (parabolic characteristic ECO)

## **Parameters**

Number	Name	Factory setting
r0025	CO: Output voltage, smoothed	- Vrms
r0066	CO: Output frequency	- Hz
r0071	Output voltage, maximum	- Vrms
p0304[M]	Rated motor voltage	0 Vrms
p0310[M]	Rated motor frequency	0 Hz
p1300[D]	Open-loop/closed-loop control operating mode	See parameter list
p1333[D]	U/f control FCC starting frequency	0 Hz
p1334[D]	U/f control slip compensation starting frequency	0 Hz
p1335[D]	Slip compensation scaling	0%
p1338[D]	U/f mode resonance damping gain	0

## 8.25.2.2 Optimizing motor starting

#### Overview

After selection of the U/f characteristic, no further settings are required in most applications.

In the following circumstances, the motor cannot accelerate to its speed setpoint after it has been switched on:

- Load moment of inertia too high
- Load torque too large
- Ramp-up time p1120 too short

To improve the starting behavior of the motor, a voltage boost can be set for the U/f characteristic at low speeds.

## Requirement

The ramp-up time of the ramp-function generator is, depending on the motor rated power, 1 s  $(< 1 \text{ kW}) \dots 10 \text{ s} (> 10 \text{ kW})$ .

## **Function description**

## Setting the voltage boost for U/f control

The converter boosts the voltage corresponding to the starting currents p1310 ... p1312.




Figure 8-46 The resulting voltage boost using a linear characteristic as example

Increase parameter values p1310 ... p1312 in steps of  $\leq$  5 %. Excessively high values in p1310 ... p1312 can cause the motor to overheat and switch off (trip) the converter due to overcurrent.

If message A07409 appears, it is not permissible that you further increase the value of any of the parameters.

## **Procedure**

- 1. Switch on the motor with a setpoint of a few revolutions per minute.
- 2. Check whether the motor rotates smoothly.

- 3. If the motor does not rotate smoothly, or even remains stationary, increase the voltage boost p1310 until the motor runs smoothly.
- 4. Accelerate the motor to the maximum speed with maximum load.
- 5. Check that the motor follows the setpoint.
- 6. If necessary, increase the voltage boost p1311 until the motor accelerates without problem.

In applications with a high break loose torque, you must also increase parameter p1312 in order to achieve a satisfactory motor response.

You have set the voltage boost.

#### **Parameter**

Number	Name	Factory setting
r0071	Output voltage, maximum	Vrms
p0310[M]	Rated motor frequency	0 Hz
p1310[D]	Starting current (voltage boost) permanent	50%
p1311[D]	Starting current (voltage boost) when accelerating	0%
p1312[D]	Starting current (voltage boost) when starting	0%

# 8.25.2.3 U/f control with Standard Drive Control application class

#### Overview





Figure 8-47 Default setting of the U/f control after selecting Standard Drive Control

Selecting application class Standard Drive Control in the quick commissioning adapts the structure and the setting options of the U/f control as follows:

- Starting current closed-loop control: At low speeds, a controlled motor current reduces the tendency of the motor to oscillate.
- With increasing speed, the converter changes from closed-loop starting current control to U/f control with load-dependent voltage boost.
- The slip compensation is activated.
- Soft starting is not possible.
- Reduced setting options

# **Function description**

## Characteristics after selecting the application class Standard Drive Control



- 1 The closed-loop starting current control optimizes the speed control at low speeds
- 2 The converter compensates the voltage drop across the motor stator resistance

Figure 8-48 Characteristics after selecting Standard Drive Control

The application class Standard Drive Control reduces the number of characteristics and setting options:

- A linear and a parabolic characteristic are available.
- Selecting a technological application defines the characteristics.

Table 8-60 Linear and parabolic characteristics

Requirement	Application examples	Remark	Charac- teristic	Parameter
The required torque is independent of the speed	Eccentric-worm pump, compressor	-	Linear	p0501 = 0
The required torque increases with the speed	Centrifugal pumps, radial fans, axial fans	Lower losses in the motor and converter than for a linear characteristic.		p0501 = 1

## **Parameter**

Number	Name	Factory setting
r0025	CO: Output voltage, smoothed	- Vrms
r0066	CO: Output frequency	- Hz
r0071	Output voltage, maximum	- Vrms

# 8.25 Motor control

Number	Name	Factory setting
p0310[M]	Rated motor frequency	0 Hz
p501	Technology application	0

## 8.25.2.4 Optimizing motor starting using Standard Drive Control

#### Overview

After selecting application class Standard Drive Control, in most applications no additional settings need to be made.

At standstill, the converter ensures that at least the rated motor magnetizing current flows. Magnetizing current p0320 approximately corresponds to the no-load current at  $50 \% \dots 80 \%$  of the rated motor speed.

In the following circumstances, the motor cannot accelerate to its speed setpoint after it has been switched on:

- Load moment of inertia too high
- Load torque too large
- Ramp-up time p1120 too short

The current can be increased at low speeds to improve the starting behavior of the motor.

## Requirement

The ramp-up time of the ramp-function generator is, depending on the motor rated power, 1 s  $(< 1 \text{ kW}) \dots 10 \text{ s} (> 10 \text{ kW})$ .

## **Function description**

#### Starting current (boost) after selecting the application class Standard Drive Control




Figure 8-49 The resulting voltage boost using a linear characteristic as example

The converter boosts the voltage corresponding to the starting currents p1310 ... p1312.

Increase parameter values p1310 ... p1312 in steps of  $\leq$  5 %. Excessively high values in p1310 ... p1312 can cause the motor to overheat and switch off (trip) the converter due to overcurrent.

If message A07409 appears, it is not permissible that you further increase the value of any of the parameters.

#### **Procedure**

- 1. Switch on the motor with a setpoint of a few revolutions per minute.
- 2. Check whether the motor rotates smoothly.
- 3. If the motor does not rotate smoothly, or even remains stationary, increase the voltage boost p1310 until the motor runs smoothly.
- 4. Accelerate the motor with the maximum load.
- 5. Check that the motor follows the setpoint.
- 6. If necessary, increase the voltage boost p1311 until the motor accelerates without problem.

In applications with a high break loose torque, you must also increase parameter p1312 in order to achieve a satisfactory motor response.

You have set the voltage boost.

#### **Parameter**


Number	Name	Factory setting
r0071	Output voltage, maximum	Vrms
p0310[M]	Rated motor frequency	0 Hz
p0320[M]	Rated motor magnetizing current / short-circuit current	0 Arms
p1310[D]	Starting current (voltage boost) permanent	50%
p1311[D]	Starting current (voltage boost) when accelerating	0%
p1312[D]	Starting current (voltage boost) when starting	0%

## 8.25.3 Sensorless vector control

#### 8.25.3.1 Structure of vector control without encoder (sensorless)

#### Overview

The vector control comprises closed-loop current control and a higher-level closed-loop speed control.



- 1) for induction motors
- 2) Settings that are required

Figure 8-50 Simplified function diagram for sensorless vector control with speed controller

Using the motor model, the converter calculates the following closed-loop control signals from the measured phase currents and the output voltage:

- Current component I
- Current component I<sub>a</sub>
- Speed actual value

The setpoint of the current component  $I_d$  (flux setpoint) is obtained from the motor data. For speeds above the rated speed, the converter reduces the flux setpoint along the field weakening characteristic.

When the speed setpoint is increased, the speed controller responds with a higher setpoint for current component  $I_q$  (torque setpoint). The closed-loop control responds to a higher torque setpoint by adding a higher slip frequency to the output frequency. The higher output frequency also results in a higher motor slip, which is proportional to the accelerating torque.

 $I_q$  and  $I_d$  controllers keep the motor flux constant using the output voltage, and adjust the matching current component  $I_q$  in the motor.

## Settings that are required

Restart quick commissioning and select the vector control in quick commissioning.

Commissioning (Page 165)

In order to achieve a satisfactory control response, as a minimum you must set the partial functions – shown with gray background in the diagram above – to match your particular application:

- Motor and current model: In the quick commissioning, correctly set the motor data on the rating plate corresponding to the connection type  $(Y/\Delta)$ , and carry out the motor data identification routine at standstill.
- Speed limits and torque limits: In the quick commissioning, set the maximum speed (p1082) and current limit (p0640) to match your particular application. When exiting quick commissioning, the converter calculates the torque and power limits corresponding to the current limit. The actual torque limits are obtained from the converted current and power limits and the set torque limits.
- **Speed controller**: Start the rotating measurement of the motor data identification. You must manually optimize the controller if the rotating measurement is not possible.

# Default settings after selecting the application class Dynamic Drive Control

Selecting application class Dynamic Drive Control adapts the structure of the vector control and reduces the setting options:

	Vector control after selecting the applica- tion class Dynamic Drive Control	Vector control without se- lecting an application class
Hold or set the integral component of the speed controller	Not possible	Possible
Acceleration model for precontrol	Default setting	Can be activated
Motor data identification at standstill or with rotating measurement	Shortened, with op- tional transition into operation	Complete

## 8.25.3.2 Optimizing the speed controller


## Optimum control response - post optimization not required

Preconditions for assessing the controller response:

- The moment of inertia of the load is constant and does not depend on the speed
- The converter does not reach the set torque limits during acceleration
- You operate the motor in the range 40 % ... 60 % of its rated speed

#### 8 25 Motor control

If the motor exhibits the following response, the speed control is well set and you do not have to adapt the speed controller manually:




The speed setpoint (broken line) increases with the set ramp-up time and rounding.

The speed actual value follows the setpoint without any overshoot.

# Control optimization required

In some cases, the self optimization result is not satisfactory, or self optimization is not possible as the motor cannot freely rotate.



Initially, the speed actual value follows the speed setpoint with some delay, and then overshoots the speed setpoint.

First, the actual speed value increases faster than the speed setpoint. Before the setpoint reaches its final value, it passes the actual value. Finally, the actual value approaches the setpoint without any significant overshoot.

In the two cases describe above, we recommend that you manually optimize the speed control.

## Optimizing the speed controller


#### Requirements

- Torque precontrol is active: p1496 = 100 %.
- The load moment of inertia is constant and independent of the speed.
- The converter requires 10 % ... 50 % of the rated torque to accelerate. When necessary, adapt the ramp-up and ramp-down times of the ramp-function generator (p1120 and p1121).

#### **Procedure**

- 1. Switch on the motor.
- 2. Enter a speed setpoint of approximately 40 % of the rated speed.
- 3. Wait until the actual speed has stabilized.
- 4. Increase the setpoint up to a maximum of 60% of the rated speed.
- 5. Monitor the associated characteristic of the setpoint and actual speed.

6. Optimize the controller by adapting the ratio of the moments of inertia of the load and motor (p0342):



- 7. Switch off the motor.
- 8. Set p0340 = 4. The converter again calculates the speed controller parameters.
- 9. Switch on the motor.
- 10. Over the complete speed range check as to whether the speed control operates satisfactorily with the optimized settings.

You have optimized the speed controller.

When necessary, set the ramp-up and ramp-down times of the ramp-function generator (p1120 and p1121) back to the value before optimization.

## Mastering critical applications

The drive control can become unstable for drives with a high load moment of inertia and gearbox backlash or a coupling between the motor and load that can possibly oscillate. In this case, we recommend the following settings:

- Increase p1452 (smoothing the speed actual value).
- Increase p1472 (integral time  $T_i$ ):  $T_i \ge 4 \cdot p1452$
- If, after these measures, the speed controller does not operate with an adequate dynamic performance, then increase p1470 (gain K<sub>P</sub>) step-by-step.

## **Parameters**

Table 8-61 Encoderless speed control

Number	Name	Factory setting
p0342[M]	Ratio between the total and motor moments of inertia	1
p1452	Speed controller actual speed value smoothing time (encoderless)	10 ms
p1470[D]	Speed controller encoderless operation P gain	0.3
p1472[D]	Speed controller encoderless operation integral time	20 ms
p1496[D]	Acceleration precontrol scaling	0%

# 8.26 Electrically braking the motor

# 8.26.1 Electrical braking

#### Overview



#### Braking with the motor in generator operation

If the motor brakes the connected load electrically, it converts the kinetic energy of the motor into electrical energy. The electrical energy E released when braking the load is proportional to the moment of inertia J of the motor and load and to the square of the speed n. The motor attempts to transfer the energy on to the converter.

#### Main features of the braking functions


## DC braking

DC braking prevents the motor from transferring the braking energy to the converter. The converter impresses a DC current into the motor, which brakes the motor. The motor converts the braking energy E of the load into heat.

- Advantage: The motor brakes the load without the converter having to process regenerative power.
- Disadvantages: significant increase in the motor temperature; no defined braking characteristics; no constant braking torque; no braking torque at standstill; braking energy E is lost as heat; does not function when the power fails

#### Compound braking


One version of DC braking. The converter brakes the motor with a defined ramp-down time and superimposes a DC current on the output current.



## Dynamic braking

Using a braking resistor, the converter converts the electrical energy into heat.

- Advantages: defined braking response; motor temperature does not increase any further; constant braking torque
- Disadvantages: Braking resistor required; braking energy E is lost in the form of heat



# Which Power Module permits which braking method?

Electrical braking method	Power Modules that can be used
DC braking	PM230, PM240P-2, PM240-2, PM330
Compound braking	PM240P-2, PM240-2
Dynamic braking	PM240-2, PM330
Braking with energy recovery into the line supply	PM250

8.26 Electrically braking the motor

# 8.26.2 DC braking

#### Overview

DC braking is used for applications where the motor must be actively braked, but where the converter is neither capable of energy recovery nor does it have a braking resistor.

Typical applications for DC braking include:

- · Centrifuges
- Saws
- · Grinding machines
- Conveyor belts

DC braking is not permissible in applications involving suspended loads, e.g. lifting equipment/cranes and vertical conveyors.

# Requirement

The DC braking function is possible only for induction motors.

#### NOTICE

# Motor overheating as a result of DC braking

The motor will overheat if you use DC braking too frequently or use it for too long. This may damage the motor.

- Monitor the motor temperature.
- Allow the motor to adequately cool down between braking operations.
- If necessary, select another motor braking method.

## **Function description**

With DC braking, a constant braking current flows through the motor. As long as the motor is rotating, the DC current generates a braking torque.

The following configurations are available for DC braking:

- DC braking initiated by a control command
- DC braking when falling below a starting speed
- DC braking when the motor is switched off

Regardless of the configuration, you also can define the DC braking as a reaction to certain converter faults.



## WARNING

## Unexpected motor acceleration

In the following configurations, the converter can accelerate the motor to the set speed without requiring a further ON command:

- DC braking initiated by a control command
- DC braking when falling below a starting speed

An unexpected acceleration of the motor can cause serious injury or material damage.

Consider the behavior of the drive in the higher-level controller.

#### DC braking initiated by a control command




Figure 8-51 Activating DC braking via a control command

Set p1231 = 4 and p1230 = control command.

The control command "DC braking activation" activates and deactivates the DC braking:

- 1 signal:
  - The converter de-energizes the motor for the motor de-excitation time p0347 in order to demagnetize the motor.
  - The converter activates the DC braking.
- 0 signal: The drive switches back to normal operation.

## DC braking when falling below a starting speed




Figure 8-52 DC braking when falling below a starting speed

Set p1231 = 14 and p1230 = control command.

With an active DC braking command (p1230 = 1 signal), the following occurs:

- If motor speed < starting speed p1234:</li>
   The converter de-energizes the motor for the motor de-excitation time p0347 in order to demagnetize the motor.
- 2. The converter activates the DC braking.
- 3. The drive switches back to normal operation if at least one of the following conditions has been fulfilled:
  - "DC braking duration" p1233 has expired.
  - The DC braking command is inactive (p1230 = 0 signal).

## DC braking when the motor is switched off




Figure 8-53 DC braking when the motor is switched off Set p1231 = 5.

The following occurs after an OFF1 or OFF3 command:

- 1. The motor brakes along the OFF1 or OFF3 deceleration ramp to starting speed p1234.
- 2. The converter de-energizes the motor for the motor de-excitation time p0347 in order to demagnetize the motor.
- 3. The converter activates the DC braking.
- 4. After "DC braking duration" p1233 expires, the converter de-energizes the motor.

If the OFF1 command is deactivated before "DC braking duration" p1233 expires, the converter terminates the DC braking and switches to normal operation.

## DC braking as reaction to a fault




Figure 8-54 DC braking as a fault reaction

Set p2101[x] = 6 and p2100[x] to the corresponding fault code.

If you have defined the DC braking as a reaction to a fault, then the following will occur:

- 1. The converter brakes the motor with OFF1.
- 2. The converter de-energizes the motor for the motor de-excitation time p0347 in order to demagnetize the motor.
- 3. The converter activates the DC braking.
- 4. After "DC braking duration" p1233 expires, the converter de-energizes the motor.

#### **Parameter**

## Settings for DC braking

Parameter	Description	Factory setting
p0347[M]	Motor de-excitation time	0 s
p1230[C]	BI: DC braking activation	0
p1231[M]	Configuring DC braking	0
p1232[M]	DC braking, braking current	0 Arms
p1233[M]	DC braking duration	1 s
p1234[M]	Speed at the start of DC braking	210000 rpm
r1239[813]	CO/BO: DC braking status word	-

# 8.26 Electrically braking the motor

Table 8-62 Configuring DC braking as a response to faults

Parameter	Description	Factory setting
p2100[019]	Changing the fault reaction, fault code	0
p2101[019]	Changing the fault reaction, reaction	0

# 8.26.3 Compound braking

#### Overview

Compound braking is suitable for applications in which the motor is normally operated at a constant speed and is only braked down to standstill in longer time intervals.

Typically, the following applications are suitable for compound braking:

- Centrifuges
- Saws
- · Grinding machines
- Horizontal conveyors

Compound braking is not permissible for applications with suspended loads, e.g. lifting equipment/cranes all vertical conveyors.

## **Function description**




Figure 8-55 Motor brakes with and without active compound braking

Compound braking prevents the DC-link voltage increasing above a critical value. The converter activates compound braking depending on the DC-link voltage. Above a DC-link voltage threshold (r1282), the converter adds a DC current to the motor current. The DC current brakes the motor and prevents an excessive increase in the DC-link voltage.

#### Note

Compound braking is possible only with the U/f control.

Compound braking does not operate in the following cases:

- The "flying restart" function is active
- · DC braking is active
- Vector control is selected

# 8.26 Electrically braking the motor

## **NOTICE**

# Overheating of the motor due to compound braking

The motor will overheat if you use compound braking too frequently or for too long. This may damage the motor.

- Monitor the motor temperature.
- Allow the motor to adequately cool down between braking operations.
- If necessary, select another motor braking method.

## **Parameter**

Table 8-63 Setting and enabling compound braking

Parameter	Description	Factory setting
r1282	Vdc_max controller switch-on level (U/f)	- V
p3856[D]	Compound braking current (%)	0%
r3859.0	CO/BO: Compound braking/equal quantity control status word	-

# 8.26.4 Dynamic braking

## Overview

Dynamic braking processes the regenerative power that occurs during braking of the motor. In this way, the converter can accelerate and brake the motor with the same dynamic response.

The following are typical applications for dynamic braking:

- Centrifuge
- Horizontal conveyors
- Vertical and inclined conveyors
- · Hoisting gear

# Requirement

You are using a PM240-2 power module and a braking resistor.

## **Function description**




Figure 8-56 Simplified representation of dynamic braking when a motor is reversed

## 8.26 Electrically braking the motor

The motor supplies regenerative power to the converter when braking. The regenerative power means that the DC-link voltage in the converter increases. Above the activation threshold for the braking module, the converter forwards the regenerative power to the braking resistor. The braking resistor converts the regenerative power into heat, thereby preventing converter faults due to excessive DC-link voltage.

Factory setting for the activation threshold for the braking module:

690 V converter: 1120 V
400 V converters: 760 V
200 V converter: 385 V

## NOTICE

## Overload of motor insulation during braking


When the motor brakes, the DC-link voltage, and thus also the voltage load of the motor, increases. Particularly when you operate a 500 V motor on a 690 V converter, the converter can overload the motor insulation and damage the motor.

• Reduce the activation threshold for the braking module

#### **Procedure**

#### 1. Setting the braking power

Using p0219, you define the maximum braking power that the braking resistor must absorb.



P<sub>max</sub> Maximum braking power of the braking resistor

p021 Maximum braking power of the application

Figure 8-57 Example of maximum braking power in an application

p0219 > 0 activates dynamic braking. Boundary conditions for p0219:

p0219 is too low:

The converter cannot fully convert the generated braking power into heat. The converter extends the ramp-down time of the motor in order to reduce the braking power.

p0219 > maximum braking power of the braking resistor:

The temperature monitoring of the braking resistor can trigger a converter fault.

Connecting the temperature contact of the braking resistor (Page 156)

You can find the maximum braking power of the braking resistor in the Hardware Installation Manual of the power module.

Overview of the manuals (Page 581)

The SIZER PC tool supports you when calculating the maximum braking power.

Configuring support (Page 584)

## 2. If necessary: Reduce the activation threshold for the braking module

You can reduce the activation threshold for the braking module for the following converters:

- 690 V converter
- 400 V converter

We recommend the following settings, particularly when using a 500 V motor:

- Set p0212.8 = 1
- Enter the rated value of the converter supply voltage in p0210.
   Enter the voltage value at the intended place of use of the converter, if known, in p0210.

You have now set the dynamic braking.

#### Example

You can find an example for configuring and commissioning a drive with braking resistor on the Internet:

Engineering and commissioning series lifting equipment/cranes (<a href="https://support.industry.siemens.com/cs/de/en/view/103156155">https://support.industry.siemens.com/cs/de/en/view/103156155</a>)

## **Parameters**

Parameter	Description	Factory setting
r0063	CO: Actual speed value	- rpm
r0070	CO: Actual DC link voltage value	- V
p0210	Device supply voltage	400 V
p0212	Power unit configuration	0000 0000 bin
p0219	Braking resistor braking power	0 kW
r0297	DC-link voltage overvoltage threshold	- V

## **Further information**

## Interaction with other functions

When you set the braking power of the braking resistor (p0219 > 0), the converter disables the Vdc max control.

Motor and converter protection by limiting the voltage (Page 401)

At the same time, p0219 defines the regenerative power limit p1531 for vector control.

Sensorless vector control (Page 374)

# 8.26.5 Braking with regenerative feedback to the line


## Overview

The typical applications for braking with energy recovery (regenerative feedback into the line supply) are as follows:

- Hoist drives
- Centrifuges
- Unwinders

For these applications, the motor must brake for longer periods of time.

The converter can feed back up to 100% of its rated power into the line supply (referred to "High Overload" base load).



## **Parameter**

## Setting the braking with regenerative feedback to the line

Parameter	Description	Factory setting
Limiting the regenerative feedback for U/f control (p1300 < 20)		
p0640[D]	Current limit	0 Arms
Limiting feedback with vector control (p1300 ≥ 20)		
p1531[D]	Power limit, generating	-0.01 kW

# 8.27 Overcurrent protection

#### Overview



The U/f control prevents too high a motor current by influencing the output frequency and the motor voltage (I-max controller).

# Requirement

You have selected U/f control.

The application must allow the motor torque to decrease at a lower speed.

# **Function description**

The I-max controller influences the output frequency and the motor voltage.

If the motor current reaches the current limit during acceleration, the I-max controller extends the acceleration operation.

If the motor load is so high during steady-state operation that the motor current reaches the current limit, then the I-max controller reduces the speed and the motor voltage until the motor current returns to the permissible range again.

If the motor current reaches the current limit during deceleration, the I-max controller extends the deceleration operation.

# Changing the settings

The factory setting for proportional gain and the integral time of the I-max controller ensures faultless operation in the vast majority of cases.

The factory setting of the I-max controller must only be changed in the following exceptional cases:

- Speed or torque of the motor tend to cause vibrations upon reaching the current limit.
- The converter goes into the fault state with an overcurrent message.

## **Parameter**

Number	Name	Factory setting
r0056.0 13	CO/BO: Status word, closed-loop control	-
p0305[M]	Rated motor current	0 Arms
p0640[D]	Current limit	0 Arms
p1340[D]	I_max frequency controller proportional gain	0
p1341[D]	I_max frequency controller integral time	0.300 s
r1343	CO: I_max controller frequency output	- rpm

# 8.28 Converter protection using temperature monitoring

#### Overview



The converter temperature is essentially defined by the following effects:

- The ambient temperature
- The ohmic losses increasing with the output current
- Switching losses increasing with the pulse frequency

## Monitoring types

The converter monitors its temperature using the following monitoring types:

- I<sup>2</sup>t monitoring (alarm A07805, fault F30005)
- Measuring the chip temperature of the Power Module (alarm A05006, fault F30024)
- Measuring the heat sink temperature of the Power Module (alarm A05000, fault F30004)

# **Function description**

## Overload response for p0290 = 0

The converter responds depending on the control mode that has been set:

- In vector control, the converter reduces the output current.
- In U/f control, the converter reduces the speed.

Once the overload condition has been removed, the converter re-enables the output current or speed.

If the measure cannot prevent a converter thermal overload, then the converter switches off the motor with fault F30024.

# Overload response for p0290 = 1

The converter immediately switches off the motor with fault F30024.

#### Overload response for p0290 = 2

We recommend this setting for drives with square-law torque characteristic, e.g. fans.

# 8.28 Converter protection using temperature monitoring

The converter responds in 2 stages:

1. If you operate the converter with increased pulse frequency setpoint p1800, then the converter reduces its pulse frequency starting at p1800.

In spite of the temporarily reduced pulse frequency, the base-load output current remains unchanged at the value that is assigned to parameter p1800.




Figure 8-58 Derating characteristic and base load output current for overload

Once the overload condition has been removed, the converter increases the pulse frequency back to the pulse frequency setpoint p1800.

- 2. If it is not possible to temporarily reduce the pulse frequency, or the risk of thermal overload cannot be prevented, then stage 2 follows:
  - In vector control, the converter reduces its output current.
  - In U/f control, the converter reduces the speed.

Once the overload condition has been removed, the converter re-enables the output current or speed.

If both measures cannot prevent a power unit thermal overload, then the converter switches off the motor with fault F30024.

## Overload response for p0290 = 3

If you operate the converter with increased pulse frequency, then the converter reduces its pulse frequency starting at the pulse frequency setpoint p1800.

In spite of the temporarily reduced pulse frequency, the maximum output current remains unchanged at the value that is assigned to the pulse frequency setpoint. Also see p0290 = 2.

Once the overload condition has been removed, the converter increases the pulse frequency back to the pulse frequency setpoint p1800.

If it is not possible to temporarily reduce the pulse frequency, or the measure cannot prevent a power unit thermal overload, then the converter switches off the motor with fault F30024.

### Overload response for p0290 = 12

The converter responds in 2 stages:

- If you operate the converter with increased pulse frequency setpoint p1800, then the
  converter reduces its pulse frequency starting at p1800.
   There is no current derating as a result of the higher pulse frequency setpoint.
   Once the overload condition has been removed, the converter increases the pulse frequency
  back to the pulse frequency setpoint p1800.
- 2. If it is not possible to temporarily reduce the pulse frequency, or the risk of converter thermal overload cannot be prevented, then stage 2 follows:
  - In vector control, the converter reduces the output current.
  - In U/f control, the converter reduces the speed.

Once the overload condition has been removed, the converter re-enables the output current or speed.

If both measures cannot prevent a power unit thermal overload, then the converter switches off the motor with fault F30024.

#### Overload response for p0290 = 13

We recommend this setting for drives with a high starting torque.

If you operate the converter with increased pulse frequency, then the converter reduces its pulse frequency starting at the pulse frequency setpoint p1800.

There is no current derating as a result of the higher pulse frequency setpoint.

Once the overload condition has been removed, the converter increases the pulse frequency back to the pulse frequency setpoint p1800.

If it is not possible to temporarily reduce the pulse frequency, or the measure cannot prevent a power unit thermal overload, then the converter switches off the motor with fault F30024.

#### **Parameters**

Number	Name	Factory setting
r0036	CO: Power unit overload I2t	%
r0037[019]	Power unit temperatures	℃
p0290	Power unit overload response	2
p0292[01]	Power unit temperature alarm threshold	[0] 5 °C, [1] 15 °C
p0294	Power Module alarm for I2t overload	95%

### Special feature for PM330


For PM330, the overload response is permanently set to p0290 = 2. It cannot be changed.

### 8.29 Motor protection with temperature sensor

#### Overview



The converter can evaluate one of the following sensors to protect the motor against overtemperature:



- KTY84 sensor
- Temperature switch (e.g. bimetallic switch)



- PTC sensor
- Pt1000 sensor

### **Function description**

#### KTY84 sensor

#### NOTICE

### Overheating of the motor due to KTY sensor connected with the incorrect polarity

If a KTY sensor is connected with incorrect polarity, the motor can be damaged by overheating, as the converter cannot detect a motor overtemperature condition.

Connect the KTY sensor with the correct polarity.



Using a KTY sensor, the converter monitors the motor temperature and the sensor itself for wire-break or short-circuit:

• Temperature monitoring:

The converter uses a KTY sensor to evaluate the motor temperature in the range from  $-48 \,^{\circ}\text{C}$  ...  $+248 \,^{\circ}\text{C}$ .

Set the temperature for the alarm and fault thresholds with parameter p0604 or p0605.

- Overtemperature alarm (A07910):
  - motor temperature > p0604 and p0610 = 0
- Overtemperature fault (F07011):

The converter responds with a fault in the following cases:

- motor temperature > p0605
- motor temperature > p0604 and p0610 > 0
- Sensor monitoring (A07015 or F07016):
  - Wire-break:

The converter interprets a resistance  $> 2120~\Omega$  as a wire-break and outputs the alarm A07015. After 100 milliseconds, the converter changes to the fault state with F07016.

– Short-circuit:

The converter interprets a resistance  $< 50 \Omega$  as a short-circuit and outputs the alarm A07015. After 100 milliseconds, the converter changes to the fault state with F07016.

### Temperature switch



The converter interprets a resistance  $\geq 100 \,\Omega$  as an opened bimetallic switch and responds according to the setting for p0610.

#### PTC sensor



The converter interprets a resistance  $> 1650 \Omega$  as being an overtemperature condition and responds according to the setting of p0610.

The converter interprets a resistance < 20  $\Omega$  as being a short-circuit and responds with alarm A07015. If the alarm is present for longer than 100 milliseconds, the converter shuts down with fault F07016.

#### Pt1000 sensor



Using a Pt1000 sensor, the converter monitors the motor temperature and the sensor itself for wire breakage and/or short-circuit:

• Temperature monitoring:

Using a Pt1000 sensor, the converter evaluates the motor temperature in the range from -48  $^{\circ}$ C ... +248  $^{\circ}$ C.

Set the temperature for the alarm and fault thresholds with parameter p0604 or p0605.

- Overtemperature alarm (A07910):
  - motor temperature > p0604 and p0610 = 0
- Overtemperature fault (F07011):

The converter responds with a fault in the following cases:

- motor temperature > p0605
- motor temperature > p0604 and p0610 > 0
- Sensor monitoring (A07015 or F07016):
  - Wire-break:

The converter interprets a resistance  $> 2120~\Omega$  as a wire-break and outputs the alarm A07015. After 100 milliseconds, the converter changes to the fault state with F07016.

– Short-circuit:

The converter interprets a resistance  $< 603 \Omega$  as a short-circuit and outputs the alarm A07015. After 100 milliseconds, the converter changes to the fault state with F07016.

### **Parameters**

Number	Name	Factory setting
p0335[M]	Type of motor cooling	0
p0601[M]	Motor temperature sensor type	0
p0604[M]	Mot_temp_mod 2/sensor alarm threshold	130 °C
p0605[M]	Mot_temp_mod 1/2/sensor threshold and temperature value	145 °C
p0610[M]	Motor overtemperature response	12
p0640[D]	Current limit	0 Arms

8.30 Motor protection by calculating the temperature

### 8.30 Motor protection by calculating the temperature

#### Overview



The converter calculates the motor temperature based on a thermal motor model. After commissioning, the converter sets the thermal motor type to match the motor.

The thermal motor model responds far faster to temperature increases than a temperature sensor.

If the thermal motor model is used together with a temperature sensor, e.g. a Pt1000, then the converter corrects the model according to the measured temperature.

### **Function description**

#### Thermal motor model 2 for induction motors

The thermal motor model 2 for induction motors is a thermal 3-mass model, consisting of stator core, stator winding and rotor. Thermal motor model 2 calculates the temperatures - both in the rotor as well as in the stator winding.




Figure 8-59 Thermal motor model 2 for induction motors

#### **Parameter**

Table 8-64 Thermal motor model 2 for induction motors

Number	Name	Factory setting
r0068[0 1]	CO: Absolute actual current value	- Arms
p0344[M]	Motor weight (for thermal motor model)	0 kg
p0604[M]	Mot_temp_mod 2/KTY alarm threshold	130 °C
p0605[M]	Mot_temp_mod 1/2/sensor threshold and temperature value	145 °C
p0610[M]	Motor overtemperature response	12
p0612[M]	Mot_temp_mod activation	0000 0010 0000 0010 bin
p0625[M]	Motor ambient temperature during commissioning	20 °C
p0627[M]	Motor overtemperature, stator winding	80 K
r0632[M]	Mot_temp_mod stator winding temperature	- °C
p0640[D]	Current limit	0 Arms

### Thermal motor model 1 for synchronous reluctance motors

Thermal motor model 1 calculates the temperature of the stator winding from the motor current and the thermal time constant of the motor model.




Figure 8-60 Thermal motor model 1 for reluctance motors

#### **Parameters**

Table 8-65 Thermal motor model 1 for reluctance motors

Number	Name	Factory setting
r0034	CO: Thermal motor load	- %
r0068[0 1]	CO: Absolute actual current value	- Arms
p0318[M]	Motor stall current	0 Arms
p0610[M]	Motor overtemperature response	12
p0611[M]	12t thermal motor model time constant	0 s
p0612[M]	Mot_temp_mod activation	0000 0010 0000 0010 bin
p0613[M]	Mot_temp_mod 1/3 ambient temperature	20 °C
p0625[M]	Motor ambient temperature during commissioning	20 °C
p0627[M]	Motor overtemperature, stator winding	80 K
r0632[M]	Mot_temp_mod stator winding temperature	- °C
p5390[M]	Mot_temp_mod 1/3 alarm threshold	110 °C
p5391[M]	Mot_temp_mod 1/3 fault threshold	120 °C

8.31 How do I achieve a motor overload protection in accordance with IEC/UL 61800-5-1?

# 8.31 How do I achieve a motor overload protection in accordance with IEC/UL 61800-5-1?

#### Overview

The thermal motor model of the converter fulfills motor overload protection according to IEC/ UL 61800-5-1.

For motor overload protection according to IEC/UL 61800-5-1, some parameters of the thermal motor model may also need to be adjusted.

### Requirement

You have correctly entered the motor data during guick commissioning.

#### NOTICE

### Thermal overload of third-party motors due to a trip threshold that is too high

With a Siemens motor, the converter sets the trip threshold of the thermal motor model to match the motor. With a third-party motor, the converter cannot ensure in every case that the trip threshold is exactly right for the motor. A trip threshold that is set too high can lead to a thermal overload, thus causing damage to the motor.

• If required for a third-party motor, reduce the corresponding trip threshold p0605, p0615, or p5391.

#### **Procedure**

- 1. Set p0610 = 12.
- 2. Set the following parameters depending on the motor:
  - Induction motor:

```
p0612.1 = 1
```

p0612.9 = 1

For a motor without temperature sensor:  $p0625 = 40 \,^{\circ}\text{C}$ 

Synchronous motor

p0612.0 = 1

p0612.8 = 1

For a motor without temperature sensor: p0613 = 40 °C

The trip threshold p0605, p0615 or p5391 parameterized in the motor data set may not be increased.

Changing additional parameters of the thermal motor model can lead to the converter no longer satisfying the motor overload protection in accordance with IEC/UL 61800-5-1.

### 8.32 Motor and converter protection by limiting the voltage

#### Overview



An electric motor converts electrical energy into mechanical energy to drive the load. If the motor is driven by its load, e.g. by the inertia of the load during braking, the energy flow reverses: The motor operates temporarily as a generator, and converts mechanical energy into electrical energy. The electrical energy flows from the motor to the converter. The converter stores the energy in its DC-link capacitors. As a consequence, the DC link voltage Vdc in the converter is higher.

An excessively high DC link voltage damages both the converter and the motor. The converter therefore monitors its DC-link voltage and, when necessary, switches off the connected motor and outputs the fault "DC-link overvoltage".

### Requirement

The Vdc\_max control can be used only with the PM230, PM240-2, PM240P-2 and PM330 Power Modules.

You must deactivate the Vdc\_max control if you are using a braking resistor.

PM250 Power Modules feed back regenerative energy into the line supply. Deactivate Vdc\_max control for PM250 Power Modules.

### **Function description**

### Protecting the motor and converter against overvoltage




Figure 8-61 Simplified representation of the Vdc\_max control

### 8.32 Motor and converter protection by limiting the voltage

The Vdc max control lengthens the motor ramp-down time when braking. Consequently, the motor feeds only so much energy back into the converter to cover the losses in the converter. The DC link voltage remains within the permissible range.



Electrical braking (Page 378)

### **Parameter**

The parameters differ depending on the motor control mode.

Table 8-66 Parameters for U/f control

Parameter	Description	Factory setting
p0210	Device supply voltage	400 V
p1280[D]	Vdc controller configuration (U/f)	1
r1282	Vdc_max controller switch-on level (U/f)	- V
p1283[D]	Vdc_max controller, dynamic factor (U/f)	100%
p1284[D]	Vdc_max controller time threshold (U/f)	4 s
p1290[D]	Vdc controller proportional gain (U/f)	1
p1291[D]	Vdc controller integral time (U/f)	40 ms
p1292[D]	Vdc controller derivative-action time (U/f)	10 ms
p1294	Vdc_max controller automatic ON level detection (U/f)	0

Table 8-67 Parameters for vector control

Parameter	Description	Factory setting
p0210	Device supply voltage	400 V
p1240[D]	Vdc controller configuration (vector control)	1
r1242	Vdc_max controller switch-in level	- V
p1243[D]	Vdc_max controller, dynamic factor	100%
p1250[D]	Vdc controller proportional gain	1
p1251[D]	Vdc controller integral time	0 ms
p1252[D]	Vdc controller derivative-action time	0 ms
p1254	Vdc_max controller automatic ON level detection	0

Further information is provided in the parameter list.

### 8.33 Monitoring the driven load



In many applications, the speed and the torque of the motor can be used to determine whether the driven load is in an impermissible operating state. The use of an appropriate monitoring function in the converter prevents failures and damage to the machine or plant.

### Examples:

- For fans, an excessively low torque indicates a torn drive belt.
- For pumps, insufficient torque can indicate a leakage or dry-running.
- The motor can be blocked by an excessively high torque at a low speed.

### Functions for monitoring the driven load

The converter provides the following options to monitor the driven load based on the output current:

M X	The stall protection recognizes a stalled asynchronous motor.
	The no-load monitoring evaluates the motor current. An insufficient current can mean that the motor cable is disconnected.
	The blocking protection triggers for a motor current that corresponds to the set current limit coupled with motor standstill.
	The torque monitoring assumes that a specific torque is associated with each speed for pumps and fans. Insufficient torque indicates that the motor and the load are no longer mechanically connected.
	An excessive torque can indicate problems in the mechanical system of the driven load, e.g. a mechanically blocked load.
	Blocking protection, leakage protection and dry-running protection are a monitoring method for pumps or fans. The monitoring combines a torque monitoring with a blocking protection.


Monitoring the driven load using a binary signal:



The speed monitoring evaluates a periodic binary signal. A signal failure indicates that the motor and the load are no longer mechanically connected with each other.

### 8.33.1 Stall protection

### **Function description**



If the load of a standard induction motor exceeds the stall torque of the motor, the motor can also stall during operation on the converter. A stalled motor is stationary and does not develop sufficient torque to accelerate the load.

If the "Motor model fault signal stall detection" r1746 for the time p2178 is present via the "Motor model error threshold stall detection" p1745, the converter signals "Motor stalled" and fault F07902.

#### **Parameter**

Number	Name	Factory setting
r1408[0 14]	CO/BO: Status word, current controller	-
p1745[D]	Motor model error threshold stall detection	5%
r1746	Motor model fault signal stall detection	- %
p2178[D]	Motor stalled delay time	0.01 s
r2198	CO/BO: Status word monitoring functions 2	-

#### See also

Blocking protection (Page 405)

### 8.33.2 No-load monitoring

### **Function description**



An insufficient motor current indicates that the motor cable is disconnected.

If the motor current for the time p2180 lies below the current level p2179, the converter signals the alarm A07929.

### **Parameters**

Number	Name	Factory setting
r0068[0 1]	CO: Absolute actual current value	- Arms
p2179[D]	Output load detection current limit	0 Arms
p2180[D]	Output load detection delay time	2000 ms
r2197[0 13]	CO/BO: Status word monitoring functions 1	-

### 8.33.3 Blocking protection

### **Function description**



If the mechanical load is too high, the motor may block. For a blocked motor, the motor current corresponds to the set current limit without the speed reaching the specified setpoint.

If the speed lies below the speed threshold p2175 for the time p2177 while the motor current reaches the current limit, the converter signals "Motor blocked" and fault F07900.

### **Parameter**

Number	Name	Factory settings
p0045	Display values of smoothing time constant	4 ms
r0063	CO: Speed actual value	- rpm
p2175[D]	Motor blocked speed threshold	120 rpm
p2177[D]	Motor blocked delay time	3 s
r2198	Status word monitoring functions 2	-


### 8.33.4 Torque monitoring

### **Function description**



In applications with fans, pumps or compressors with the flow characteristic, the torque follows the speed according to a specific characteristic. An insufficient torque for fans indicates that the power transmission from the motor to the load is interrupted. For pumps, insufficient torque can indicate a leakage or dry-running.

The converter monitors the torque based on the envelope curve depending on the speed against a lower and upper torque.



If the torque lies in the impermissible range longer than time p2192, the converter reacts as specified in p2181.

The monitoring is not active below speed threshold 1 and above speed threshold 3.

#### Setting monitoring

- 1. Operate the drive at three different speeds in succession.
- 2. Set the speed thresholds p2182 ... p2184 to the respective values.
- 3. Set the torque thresholds for each speed. The converter displays the current torque in r0031.
- 4. Set p2193 = 1.

You have now set monitoring.

#### **Parameter**

Number	Name	Factory setting
r0031	Torque actual value, smoothed	-
p2181[D]	Load monitoring, response	0
p2182[D]	Load monitoring, speed threshold 1	150 rpm
p2183[D]	Load monitoring, speed threshold 2	900 rpm
p2184[D]	Load monitoring, speed threshold 3	1500 rpm

## 8.33 Monitoring the driven load

Number	Name	Factory setting
p2185[D]	Load monitoring, torque threshold 1, upper	10000000 Nm
p2186[D]	Load monitoring torque threshold 1, lower	0 Nm
p2187[D]	Load monitoring torque threshold 2, upper	10000000 Nm
p2188[D]	Load monitoring torque threshold 2, lower	0 Nm
p2189[D]	Load monitoring torque threshold 3, upper	10000000 Nm
p2190[D]	Load monitoring torque threshold 3, lower	0 Nm
p2191[D]	Load monitoring torque threshold, no load	0 Nm
p2192[D]	Load monitoring, delay time	10 s
p2193[D]	Load monitoring configuration	1


### 8.33.5 Blocking protection, leakage protection and dry-running protection

### Overview



In applications with fans, pumps or compressors with the flow characteristic, the torque follows the speed according to a specific characteristic. An insufficient torque for fans indicates that the power transmission from the motor to the load is interrupted. For pumps, insufficient torque can indicate a leakage or dry-running.

### **Function description**



If the torque and speed lie in the impermissible range longer than time p2192, the converter reacts as specified in p2181.

For applications with pumps, the converter detects the following states of the driven load:

- Blocked
- Leakage
- Dry running

For applications with fans or compressors, the converter detects the following states of the driven load:

- Blocked
- Torn belt

The monitoring is not active below speed threshold 1 and above speed threshold 3.

When using the control mode "U/f control" (p1300 < 10), the "Blocking protection" function becomes active when the current limit is reached.

Blocking protection (Page 405)

### **Setting pump monitoring**

- 1. Set p2193 = 4.
- 2. The converter sets the monitoring as shown.




Figure 8-62 Default settings for pumps

- 3. The converter sets monitoring response p2181 = 7
- 4. If necessary, adjust the speed thresholds p2182 ... p2184.
- 5. If necessary, adjust the torque threshold for each speed. The converter displays the current torque in r0031.

You have now set monitoring.

### Setting fan and compressor monitoring

- 1. Set p2193 = 5.
- 2. The converter sets the monitoring as shown.




Figure 8-63 Default settings for fans and compressors

3. The converter sets monitoring response p2181 = 7

### 8.33 Monitoring the driven load

- 4. If necessary, adjust the speed thresholds p2182 ... p2184.
- 5. Set the torque threshold for each speed. The converter displays the current torque in r0031.

You have now set monitoring.

#### **Parameter**

Number	Name	Factory setting
r0031	Torque actual value, smoothed	-
p0311[M]	Rated motor speed	0 rpm
r0333[M]	Rated motor torque	-
p1080[D]	Minimum speed	0 rpm
p1082[D]	Maximum speed	1500 rpm
p1300[D]	Open-loop/closed-loop control operating mode	See parameter list
p2165[D]	Load monitoring blocking monitoring threshold, upper	0 rpm
p2168[D]	Load monitoring blocking monitoring torque threshold	10000000 Nm
p2181[D]	Load monitoring, response	0
p2182[D]	Load monitoring, speed threshold 1	150 rpm
p2183[D]	Load monitoring, speed threshold 2	900 rpm
p2184[D]	Load monitoring, speed threshold 3	1500 rpm
p2186[D]	Load monitoring torque threshold 1, lower	0 Nm
p2188[D]	Load monitoring torque threshold 2, lower	0 Nm
p2190[D]	Load monitoring torque threshold 3, lower	0 Nm
p2191[D]	Load monitoring torque threshold, no load	0 Nm
p2192[D]	Load monitoring, delay time	10 s
p2193[D]	Load monitoring configuration	1

### **Further information**

If you deselect monitoring with p2193 < 4, the converter then resets the load monitoring parameters to factory settings.

### See also

Torque monitoring (Page 406)

### 8.33.6 Rotation monitoring

### **Function description**



The converter monitors the speed or velocity of a machine component via an electromechanic or electronic encoder, e.g. a proximity switch. Examples of how the function can be used:

- Drive belt monitoring for fans
- Blocking protection for pumps

The converter checks whether the encoder consistently supplies a 24 V signal during motor operation. If the encoder signal fails for time p2192, the converter signals fault F07936.



Figure 8-64 Function plan and time response of the speed monitoring

### Setting monitoring

- 1. Set p2193 = 1.
- 2. Interconnect p3232 with a digital input of your choice.
- 3. If necessary, adjust the delay time.

You have now set monitoring.

#### **Parameter**

Number	Name	Factory setting
r0722	CO/BO: CU digital inputs, status	-
p2192[D]	Load monitoring, delay time	10 s
p2193[D]	Load monitoring configuration	1
p3232[C]	BI: Load monitoring, failure detection	1

#### See also

Torque monitoring (Page 406)

## 8.34 Flying restart – switching on while the motor is running

#### Overview



If you switch on the motor while it is still rotating, without the "Flying restart" function, there is a high probability that a fault will occur as a result of overcurrent (F30001 or F07801). Examples of applications involving an unintentionally rotating motor directly before switching on:

- The motor rotates after a brief line interruption.
- A flow of air turns the fan impeller.
- A load with a high moment of inertia drives the motor.

### Requirement

The converter may operate precisely one motor only.

It is not permissible that you enable the "Flying restart" function if the converter is simultaneously driving several motors. Exception: a mechanical coupling ensures that all of the motors always operate with the same speed.

### **Function description**

The "Flying restart" function comprises the following steps:

- 1. After the on command, the converter impresses the search current in the motor and increases the output frequency.
- 2. When the output frequency reaches the actual motor speed, the converter waits for the motor excitation build up time.
- 3. The converter accelerates the motor to the actual speed setpoint.




Figure 8-65 Principle of operation of the "flying restart" function

### **Parameter**

Number	Name	Factory setting
p1200[D]	Flying restart operating mode	0
r0331[M]	Actual motor magnetizing current / short-circuit current	- Arms
p0346[M]	Motor excitation build-up time	0 s

## 8.34 Flying restart – switching on while the motor is running

Number	Name	Factory setting
p0347[M]	Motor de-excitation time	0 s
p1201[C]	BI: Flying restart enable signal source	1
p1202[D]	Flying restart detection current	90% 100%
p1203[D]	Flying restart search rate factor	150% 100%

### 8.35 Automatic restart

#### Overview



The automatic restart includes two different functions:

- The converter automatically acknowledges faults.
- After a fault occurs or after a power failure, the converter automatically switches-on the motor again.

The converter interprets the following events as power failure:

- The converter signals fault F30003 (undervoltage in the DC link), after the converter line voltage has been briefly interrupted.
- All the converter power supplies have been interrupted and all the energy storage devices in the converter have discharged to such a level that the converter electronics fail.

### **Function description**

### Setting the automatic restart function



#### WARNING

### Unexpected machine motion caused by the active automatic restart function

When the "automatic restart" function is active (p1210 > 1), the motor automatically starts after a line supply phase. Unexpected movement of machine parts can result in serious injury and material damage.

• Block off hazardous areas within the machine to prevent inadvertent access.

If it is possible that the motor is still rotating for a longer period of time after a power failure or after a fault, then you must also activate the "flying restart" function.

Flying restart – switching on while the motor is running (Page 412)

Using p1210, select the automatic restart mode that best suits your application.





Figure 8-66 Automatic restart modes

The principle of operation of the other parameters is explained in the following diagram and in the table below



1) The converter automatically acknowledges faults under the following conditions:

- p1210 = 1 or 26: Always.
- p1210 = 4 or 6: If the command to switch-on the motor is available at a digital input or via the fieldbus (ON/OFF1 = 1).
- p1210 = 14 or 16: Never.

2) The converter attempts to automatically switch the motor on under the following conditions:

- p1210 = 1: Never.
- p1210 = 4, 6, 14, 16, or 26: If the command to switch-on the motor is available at a digital input or via the fieldbus (ON/OFF1 = 1).

Figure 8-67 Time response of the automatic restart

Further information is provided in the parameter list.

### Advanced settings

If you with to suppress the automatic restart function for certain faults, then you must enter the appropriate fault numbers in p1206[0 ... 9].

Example:  $p1206[0] = 07331 \Rightarrow No restart for fault F07331$ .

 $<sup>^{3)}</sup>$  If, after a flying restart and magnetization (r0056.4 = 1) no fault occurs within one second, then the start attempt was successful.

#### 8.35 Automatic restart

Suppressing the automatic restart only functions for the setting p1210 = 6, 16 or 26.

### Note

### Motor starts in spite of an OFF command via the fieldbus

The converter responds with a fault if fieldbus communication is interrupted. For one of the settings p1210 = 6, 16 or 26, the converter automatically acknowledges the fault and the motor restarts, even if the higher-level control attempts to send an OFF command to the converter.

• In order to prevent the motor automatically starting when the fieldbus communication fails, you must enter the fault number of the communication error in parameter p1206.

### **Parameter**

Number	Name	Factory setting
p1206	Automatic restart faults not active	0
p1210	Automatic restart mode	0
p1211	Automatic restart, start attempts	3
p1212	Automatic restart, wait time start attempts	1 s
p1213[0]	Automatic restart monitoring time for restart	60 s
p1213[1]	Reset automatic restart monitoring time for startup counter	0 s

### 8.36 Kinetic buffering (Vdc min control)

#### Overview



Kinetic buffering increases the drive availability. The kinetic buffering utilizes the kinetic energy of the load to buffer line dips and failures. During a line dip, the converter keeps the motor in the switched-on state for as long as possible. One second is a typical maximum buffer time.

### Requirement

The following requirements must be fulfilled to practically use the "kinetic buffering" function:

- The driven machine has a sufficiently high inertia.
- The application allows a motor to be braked when the line supply fails.

The Vdc\_min control is possible only with the PM240-2, PM240P-2 and PM330 Power Modules.

### **Function description**

When the line supply dips, the DC-link voltage in the converter decreases. The kinetic buffering ( $V_{DCmin}$  control) intervenes at an adjustable threshold. The  $V_{DCmin}$  control forces the load to go into slightly regenerative operation. As a consequence, the converter covers its power loss and the losses in the motor with the kinetic energy of the load. The load speed decreases, but the DC-link voltage remains constant during the kinetic buffering. After the line supply returns, the converter immediately resumes normal operation.




Figure 8-68 Principle mode of operation of kinetic buffering

8.36 Kinetic buffering (Vdc min control)

### Parameter

Parameter	Description	Factory setting
r0056[015]	CO/BO: Status word, closed-loop control	-
p0210	Device supply voltage	400 V
p1240[D]	Vdc controller configuration (vector control)	1
p1245[D]	Vdc_min controller switch-in level (kinetic buffering)	73% 76%
r1246	Vdc_min controller switch-in level (kinetic buffering)	- V
p1247[D]	Vdc_min controller dynamic factor (kinetic buffering)	300%
p1255[D]	Vdc_min controller, time threshold	0 s
p1257[D]	Vdc_min controller, speed threshold	50 rpm

#### 8.37 Essential service mode

#### Overview



In essential service mode (ESM), the converter attempts to operate the motor for as long as possible despite irregular ambient conditions.

The converter logs the essential service mode and any faults that occur during essential service mode. The log is accessible only for the service and repair organization.

#### Note

### Warranty is lost in the essential service mode

When the essential service mode is active, and faults occur in the converter, all warranty claims associated with the converter become null and void. The faults can have the following causes:

- Exceptionally high temperatures inside and outside the converter
- Open fire inside and outside the converter
- Emissions of light, noise, particles or gases

### **Function description**

#### Activating and terminating essential service mode

Signal p3880 = 1 activates the essential service mode.

Signal p3880 = 0 deactivates the essential service mode.

### Switching the motor on and off during active essential service mode

The OFF1, OFF2 and OFF3 commands for switching off the motor have no effect.

The converter blocks all functions that switch off the motor to save energy, e.g. PROFlenergy or hibernation mode.

The "Safe Torque Off" safety function terminates the essential service mode.



### **▲** WARNING

### Unexpected exiting of the essential service mode by selecting "Safe Torque Off"

An active Safe Torque Off (STO) safety function switches the motor off, thus terminating the essential service mode. The termination of essential service mode can cause severe injury or death, e.g. for the failure of a flue gas extraction.

- Prevent the STO safety function from being selected in essential service mode by controlling the converter appropriately.
- Take the unintentional selection of the STO safety function into account in the risk analysis of the system.

### Setpoint during active essential service mode

The converter changes the speed setpoint to the ESM setpoint source.

#### 8 37 Essential service mode

P3881 determines the ESM setpoint source. If you have defined an analog input as setpoint source using p3881, the converter can switch over to setpoint p3882 in case of wire breakage.

### Reaction to faults during active essential service mode

In "essential service mode", the converter does not switch off the motor when faults develop, but rather reacts differently depending on the fault type:

- The converter ignores faults, which do not directly result in the destruction of the converter or the motor.
- Faults with the reaction "OFF2" switch the motor off immediately. In this case, the converter attempts to automatically acknowledge the faults using the automatic restart function.
- For faults that cannot be acknowledged, it is possible to switch over the motor to line operation using the bypass function.

### Automatic restart during active essential service mode

The converter ignores the settings in p1206 (faults without automatic restart) and works with the setting "restart after a fault with further start attempts" (p1210 = 6).

The converter carries out the maximum number of restart attempts set in p1211 corresponding to the settings in p1212 and p1213. The converter outputs fault F07320 if the restart attempts are not successful.

### Interaction for bypass and essential service mode

- If the bypass mode is active when the essential service mode is activated, the converter changes to converter mode. This ensures that the converter uses the ESM setpoint source.
- If faults are still present after the number of start attempts parameterized in p1211, then the converter goes into a fault condition with F07320. In this case, there is an option of switching over to bypass operation and then directly connecting the motor to the line supply.

#### Procedure: Commissioning the essential service mode

- Interconnect a free digital input as signal source for the ESM activation.
   You must use a negated digital input if the essential service mode should also be active for a ground fault or if the control cable is interrupted.
   Example for negated digital input DI 3: Set p3880 = 723.3.
   It is not permissible to interconnect the digital input for ESM activation with other functions.
- 2. Set the ESM setpoint source via p3881.
- 3. Set the alternative ESM setpoint source via p3882.

- 4. Set the source to select the direction of rotation.
  - p3881 = 0, 1, 2, 3:

When you interconnect p3883 with a free digital input of your choice, p3883 inverts the direction of rotation during essential service mode.

For example, to interconnect p3883 with DI 4, set p3883 = 722.4.

- p3881 = 4:

The technology setpoint direction of rotation is valid.

5. Optional switching to bypass mode

If the converter is not able to acknowledge pending faults with automatic restart, it signals fault F07320 and does not make any other attempts to restart.

If the motor still continues to operate in this case, you must set the following:

- Set p1266 = 3889.10. The converter switches the motor to bypass mode with r3889.10 = 1.
- Ensure that the direction of rotation does not change when switching over to bypass operation.
- Set p1267.0 = 1. The converter switches the motor to bypass mode independent of the speed with control signal p1266.
- Commission the "Bypass" function.
   Bypass (Page 426)

You have commissioned the essential service mode.

### Example

To improve the air circulation in the stairwells, the ventilation control creates an underpressure in the building. With this control, a fire would mean that flue gases enter into the stairwell. This would then mean that the stairs would be blocked as escape or evacuation route.

Using the essential service mode function, the ventilation switches over to the control of an overpressure. The essential service mode prevents the propagation of flue gas in the stairwell, thereby keeping the stairs free as an evacuation route as long as possible.

An application example for the essential service mode can be found on the Internet:

http://support.automation.siemens.com/WW/view/en/63969509 (http://support.automation.siemens.com/WW/view/en/63969509)

#### **Parameters**

Number	Name	Factory setting
p1206[09]	Automatic restart faults not active	0
p1210	Automatic restart mode	0
p1211	Automatic restart, start attempts	3
p1212	Automatic restart, wait time start attempts	1 s
p1213	Automatic restart monitoring time for restart	60 s
p1213	Automatic restart reset monitoring time for start counter	0 s
p1266	BI: Bypass control command	0

### 8.37 Essential service mode

Number	Name	Factory setting
p1267	Bypass changeover source configuration	0000 bin
p3880	BI: ESM activation signal source	0
p3881	ESM setpoint source	0
p3882	ESM alternative setpoint source	0
p3883	BI: ESM direction of rotation signal source	0
p3884	CI: ESM technology controller setpoint	0
r3889[010]	CO/BO: ESM status word	-

# 8.38 Efficiency optimization

#### Overview



The efficiency optimization reduces the motor losses as far as possible.

Active efficiency optimization has the following advantages:

- Lower energy costs
- Lower motor temperature rise
- Lower motor noise levels

Active efficiency optimization has the following disadvantage:

• Longer acceleration times and more significant speed dips during torque surges.

The disadvantage is only relevant when the motor must satisfy high requirements relating to the dynamic performance. Even when efficiency optimization is active, the converter closed-loop motor control prevents the motor from stalling.

### Requirement

Efficiency optimization functions under the following preconditions:

- Operation with an induction motor
- Vector control is set in the converter.

### **Function description**




Figure 8-69 Efficiency optimization by changing the motor flux

The three variables that the converter can directly set, which define efficiency of an induction motor, are speed, torque and flux.

However, in all applications, speed and torque are specified by the driven machine. As a consequence, the remaining variable for the efficiency optimization is the flux.

The converter has two different methods of optimizing the efficiency.

### Efficiency optimization, method 2

Generally, energy efficiency optimization method 2 achieves a better efficiency than method 1.

We recommend that you set method 2.





Figure 8-70 Determining the optimum flux from the motor thermal model

Based on its thermal motor model, the converter continually determines - for the actual operating point of the motor - the interdependency between efficiency and flux. The converter then sets the flux to achieve the optimum efficiency.



- 1 Efficiency optimization is not active
- 2 Efficiency optimization is active

Figure 8-71 Qualitative result of efficiency optimization, method 2

Depending on the motor operating point, the converter either decreases or increases the flux in partial load operation of the motor.

### Efficiency optimization, method 1




Figure 8-72 Reduce the flux setpoint in the partial load range of the motor

The motor operates in partial load mode between no-load operation and the rated motor torque. Depending on p1580, in the partial load range, the converter reduces the flux setpoint linearly with the torque.




Figure 8-73 Qualitative result of efficiency optimization, method 1

The reduced flux in the motor partial load range results in higher efficiency.

### **Parameters**

Table 8-68 Efficiency optimization, method 2

Number	Name	Factory setting
p1401[D]	Flux control configuration	0000 0000 0000 0110 bin
p1570[D]	CO: Flux setpoint	100%
p3315[D]	Efficiency optimization 2 minimum flux limit value	50%
p3316[D]	Efficiency optimization 2 maximum flux limit value	110 %

Table 8-69 Efficiency optimization, method 1

Number	Name	Factory setting
p1570[D]	CO: Flux setpoint	100%
p1580[D]	Efficiency optimization	80%

8.39 Bypass

### 8.39 Bypass

#### Overview



The "Bypass" function switches the motor between converter and line operation.




Figure 8-74 Bypass with control via the converter

Requirements placed on the K1 converter contactor and K2 line contactor:

- K1 and K2 are designed for switching under load.
- K2 is designed for switching an inductive load.
- K1 and K2 are interlocked against closing at the same time.

### Requirements

- The "Bypass" function is supported only for induction motors.
- The "Flying restart" function must be activated for the "Bypass" function (p1200 = 1 or 4).

  Flying restart switching on while the motor is running (Page 412)

### **Function description**

### Switching from converter operation to line operation

- 1. The converter switches the motor OFF.
- 2. The converter opens the K1 converter contactor via a digital output.

- 3. The converter waits for the unlocking time of the motor.
- 4. The converter waits for the feedback that the K1 converter contactor is open.
- 5. The converter closes the K2 line contactor via a digital output.

The motor is now operated directly on the line supply. A multiple of the motor rated current can flow before the motor speed has reached the line frequency.

### Switching from line operation to converter operation

- 1. The converter opens the K2 line contactor via a digital output.
- 2. The converter waits for the unlocking time of the motor.
- 3. The converter waits for the feedback that the K2 line contactor is open.
- 4. The converter closes the K1 converter contactor via a digital output.
- 5. The converter switches the motor on.
- 6. The converter adjusts with the "Flying restart" function its output frequency to the speed of the motor.

The motor is now operated on the converter.

### How is the changeover triggered?

The following options are provided to switch between converter operation and line operation:

• Changeover for activation via a control command




Figure 8-75 Changeover when activating via a control signal (p1267.0 = 1)

The converter switches the motor between converter operation and line operation depending on the bypass control command p1266.

· Changeover depending on the speed




Figure 8-76 Changeover depending on the speed (p1267.1 = 1)

If the speed setpoint r1119 lies above the bypass speed threshold p1265, the converter switches the motor to line operation.

If the speed setpoint falls below the bypass speed threshold, the converter switches the motor to converter operation.

### **Parameter**

Number	Name	Factory setting
p0347[M]	Motor de-excitation time	0 s
p1260	Bypass configuration (factory setting: 0)	0
	0: Bypass is deactivated	
	3: Bypass without synchronization	
r1261	Bypass control/status word	-
p1262[D]	Bypass dead time	1 s
p1263	Debypass (revert to drive) delay time	1 s
p1264	Bypass delay time	1 s
p1265	Bypass speed threshold	1480 rpm
p1266	BI: Bypass control command	0
p1267	Bypass changeover source configuration	0000 bin
p1269	BI: Bypass switch feedback signal	[0] 1261.0
		[1] 1261.1
p1274[01]	Bypass switch monitoring time	1000 ms

Further information is provided in the parameter list.



Overview of the manuals (Page 581)

### **Further information**

Interaction with other functions:

- Essential service mode
  - The activated "Essential service mode" function influences the "Bypass" function. Essential service mode (Page 419)
- Converter control

For operation of the motor on the line supply, the converter no longer responds to the OFF1 command, but rather only to OFF2 and OFF3.

- Temperature monitoring for the motor
  - The converter evaluates the temperature sensor in the motor, also for line operation of the
  - Motor protection with temperature sensor (Page 396)
- Disconnecting the converter from the line supply If for line operation of the motor, you disconnect the converter from the line supply, the converter opens the K2 contactor and the motor coasts down.

To operate the motor on the line supply also for deactivated converter, the higher-level control must supply the signal for the K2 line contactor.

#### 8.40 Hibernation mode

#### Overview



When the hibernation mode is active, the converter switches off the motor once the system conditions allow it.

The hibernation mode saves energy, reduces wear and noise.

Pressure and temperature controls involving pumps and fans are typical applications for the hibernation mode.

### Requirement

As long as the cascade control operates a motor directly on the supply system, the converter does not activate the hibernation mode.



Cascade control (Page 357)

### **Function description**

#### Activating hibernation mode

The converter activates the hibernation mode in the following cases:

- After switching the converter on, a wait time starts in the converter. The longest wait time is at the following times:
  - p1120
  - p2391
  - 20 s

If the motor does not reach the hibernation mode start speed within the wait time, the converter activates the hibernation mode and switches off the motor.

The motor speed drops below the hibernation mode starting speed.

### Deactivating hibernation mode

The converter deactivates the hibernation mode in the following cases:

- With external setpoint value specification:
  - The converter deactivates the hibernation mode once the positive setpoint value is greater than the restart speed.
  - To monitor the setpoint, set p1110 = 0.
  - Activate the motorized potentiometer as ramp-function generator to use the motorized potentiometer of the converter as setpoint for the hibernation mode:
  - Motorized potentiometer: p1030.4 = 1
  - Technology motorized potentiometer: p2230.4 = 1
- If the setpoint value specification is set via the technology controller:
   The converter deactivates the hibernation mode once the positive control deviation of the technology controller is greater than the hibernation mode restart speed (p2392).
   To monitor the value of the control deviation of the technology controller, set p2298 = 2292 and set the minimum threshold in p2292.
- Time-controlled To avoid tank deposits, e.g. where liquids are involved, it is possible to deactivate the hibernation mode at the latest after the time p2396 has expired.

#### **Boost speed**

The boost speed prevents the motor from being switched on and off too frequently.

### **Parameter**

Table 8-70 Setpoint value specification via the technology controller

Number	Name	Factory setting
p1080	Minimum speed	0 [rpm]
p2200	BI: Technology controller enable	0
	1 signal: Technology controller is enabled	
r2237	Technology controller motorized potentiometer maximum value	- [%]
p2298	CI: Technology controller minimum limiting signal source	2292[0]
p2390[D]	Hibernation mode start speed	0 [rpm]
p2391[D]	Hibernation mode delay time	120 [s]
p2392	Hibernation mode restart value with technology controller	0 [%]
p2394[D]	Hibernation mode boost period	0 [s]
p2395[D]	Hibernation mode boost speed	0 [rpm]
p2396[D]	Hibernation mode switch-off time maximum	0 [s]
r2397	CO: Hibernation mode output speed current	- [rpm]
p2398	Hibernation mode duty type	0

## 8.40 Hibernation mode

Number	Name		Factory setting
r2399	CO/BO: H	libernation mode status word	-
	01 Hiber 02 Hiber 03 Hiber 04 Hiber 05 Hiber 06 Energ 07 Hiber generato 08 Hiber	nation mode bypasses ramp-function generator in	
	setpoint	Hibernation mode enabled (P2398 <> 0)	
	.01	Hibernation mode active	
	.02	Hibernation mode delay time active	
	.03	Hibernation mode boost active	
	.04	Hibernation mode motor switched off	
	.05	Hibernation mode motor switched off, cyclic restart active	
	.06	Hibernation mode motor is restarting	
	.07	Hibernation mode supplies total setpoint of ramp- function generator	
	.08	Hibernation mode bypasses the ramp-function generator in the setpoint channel	

Table 8-71 Setpoint value specification by means of external setpoint

Number	Name	Factory setting
p1080	Minimum speed	0 [rpm]
p1110	BI: Inhibit negative direction	1
p2390[D]	Hibernation mode start speed	0 [rpm]
p2391[D]	Hibernation mode delay time	120 [s]
p2393[D]	Hibernation mode restart speed relative w/o technology controller	0 [rpm]
p2394[D]	Hibernation mode boost period	0 [s]
p2395[D]	Hibernation mode boost speed	0 [rpm]
p2396[D]	Hibernation mode switch-off time maximum	0 [s]
r2397	CO: Hibernation mode output speed current	- [rpm]
p2398	Hibernation mode duty type	0

Number	Name		Factory setting
r2399	CO/BO:	Hibernation mode status word	-
	01 Hibe 02 Hibe 03 Hibe 04 Hibe 05 Hibe	ernation mode enabled (p2398 <> 0) ernation mode active ernation mode delay time active ernation mode boost active ernation mode motor switched off ernation mode motor switched off, cyclic restart active rgy-saving mode motor restarts	
	generat 08 Hibe	ernation mode supplies total setpoint of ramp-function tor ernation mode bypasses ramp-function generator in t channel	
	.00	Hibernation mode enabled (P2398 <> 0)	
	.01	Hibernation mode active	
	.02	Hibernation mode delay time active	
	.03	Hibernation mode boost active	
	.04	Hibernation mode motor switched off	
	.05	Hibernation mode motor switched off, cyclic restart active	
	.06	Hibernation mode motor is restarting	
	.07	Hibernation mode supplies total setpoint of ramp- function generator	
	.08	Hibernation mode bypasses the ramp-function generator in the setpoint channel	

## 8.41 Line contactor control

#### Overview



A line contactor disconnects the converter from the line supply, and therefore reduces the converter losses when the motor is not operational.

## Requirement

The line contactor control requires a 24 V power supply from the converter. The 24 V power supply must be maintained, even when the line contactor is open.

## **Function description**

The converter controls its own line contactor using a digital output.




Figure 8-77 Line contactor control via DO 2 with feedback signal via DI 3

## Activating the line contactor control

Connect the digital output that controls the line contactor with signal r0863.1.

Example for DO 2: p0732 = 863.1.

#### Line contactor control with feedback signal

Interconnect p0860 with the signal of the corresponding digital input:

- p0860 = 722.x: Feedback signal of an NO contact via DIx
- p0860 = 723.x: Feedback signal of an NC contact via DIx




Figure 8-78 Line contactor control via DO 2 with feedback signal via DI 3

If the line contactor feedback signal is not available for longer than the time set in p0861, then the converter issues fault F07300.

#### **Parameter**

Number	Name	Factory setting
r0046.0n	CO/BO: Missing enable signals	-
p0860	BI: Line contactor feedback signal	863.1
p0861	Line contactor monitoring time	100 ms
r0863.01	CO/BO: Drive coupling status word / control word	-
p0867	Power unit main contactor holding time after OFF1	50 ms
p0869	Configuration sequence control	0000 bin
p0870	BI: close main contactor	0

Further information is provided in the parameter list.

## Line contactor control for PM330 Power Modules

For a PM330, you can connect a line contactor via terminals X9.11 and X9.12.

In this case, parameter p0860 must be set to the factory setting: p0860 = 863.1: No feedback signal

Additional digital inputs and outputs on PM330 Power Modules (Page 142)

## 8.42 Calculating the energy saving for fluid flow machines

#### Overview



Fluid flow machines, which mechanically control the flow rate using valves or throttle flaps, operate with a constant speed corresponding to the line frequency.



Figure 8-79 Flow control with pump and throttle connected to a 50 Hz line supply

The lower the flow rate, the poorer the efficiency of the fluid flow machine (pump). The fluid flow machine (pump) has the poorest efficiency when the throttle or valve is completely closed. Further, undesirable effects can occur, for example the formation of vapor bubbles in liquids (cavitation) or the temperature of the medium being pumped can increase.

The converter controls the flow rate by appropriately varying the speed of the fluid flow machine. By controlling the flow rate, the fluid flow machine operates at the optimum efficiency for each flow rate. This situation means that in the partial load range less electric power is required than when controlling the flow rate using valves and throttles.





Figure 8-80 Flow control with pump and converter

### **Function description**



The converter calculates the energy saving from the flow characteristic associated with a mechanical flow control and the measured electric power that is drawn. The calculation is suitable for centrifugal pumps, fans, radial and axial compressors, for instance.

#### Flow characteristic




Figure 8-81 Factory setting of the flow characteristic

To set the characteristic, you require the following data from the machine manufacturer for each speed interpolation point:

- The flow rate of the fluid-flow machine associated with the 5 selected converter speeds
- At constant speed, the power drawn which is associated with the 5 flow rates corresponds to the line frequency and mechanical throttling of the flow rate.

#### **Parameters**

Number	Name	Factory setting
r0039[0n]	CO: Energy display	-
p0040	Reset energy consumption display	0
r0041	Energy saved	-
r0042[0n]	CO: Process energy display	-
p0043	BI: Energy consumption display enabled.	0
p3320[0n]	Fluid flow machine power, point 1	25
p3321[0n]	Fluid flow machine speed, point 1	0
p3322[0n]	Fluid flow machine power, point 2	50
p3323[0n]	Fluid flow machine speed, point 2	25
p3324[0n]	Fluid flow machine power, point 3	77
p3325[0n]	Fluid flow machine speed, point 3	50
p3326[0n]	Fluid flow machine power, point 4	92
p3327[0n]	Fluid flow machine speed, point 4	75
p3328[0n]	Fluid flow machine power, point 5	100
p3329[0n]	Fluid flow machine speed, point 5	100

## 8.43 Switchover between different settings

#### Overview

There are applications that require different converter settings.

#### **Example:**

Different motors are operated on one converter. The converter must operate with the motor data of the particular motor and the appropriate ramp-function generator.

## **Function description**

## **Drive Data Sets (DDS)**

Some converter functions can be set differently, and there can be a switch between the different settings.


#### Note

You can only switch over the motor data of the drive data sets in the "ready for operation" state with the motor switched off. The switchover time is approx. 50 ms.

If you do not switch over the motor data together with the drive data sets (i.e. same motor number in p0826), then the drive data sets can also be switched over in operation.

The associated parameters are indexed (index 0, 1, 2, or 3). One of the four indexes is selected with control commands, and thereby one of the four saved settings.

The settings in the converter with the same index are called a drive data set.



## Selecting the number of drive data sets

Parameter p0180 defines the number of drive data sets (1 ... 4).

Parameter	Description
p0010 = 0	Drive commissioning: Ready
p0010 = 15	Drive commissioning: Data sets
p0180	Drive data set (DDS) number

## Copying the drive data sets

Parameter	Description
p0819[0]	Source drive data set
p0819[1]	Target drive data set
p0819[2] = 1	Starts the copy operation

## **Parameters**

Number	Name	Factory setting
p0010	Drive commissioning parameter filter	1
r0051	CO/BO: Drive data set DDS effective	-
p0180	Drive data set (DDS) number	1
p0819[0 2]	Copy drive data set DDS	0
p0820[C]	BI: Drive data set DDS selection, bit 0	0
p0821[C]	BI: Drive data set DDS selection, bit 1	0
p0826[M]	Motor changeover, motor number	0

8.43 Switchover between different settings

Alarms, faults and system messages

9

The converter has the following diagnostic types:

• LED

The LEDs at the front of the converter immediately inform you about the most important converter states.

• System runtime

The system run time is the total time that the converter has been supplied with power since the initial commissioning.

· Alarms and faults

The converter signals alarms and faults via the following interfaces:

- Fieldbus
- Terminal strip with the appropriate setting
- Interface for an operator panel
- Interface for a PC
- Identification & maintenance data (I&M)
  If requested, the converter sends data to the higher-level control via PROFIBUS or PROFINET:
  - Converter-specific data
  - Plant-specific data

# 9.1 Operating states indicated via LEDs

Table 9-1 Explanation of symbols for the following tables

-	LED is ON
	LED is OFF
2 s	LED flashes slowly
2 s	LED flashes quickly
	LED flashes with variable frequency

Please contact Technical Support for LED states that are not described in the following.

Table 9-2 Basic states

RDY	Explanation
	Temporary state after the supply voltage is switched on.
-	The converter is free of faults
	Commissioning or reset to factory settings
洪	A fault is active
	Firmware update is active
洪	Converter waits until the power supply is switched off and switched on again after a firmware update

Table 9-3 PROFINET fieldbus

LNK	Explanation
	Communication via PROFINET is error-free
	Device naming is active
	No communication via PROFINET

Table 9-4 Fieldbuses via RS 485 interface

BF	Explanat	Explanation						
	Data excl	Data exchange between the converter and control system is active						
-14-	The fieldb	ous is active, however, the converter is not receiving any process data						
	RDY	When LED RDY flashes simultaneously:						
		Converter waits until the power supply is switched off and switched on again after a firmware update						
144	No fieldbus connection available							
	RDY	When LED RDY flashes simultaneously:						
	***	Incorrect memory card						
崇	Firmware update failed							
	Firmware	update is active						

## **Communication via Modbus or USS:**

If the fieldbus monitoring is deactivated with p2040 = 0, the BF-LED remains dark, independent of the communication state.

Table 9-5 PROFINET fieldbus

BF	Explanat	Explanation						
	Data excl	Data exchange between the converter and control system is active						
-\\\-	The fieldbus is improperly configured.							
	RDY	In conjunction with a synchronously flashing LED RDY:						
		Converter waits until the power supply is switched off and switched on again after a firmware update						
-14-	No communication with higher-level controller							
	RDY	In conjunction with an asynchronously flashing LED RDY:						
		Incorrect memory card						
***	Firmware update failed							
-11-	Firmware update is active							

## 9.1 Operating states indicated via LEDs

Table 9-6 PROFIBUS fieldbus

BF	Explanation							
	Data exch	Data exchange between the converter and control system is active						
	Fieldbus i	interface is not being used						
-14-	The fieldb	ous is improperly configured.						
	RDY	In conjunction with a synchronously flashing LED RDY:						
	Converter waits until the power supply is switched off and switched on again after firmware update							
\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	No communication with higher-level controller							
	RDY	In conjunction with an asynchronously flashing LED RDY:						
		Incorrect memory card						
	Firmware update failed							
-11-	Firmware	update is active						

## 9.2 System runtime

#### Overview

By evaluating the system runtime of the converter, you can decide when you should replace components subject to wear in time before they fail - such as fans, motors and gear units.

## **Function description**

The system runtime is started once the power supply of the converter is switched on. The system runtime stops when the power supply is switched off.

The system runtime comprises r2114[0] (milliseconds) and r2114[1] (days):

System runtime =  $r2114[1] \times days + r2114[0] \times milliseconds$ 

If r2114[0] has reached a value of 86,400,000 ms (24 hours), r2114[0] is set to the value 0 and the value of r2114[1] is increased by 1.

## Example

Parameter	Description		
r2114[0]	System runtime (ms)		
r2114[1]	System runtime (days)		

You cannot reset the system runtime.

#### **Parameters**

Parameter Description		Factory setting	
r2114[0 1]	Total system runtime	-	

## 9.3 Identification & maintenance data (I&M)

## **I&M** data

The converter supports the following identification and maintenance (I&M) data.

I&M data	Format	Explanation	Associated parameters	Example for the content
I&M0	u8[64] PROFIBUS u8[54] PROFINET	Converter-specific data, read only	-	See below
I&M1	Visible String [32]	Plant/system identifier	p8806[0 31]	"ak12-ne.bo2=fu1"
	Visible String [22]	Location code	p8806[32 53]	"sc2+or45"
I&M2	Visible String [16]	Date	p8807[0 15]	"2013-01-21 16:15"
I&M3	Visible String [54]	Any comment	p8808[0 53]	-
I&M4	Octet String[54]	Check signature to track changes for Safety Integrated.  This value can be changed by the user.	p8809[0 53]	Values of r9781[0] and r9782[0]
		The test signature is reset to the value generated by the machine if p8805 = 0 is used.		

When requested, the converter transfers its I&M data to a higher-level control or to a PC/PG with installed STEP 7 or TIA Portal.

## 1&M0

Designation	Format	Example for the content	Valid for PROFI- NET	Valid for PROFI- BUS
Manufacturer-specific	u8[10]	00 00 hex		✓
MANUFACTURER_ID	u16	42d hex (=Siemens)	✓	✓
ORDER_ID	Visible String [20]	"6SL3246-0BA22-1FA0"	✓	✓
SERIAL_NUMBER	Visible String [16]	"T-R32015957"	✓	✓
HARDWARE_REVISION	u16	0001 hex	✓	✓
SOFTWARE_REVISION	char, u8[3]	"V" 04.70.19	✓	✓
REVISION_COUNTER	u16	0000 hex	✓	✓
PROFILE_ID	u16	3A00 hex	✓	✓
PROFILE_SPECIFIC_TYPE	u16	0000 hex	✓	✓
IM_VERSION	u8[2]	01.02	✓	✓
IM_SUPPORTED	bit[16]	001E hex	✓	✓

## 9.4 Alarms, alarm buffer, and alarm history

#### Overview

An alarm generally indicates that the converter may no longer be able to maintain the operation of the motor in future.

The extended diagnostics have an alarm buffer and an alarm history, in which the converter stores the most recent alarms.

## **Function description**

Alarms have the following properties:

- Incoming alarms have no direct influence on the converter.
- A warning disappears as soon as its cause is eliminated.
- Alarms do not have to be acknowledged.

Alarm code or alarm value describe the cause of the alarm.

#### Alarm buffer

Alarm code	ode Alarm value		ode Alarm value Alarm time received		Alarm time	e removed	
	132	float	Days	ms		Days	ms
r2122[0]	r2124[0]	r2134[0]	r2145[0]	r2123[0]	old	r2146[0]	r2125[0]
[1]	[1]	[1]	[1]	[1]		[1]	[1]
[2]	[2]	[2]	[2]	[2]		[2]	[2]
[3]	[3]	[3]	[3]	[3]		[3]	[3]
[4]	[4]	[4]	[4]	[4]		[4]	[4]
[5]	[5]	[5]	[5]	[5]		[5]	[5]
[6]	[6]	[6]	[6]	[6]	\	[6]	[6]
[7]	[7]	[7]	[7]	[7]	new	[7]	[7]

Figure 9-1 Alarm buffer

The converter saves incoming alarms in the alarm buffer. An alarm includes an alarm code, an alarm value, and two alarm times:

- Alarm code: r2122
- Alarm value: r2124 in fixed-point format "I32", r2134 in floating-point format "Float"
- Alarm time received = r2145 + r2123
- Alarm time removed = r2146 + r2125

The converter takes its internal time calculation to save the alarm times.

Real time clock (RTC) (Page 361)

Up to 8 alarms can be saved in the alarm buffer.

In the alarm buffer, the alarms are sorted according to "Alarm time received". If the alarm buffer is completely filled and an additional alarm occurs, then the converter overwrites the values with Index [7].

### **Alarm history**




Figure 9-2 Shifting removed alarms into the alarm history

If the alarm buffer is completely filled and an additional alarm occurs, the converter shifts all removed alarms into the alarm history. The following occurs in detail:

- 1. To create space after position [8] in the alarm history, the converter shifts the alarms already stored in the alarm history "down" by one or more positions.

  If the alarm history is completely full, the converter will delete the oldest alarms.
- 2. The converter moves the removed alarms from the alarm buffer to the now freed up positions of the alarm history.
  - Alarms that have not been removed remain in the alarm buffer.
- 3. The converter closes gaps in the alarm buffer that occurred when the removed alarms were shifted in the alarm history by shifting the alarms that have not been removed "up".
- 4. The converter saves the received alarm as the latest alarm in the alarm buffer.

The alarm history saves up to 56 alarms.

In the alarm history, alarms are sorted according to the "alarm time removed". The latest alarm to be removed has Index [8].

### **Parameter**

Table 9-7 Parameters of the alarm buffer and the alarm history

Parameter	Description	Factory setting
p2111	Alarm counter	0
r2122[0 63]	Alarm code	-
r2123[0 63]	Alarm time received in milliseconds	- ms
r2124[0 63]	Alarm value	-
r2125[0 63]	Alarm time removed in milliseconds	- ms

Parameter	rameter Description	
r2132	CO: Actual alarm code	-
r2134[0 63]	Alarm value for float values	-
r2145[0 63]	Alarm time received in days	-
r2146[0 63]	Alarm time removed in days	-

Table 9-8 Extended settings for alarms

Parameter	Factory setting			
You can change up to 20 different alarms into a fault or suppress alarms:				
p2118[019]	p2118[019] Change message type, message number			
p2119[0 19] Change message type, type		1		

Further information is provided in the parameter list.

## 9.5 Faults, alarm buffer and alarm history

#### Overview

A fault generally indicates that the converter can no longer maintain the operation of the motor.

The extended diagnostics have a fault buffer and a fault history, in which the converter stores the most recent faults.

## **Function description**

Faults have the following properties:

- In general, a fault leads to the motor being switched off.
- A fault must be acknowledged.

#### Fault buffer

Fault code	Fault code Fault value		Fault time received		Fault time removed		
	132	float	Days	ms		Days	ms
r0945[0]	r0949[0]	r2133[0]	r2130[0]	r0948[0]	Old	r2136[0]	r2109[0]
[1]	[1]	[1]	[1]	[1]	_	[1]	[1]
[2]	[2]	[2]	[2]	[2]	_	[2]	[2]
[3]	[3]	[3]	[3]	[3]	-	[3]	[3]
[4]	[4]	[4]	[4]	[4]	-	[4]	[4]
[5]	[5]	[5]	[5]	[5]	-	[5]	[5]
[6]	[6]	[6]	[6]	[6]	_	[6]	[6]
[7]	[7]	[7]	[7]	[7]	New	[7]	[7]

Figure 9-3 Fault buffer

The converter saves incoming faults in the fault buffer. A fault includes a fault code, a fault value, and two fault times:

- Fault code: r0945
  The fault code and fault value describe the cause of the fault.
- Fault value: r0949 in fixed-point format "I32", r2133 in floating-point format "Float"
- Fault time received = r2130 + r0948
- Fault time removed = r2136 + r2109

The converter takes its internal time calculation to save the fault times.

Real time clock (RTC) (Page 361)

Up to 8 faults can be saved in the fault buffer.

In the fault buffer, the faults are sorted according to "Fault time received". If the fault buffer is completely full, and an additional fault is received in the fault buffer, then the converter overwrites the values with Index [7].

#### Acknowledge fault

To acknowledge a fault, you have the following options:

- PROFIdrive control word 1, bit 7 (r2090.7)
- · Acknowledge via a digital input
- Acknowledge via the Operator Panel
- Switch off the converter power supply and switch on again

Faults detected during the converter-internal monitoring of hardware and firmware can be acknowledged only by switching the supply voltage off and on again. In the list of faults in the List Manual, at the corresponding fault codes you may find the information on limitations when acknowledging.

### Fault history




Figure 9-4 Fault history after acknowledging the faults

If at least one of the fault causes in the fault buffer has been removed and you acknowledge the faults, the following takes place:

- 1. The converter shifts the values previously saved in the fault history each by eight indices. The converter deletes the faults that were saved in the indexes [56 ... 63] before the acknowledgement.
- 2. The converter copies the contents of the fault buffer to the memory locations [8 ... 15] in the fault history.
- 3. The converter deletes the faults that have been removed from the fault buffer.

  The faults that have not been removed are now saved both in the fault buffer and in the fault history.
- 4. The converter writes the time of acknowledgement of the removed faults to "Fault time removed".

The "Fault time removed" of the faults that have not been removed retains the value = 0.

The fault history can contain up to 56 faults.

## Deleting the fault history

To delete all faults from the fault history, set parameter p0952 = 0.

## **Parameter**

Table 9-9 Parameters of the fault buffer and the fault history

Parameter	Description	Factory setting
r0945[0 63]	Fault code	-
r0948[0 63]	Fault time received in milliseconds	- ms
r0949[063]	Fault value	-
p0952	Fault cases counter	0
r2109[0 63]	Fault time removed in milliseconds	- ms
r2130[0 63]	Fault time received in days	-
r2131	CO: Actual fault code	-
r2133[0 63]	Fault value for float values	-
r2136[0 63]	Fault time removed in days	-

## **Extended settings for faults**

Parameter	Description	Factory setting
p2100[019]	Changing the fault reaction, fault number	0
p2101[019]	Changing the fault reaction, reaction	0
p2118[019]	Change message type, message number	0
p2119[0 19]	Change message type, type	1
p2126[0 19]	Changing the acknowledge mode, fault number	0
p2127[0 19]	Changing the acknowledge mode	1

Further information is provided in the parameter list.

Axxxxx Alarm Fyyyyy: Fault

Table 9-10 The most important alarms and faults

Number	Cause	Remedy		
F01000	Software error in the CU	Replacing the Control Unit.		
F01001	Floating point exception	Switch the Control Unit off and on again.		
F01015	Software error in the CU	Upgrade firmware or contact technical support.		
F01018	Power-up aborted more than once	1. Switch the module off and on again.		
		2. After this fault has been output, the module is powered up with the factory settings.		
		3. Recommission the converter.		
A01028	Configuration error	Explanation: Parameterization on the memory card has been created with a different type of module (Article number, MLFB).		
		Check the module parameters and recommission if necessary.		
F01033	Switching over units: Reference parameter value invalid	Set the value of the reference parameter not equal to 0.0 (p0304, p0305, p0310, p0596, p2000, p2001, p2002, p2003, r2004).		
F01034	Switching over units: Calculation of the parameter values after refer- ence value change unsuccessful	Select the value of the reference parameter so that the parameters involved can be calculated in the per unit notation (p0304, p0305, p0310, p0596, p2000, p2001, p2002, p2003, r2004).		
F01040	Parameters must be saved	Save parameters (p0971). Switch the Control Unit off and on again.		
F01044	Error loading data from memory card	Replace the memory card or the Control Unit.		
A01053 F01054	System overload measured System limit exceeded	The maximum computing power of the Control Unit was exceeded. The following measures reduce the load on the Control Unit:		
101054	System mint exceeded	Use only one data record (CDS and DDS)		
		Only use the safety features of the basic functions		
		Deactivate the technology controller		
		Use the simple ramp-function generator rather than the extended ramp-function generator		
		Do not use any free function components		
		Reduce the sampling time of the free function blocks		
A01101	Memory card not available	Insert a memory card or deactivate alarm A01101.  Message for a memory card that is not inserted (Page 222)		
F01105	CU: Insufficient memory	Reduce number of data sets.		
F01122	Frequency at the probe input too high	Reduce the frequency of the pulses at the probe input.		
F01205	CU: Time slice overflow	Contact technical support.		
F01250	CU hardware fault	Replacing the Control Unit.		
F01512	An attempt has been made to estab- lish a conversion factor for scaling which does not exist	Create scaling or check transfer value.		
A01590	Motor maintenance interval expired	Carry out maintenance and reset the maintenance interval (p0651).		

Number	Cause	Remedy
F01662	Error, internal communications	Check the electrical cabinet design and cable routing for EMC compliance.
		• Check whether an impermissible voltage is connected at one of the digital outputs.
		• Check whether a digital output is loaded with an impermissible current.
		If the checks are unsuccessful:
		Switch off the converter power supply and switch it on again
		Upgrade the firmware
		Contact technical support
A01900	PROFIBUS: Configuration telegram faulty	Explanation: A PROFIBUS master is attempting to establish a connection with a faulty configuration telegram.
		Check the bus configuration on the master and device side.
A01910 F01910	Setpoint timeout	The alarm is generated when p2040 $\neq$ 0 ms and one of the following causes is present:
		The bus connection is interrupted
		The Modbus master is switched off
		Communications error (CRC, parity bit, logical error)
		An excessively low value for the fieldbus monitoring time (p2040)
A01920	PROFIBUS: Cyclic connection inter-	Explanation: The cyclic connection to PROFIBUS master is interrupted.
	rupt	Establish the PROFIBUS connection and activate the PROFIBUS master with cyclic operation.
F03505	Analog input, wire break	Check the wiring for interruptions. Check the level of the injected signal. The input current measured by the analog input can be read out in r0752.
A03520	Temperature sensor fault	Check that the sensor is connected correctly.
A05000 A05001 A05002 A05004 A05006	Power Module overtemperature	Check the following: - Is the ambient temperature within the defined limit values? - Are the load conditions and duty cycle configured accordingly? - Has the cooling failed?
F06310	Supply voltage (p0210) incorrectly	Check the set supply voltage and if required change (p0210).
	set	Check the line voltage.
F07011	Motor overtemperature	Reduce the motor load.
		Check ambient temperature.
		Check the wiring and connection of the sensor.
A07012	I2t motor model overtemperature	Check and if necessary reduce the motor load.
		Check the motor's ambient temperature.
		Check the thermal time constant p0611.
		Check overtemperature fault threshold p0605.
A07015	Motor temperature sensor alarm	Check that the sensor is connected correctly.
		Check the parameter assignment (p0601).
F07016	Motor temperature sensor fault	Make sure that the sensor is connected correctly.
		Check the parameterization (p0601).
		Deactivate the motor temperature sensor fault evaluation (p0607 = $0$ ).

Number	Cause	Remedy		
F07086 F07088	Switching over units: Parameter limit violation	Check the adapted parameter values and if required correct.		
F07320	Automatic restart aborted	Increase the number of restart attempts (p1211). The current number of start attempts is shown in r1214.		
		Increase the wait time in p1212 and/or monitoring time in p1213.		
		Connect an ON command (p0840).		
		Increase the monitoring time of the power unit or switch off (p0857).		
		Reduce the wait time for resetting the fault counter p1213[1] so that fewer faults are registered in the time interval.		
A07321	Automatic restart active	Explanation: The automatic restart (AR) is active. During voltage recovery and/or when remedying the causes of pending faults, the drive is automatically switched back on.		
F07330	Search current measured too low	Increase the search current (p1202), check the motor connection.		
A07353	DC quantity control deactivated	The controller to suppress DC components in the motor current was at its limit and deactivated itself.		
		Increase the integral time p3858 of the DC quantity controller		
		Decrease the gain p3857 of the DC quantity controller		
F07390	Forming the DC link capacitors was faulty	The converter has canceled the "Forming the DC link capacitors" function $(r3382.3 = 1)$ . The expected DC link voltage is outside the tolerance.		
		Check the converter, e.g. supply voltage and connecting terminals		
		• Set the forming duration again (p3380 > 0), and restart forming.		
A07391	Forming the DC link capacitors active	The "DC link forming" function is active. After forming has been completed, the converter withdraws the alarm ( $r3382.2 = 1$ ).		
A07400	DC-link voltage maximum controller	If the controller is not to intervene:		
	active	Increase the ramp-down times.		
		• Deactivate the Vdc_max control (p1240 = 0 for vector control, p1280 = 0 for U/f control).		
A07409	U/f control, current limiting control-	The alarm automatically disappears after one of the following measures:		
	ler active	Increase the current limit (p0640).		
		Reduce the load.		
		Slow down the ramp up to the setpoint speed.		
F07426	Technology controller actual value	Adapt the limits to the signal level (p2267, p2268).		
	limited	Check the actual value scaling (p2264).		
A07444	PID autotuning is activated	Automatic setting of the PID controller (autotuning) is active (p2350 > 0). The alarm disappears automatically after completion of the autotuning.		
F07445	PID autotuning canceled	The converter has canceled the automatic setting of the PID controller (autotuning) because of a fault.		
		Remedy: Increase p2355 and restart autotuning.		

Number	Cause	Remedy		
F07801	Motor overcurrent	Check current limits (p0640).		
		Vector control: Check current controller (p1715, p1717).		
		U/f control: Check the current limiting controller (p1340 p1346).		
		Increase the acceleration ramp (p1120) or reduce the load.		
		Check the motor and motor cables for short-circuit and ground fault.		
		Check the motor regarding the star/delta connection and rating plate parameterization.		
		Check power unit / motor combination.		
		Select the flying restart function (p1200) if switched to rotating motor.		
A07805	Drive: Power unit overload I2t	Reduce the continuous load.		
		Adapt the load cycle.		
		Check the assignment of rated currents of the motor and power unit.		
F07806	Regenerative power limit exceeded	Increase the deceleration ramp.		
		Reduce the driving load.		
		Use a power unit with higher energy recovery capability.		
		For vector control, the regenerative power limit in p1531 can be reduced until the fault is no longer activated.		
F07807	Short circuit detected	Check the converter connection on the motor side for any phase-phase short-circuit.		
		Rule out that line and motor cables have been interchanged.		
A07850	External alarm 1 3	The signal for "external alarm 1" has been triggered.		
A07851 A07852		Parameters p2112, p2116 and p2117 determine the signal sources for the external alarm 1 3.		
		Remedy: Remove the causes of these alarms.		
F07860 F07861 F07862	External fault 1 3	Remove the external causes for this fault.		
A07891	Load monitoring, pump/fan blocked	Check the pump/fan for blockage and rectify if necessary.		
		Check the fan for sluggishness and rectify if necessary.		
		Adapt the parameterization depending on the load (p2165, p2168).		
A07892	Load monitoring, pump/fan without	For a pump, check the conveyor medium and provide if necessary.		
	load	For a fan, check the belt and replace if necessary		
		If necessary, increase the torque threshold for detection (p2191).		
A07893	Load monitoring, pump leakage	Rectify the leakage in the pump circuit.		
7107033	Loud Montomig, pump reakage	For a false tripping, reduce the torque thresholds of the leakage charac-		
		teristic (p2186, p2188, p2190).		
F07894	Load monitoring, pump/fan blocked	Check the pump/fan for blockage and rectify if necessary.		
		Check the fan for sluggishness and rectify if necessary.		
		Adapt the parameterization depending on the load (p2165, p2168).		
F07895	Load monitoring, pump/fan without	For a pump, check the conveyor medium and provide if necessary.		
	load	For a fan, check the belt and replace if necessary		

Number	Cause	Remedy		
F07896	Load monitoring, pump leakage	Rectify the leakage in the pump circuit.		
		• For a false tripping, reduce the torque thresholds of the leakage characteristic (p2186, p2188, p2190).		
F07900	Motor blocked	Check that the motor can run freely.		
		Check the torque limits (r1538 and r1539).		
		Check the parameters of the "Motor blocked" message (p2175, p2177).		
F07901	Motor overspeed	Activate the precontrol for the speed limiting controller (p1401 bit $7 = 1$ ).		
		Increase the hysteresis for overspeed signal p2162.		
F07902	Motor stalled	Check whether the motor data has been set correctly and perform a motor identification.		
		Check the current limits (p0640, r0067, r0289). If the current limits are too low, the drive cannot be magnetized.		
		Check whether motor cables are disconnected during operation.		
A07903	Motor speed deviation	Increase p2163 and/or p2166.		
		Increase the torque, current and power limits.		
A07910	Motor overtemperature	Check the motor load.		
		Check the motor's ambient temperature.		
		Check the KTY84 or PT1000 sensor.		
		Check the overtemperatures of the thermal model (p0626 p0628).		
A07920	Torque/speed too low	The torque deviates from the torque/speed envelope curve.		
A07921	Torque/speed too high	Check the connection between the motor and the load.		
A07922	Torque/speed out of tolerance	Adapt the parameterization corresponding to the load.		
F07923	Torque/speed too low	Check the connection between the motor and the load.		
F07924	Torque/speed too high	Adapt the parameterization corresponding to the load.		
A07927	DC braking active	Not required		
A07980	Rotary measurement activated	Not required		
A07981	No enabling for rotary measurement	Acknowledge pending faults.		
		Establish missing enables (see r00002, r0046).		
A07991	Motor identification activated	Switch on the motor and identify the motor data.		
F08501	Setpoint timeout	Check the PROFINET connection.		
		Set the controller to RUN mode.		
		If the fault occurs repeatedly, check the monitoring time set p2044.		
F08502	Monitoring time, sign-of-life expired	Check the PROFINET connection.		
F08510	Send configuration data not valid	Check the PROFINET configuration		
A08511	Receive configuration data not valid			
A08526	No cyclic connection	Activate the control with cyclic operation.		
		Check the parameters "Name of Station" and "IP of Station" (r61000, r61001).		
A08565	Consistency error affecting adjusta-	Check the following:		
	ble parameters	IP address, subnet mask or default gateway is not correct.		
		IP address or station name used twice in the network.		
		Station name contains invalid characters.		

Number	Cause	Remedy		
F13100	Know-how protection: Copy protection error	The know-how protection and the copy protection for the memory card are active. An error occurred when checking the memory card.		
		• Insert a suitable memory card and switch the converter supply voltage temporarily off and then on again (POWER ON).		
		Deactivate the copy protection (p7765).		
F13101	Know-how protection: Copy protection cannot be activated	Insert a valid memory card.		
F30001	Overcurrent	Check the following:		
		Motor data, if required, carry out commissioning		
		Motor connection method (Y / Δ)		
		Ulf operation: Assignment of rated currents of motor and Power Module		
		Line quality		
		Make sure that the line commutating reactor is connected properly		
		Power cable connections		
		Power cables for short-circuit or ground fault		
		Power cable length		
		Line phases		
		If this doesn't help:		
		Ulf operation: Increase the acceleration ramp		
		Reduce the load		
		Replace the power unit		
F30002	DC-link voltage overvoltage	Increase the ramp-down time (p1121).		
. 50002	De link voltage over voltage	Set the rounding times (p1130, p1136).		
		Activate the DC-link voltage controller (p1240, p1280).		
		Check the line voltage (p0210).		
		Check the line phases.		
F30003	DC-link voltage undervoltage	Check the line voltage (p0210).		
F30004	Converter overtemperature	Check whether the converter fan is running.		
		Check whether the ambient temperature is in the permissible range.		
		Check whether the motor is overloaded.		
		Reduce the pulse frequency.		
F30005	I2t converter overload	Check the rated currents of the motor and Power Module.		
		Reduce the current limit p0640.		
		When operating with U/f characteristic: Reduce p1341.		
F30011	Line phase failure	Check the converter's input fuses.		
		Check the motor feeder cables.		
F30015	Motor cable phase failure	Check the motor cables.		
		Increase the ramp-up or ramp-down time (p1120).		
F30021	Ground fault	Check the power cable connections.		
		Check the motor.		
		Check the current transformer.		
		Check the cables and contacts of the brake connection (a wire might be broken).		

Number	Cause	Remedy
F30022	Power Module: Monitoring U <sub>CE</sub>	Check or replace Power Module.
F30027	Time monitoring for DC link pre-	Check the line voltage at the input terminals.
	charging	Check the line voltage setting (p0210).
F30035	Overtemperature, intake air	Check whether the fan is running.
F30036	Overtemperature, inside area	Check the fan filter elements.
		Check whether the ambient temperature is in the permissible range.
F30037	Rectifier overtemperature	See F30035 and, in addition:
		Check the motor load.
		Check the line phases
A30049	Internal fan defective	Check the internal fan and if required replace.
F30052	Incorrect Power Module data	Replace the Power Module or upgrade the Control Unit firmware.
F30053	Error in FPGA data	Replace the Power Module.
F30059	Internal fan defective	Check the internal fan and if required replace.
F30074	Communications error between Control Unit and Power Module	There is a communications fault between the Control Unit and the Power Module. Possible causes:
		The Control Unit may have been removed or inserted incorrectly.
		• The external 24 V Control Unit power supply has dipped to ≤95% of the rated voltage for ≤3 ms
A30502	DC link overvoltage	Check the device supply voltage (p0210).
		Check the line reactor dimensioning
F30662	CU hardware fault	Switch the Control Unit off and on again, upgrade the firmware or contact technical support.
F30664	CU power up aborted	Switch the Control Unit off and on again, upgrade the firmware or contact technical support.
F30850	Software fault in the Power Module	Replace Power Module or contact technical support.
A30920	Temperature sensor fault	Check that the sensor is connected correctly.
A50001	PROFINET configuration error	A PROFINET control is attempting to establish a connection with an incorrect configuration telegram. Check whether "Shared Device" is activated (p8929 = 2).
A50010	PROFINET name of station invalid	Correct the name of station (p8920) and activate (p8925 = 2).
A50020	PROFINET: Second control missing	"Shared Device" is activated (p8929 = 2). However, only the connection to a PROFINET control is available.

Further information on this topic is provided in the List Manual.



Overview of the manuals (Page 581)

Corrective maintenance



#### WARNING

#### Fire or electric shock due to defective components

If an overcurrent protection device is triggered, the converter may be defective. A defective converter can cause a fire or electric shock.

Have the converter and the overcurrent protection device checked by a specialist.

### Repair



## WARNING

### Fire or electric shock due to improper repair

Improper repair of the converter may cause malfunctions or result in consequential damage such as fire or electric shock.

- Only commission the following persons to repair the converter:
  - Siemens customer service
  - A repair center that has been authorized by Siemens
  - Specialist personnel who are thoroughly acquainted with all the warnings and operating procedures contained in this manual.
- Only use original spare parts when carrying out repairs.

#### Recycling and disposal



For environmentally-friendly recycling and disposal of your old device, please contact a company certified for the disposal of waste electrical and electronic equipment, and dispose of the old device as prescribed in the respective country of use.

### Continuous development within the scope of product maintenance

Converter components are being continuously developed within the scope of product maintenance. Product maintenance includes, for example, measures to increase the ruggedness or hardware changes which become necessary as components are discontinued.

These further developments are "spare parts-compatible" and do not change the article number.

In the scope of such spare parts-compatible ongoing development, plug connector or connection positions are sometimes slightly modified. This does not cause any problems when the components are properly used. Please take this fact into consideration in special installation situations (e.g. allow sufficient reserve regarding the cable length).

#### 10.1 **Replace Control Unit**

#### Overview

You are only permitted to replace a Control Unit with a different Control Unit under certain preconditions. After the replacement, you must transfer the settings of the Control Unit that was replaced to the new Control Unit.

## Requirement

The following preconditions apply for making a replacement:

- The new Control Unit is the same type as the Control Unit that was replaced.
- The new Control Unit has the same or more recent firmware version than that of the Control Unit that was replaced.

## Description



## **▲** WARNING

### Unexpected machine motion caused when using an inappropriate Control Unit

Replacing Control Units of different types can result in incomplete or inappropriate/incorrect converter settings. As a consequence, machines can unexpectedly move, e.g. speed oscillation, overspeed or incorrect direction of rotation. Unexpected machine motion can result in death, injury and/or material damage.

In all cases not permitted according to the above precondition, you must recommission the drive after replacing the Control Unit.



#### **▲** WARNING

#### Unexpected machine motion caused by inappropriate/incorrect converter settings

Missing or incorrect converter settings can lead to unexpected operating states or machine movements, e.g. a non-functioning EMERGENCY STOP or an incorrect direction of rotation. As a consequence, machine components or devices can become damaged or death or bodily injury may result.

- If possible, back up the settings of the Control Unit to be replaced by uploading them to an external storage medium, e.g. a memory card.
- Transfer the settings of the Control Unit that was replaced per download to the new Control
- If you do not have a backup of the converter settings, commission the converter as new converter.
- After replacing the Control Unit, you must check the function of the converter.

#### **Procedure**

- 1. Switch off the line voltage to the Power Module.
- 2. If being used, switch off the supply voltage for the digital outputs on the Control Unit.

#### 10.1 Replace Control Unit

- 3. If being used, switch off the external 24 V supply of the Control Unit.
- 4. Carefully check that the Control Unit terminals have a no voltage condition.
- 5. Remove the signal cables from the Control Unit.
- 6. Remove the defective Control Unit.
- 7. Mount the new Control Unit on the Power Module.
- 8. Reconnect the signal cables of the Control Unit.
- 9. Switch on all of the converter power supplies again.
- 10. Set the new converter to suit the application:
  - If the settings of the replaced Control Unit are backed up on an external storage medium, transfer the settings using a download.
     Downloading the converter settings (Page 465)
  - If there is no data backup of the replaced Control Unit, commission the converter as new converter.

You have	replaced	the	Control	Unit

## 10.2 Downloading the converter settings

## 10.2.1 Automatic download from the memory card

#### Overview

We recommend that you insert the memory card before switching on the converter. The converter automatically imports its settings from the inserted memory card.

#### Precondition

The following requirements apply:

- The converter power supply has been switched off.
- The converter settings are not protected against copying.
   Download from the PC using Startdrive (Page 473)

## **Function description**

#### **Procedure**

- 1. Insert the memory card into the converter.
- 2. Switch on the power supply for the converter.
- 3. The converter loads the settings from the memory card.
- 4. After loading, check whether the converter outputs Alarm A01028.
  - Alarm A01028:
    - The loaded settings are not compatible with the converter.
    - Delete the alarm with p0971 = 1.
    - Recommission the drive.
  - No alarm A01028:

The converter accepts the settings that have been loaded.

You have transferred the settings to the converter.

## 10.2.2 Manual downloading from the memory card with the BOP-2

#### Overview

If you have backed up the settings of several converters on the memory card, the settings download must be started manually.

10.2 Downloading the converter settings

#### Precondition

The following requirements apply:

- The converter power supply has been switched on.
- The converter settings are not protected against copying.
   Download from the PC using Startdrive (Page 473)

## **Function description**

#### **Procedure**

- 1. Insert the memory card into the converter.
- 2. Select the download.



3. Set the number of your data backup. You can back up 99 different settings on the memory card.




4. Start the data transfer.



5. Wait until the converter has transferred the settings from the memory card.



6. Back up the settings so that they are protected against power failure.



You have transferred the settings from the memory card to the converter.  $\ensuremath{\square}$ 

## 10.2.3 Manual download from the memory card using Startdrive

#### Overview

If you have backed up the settings of several converters on the memory card, the settings download must be started manually.

## Requirement


The following preconditions apply:

- The converter power supply has been switched on.
- The PC and converter are connected with one another via a USB cable or via the fieldbus.
- The converter settings are not protected against copying.

  Download from the PC using Startdrive (Page 473)

## **Function description**

#### **Procedure**



- 1. Go online.
- 2. Select "Online & diagnostics".
- 3. Select "Back up/reset".
- 4. Set the number of your data backup. You can back up 99 different settings on the memory card.
- 5. Start the data transfer.
- 6. Wait until Startdrive has signaled that the data transfer has been completed.
- 7. Go offline.

You have transferred your settings from a memory card to the converter.

## 10.2.4 Download from BOP-2 operator panel

#### Overview

You can transfer the converter settings that are backed up on the BOP-2 operator panel back into the converter.

#### 10.2 Downloading the converter settings

#### Precondition

The following requirements apply:

- The converter power supply has been switched on.
- The converter settings are not protected against copying.

  Download from the PC using Startdrive (Page 473)

## **Function description**

#### **Procedure**

- 1. Attach the Operator Panel to the converter.
- 2. Select the download from the operator panel to the converter.



3. Start the download.



4. Wait until the download is completed.




5. After loading, check whether the converter outputs Alarm A01028.



- Alarm A01028:

The loaded settings are not compatible with the converter. Delete the alarm with p0971 = 1. Recommission the drive.

- No alarm A01028: Proceed with the next step.
- 6. Back up the settings so that they are protected against power failure.



You have transferred the settings to the converter.

## 10.2.5 Download from IOP-2 operator panel

#### Overview

You can transfer the converter settings that are backed up on the IOP-2 operator panel back into the converter.

#### Precondition


The following requirements apply:

- The converter power supply has been switched on.
- The converter settings are not protected against copying.
   Download from the PC using Startdrive (Page 473)

## **Function description**

#### Procedure


- 1. Connect the operator panel to the converter.
- 2. Start the download.



3. Wait until the download is completed.

#### 10.2 Downloading the converter settings


4. After loading, check whether the converter outputs Alarm A01028.



- Alarm A01028:

The loaded settings are not compatible with the converter. Delete the alarm with p0971 = 1. Recommission the drive.

- No alarm A01028: Proceed with the next step.
- 5. Back up the settings so that they are protected against power failure.



You transferred the settings to the converter.

## 10.2.6 Download from Smart Access

#### Overview

You can transfer the converter settings that are backed up on the digital terminal device back into the converter.

#### Precondition

The following requirements apply:

- The converter power supply has been switched on.
- The converter settings are not protected against copying.

  Download from the PC using Startdrive (Page 473)

# **Function description**

#### **Procedure**

- 1. Attach the Smart Access to the converter.
- 2. Connect your terminal device with the Smart Access.
- 3. Select the file for restoring the converter settings.



## 10.2 Downloading the converter settings

4. Back up the settings so that they are protected against power failure.



5. After loading, check whether the converter outputs Alarm A01028.



Alarm A01028:
 The loaded settings are not compatible with the converter.
 Delete the alarm with p0971 = 1.
 Recommission the drive.

- No alarm A01028: Proceed with the next step.

You transferred the settings from the Smart Access to the new converter.  $\hfill\Box$ 

## 10.2.7 Download from the PC using Startdrive

#### Overview

You can transfer the converter settings that have been backed up to a PC back to the converter.

## Requirement

The following preconditions apply:

- The PC and converter are connected with one another.
- The converter settings are not protected against copying.
   Download from the PC using Startdrive (Page 473)

## **Function description**

#### **Procedure**

- 1. Open the Startdrive project that matches the drive.
- 2. Select "Load to device".
- 3. Confirm the prompt for saving your settings (copy RAM to ROM).

You transferred the settings from the PC to the new converter.

#### Overview

The know-how protection function prevents converter settings from being copied.

There are two options to avoid recommissioning after a converter has been replaced.

## Requirement

The following preconditions apply:

- The end user uses a SIEMENS memory card.
- The machine manufacturer (OEM) has an identical machine.

#### 10.2 Downloading the converter settings

#### **Function description**

# Procedure 1: The machine manufacturer only knows the serial number of the new converter

- 1. The end customer provides the machine manufacturer with the following information:
  - For which machine must the converter be replaced?
  - What is the serial number (r7758) of the new converter?
- 2. The machine manufacturer performs the following steps online on the prototype machine:
  - Deactivating know-how protection
     Activating and deactivating know-how protection (Page 238)
  - Enter the serial number of the new converter in p7759.
  - Enter the serial number of the inserted memory card as reference serial number in p7769.
  - Activate know-how protection with copy protection. "Copy RAM to ROM" must be activated.
  - Write the configuration with p0971 = 1 to the memory card.
  - Send the memory card to the end customer.
- 3. The end user inserts the memory card.
- 4. The end user switches on the converter power supply.
- 5. The converter checks the serial numbers of the card and the converter, and when there is a match the converter goes into the "Ready for switching on" state.
  If the numbers do not match, then the converter signals fault F13100 (no valid memory card).

The settings have been transferred to the converter.  $\Box$ 

# Procedure 2: The machine manufacturer knows the serial number of the new converter and the serial number of the memory card

- 1. The end customer provides the machine manufacturer with the following information:
  - For which machine must the converter be replaced?
  - What is the serial number (r7758) of the new converter?
  - What is the serial number of the memory card?
- 2. The machine manufacturer performs the following steps online on the prototype machine:
  - Deactivating know-how protection
     Activating and deactivating know-how protection (Page 238)
  - Enter the serial number of the new converter in p7759.
  - Enter the serial number of the customer's memory card as reference serial number in p7769.
  - Activate know-how protection with copy protection. "Copy RAM to ROM" must be activated.
  - Write the configuration with p0971 = 1 to the memory card.
  - Copy the encrypted project from the card to the associated PC.
  - Send the encrypted project to the end customer, e.g. via e-mail.
- 3. The end user copies the project to the Siemens memory card that belongs to the machine.
- 4. The end user inserts the Siemens memory card into the converter.
- 5. The end user switches on the converter power supply.
- 6. The converter checks the serial numbers of the card and the converter, and when there is a match the converter goes into the "Ready for switching on" state.
  If the numbers do not match, then the converter signals fault F13100 (no valid memory card).

The settings have been transferred to the converter.  $\Box$ 

## 10.3 Replacing a Power Module

#### Overview

You are only permitted to replace the Power Module by another Power Module under certain specific preconditions.

## Requirement

The following preconditions apply when making a replacement:

- The new and replaced Power Modules have the same power rating.
- The new Power Module has a different power rating than the replaced Power Module, however still the same frame size.

In this case, the rated power of the Power Module and the rated power of the motor must not differ too much.

The following values are permissible for the quotients (rated motor power)/(rated Power Module power):

- 200 V Power Modules and 400 V Power Modules: 0.25 ... 1.5
- 690 V Power Modules: 0.5 ...1.5

## Description

#### **Procedure**

- 1. Switch off the line voltage to the Power Module. You do not have to switch off an external 24 V power supply for the Control Unit if one is being used.
- 2. Remove the connecting cables of the Power Module.
- 3. Remove the Control Unit from the Power Module.
- 4. Replace the previous Power Module with the new Power Module.
- 5. Mount the Control Unit onto the new Power Module.
- 6. Connect up the new Power Module using the connecting cables.

#### NOTICE

## Motor damage due to interchanged motor connecting cables

The direction in which the motor rotates switches if you exchange the two phases of the motor line. A motor with an incorrect direction of rotation can damage the machine or installation. Driven loads with only one permissible direction of rotation include certain compressors, saws and pumps, for example.

- Connect the 3 phases of the motor lines in the correct sequence.
- After replacing the Power Module, check the direction of motor rotation.
- 7. Switch on the line supply and, if necessary, the 24 V supply of the Control Unit.

10.3 Replacing a Power Module

You have successfully replaced the Power Module.

10.4 PROFINET device name

## 10.4 PROFINET device name

#### Overview

Converters with PROFINET interface support "Device replacement without removable data storage medium".

## Requirement

The topology of the PROFINET IO system with the IO device involved is configured in the higher-level control system.

## **Function description**

The converter can be replaced without having to insert a removable data storage medium (e.g. a memory card) with the saved device names in the converter – or having to reassign the device names using a PG.

#### **Further information**

Details of the device replacement without removable storage medium can be found on the Internet:

PROFINET system description (<a href="http://support.automation.siemens.com/WW/view/en/">http://support.automation.siemens.com/WW/view/en/</a> 19292127)

# 10.5 Firmware upgrade and downgrade

## 10.5.1 Overview




Figure 10-1 Overview of the firmware upgrade and firmware downgrade

10.5 Firmware upgrade and downgrade

## 10.5.2 Preparing the memory card

#### Overview

You can load the converter firmware from the Internet to a memory card.

#### Precondition

You have the appropriate memory card.

Recommended memory cards (Page 220)

## **Function description**

#### **Procedure**

- 1. Download the required firmware to your PC from the Internet.

  Download (https://support.industry.siemens.com/cs/ww/en/view/67364620)
- 2. Extract the files to a directory of your choice on your PC.
- 3. Transfer the unzipped files into the root directory of the memory card.

<b></b> ■ USER	ATMG168.UFW	B2XX_BE. 10
B2XX_BE.15	B2XX_DSP.10	B2XX_DSP.15
B2XX_S.5	B2XX_S. 10	B230.10
BET200.10	BG110M.10	cbe20_1.ufw
CONTENT.TXT	F230P.BIN	F230P_BT.BIN
F240B.BIN	F240D.BIN	F240E.BIN
F250D.BIN	F250S.BIN	FET200.BIN
FG110M.BIN	FG120C.BIN	img_G120MC.lst
UPDATE.CTR	UPDATER.INF	

Figure 10-2 Example of memory card contents after the file transfer

Depending on the firmware, the filenames and the number of files may differ from the display above.

The "USER" directory does not exist on unused memory cards. After the memory card is plugged in for the first time, the converter creates a new "USER" directory.

You have prepared the memory card for the firmware upgrade or downgrade.  $\ensuremath{\square}$ 

## 10.5.3 Upgrading the firmware

#### Introduction

When upgrading the firmware, you replace the converter firmware by a later version.

#### Requirements

- Your converter's firmware is at least version V4.5.
- Converter and memory card have different firmware versions.

## **Function Description**

#### **Procedure**

- 1. Switch off the converter power supply.
- 2. Wait until all LEDs on the converter are dark.
- 3. Insert the card with the matching firmware into the converter slot until it latches into place.
- 4. Switch on the converter power supply again.
- 5. The converter transfers the firmware from the memory card into its memory.

The transfer takes between 5 and 10 minutes.


While data is being transferred, the LED RDY on the converter stays red. The BF LED flashes orange with a variable frequency.

6. At the end of the transfer, the LED RDY and BF slowly flash red (0.5 Hz).

## Power supply failure during transfer

The converter firmware will be incomplete if the power supply fails during the transfer.

• Start again with step 1 of the instructions.




#### 10.5 Firmware upgrade and downgrade

- 7. Switch off the converter power supply.
- 8. Wait until all LEDs on the converter are dark.


Decide whether you want to withdraw the memory card from the converter:

- You remove the memory card:
  - ⇒ The converter keeps its settings.



- You leave the memory card in the converter:
  - $\Rightarrow$  If the memory card still does not have a data backup of the converter settings, in step 9 the converter writes its settings to the memory card.
  - $\Rightarrow$  If the memory card already includes a data backup, the converter imports the settings from the memory card in step 9.
- 9. Switch on the converter power supply again.
- 10. If the firmware upgrade was successful, the converter LED RDY turns green after several seconds.

If the memory card is still inserted, depending on the previous content of the memory card, one of the two following cases has occurred:



- The memory card contains a data backup:
  - ⇒ The converter has taken the settings from the memory card.
- There was no data backup on the memory card:
  - $\Rightarrow$  The converter has written its settings to the memory card.

You have upgraded the converter firmware.

## 10.5.4 Firmware downgrade

#### Overview

When downgrading the firmware, you replace the converter firmware by an older version.


#### Requirement


- Your converter's firmware is at least version V4.6.
- Converter and memory card have different firmware versions.
- You have backed up your settings on the memory card, in an Operator Panel or in a PC.

## **Function Description**

#### **Procedure**

- 1. Switch off the converter power supply.
- 2. Wait until all LEDs on the converter are dark.





- 4. Switch on the converter power supply again.
- 5. The converter transfers the firmware from the memory card into its memory.

The transfer takes between 5 and 10 minutes.


While data is being transferred, the LED RDY on the converter stays red. The BF LED flashes orange with a variable frequency.

6. At the end of the transfer, the LED RDY and BF slowly flash red (0.5 Hz).

#### Power supply failure during transfer

The converter firmware will be incomplete if the power supply fails during the transfer.

• Start again with Step 1 of these instructions.




#### 10.5 Firmware upgrade and downgrade

- 7. Switch off the converter power supply.
- 8. Wait until all LEDs on the converter are dark.

Decide whether you want to withdraw the memory card from the converter:

- The memory card contains a data backup:
  - ⇒ The converter has taken the settings from the memory card.
- There was no data backup on the memory card:
  - ⇒ The converter has the factory setting.
- 9. Switch on the converter power supply again.
- 10. If the firmware downgrade was successful, after several seconds the converter LED RDY turns green.

If the memory card is still inserted, depending on the previous content of the memory card, one of the two following cases has occurred:




- The memory card contains a data backup:
  - $\Rightarrow$  The converter has taken the settings from the memory card.
- There was no data backup on the memory card:
  - ⇒ The converter has the factory setting.
- 11. If the memory card did not contain a data backup of the converter settings, then you must transfer your settings to the converter from another data backup.
  - Downloading the converter settings (Page 465)

You have replaced the converter firmware by an older version.

# 10.5.5 Correcting an unsuccessful firmware upgrade or downgrade

## Requirements



- When upgrading, the converter has firmware version V4.5 as a minimum.
- When downgrading, as a minimum the converter has firmware version V4.6.

## **Function Description**

To correct a failed firmware upgrade or downgrade you can check the following:

- Have you inserted the card properly?
- Does the card contain the correct firmware?

Repeat the firmware upgrade or downgrade

## 10.6 If the converter no longer responds

#### If the converter no longer responds

For example, when loading an incorrect file from the memory card, the converter can go into a state where it can no longer respond to commands from the operator panel or from a higher-level control system. In this case, you must reset the converter to its factory setting and recommission it. This converter state is manifested in two different ways:

#### Case 1

- The motor is switched off.
- You cannot communicate with the converter, either via the operator panel or other interfaces.
- The LEDs flicker and after 3 minutes the converter has still not powered up.

#### **Procedure**

- 1. Remove the memory card if one is inserted in the converter.
- 2. Switch off the converter power supply.
- 3. Wait until all LEDs on the converter are dark. Then switch on the converter power supply again.
- 4. Repeat steps 2 and 3 as often as required until the converter outputs fault F01018.
- 5. Set p0971 = 1.
- 6. Switch off the converter power supply.
- 7. Wait until all LEDs on the converter are dark. Then switch on the converter power supply again.

The converter now powers up with the factory settings.

8. Recommission the converter.

You have restored the converter factory settings.  $\Box$ 

# Case 2

- The motor is switched off.
- You cannot communicate with the converter, either via the operator panel or other interfaces.
- The LEDs flash and are dark this process is continually repeated.

#### **Procedure**

- 1. Remove the memory card if one is inserted in the converter.
- 2. Switch off the converter power supply.
- 3. Wait until all LEDs on the converter are dark. Then switch on the converter power supply again.
- 4. Wait until the LEDs flash orange.

- 5. Repeat steps 2 and 3 as often as required until the converter outputs fault F01018.
- 6. Now set p0971 = 1.
- 7. Switch off the converter power supply.
- 8. Wait until all LEDs on the converter are dark. Then switch on the converter power supply again.
  - The converter now powers up with the factory settings.
- 9. Recommission the converter.

You have restored the converter factory settings.

#### The motor cannot be switched-on

If the motor cannot be switched-on, then check the following:

- Is a fault present?
  If there is, then remove the fault cause and acknowledge the fault.
- Has the converter been completely commissioned p0010 = 0? If not, the converter is e.g. still in a commissioning state.
- Is the converter reporting the "ready to start" status (r0052.0 = 1)?
- Is the converter missing some enable signals (r0046)?
- How does the converter receive its setpoint and commands? Digital inputs, analog inputs or fieldbus?

10.6 If the converter no longer responds

Technical data

# 11.1 Technical data, CU230P-2 Control Unit

Property	Data / explanatio	n		
Fieldbus interfaces	CU230P-2 HVAC CU230P-2 BT	With RS485 interface for the following protocols:  USS  Modbus RTU  BACnet MS/TP  P1	Article numbers: Control Units (Page 35)	
	CU230P-2 DP	With PROFIBUS interface	_	
	CU230P-2 PN	With PROFINET interface		
Operating voltage	•	ons for the Control Unit power supply:		
	<ul> <li>Supply from th</li> </ul>	e Power Module		
	External 20.4 \	/ 28.8 V DC supply via terminals 31 and	32.	
Current consumption	≤ 1.5 A			
Power loss	5.0 W			
Output voltages	+24 V out (terminal 9),18 V 28.8 V, max. 100 mA			
	+10 V out (termina	als 1 and 35), 9.5 V 10.5 V, max. 10 mA		
Setpoint resolution	0.01 Hz			
Digital inputs	6 (DI 0 DI 5)	Electrically isolated		
		• Voltage: ≤ 30 V		
		<ul><li>Voltage for "low" state: &lt; 5 V</li></ul>		
		<ul> <li>Voltage for "high" state: &gt; 11 V</li> </ul>		
		<ul> <li>Current for 24 V input voltage: 2.7 mA 4.7 mA</li> </ul>		
		Minimum current for the "high" state	e: 1.8 mA 3.9 mA	
		Compatible to SIMATIC outputs		
		Response time for debounce time por	0724 = 0: 10 ms	

# 11.1 Technical data, CU230P-2 Control Unit

Property	Data / explanation	
Analog inputs	4 (Al 0 Al 3)	Differential inputs
		• 12-bit resolution
		• 13 ms response time
		Al 0 and Al 1 can be switched over:
		-~ 0 V 10 V or -10 V +10 V (typical power consumption: 0.1 mA, voltage $<$ 35 V)
		$-~0$ mA 20 mA (120 $\Omega$ input resistance, voltage $<$ 10 V, current $<$ 80 mA)
		• If AI 0 and AI 1 are configured as supplementary digital inputs: Voltage $<$ 35 V, low $<$ 1.6 V, high $>$ 4.0 V, 13 ms $\pm$ 1 ms response time for debounce time p0724 = 0.
		Al 2 switchable:
		<ul><li>0 mA 20 mA (voltage &lt; 10 V, current &lt; 80 mA)</li></ul>
		<ul> <li>Temperature sensor Pt1000/LG-Ni1000/DIN-Ni1000 (characteristics: See below)</li> </ul>
		<ul> <li>Al 3: Temperature sensor Pt1000/LG-Ni1000/DIN-Ni1000 (characteristics: See below)</li> </ul>
Digital outputs /relay out-	3 (DO 0 DO 2)	• DO 0, DO 2: 30 VDC 5 A / 250 VAC, 2 A <sup>1)</sup>
puts		• DO 1: 30 VDC 0.5 A
		2 ms update time
Analog outputs	2 (AO 0 AO 1)	• 0 V 10 V or 0 mA 20 mA
		16-bit resolution
		4 ms update time
		• <400 mV offset at 0 %
Temperature sensor	PTC	• Short-circuit monitoring $< 20 \Omega$
		• Overtemperature 1650 $\Omega$
	KTY84	• Short-circuit monitoring $< 50 \Omega$
		• Wire-break: > 2120 Ω
	Pt1000	• Short-circuit monitoring $< 603 \Omega$
		• Wire-break > 2120 Ω
	Temperature switch	with NC contact
USB interface	Mini-B	
Dimensions (W $\times$ H $\times$ D)	73 mm × 199 mm × 50 mm	Depth when mounting on the Power Module
Memory card (optional)	Slot for SD or MMC memory cards.  Recommended memory cards (Page 220)	
Weight	0.61 kg	

Property	Data / explanatio	n
Operating temperature	-10 °C 60 °C CU230P-2 HVAC, CU230P-2 DP and CU230P-2 BT without inserted Operanel	
	-10 °C 55 °C	CU230P-2 PN without inserted Operator Panel
	0 °C 50 °C	With inserted BOP-2 or IOP-2 operator panel
	Observe any possi Module.	ble restrictions regarding the operating temperature as a result of the Power
Storage temperature	- 40 °C 70 °C	
Relative humidity	< 95 %	Condensation is not permissible.

<sup>1)</sup> The following applies to systems compliant with UL: A maximum of 3 A 30 VDC or 2 A 250 VAC may be connected via terminals 18 / 20 (DO 0 NC) and 23 / 25 (DO 2 NC).




Figure 11-1 Temperature sensor characteristic of analog inputs AI 2 and AI 3

11.2 Overload capability of the converter

## 11.2 Overload capability of the converter

Overload capability is the property of the converter to temporarily supply a current that is higher than the rated current to accelerate a load. Two typical load cycles are defined to clearly demonstrate the overload capability: "Low Overload" and "High Overload"

#### **Definitions**

#### **Base load**

Constant load between the accelerating phases of the drive

#### Low Overload

# LO base load input current Permissible input current for a "Low Overload" load cycle

- LO base load output current Permissible output current for a "Low Overload" load cycle
- LO base load power
   Rated power based on the LO base load output current

## **High Overload**

- HO base load input current
   Permissible input current for a "High Overload" load cycle
- HO base load output current
   Permissible output current for a "High Overload" load cycle
- HO base load power Rated power based on the HO base load output current

If not specified otherwise, the power and current data in the technical data always refer to a load cycle according to Low Overload.

We recommend using the "SIZER" engineering software to select the converter.

You can find additional information about SIZER on the Internet:

Download SIZER (http://support.automation.siemens.com/WW/view/en/10804987/130000)

#### Load cycles and typical applications:

#### "Low Overload" load cycle

The "Low Overload" load cycle assumes a uniform base load with low requirements placed on brief accelerating phases. Typical applications when designing according to "Low Overload" include:

- Pumps, fans and compressors
- Wet or dry blasting technology
- Mills, mixers, kneaders, crushers, agitators
- Basic spindles
- Rotary furnaces
- Extruders

## "High Overload" load cycle

The "High Overload" load cycle permits dynamic accelerating phases at a reduced base load. Typical applications when designing according to "High Overload" include:

- Horizontal and vertical conveyor technology (conveyor belts, roller conveyors, chain conveyors)
- Centrifuges
- Escalators/moving stairways
- Lifters/Lowerers
- Elevators
- · Gantry cranes
- Cable railways
- Storage and retrieval machines

# 11.3 Technical data, PM230 Power Module

## Typical converter load cycles




Figure 11-2 Duty cycles, "High Overload" and "Low Overload"

## 11.3.1 Ambient conditions

Property	Version
Ambient conditions for tran	sport in the transport packaging
Climatic ambient conditions	- 40 °C + 70 °C, according to Class 2K4 to EN 60721-3-2 maximum humidity 95 % at 40 °C
Mechanical ambient condi-	FSA FSC: Shock and vibration permissible according to 1M2 to EN 60721-3-2
tions	FSD FSF: Shock and vibration permissible according to 2M3 to EN 60721-3-2
Protection against chemical substances	Protected according to Class 2C2 to EN 60721-3-2
Biological ambient conditions	Suitable according to Class 2B1 to EN 60721-3-2
Ambient conditions for long	g-term storage in the product packaging
Climatic ambient conditions	- 25 °C + 55 °C, according to Class 1K3 to EN 60721-3-1
Protection against chemical substances	Protected according to Class 1C2 to EN 60721-3-1
Biological ambient conditions	Suitable according to Class 1B1 according to EN 60721-3-1

# 11.3 Technical data, PM230 Power Module

Property	Version	
Ambient conditions in oper	ation	
Installation altitude	Up to 1000 m above sea level without derating, > 1000 m Restrictions for special ambient conditions (Page 562)	
Climatic ambient	Temperature range without derating <sup>2)</sup>	
conditions 1)	<ul> <li>LO base load power: 0 °C40 °C</li> </ul>	
	– HO base load power: 0 °C50 °C	
	For higher temperatures. Restrictions for special ambient conditions (Page 562)	
	Relative humidity: 5 95%, condensation not permitted	
	• Oil mist, salt mist, ice formation, condensation, dripping water, spraying water, splashing water and water jets are not permitted	
Mechanical ambient condi-	FSA FSF: Vibration levels permissible according to Class 3M1 to EN 60721-3-3	
tions	FSA FSC: Shock, permissible according to Class 3M2 to EN 60721-3-3	
	FSD FSF: Shock permissible according to Class 3M1 to EN 60721-3-3	
Protection against chemical substances	Protected according to 3C2 to EN 60721-3-3	
Biological ambient conditions	Suitable according to 3B1 to EN 60721-3-3	
Pollution	Suitable for environments with degree of pollution 2 according to EN 61800-5-1	
Cooling	Forced air cooling AF, according to EN 60146	
Cooling air	clean and dry air	

<sup>1)</sup> Increased ruggedness regarding temperature range and relative humidity; therefore better than Class 3K3 to EN 60721-3-3

<sup>2)</sup> Observe the permissible ambient temperatures for the Control Unit and possibly the operator panel (IOP-2 or BOP-2).

# 11.3.2 General technical data, PM230, IP55

Property	Version
Line voltage	380 480 V 3 AC ± 10%
Output voltage	0 V 3 AC input voltage x 0.95 (max.)
Input frequency	50 Hz 60 Hz, ± 3 Hz
Output frequency	0 Hz 550 Hz, depending on the control mode
Power factor λ	0.9
Line impedance	$Uk \le 1\%$ , no line reactor permitted
Inrush current	Low LO base load input current
Pulse frequency (factory setting)	4 kHz The pulse frequency can be increased in 2 kHz steps up to 16 kHz (up to 8 kHz for 75 kW and 90 kW). An increase in the pulse frequency results in a lower output current.
Braking methods	DC braking
Degree of protection IP55	To comply with this degree of protection requires the following:  Operation with operator panel or dummy cover
	<ul> <li>Connections for control cables are made properly using EMC cable glands.</li> <li>Restrictions for special ambient conditions (Page 562)</li> </ul>
Rated short-circuit current	When fused using a type J or 3NE1 fuse, rated voltage 480 VAC with the rated current of the specific converter.
	FSA FSC: 40 kA FSD FSF: 65 kA

# 11.3.3 Specific technical specifications PM230, IP55

Table 11-1 PM230, IP55, Frame Size A, 3-ph. AC 380 V ... 480 V

Article No. with filter, C2 Article No. with filter, C1	6SL3223-0DE13-7AG1 6SL3223-0DE13-7BG1	6SL3223-0DE15-5AG1 6SL3223-0DE15-5BG1	6SL3223-0DE17-5AG1 6SL3223-0DE17-5BG1
LO base load power	0.37 kW	0.55 kW	0.75 kW
LO base load input current	1.3 A	1.8 A	2.3 A
LO base load output current	1.3 A	1.7 A	2.2 A
HO base load power	0.25 kW	0.37 kW	0.55 kW
HO base load input current	0.9 A	1.3 A	1.8 A
HO base load output current	0.9 A	1.3 A	1.7 A
Fuse according to IEC Fuse according to UL, class J	3NA3803 10 A	3NA3803 10 A	3NA3803 10 A
Power loss	0.06 kW	0.06 kW	0.06 kW
Required cooling air flow	7 l/s	7 l/s	7 l/s
Weight	4.3 kg	4.3 kg	4.3 kg

Table 11-2 PM230, IP55, Frame Size A, 3-ph. AC 380 V ... 480 V

Article No. with filter, C2 Article No. with filter, C1	6SL3223-0DE21-1AG1 6SL3223-0DE21-1BG1	6SL3223-0DE21-5AG1 6SL3223-0DE21-5BG1	6SL3223-0DE22-2AG1 6SL3223-0DE22-2BG1
LO base load power	1.1 kW	1.5 kW	2.2 kW
LO base load input current	3.2 A	4.2 A	6.1 A
LO base load output current	3.1 A	4.1 A	5.9 A
HO base load power	0.75 kW	1.1 kW	1.5 kW
HO base load input current	2.3 A	3.2 A	4.2 A
HO base load output current	2.2 A	3.1 A	4.1 A
Fuse according to IEC Fuse according to UL, class J	3NA3803 10 A	3NA3803 10 A	3NA3803 10 A
Power loss	0.07 kW	0.08 kW	0.1 kW
Required cooling air flow	7 l/s	7 l/s	7 l/s
Weight	4.3 kg	4.3 kg	4.3 kg

Table 11-3 PM230, IP55, Frame Size A, 3-ph. AC 380 V ... 480 V

Article No. with filter, C2 Article No. with filter, C1	6SL3223-0DE23-0AG1 6SL3223-0DE23-0BG1	
LO base load power	3 kW	
LO base load input current	8.0 A	
LO base load output current	7.7 A	
HO base load power	2.2 kW	
HO base load input current	6.1 A	
HO base load output current	5.9 A	

Article No. with filter, C2 Article No. with filter, C1	6SL3223-0DE23-0AG1 6SL3223-0DE23-0BG1	
Fuse according to IEC Fuse according to UL, class J	3NA3803 10 A	
Power loss	0.12 kW	
Required cooling air flow	7 l/s	
Weight	4.3 kg	

Table 11-4 PM230, IP55, Frame Size B, 3-ph. AC 380 V ... 480 V

Article No. with filter, C2 Article No. with filter, C1	6SL3223-0DE24-0AG1 6SL3223-0DE24-0BG1	6SL3223-0DE25-5AG1 6SL3223-0DE25-5BG1	6SL3223-0DE27-5AG1 6SL3223-0DE27-5BG1
LO base load power	4 kW	5.5 kW	7.5 kW
LO base load input current	10.5 A	13.6 A	18.6 A
LO base load output current	10.2 A	13.2 A	18 A
HO base load power	3 kW	4 kW	5.5 kW
HO base load input current	8.0 A	10.5 A	13.6 A
HO base load output current	7.7 A	10.2 A	13.2 A
Fuse according to IEC Fuse according to UL, class J	3NA3805 16 A	3NA3807 25 A	3NA3810 35 A
Power loss	0.14 kW	0.18 kW	0.24 kW
Required cooling air flow	9 l/s	9 l/s	9 l/s
Weight	6.3 kg	6.3 kg	6.3 kg

Table 11-5  $\,$  PM230, IP55, Frame Size C, 3-ph. AC 380 V ... 480 V

Article No. with filter, C2 Article No. with filter, C1	6SL3223-0DE31-1AG1 6SL3223-0DE31-1BG1	6SL3223-0DE31-5AG1 6SL3223-0DE31-5BG1	6SL3223-0DE31-8AG1 
LO base load power	11 kW	15 kW	18.5 kW
LO base load input current	26.9 A	33.1 A	39.2 A
LO base load output current	26 A	32 A	38 A
HO base load power	7.5 kW	11 kW	15 kW
HO base load input current	18.6 A	26.9 A	33.1 A
HO base load output current	18 A	26 A	32 A
Fuse according to IEC Fuse according to UL, class J	3NA3814 40 A	3NA3820 50 A	3NA3820 50 A
Power loss	0.32 kW	0.39 kW	0.46 kW
Required cooling air flow	20 l/s	20 l/s	20 l/s
Weight	9.5 kg	9.5 kg	9.5 kg

## 11.3 Technical data, PM230 Power Module

Table 11-6 PM230, IP55, Frame Size D, 3-ph. AC 380 V ... 480 V

Article No. with filter, C2 Article No. with filter, C1	 6SL3223-0DE31-8BA0	6SL3223-0DE32-2AA0 6SL3223-0DE32-2BA0	6SL3223-0DE33-0AA0 6SL3223-0DE33-0BA0
LO base load power	18.5 kW	22 kW	30 kW
LO base load input current	39.2 A	42 A	56 A
LO base load output current	38 A	45 A	60 A
HO base load power	15 kW	18.5 kW	22 kW
HO base load input current	33.1 A	36 A	42 A
HO base load output current	32 A	38 A	45 A
Fuse according to IEC Fuse according to UL, class J	3NA3820 50 A	3NA3822 63 A	3NA3824 80 A
Power loss	0.46 kW	0.52 kW	0.68 kW
Required cooling air flow	20 l/s	39 l/s	39 l/s
Weight	31 kg	31 kg	31 kg

Table 11-7 PM230, IP55, Frame Size E, 3-ph. AC 380 V ... 480 V

Article No. with filter, C2 Article No. with filter, C1	6SL3223-0DE33-7AA0 6SL3223-0DE33-7BA0	6SL3223-0DE34-5AA0 6SL3223-0DE34-5BA0	
LO base load power	37 kW	45 kW	
LO base load input current	70 A	84 A	
LO base load output current	75 A	90 A	
HO base load power	30 kW	37 kW	
HO base load input current	56 A	70 A	
HO base load output current	60 A	75 A	
Fuse according to IEC Fuse according to UL, class J	3NA3830 100 A	3NA3832 125 A	
Power loss	0.99 kW	1.2 kW	
Required cooling air flow	39 l/s	39 l/s	
Weight	37 kg with filter C1 38 kg with filter C2	37 kg with filter C1 38 kg with filter C2	

Table 11-8 PM230, IP55, Frame size F, 3-ph. AC 380 V ... 480 V

Article No. with filter, C2 Article No. with filter, C1	6SL3223-0DE35-5AA0 6SL3223-0DE35-5BA0	6SL3223-0DE37-5AA0 6SL3223-0DE37-5BA0	6SL3223-0DE38-8AA0 6SL3223-0DE38-8BA0
LO base load power	55 kW	75 kW	90 kW
LO base load input current	102 A	135 A	166 A
LO base load output current	110 A	145 A	178 A
HO base load power	45 kW	55 kW	75 kW
HO base load input current	84 A	102 A	135 A
HO base load output current	90 A	110 A	145 A

## 11.3 Technical data, PM230 Power Module

Article No. with filter, C2 Article No. with filter, C1	6SL3223-0DE35-5AA0 6SL3223-0DE35-5BA0	6SL3223-0DE37-5AA0 6SL3223-0DE37-5BA0	6SL3223-0DE38-8AA0 6SL3223-0DE38-8BA0
Fuse according to IEC Fuse according to UL, class J	3NA3836 160 A	3NA3140 200 A	3NA3144 250 A
Power loss	1.4 kW	1.9 kW	2.3 kW
Required cooling air flow	117 l/s	117 l/s	117 l/s
Weight	70 kg	70 kg	70 kg

# 11.3.4 General technical data, PM230

Property	Version		
Line voltage	380 480 V 3 AC ± 10%		
Output voltage	3-phase 0 VAC input voltage x 0.95 (max.)		
Input frequency	50 Hz 60 Hz, ± 3 Hz		
Output frequency	0 Hz 550 Hz, depending on the control mode		
Power factor λ	0.9		
Line impedance	Uk ≤ 1%, line reactor not permissible		
Inrush current	< LO base load input current		
Pulse frequency (factory setting)	4 kHz The pulse frequency can be increased in 2 kHz steps up to 16 kHz (up to 8 kHz for 55 kW and 75 kW). An increase in the pulse frequency results in a lower output current.		
Electromagnetic compatibility	Devices with filters in compliance with EN 61800-3: 2004 are suitable for Category C2 environments.		
Braking methods	DC braking		
Degree of protection	IP20 built-in units IP20 when mounted in a control cabinet PT devices IP54 on the control cabinet wall		
Operating temperature at	LO base load power without derating 0° C +40° C		
	HO base load power without derating 0° C +50° C		
	LO/HO base load power with derating: Up to 60° C		
	Restrictions for special ambient conditions (Page 562)		
Storage temperature	-40° C +70° C		
Relative humidity	< 95% - condensation not permissible		
Pollution	Protected according to pollution degree 2 according to EN 61800-5-1: 2007		
Ambient conditions	Protected against damaging chemical substances according to environmental class 3C2 according to EN 60721-3-3: 1995		
Shock and vibration	<ul> <li>Long-term storage in the transport packaging according to Class 1M2 according to EN 60721-3-1: 1997</li> </ul>		
	<ul> <li>Transport in the transport packaging according to Class 2M3 according to EN 60721-3-2: 1997</li> </ul>		
	Vibration during operation according to Class 3M2 according to EN 60721-3-3: 1995		
Installation altitude	without derating: up to 1000 m above ing: Restrictions for special ambient conditions (Page 562) with derating: up to 4000 m above sea level		
Permissible short-circuit current	Frame size D F: 65 kA <sup>1)</sup>		
Overvoltage category	Supply circuits: Overvoltage category III Non-supply circuits: Overvoltage category II		
Standards	UL <sup>1),2)</sup> , CE, C-tick The drive only satisfies the UL requirements when UL-certified fuses are used.		

<sup>1)</sup> If fuse-protected with a listed Class J or 3NE1 fuse, rated voltage 600 VAC with the rated current of the specific converter.

<sup>2)</sup> UL available soon for frame sizes D ... F

## 11.3.5 Detailed technical data, PM230

Table 11-9 PM230, IP20, frame size A, 3 AC 380 V ... 480 V

Article number without filter Article number with filter	6SL3210-1NE11-3UG1 6SL3210-1NE11-3AG1	6SL3210-1NE11-7UG1 6SL3210-1NE11-7AG1	6SL3210-1NE12-2UG1 6SL3210-1NE12-2AG1
LO base load power	0.37 kW	0.55 kW	0.75 kW
LO base load input current	1.3 A	1.8 A	2.3 A
LO base load output current	1.3 A	1.7 A	2.2 A
HO base load power	0.25 kW	0.37 kW	0.55 kW
HO base load input current	0.9 A	1.3 A	1.8 A
HO base load output current	0.9 A	1.3 A	1.7 A
Fuse according to IEC / UL Fuse according to UL, Class J	3NE1813-0 2 A	3NE1813-0 4 A	3NE1813-0 4 A
Circuit breaker 3RV2711-1KD10	12.5 A	12.5 A	12.5 A
Power loss	0.04 kW	0.04 kW	0.05 kW
Required cooling air flow	1.5 l/s	1.5 l/s	4.5 l/s
Weight without filter	1.4 kg	1.4 kg	1.4 kg
Weight with filter	1.6 kg	1.6 kg	1.6 kg

Table 11-10 PM230, IP20, frame size A, 3 AC 380 V ... 480 V

Article number without filter Article number with filter	6SL3210-1NE13-1UG1 6SL3210-1NE13-1AG1	6SL3210-1NE14-1UG1 6SL3210-1NE14-1AG1	6SL3210-1NE15-8UG1 6SL3210-1NE15-8AG1
LO base load power	1.1 kW	1.5 kW	2.2 kW
LO base load input current	3.2 A	4.2 A	6.1 A
LO base load output current	3.1 A	4.1 A	5.9 A
HO base load power	0.75 kW	1.1 kW	1.5 kW
HO base load input current	2.3 A	3.2 A	4.2 A
HO base load output current	2.2 A	3.1 A	4.1 A
Fuse according to IEC / UL Fuse according to UL, Class J	3NE1813-0 6 A	3NE1813-0 6 A	3NE1813-0 10 A
Power loss	0.06 kW	0.07 kW	0.08 kW
Circuit breaker N3RV2711-1KD10	12.5 A	12.5 A	12.5 A
Required cooling air flow	4.5 l/s	4.5 l/s	4.5 l/s
Weight without filter	1.4 kg	1.4 kg	1.4 kg
Weight with filter	1.6 kg	1.6 kg	1.6 kg

Table 11-11 PM230, IP20, frame size A, 3 AC 380 V ... 480 V

Article number without filter Article number with filter	6SL3210-1NE17-7UG1 6SL3210-1NE17-7AG1	
LO base load power	3 kW	
LO base load input current	8.0 A	

## 11.3 Technical data, PM230 Power Module

Article number without filter Article number with filter	6SL3210-1NE17-7UG1 6SL3210-1NE17-7AG1	
LO base load output current	7.7 A	
HO base load power	2.2 kW	
HO base load input current	6.1 A	
HO base load output current	5.9 A	
Fuse according to IEC / UL Fuse according to UL, Class J	3NE1813-0 10 A	
Circuit breaker N3RV2711-1KD10	12.5 A	
Power loss	0.11 kW	
Required cooling air flow	4.5 l/s	
Weight without filter	1.4 kg	
Weight with filter	1.6 kg	

Table 11-12 PM230, PT, frame size A, 3 AC 380 V ... 480 V

Article number without filter Article number with filter	6SL3211-1NE17-7UG1 6SL3211-1NE17-7AG1	
LO base load power	3 kW	
LO base load input current	8.0 A	
LO base load output current	7.7 A	
HO base load power	2.2 kW	
HO base load input current	6.1 A	
HO base load output current	5.9 A	
Fuse according to IEC / UL Fuse according to UL, Class J	3NE1813-0 10 A	
Power loss	0.11 kW	
Required cooling air flow	4.5 l/s	
Weight without filter	1.7 kg	
Weight with filter	1.9 kg	

Table 11-13 PM230, IP20, frame size B, 3-phase 380 ... 480 VAC

Article number without filter Article number with filter	6SL3210-1NE21-0UG1 6SL3210-1NE21-0AG1	6SL3210-1NE21-3UG1 6SL3210-1NE21-3AG1	6SL3210-1NE21-8UG1 6SL3210-1NE21-8AG1
LO base load power	4 kW	5.5 kW	7.5 kW
LO base load input current	10.5 A	13.6 A	18.6 A
LO base load output current	10.2 A	13.2 A	18 A
HO base load power	3 kW	4 kW	5.5 kW
HO base load input current	8.0 A	10.5 A	13.6 A
HO base load output current	7.7 A	10.2 A	13.2 A
Fuse according to IEC / UL Fuse according to UL, Class J	3NE1813-0 15 A	3NE1814-0 20 A	3NE1815-0 25 A

Article number without filter Article number with filter	6SL3210-1NE21-0UG1 6SL3210-1NE21-0AG1	6SL3210-1NE21-3UG1 6SL3210-1NE21-3AG1	6SL3210-1NE21-8UG1 6SL3210-1NE21-8AG1
Power loss	0.12 kW	0.15 kW	0.22 kW
Required cooling air flow	9.2 l/s	9.2 l/s	9.2 l/s
Weight without filter	2.8 kg	2.8 kg	2.8 kg
Weight with filter	3 kg	3 kg	3 kg

Table 11-14 PM230, PT, frame size B, 3 AC 380 V ... 480 V

Article number without filter Article number with filter	6SL3211-1NE21-8UG1 6SL3211-1NE21-8AG1	
LO base load power	7.5 kW	_
LO base load input current	18.6 A	
LO base load output current	18 A	
HO base load power	5.5 kW	
HO base load input current	13.6 A	
HO base load output current	13.2 A	
Fuse according to IEC / UL Fuse according to UL, Class J	3NE1815-0 25 A	
Power loss	0.22 kW	
Required cooling air flow	9.2 l/s	
Weight without filter	3.4 kg	
Weight with filter	3.6 kg	

Table 11-15 PM230, IP20, frame size C, 3 AC 380 V ... 480 V

Article number without filter Article number with filter	6SL3210-1NE22-6UG1 6SL3210-1NE22-6AG1	6SL3210-1NE23-2UG1 6SL3210-1NE23-2AG1	6SL3210-1NE23-8UG1 6SL3210-1NE23-8AG1
LO base load power	11 kW	15 kW	18.5 kW
LO base load input current	26.9 A	33.1 A	39.2 A
LO base load output current	26 A	32 A	38 A
HO base load power	7.5 kW	11 kW	15 kW
HO base load input current	18.6 A	26.9 A	33.1 A
HO base load output current	18 A	26 A	32 A
Fuse according to IEC / UL Fuse according to UL, Class J	3NE1803-0 35 A	3NE1817-0 45 A	3NE1817-0 50 A
Power loss	0.3 kW	0.35 kW	0.45 kW
Required cooling air flow	18.5 l/s	18.5 l/s	18.5 l/s
Weight without filter	4.5 kg	4.5 kg	4.5 kg
Weight with filter	5.1 kg	5.1 kg	5.1 kg

Table 11-16 PM230, PT, frame size C, 3 AC 380 V ... 480 V

Article number without filter Article number with filter	6SL3211-1NE23-8UG1 6SL3211-1NE23-8AG1	
LO base load power	18.5 kW	
LO base load input current	39.2 A	
LO base load output current	38 A	
HO base load power	15 kW	
HO base load input current	33.1 A	
HO base load output current	32 A	
Fuse according to IEC / UL Fuse according to UL, Class J	3NE1817-0 50 A	
Power loss	0.45 kW	
Required cooling air flow	18.5 l/s	
Weight without filter	5.4 kg	
Weight with filter	6 kg	

Table 11-17 PM230, IP20, frame size D, 3 AC 380 V ... 480 V

Article number without filter Article number with filter	6SL3210-1NE24-5UL0 6SL3210-1NE24-5AL0	6SL3210-1NE26-0UL0 6SL3210-1NE26-0AL0	
LO base load power	22 kW	30 kW	
LO base load input current	42 A	56 A	
LO base load output current	45 A	60 A	
HO base load power	18.5 kW	22 kW	
HO base load input current	36 A	42 A	
HO base load output current	38 A	45 A	
Fuse according to IEC / UL	3NE1818-0	3NE1820-0	
Power loss	0.52 kW	0.68 kW	
Required cooling air flow	80 l/s	80 l/s	
Weight without filter	11 kg	11 kg	
Weight with filter	14 kg	14 kg	

Table 11-18 PM230, IP20, frame size E, 3 AC 380 V ... 480 V

Article number without filter Article number with filter	6SL3210-1NE27-5UL0 6SL3210-1NE27-5AL0	6SL3210-1NE28-8UL0 6SL3210-1NE28-8AL0	
LO base load power	37 kW	45 kW	
LO base load input current	70 A	84 A	
LO base load output current	75 A	90 A	
HO base load power	30 kW	37 kW	
HO base load input current	56 A	70 A	
HO base load output current	60 A	75 A	
Fuse according to IEC / UL	3NE1021-0	3NE1022-0	

Article number without filter Article number with filter	6SL3210-1NE27-5UL0 6SL3210-1NE27-5AL0	6SL3210-1NE28-8UL0 6SL3210-1NE28-8AL0	
Power loss	0.99 kW	1.2 kW	
Required cooling air flow	80 l/s	80 l/s	
Weight without filter	15 kg	15 kg	
Weight with filter	22 kg	22 kg	

Table 11-19  $\,$  PM230, IP20, frame size F, 3 AC 380 V ... 480 V

Article number without filter Article number with filter	6SL3210-1NE31-1UL0 6SL3210-1NE31-1AL0	6SL3210-1NE31-5UL0 6SL3210-1NE31-5AL0	
LO base load power	55 kW	75 kW	
LO base load input current	102 A	135 A	
LO base load output current	110 A	145 A	
HO base load power	45 kW	55 kW	
HO base load input current	84 A	102 A	
HO base load output current	90 A	110 A	
Fuse according to IEC / UL	3NE1224-0	3NE1225-0	
Power loss	1.4 kW	1.9 kW	
Required cooling air flow	150 l/s	150 l/s	
Weight without filter	33 kg	33 kg	_
Weight with filter	48 kg	48 kg	

# 11.3.6 Current reduction depending on pulse frequency

## Current derating depending on the pulse frequency

LO base	Output ba	se-load cui	rent at a pu	ulse freque	ncy of			
load	2 kHz	4 kHz	6 kHz	8 kHz	10 kHz	12 kHz	14 kHz	16 kHz
kW	Α	Α	Α	Α	Α	Α	Α	Α
0.37		1.3	1.11	0.91	0.78	0.65	0.59	0.52
0.55		1.7	1.45	1.19	1.02	0.85	0.77	0.68
0.75		2.2	1.87	1.54	1.32	1.10	0.99	0.88
1.1		3.1	2.64	2.17	1.86	1.55	1.4	1.24
1.5		4.1	3.49	2.87	2.46	2.05	1.85	1.64
2.2		5.9	5.02	4.13	3.54	2.95	2.66	2.36
3.0		7.7	6.55	5.39	4.62	3.85	3.47	3.08
4.0		10.2	8.67	7.14	6.12	5.1	4.59	4.08
5.5		13.2	11.22	9.24	7.92	6.6	5.94	5.28
7.5		18	15.3	12.6	10.8	9	8.1	7.2
11.0		26	22.1	18.2	15.6	13	11.7	10.4
15.0		32	27.2	22.4	19.2	16	14.4	12.8
18.5		38	32.3	26.6	22.8	19	17.1	15.2
22		45	38.25	31.5	27	22.5	20.25	18
30		60	51	42	36	30	27	24
37		75	63.75	52.5	45	37.5	33.75	30
45		90	76.5	63	54	45	40.5	36
55		110	93.5	77	66 <sup>1)</sup>	55 <sup>1)</sup>	49.5 <sup>1)</sup>	44 <sup>1)</sup>
75		145	123.3	101.5				
90		178	151.3	124.6				

The permissible cable length to the motor also depends on the cable type and the selected pulse frequency.

<sup>1)</sup> Values apply to IP20 versions only.

### Protective devices for the Power Module

The fuses listed in the following tables are examples of suitable fuses.

Additional components for branch protection are available in the Internet:

Branch protection and short-circuit strength according to UL and IEC (<a href="https://support.industry.siemens.com/cs/ww/en/view/109479152">https://support.industry.siemens.com/cs/ww/en/view/109479152</a>)

## Typical converter load cycles




Figure 11-3 "Low Overload" and "High Overload" load cycles

### 11.4.1 Ambient conditions

Property	Version	
Ambient conditions for tran	sport in the transport packaging	
Climatic ambient conditions	- 40 °C + 70 °C, according to Class 2K4 to EN 60721-3-2:1997 maximum humidity 95% at 40 °C	
Mechanical ambient conditions	Shocks and vibrations permissible according to 2M3 to IEC 60721-3-2:1997	
Protection against chemical substances	Protected according to Class 2C2 to IEC 60721-3-2:1997	
Biological environmental conditions	Suitable according to Class 2B1 to IEC 60721-3-2:1997	
Ambient conditions for long	g-term storage in the product packaging	
Climatic ambient conditions	- 25 °C + 55 °C, according to Class 1K3 to IEC 60721-3-1:1997	
Protection against chemical substances	Protected according to Class 1C2 to IEC 60721-3-1:1997	
Biological environmental conditions	Suitable according to Class 1B1 to IEC 60721-3-1:1997	
Ambient conditions in operation		

Property	Version	
Installation altitude	Up to 1000 m above sea level without derating, > 1000 m Restrictions for special ambient conditions (Page 562)	
Climatic ambient	Frame sizes FSD FSF temperature range <sup>2)</sup>	
conditions 1)	- in operation acc. to LO: -20 °C +40 °C	
	– in operation acc. to HO: $-20 ^{\circ}\text{C}$ $+50 ^{\circ}\text{C}$	
	– for higher temperatures	
	Restrictions for special ambient conditions (Page 562)	
	Relative humidity: 5 95%, condensation not permitted	
	<ul> <li>Oil mist, ice formation, condensation, dripping water, spraying water, splashing water and water jets are not permitted</li> </ul>	
Mechanical ambient condi-	Vibration levels permissible according to Class 3M1 to EN 60721-3-3:2002	
tions	<ul> <li>Shocks permissible according to Class 3M1 to EN 60721-3-3:2002</li> </ul>	
Protection against chemical substances	Protected according to 3C2 to IEC 60721-3-3:2002	
Biological environmental conditions	Suitable according to 3B1 to IEC 60721-3-3: 2002	
Pollution	Suitable for environments with degree of pollution 2 according to EN 61800-5-1	
Cooling	Forced air cooling AF, according to EN 60146	
Cooling air	Clean and dry air	

<sup>&</sup>lt;sup>1)</sup> Increased ruggedness regarding temperature range and relative humidity; therefore better than 3K3 according to IEC 60721-3-3: 2002

<sup>&</sup>lt;sup>2)</sup> Observe the permissible ambient temperatures for the Control Unit and possibly the operator panel (IOP-2 or BOP-2).

# 11.4.2 General technical data, 400 V converters

Property	Version
Line voltage	3 AC 380 V 480 V ± 10% (in operation -20% < 1 min)
Line system configurations	Grounded TN/TT line systems or non-grounded IT line systems
Line impedance	Uk < 4%, line reactor is not required
Power factor λ	> 0.9
Output voltage	3 AC 0 V 0.95 x input voltage (max.)
Input frequency	50 Hz 60 Hz, ± 3 Hz
Output frequency	0 550 Hz, depending on the control mode
Inrush current	< LO base load input current
Overvoltage category according to EN 61800-5-1	III for line supplies
Pulse frequency	Factory setting
	<ul> <li>4 kHz for devices with an LO base load power &lt; 75 kW</li> </ul>
	• 2 kHz for devices with an LO base load power ≥ 75 kW
	Can be adjusted in 2 kHz steps as follows:
	• 2 kHz 16 kHz for devices with an LO base load power < 55 kW
	• 2 kHz 8 kHz for devices with an LO base load power $\geq$ 55 kW
	• 2 kHz 4 kHz for devices with an LO base load power $\geq$ 110 kW
	If you increase the pulse frequency, the converter reduces the maximum output current.
Short-circuit current rating (SCCR) and branch protection	≤ 100 kA rms  Branch protection and short-circuit strength according to UL and IEC ( <a href="https://support.industry.siemens.com/cs/ww/en/view/109479152">https://support.industry.siemens.com/cs/ww/en/view/109479152</a> )
Braking methods	DC braking, compound braking
Degree of protection according to EN 60529	IP20 Must be installed in a control cabinet
Protection class according to EN 61800-5-1	The converters are devices with protection class I
Touch protection according to EN 50274	DGUV regulation 3 when used for the intended purpose
Cooling in compliance with EN 60146	Forced air cooling AF

## 11.4.3 Specific technical data, 400 V converters

The fuses listed in the following tables are examples of suitable fuses.

You can find additional suitable fuses in the Internet:

Branch protection and short-circuit strength according to UL and IEC (<a href="https://support.industry.siemens.com/cs/ww/en/view/109479152">https://support.industry.siemens.com/cs/ww/en/view/109479152</a>)

Table 11-20 PM240P-2, IP20, Frame Size D, 3-ph. AC 380 V ... 480 V

Article number without filter Article number with filter	6SL3210-1RE24-5UL0 6SL3210-1RE24-5AL0	6SL3210-1RE26-0UL0 6SL3210-1RE26-0AL0	6SL3210-1RE27-5UL0 6SL3210-1RE27-5AL0
LO base load power	22 kW	30 kW	37 kW
LO base load input current	42 A	57 A	70 A
LO base load output current	45 A	60 A	75 A
HO base load power	18.5 kW	22 kW	30 kW
HO base load input current	38 A	47 A	62 A
HO base load output current	38 A	45 A	60 A
Siemens fuse according to IEC/UL Fuse according to IEC/UL, Class J	3NE1820-0 / 80 A 70 A	3NE1021-0 / 100 A 90 A	3NE1021-0 / 100 A 100 A
Power loss without filter	0.68 kW	0.76 kW	1.01 kW
Power loss with filter	0.68 kW	0.77 kW	1.02 kW
Required cooling air flow	55 l/s	55 l/s	55 l/s
Weight without filter	16 kg	17 kg	17 kg
Weight with filter	17.5 kg	18.5 kg	18.5 kg

Table 11-21 PM240P-2, IP20, Frame Size E, 3-ph. AC 380 V ... 480 V

Article number without filter Article number with filter	6SL3210-1RE28-8UL0 6SL3210-1RE28-8AL0	6SL3210-1RE31-1UL0 6SL3210-1RE31-1AL0	
LO base load power	45 kW	55 kW	
LO base load input current	86 A	104 A	
LO base load output current	90 A	110 A	
HO base load power	37 kW	45 kW	
HO base load input current	78 A	94 A	
HO base load output current	75 A	90 A	
Siemens fuse according to IEC/UL Fuse according to IEC/UL, Class J	3NE1022-0 / 125 A 125 A	3NE1224-0 / 160 A 150 A	
Power loss without filter	1.19 kW	1.54 kW	
Power loss with filter	1.2 kW	1.55 kW	
Required cooling air flow	83 l/s	83 l/s	
Weight without filter	26 kg	26 kg	
Weight with filter	28 kg	28 kg	

Table 11-22 PM240P-2, IP20, Frame Size F, 3-ph. AC 380 V ... 480 V

Article number without filter Article number with filter	6SL3210-1RE31-5UL0 6SL3210-1RE31-5AL0	6SL3210-1RE31-8UL0 6SL3210-1RE31-8AL0	6SL3210-1RE32-1UL0 6SL3210-1RE32-1AL0
LO base load power	75 kW	90 kW	110 kW
LO base load input current	140 A	172 A	198 A
LO base load output current	145 A	178 A	205 A
HO base load power	55 kW	75 kW	90 kW
HO base load input current	117 A	154 A	189 A
HO base load output current	110 A	145 A	178 A
Siemens fuse according to IEC/UL Fuse according to IEC/UL, Class J	3NE1225-0 / 200 A 200 A	3NE1227-0 / 250 A 250 A	3NE1230-0 / 315 A 300 A
Power loss without filter	1.95 kW	2.54 kW	2.36 kW
Power loss with filter	1.97 kW	2.56 kW	2.38 kW
Required cooling air flow	153 l/s	153 l/s	153 l/s
Weight without filter	57 kg	57 kg	61 kg
Weight with filter	63 kg	63 kg	65 kg

Table 11-23 PM240P-2, IP20, Frame Size F, 3-ph. AC 380 V ... 480 V

Article number without filter Article number with filter	6SL3210-1RE32-5UL0 6SL3210-1RE32-5AL0	
LO base load power	132 kW	
LO base load input current	242 A	
LO base load output current	250 A	
HO base load power	110 kW	
HO base load input current	218 A	
HO base load output current	205 A	
Siemens fuse according to IEC/UL Fuse according to IEC/UL, Class J	3NE1331-0 / 350 A 350 A	
Power loss without filter	3.09 kW	
Power loss with filter	3.12 kW	
Required cooling air flow	153 l/s	
Weight without filter	61 kg	
Weight with filter	65 kg	

# 11.4.4 Current derating depending on the pulse frequency, 400 V converters

Article number	LO power [kW]	LO base load output current [A]							
Pulse frequency [kHz]		2	4 *)	6	8	10	12	14	16
6SL3210-1RE24-5 . L0	22	45	45	38.3	31.5	27	22.5	20.3	18
6SL3210-1RE26-0 . L0	30	60	60	51	42	36	30	27	24
6SL3210-1RE27-5 . LO	37	75	75	63.8	52.5	45	37.5	33.8	30
6SL3210-1RE28-8 . LO	45	90	90	76.5	63	54	45	40.5	36
6SL3210-1RE31-1 . LO	55	110	110	93.5	77				
Pulse frequency [kHz]		2 *)	4	6	8	10	12	14	16
6SL3210-1RE31-5 . LO	75	145	145	123.3	101.5				
6SL3210-1RE31-8 . LO	90	178	178	151.3	124.6				
6SL3210-1RE32-1 . LO	110	205	143.5						
6SL3210-1RE32-5 . L0	132	250	175						

<sup>\*)</sup> Factory setting

The permissible motor cable length depends on the particular cable type and the pulse frequency that has been selected

# 11.4.5 General technical data, 690 V converters

Property	Version
Line voltage	3 AC 500 V 690 V ± 10% (in operation -20% < 1 min) with Class J fuses, maximum 600 V
Line system configurations	Grounded TN/TT line systems or non-grounded IT line systems
Line impedance	Uk < 4%, line reactor is not required
Power factor λ	> 0.9
Output voltage	3 AC 0 V 0.95 × input voltage (max.)
Input frequency	50 Hz 60 Hz, ± 3 Hz
Output frequency	0 550 Hz, depending on the control mode
Inrush current	< LO base load input current
Overvoltage category according to EN 61800-5-1	III for line supplies
Pulse frequency	2 kHz (factory setting), can be adjusted to 4 kHz
	If you increase the pulse frequency, the converter reduces the maximum output current.
Short-circuit current rating (SCCR) and branch protection	≤ 100 kA rms  Branch protection and short-circuit strength according to UL and IEC ( <a href="https://support.industry.siemens.com/cs/ww/en/view/109479152">https://support.industry.siemens.com/cs/ww/en/view/109479152</a> )
Braking methods	DC braking, compound braking
Degree of protection according to EN 60529	IP20; must be installed in a control cabinet
Protection class according to EN 61800-5-1	The converters are devices with protection class I
Touch protection according to EN 50274	DGUV regulation 3 when used for the intended purpose
Cooling in compliance with EN 60146	Forced air cooling AF

## 11.4.6 Specific technical data, 690 V converters

The fuses listed in the following tables are examples of suitable fuses.

You can find additional suitable fuses in the Internet:

Branch protection and short-circuit strength according to UL and IEC (<a href="https://support.industry.siemens.com/cs/ww/en/view/109479152">https://support.industry.siemens.com/cs/ww/en/view/109479152</a>)

Table 11-24 PM240P-2, IP20, frame size D, 3 AC 500 V ... 690 V

Article number without filter Article number with filter	6SL3210-1RH21-4UL0 6SL3210-1RH21-4AL0	6SL3210-1RH22-0UL0 6SL3210-1RH22-0AL0	6SL3210-1RH22-3UL0 6SL3210-1RH22-3AL0
LO base load power	11 kW	15 kW	18.5 kW
LO base load input current	14 A	18 A	22 A
LO base load output current	14 A	19 A	23 A
HO base load power	7.5 kW	11 kW	15 kW
HO base load input current	11 A	14 A	20 A
HO base load output current	11 A	14 A	19 A
Siemens fuse according to IEC/UL Fuse according to IEC/UL, Class J	3NE1815-0 / 25 A 20 A	3NE1815-0 / 25 A 25 A	3NE1803-0 / 35 A 30 A
Power loss	0.32 kW	0.41 kW	0.48 kW
Required cooling air flow	55 l/s	55 l/s	55 l/s
Weight without filter	17 kg	17 kg	17 kg
Weight with filter	18.5 kg	18.5 kg	18.5 kg

Table 11-25 PM240P-2, IP20, frame size D, 3 AC 500 V ... 690 V

Article number without filter Article number with filter	6SL3210-1RH22-7UL0 6SL3210-1RH22-7AL0	6SL3210-1RH23-5UL0 6SL3210-1RH23-5AL0	6SL3210-1RH24-2UL0 6SL3210-1RH24-2AL0
LO base load power	22 kW	30 kW	37 kW
LO base load input current	25 A	33 A	40 A
LO base load output current	27 A	35 A	42 A
HO base load power	18.5 kW	22 kW	30 kW
HO base load input current	24 A	28 A	36 A
HO base load output current	23 A	27 A	35 A
Siemens fuse according to IEC/UL Fuse according to IEC/UL, Class J	3NE1803-0 / 35 A 35 A	3NE1817-0 / 50 A 50 A	3NE1818-0 / 63 A 60 A
Power loss without filter	0.56 kW	0.72 kW	0.88 kW
Power loss with filter	0.56 kW	0.73 kW	0.88 kW
Required cooling air flow	55 l/s	55 l/s	55 l/s
Weight without filter	17 kg	17 kg	17 kg
Weight with filter	18.5 kg	18.5 kg	18.5 kg

Table 11-26 PM240P-2, IP20, frame sizes E, 3 AC 500 V ... 690 V

Article number without filter Article number with filter	6SL3210-1RH25-2UL0 6SL3210-1RH25-2AL0	6SL3210-1RH26-2UL0 6SL3210-1RH26-2AL0	
LO base load power	45 kW	55 kW	
LO base load input current	50 A	59 A	
LO base load output current	52 A	62 A	
HO base load power	37 kW	45 kW	
HO base load input current	44 A	54 A	
HO base load output current	42 A	52 A	
Siemens fuse according to IEC/UL Fuse according to IEC/UL, Class J	3NA1820-0 / 80 A 80 A	3NE1820-0 / 80 A 80 A	
Power loss without filter	1.00 kW	1.21 kW	
Power loss with filter	1.00 kW	1.22 kW	
Required cooling air flow	83 l/s	83 l/s	
Weight without filter	26 kg	26 kg	
Weight with filter	28 kg	28 kg	

Table 11-27 PM240-2, IP20, frame size F, 3 AC 500 V ... 690 V

Article number without filter Article number with filter	6SL3210-1RH28-0UL0 6SL3210-1RH28-0AL0	6SL3210-1RH31-0UL0 6SL3210-1RH31-0AL0	6SL3210-1RH31-2UL0 6SL3210-1RH31-2AL0
LO base load power	75 kW	90 kW	110 kW
LO base load input current	78 A	97 A	111 A
LO base load output current	80 A	100 A	115 A
HO base load power	55 kW	75 kW	90 kW
HO base load input current	66 A	85 A	106 A
HO base load output current	62 A	80 A	100 A
Siemens fuse according to IEC/UL Fuse according to IEC/UL, Class J	3NE1021-0 / 100 A 110 A	3NE1022-0 / 125 A 150 A	3NE1224-0 / 160 A 150 A
Power loss without filter	1.34 kW	1.71 kW	2 kW
Power loss with filter	1.35 kW	1.72 kW	2.02 kW
Required cooling air flow	153 l/s	153 l/s	153 l/s
Weight without filter	60 kg	60 kg	60 kg
Weight with filter	64 kg	64 kg	64 kg

Table 11-28 PM240-2, IP20, frame size F, 3 AC 500 V ... 690 V

Article number without filter Article number with filter	6SL3210-1RH31-4UL0 6SL3210-1RH31-4AL0	
LO base load power	132 kW	
LO base load input current	137 A	
LO base load output current	142 A	
HO base load power	110 kW	

Article number without filter Article number with filter	6SL3210-1RH31-4UL0 6SL3210-1RH31-4AL0	
HO base load input current	122 A	
HO base load output current	115 A	
Siemens fuse according to IEC/UL Fuse according to IEC/UL, Class J	3NE1225-0 / 200 A 200 A	
Power loss without filter	2.56 kW	
Power loss with filter	2.59 kW	
Required cooling air flow	153 l/s	
Weight without filter	60 kg	
Weight with filter	64 kg	

# 11.4.7 Current derating depending on the pulse frequency, 690 V converters

Article number	LO pow- er [kW]	LO base load output current [A]	
Pulse frequency [kHz]		2	4
6SL3210-1RH21-4 . L0		14	8.4
6SL3210-1RH22-0 . L0		19	11.4
6SL3210-1RH22-3 . L0		23	13.8
6SL3210-1RH22-7 . L0		27	16.2
6SL3210-1RH23-5 . L0		35	21
6SL3210-1RH24-2 . L0		42	25.2
6SL3210-1RH25-2 . L0		52	31.2
6SL3210-1RH26-2 . L0		62	37.2
6SL3210-1RH28-0 . L0		80	48
6SL3210-1RH31-0 . L0		100	60
6SL3210-1RH31-2 . L0		115	69
6SL3210-1RH31-4 . L0		142	85.2

The permissible motor cable length depends on the cable type and the selected pulse frequency.

# 11.5 Technical data, PM330 Power Module

### Permissible converter overload

The converters have different load capabilities, "High Overload" and "Low Overload", depending on the expected.




Figure 11-4 Load cycles, "Low Overload" and "High Overload"

## 11.5.1 General technical data, PM330

Table 11-29 General technical data

Electrical data	
Line system configurations	Grounded TN/TT systems or ungrounded IT systems (a grounded phase conductor is not permissible in 690 V line supplies)
Line requirement	A line reactor (2% u <sub>k</sub> ) must be connected in series
Line voltage	380 V (-10 %) 480 V (+10 %) 500 V (-10 %) 690 V (+10 %)
Line frequency	47 63 Hz
Output frequency	0 100 Hz
Displacement factor $\cos \phi$ power factor $\lambda$	$0.96$ $0.75 \dots 0.93$ (with line reactor $u_k = 2\%$ )
Converter efficiency	> 98%
Short-circuit current rating according to IEC, in conjunction with the specified fuses	160 630 kW: 100 kA
Short-circuit current rating according to UL61800-5-1 (up to 480 V AC or 600 V AC), in conjunction with the specified fuses	160 630 kW: 100 kA Can be used on line supplies that cannot supply more than 100 kA symmetrically at a maximum voltage of 480 V AC or 600 V AC when they are protected with the semiconductor fuses specified in Chapter "Technical Data" of this manual.
Overvoltage category	III according to EN 61800-5-1
Mechanical data	
Degree of protection	IP20
Protection class	according to EN 61800-5-1: Class I (with protective conductor system) and Class III (PELV)
Cooling method	Forced air cooling AF according to EN 60146
Sound pressure level L <sub>PA</sub> (1 ma)	$\leq$ 74 dB(A) 1)

Touch protection	according to EN 61800-5-1: Fo	or the intended purpose			
Compliance with standards					
Standards	EN 60146-1-1, EN 61800-2, El UL61800-5-1, CSA 22.2 No. 2	N 61800-3, EN 61800-5-1, EN 6 74-13	50204-1, EN 60529		
CE marking	In accordance with EMC Direct	tive No. 2014/30/EU and Low-Vo	oltage Directive No. 2014/35/EU		
Radio interference suppression	In accordance with the EMC penvironment <sup>2)</sup> . Application in "first environme	·	eed drives EN 61800-3, "second		
Approval	cULus (File No.: E192450), CE	, RCM, EAC, KC			
Ambient conditions	During storage 3)	During transport 3)	During operation		
Ambient temperature	-25° +55° C	-25 +70 °C from –40 °C for 24 hours	0° +40° C up to + 50° C with derating		
Relative humidity (no condensation)	5 to 95%	5 95% at 40° C	5 95%		
Corresponds to class	1K4 according to EN 2K3 according to 3K3 according to EN 60721-3-1 EN 60721-3-2 EN 60721-3-3				
Environmental class / harmful chemical substances	1C2 according to EN 60721-3-1				
Organic/biological influences	1B1 according to         2B1 according to         3B1 according to           EN 60721-3-1         EN 60721-3-2         EN 60721-3-3				
Pollution degree	2 according to EN 61800-5-1				
Installation altitude	up to 1000 m above sea level without derating, > 1000 m above sea level with derating (see Chapter Restrictions for special ambient conditions (Page 562))				
Mechanical strength	During storage 3)	During transport 3)	During operation		
Vibrational load - Displacement - Acceleration	Fc test according to EN		0.075 mm for 10 58 Hz 9.81 ma/s <sup>2</sup> (1 x g) at > 58		
Shock load - Displacement	Fc test according to EN Fc test according to EN Fc test according to EN 60068-2-6 Fc test according to EN 60068-2-27 (EA shock ty				
- Acceleration	±1.5 mm for 5 9 Hz 0.5 g for 9 200 Hz	±1.5 mm for 5 9 Hz 0.5 g for 9 200 Hz	49 ma/s² (5 x g)/30 ms 147 m/s² (15 x g)/11 ms		

Deviations from the defined classes are shown in italics.

maximum sound pressure level, ascertained in the IP20 cabinet

<sup>&</sup>lt;sup>2)</sup> Standard construction: Devices installed in the control cabinet with installation in conformance with EMC regulations, line reactor uk = 2%, shielded motor cable (e.g. Protoflex EMC) with max. 100 m cable length, line harmonics according to EN 61000-2-4: Class 2, THD(U) total = 8% for typical line conditions (RSC > 30 ... 50); THD(I) total: typically 30 ... 45 % (15 < RSC < 50)

<sup>3)</sup> in transport packaging

### 11.5.2 Power-dependent technical data, PM330

#### Note

### **Recommended connection cross-sections**

The recommended connection cross-sections are determined for copper cables at  $45 \,^{\circ}$ C ambient temperature and cables with a permitted operating temperature at the conductor of  $70 \,^{\circ}$ C (routing type C - factor for bundling 0.75 considered) according to DIN VDE 0298-4/08.03).

Protective conductor cross-section (S: Cross-section of the supply connection phase conductor, MS: Cross-section of the external protective conductor):

Minimum cross-sections:

- $S < 16 \text{ mm}^2 \rightarrow MS = S$
- $16 \text{ mm}^2 \le S \le 35 \text{ mm}^2 \rightarrow MS = 16 \text{ mm}^2$
- $S > 35 \text{ mm}^2 \rightarrow MS = 0.5 \times S$

Recommended cross-sections:

• MS ≥ S

Table 11-30 PM330 frame sizes GX, 3-phase 380 ... 480 VAC

Article No.	6SL3310-	1PE33-0AA0	1PE33-7AA0	1PE34-6AA0
Rated input current				
- at 380/400 V, 45° C		317 A	375 A	469 A
- at 480 V, 45° C		262 A	314 A	376 A
- at 380/400 V, 55° C		269 A	319 A	399 A
- at 480 V, 55° C		220 A	266 A	319 A
Rated input current DCP/DCN				
(for 2/3 of the converter power)				
- at 510 $V_{DC}$ , 45 $^{\circ}C$		255 A	315 A	392 A
- at 650 V <sub>DC</sub> , 45 °C		209 A	263 A	314 A
- at 510 V <sub>DC</sub> , 55 °C		217 A	268 A	333 A
- at 650 V <sub>DC</sub> , 55 °C		177 A	223 A	267 A
Rated output current I <sub>N</sub>				
- at 380/400 V, 45° C		300 A	370 A	460 A
- at 480 V, 45° C		245 A	308 A	369 A
- at 380/400 V, 55° C		255 A	315 A	391 A
- at 480 V, 55° C		208 A	262 A	313 A
LO base load power		160 kW	200 kW	250 kW
LO base load input current at 400 V		307 A	365 A	459 A
LO base load output current at 400 V		290 A	360 A	450 A
HO base load power		132 kW	160 kW	200 kW
HO base load input current at 400 V		254 A	300 A	375 A
HO base load output current at 400 \	/	240 A	296 A	368 A
Fuse according to IEC		3NE1333-2	3NE1334-2	3NE1435-2
-		(450 A/690 V)	(500 A/690 V)	(560 A/690 V)
manufacturer:		Siemens AG	Siemens AG	Siemens AG
Maximum permissible line short-circu	uit current I <sub>kmax</sub>	≤ 100 kA	≤ 100 kA	≤ 100 kA
Minimum line short-circuit current re	quired I <sub>kmin</sub> 1)	> 3.5 kA	> 4.5 kA	> 7.0 kA

Article No. 6SL3310-	1PE33-0AA0	1PE33-7AA0	1PE34-6AA0
Fuse in compliance with UL <sup>2)</sup>	3NE1333-2 (450 A/690 V)	3NE1334-2 (500 A/690 V)	3NE1435-2 (560 A/690 V)
Manufacturer:	Siemens AG	Siemens AG	Siemens AG
Maximum permissible line short-circuit current $I_{kmax}$	≤ 100 kA	≤ 100 kA	≤ 100 kA
Minimum line short-circuit current required I <sub>kmin</sub> 1)	> 3.5 kA	> 4.5 kA	> 7.0 kA
max. power loss, at I <sub>N</sub> , 45 °C, 400 V	3.642 kW	4.414 kW	5.125 kW
Required cooling air flow	210 l/s	210 l/s	210 l/s
Maximum connectable cross-section of the line, motor and DC-link cable	2 x 240 mm <sup>2</sup> 2 x 500 kcmil	2 x 240 mm <sup>2</sup> 2 x 500 kcmil	2 x 240 mm <sup>2</sup> 2 x 500 kcmil
Recommended cable cross-section for 380 V/400 V - line cable - motor cable	2 x 120 mm <sup>2</sup> 2 x 95 mm <sup>2</sup>	2 x 120 mm <sup>2</sup> 2 x 95 mm <sup>2</sup>	2 x 185 mm <sup>2</sup> 2 x 150 mm <sup>2</sup>
Recommended cable cross-section for 480 V - line cable - motor cable	2 x 95 mm <sup>2</sup> 2 x 70 mm <sup>2</sup>	2 x 120 mm <sup>2</sup> 2 x 95 mm <sup>2</sup>	2 x 120 mm <sup>2</sup> 2 x 120 mm <sup>2</sup>
Recommended cable cross-section for 380 V/400 V - DC link infeed (2/3 converter power) - Braking Module <sup>3)</sup>	2 x 120 mm² 35 mm²	2 x 120 mm² 35 mm²	2 x 150 mm² 35 mm²
Recommended cable cross-section for 480 V - DC link infeed (2/3 converter power) - Braking Module <sup>3)</sup>	2 x 95 mm² 35 mm²	2 x 95 mm² 35 mm²	2 x 120 mm² 35 mm²
Tightening torque for line, motor, DC link, and ground cable	50 Nm / 443 lbf in	50 Nm / 443 lbf in	50 Nm / 443 lbf in
Dimensions: Width x height x depth [mm]	452 x 1447 x 327.5	452 x 1447 x 327.5	452 x 1447 x 327.5
Weight	98 kg	104 kg	109 kg

The line supply must be capable of supplying the minimum short-circuit current so that the fuses trigger and consequential damage is avoided.

Note: If the minimum short-circuit current is not reached, then the tripping time for the fuses increases, and this may result in consequential damage.

Table 11-31 PM330, frame size HX, 3-phase 380 ... 480 VAC

Article No.	6SL3310-	1PE35-8AA0	1PE36-6AA0	1PE37-4AA0
Rated input current	'			
- at 380/400 V, 45° C		597 A	668 A	750 A
- at 480 V, 45° C		497 A	536 A	614 A
- at 380/400 V, 55° C		507 A	568 A	637 A
- at 480 V, 55° C		422 A	456 A	522 A
Rated input current DCP/DCN				
(for 2/3 of the converter power)				
- at 510 V <sub>DC</sub> , 45 °C		498 A	558 A	626 A
- at 650 V <sub>DC</sub> , 45 °C		415 A	448 A	513 A
- at 510 V <sub>DC</sub> , 55 °C		423 A	474 A	532 A
- at 650 V <sub>DC</sub> , 55 °C		352 A	381 A	436 A

<sup>&</sup>lt;sup>2)</sup> When semiconductor fuses are used, they must be mounted in the same higher construction as the converter.

<sup>3)</sup> When connecting a Braking Module with rated power 50 kW, P<sub>20</sub> power 200 kW.

Article No. 6SL3	3310- 1PE35-8AA0	1PE36-6AA0	1PE37-4AA0
Rated output current I <sub>N</sub>	·		
- at 380/400 V, 45° C	585 A	655 A	735 A
- at 480 V, 45° C	487 A	526 A	602 A
- at 380/400 V, 55° C	497 A	557 A	625 A 512 A
- at 480 V, 55° C	414 A	447 A	
LO base load power	315 kW	355 kW	400 kW
LO base load input current at 400 V LO base load output current at 400 V	581 A 570 A	653 A 640 A	734 A 720 A
· · · · · · · · · · · · · · · · · · ·			
HO base load power	250 kW 477 A	250 kW 501 A	315 kW
HO base load input current at 400 V HO base load output current at 400 V	477 A 468 A	491 A	562 A 551 A
·			
Fuse according to IEC	3NE1437-2	3NE1438-2	3NE1448-2
manufacturer:	(710 A/690 V) Siemens AG	(800 A/690 V) Siemens AG	(850 A/690 V) Siemens AG
		≤ 100 kA	≤ 100 kA
Maximum permissible line short-circuit cur			
Minimum line short-circuit current require		> 11.0 kA	> 13.0 kA
Fuse in compliance with UL 2)	3NE1437-2	3NE1438-2	3NE1448-2
	(710 A/690 V)	(800 A/690 V)	(850 A/690 V)
Manufacturer:	Siemens AG	Siemens AG	Siemens AG
Maximum permissible line short-circuit cur		≤ 100 kA	≤ 100 kA
Minimum line short-circuit current require	$d I_{kmin}^{1)} > 10.0 kA$	> 11.0 kA	> 13.0 kA
max. power loss, at $I_N$ , 45 °C, 400 V	6.791 kW	7.687 kW	8.385 kW
Required cooling air flow	360 l/s	360 l/s	360 l/s
Maximum connectable cross-section of the		4 x 240 mm <sup>2</sup>	4 x 240 mm <sup>2</sup>
tor and DC-link cable	4 x 500 kcmil	4 x 500 kcmil	4 x 500 kcmil
Recommended cable cross-section for 380	V/400 V		
- line cable	2 x 240 mm <sup>2</sup>	3 x 150 mm <sup>2</sup>	3 x 185 mm <sup>2</sup>
- motor cable	2 x 185 mm²	2 x 240 mm <sup>2</sup>	2 x 240 mm <sup>2</sup>
Recommended cable cross-section for 480	V		
- line cable	2 x 185 mm <sup>2</sup>	2 x 240 mm <sup>2</sup>	2 x 240 mm <sup>2</sup>
- motor cable	2 x 150 mm²	2 x 185 mm <sup>2</sup>	2 x 240 mm <sup>2</sup>
Recommended cable cross-section for 380			
- DC link infeed (2/3 converter power)	2 x 185 mm <sup>2</sup>	2 x 240 mm <sup>2</sup>	3 x 150 mm <sup>2</sup>
- Braking Module <sup>3)</sup>	35 mm²	35 mm <sup>2</sup>	35 mm²
Recommended cable cross-section for 480			
- DC link infeed (2/3 converter power)	2 x 150 mm <sup>2</sup>	2 x 185 mm <sup>2</sup>	2 x 240 mm <sup>2</sup>
- Braking Module 3)	35 mm²	35 mm <sup>2</sup>	35 mm²
Tightening torque for line, motor, DC link, as cable	nd ground 50 Nm / 443 lbf in	50 Nm / 443 lbf in	50 Nm / 443 lbf in
Dimensions: Width x height x depth [mm]	548 x 1695 x 393	548 x 1695 x 393	548 x 1695 x 393
Weight	151 kg	157 kg	159 kg
Minimum control cabinet size for installation Power Module (width x height x depth)	on of the 80	00 mm x 2000 mm x 600	mm

The line supply must be capable of supplying the minimum short-circuit current so that the fuses trigger and consequential damage is avoided.

Note: If the minimum short-circuit current is not reached, then the tripping time for the fuses increases, and this may result in consequential damage.

When semiconductor fuses are used, they must be mounted in the same higher construction as the converter.

Table 11-32 PM330, frame size JX, 3-phase 380 ... 480 VAC

Article No. 6S	L3310-	1PE38-4AA0	1PE38-8AA0	1PE41-0AA0
Rated input current				
- at 380/400 V, 45° C		870 A	945 A	1061 A
- at 480 V, 45° C		702 A	767 A	880 A
- at 380/400 V, 55° C		740 A	803 A	901 A
- at 480 V, 55° C		596 A	652 A	748 A
Rated input current DCP/DCN				
(for 2/3 of the converter power)				
- at 510 $V_{DC}$ , 45 $^{\circ}C$		715 A	775 A	870 A
- at 650 V <sub>DC</sub> , 45 °C		577 A	629 A	722 A
- at 510 V <sub>DC</sub> , 55 °C		608 A	659 A	739 A
- at 650 V <sub>DC</sub> , 55 °C		490 A	535 A	613 A
Rated output current I <sub>N</sub>		0.40.4	040.4	1001
- at 380/400 V, 45° C		840 A	910 A	1021 A
- at 480 V, 45° C		677 A	739 A	847 A
- at 380/400 V, 55° C		714 A	774 A	868 A
- at 480 V, 55° C		576 A	628 A	720 A
LO base load power		450 kW	500 kW	560 kW
LO base load input current at 400 V		850 A	925 A	1039 A
LO base load output current at 400 V		820 A	890 A	1000 A
HO base load power		355 kW	400 kW	450 kW
HO base load input current at 400 V		696 A	756 A	816 A
HO base load output current at 400 V		672 A	728 A	786 A
Fuse according to IEC		2 x 3NE1334-2 //	2 x 3NE1435-2 //	2 x 3NE1436-2 //
		(2 x 500 A / 690 V)	(2 x 560 A / 690 V)	(2 x 630 A / 690 V)
manufacturer:		Siemens AG	Siemens AG	Siemens AG
Maximum permissible line short-circuit c	urrent I <sub>kmax</sub>	≤ 100 kA	≤ 100 kA	≤ 100 kA
Minimum line short-circuit current requir	red I <sub>kmin</sub> 1)	> 10.4 kA	> 14.0 kA	> 16.0 kA
Fuse in compliance with UL <sup>2)</sup>		3NB3350-1KK26	3NB3351-1KK26	3NB3352-1KK26
·		(1000 A/690 V)	(1100 A/690 V)	(1250 A/690 V)
Manufacturer:		Siemens AG	Siemens AG	Siemens AG
Minimum line short-circuit current requir	red I <sub>kmin</sub> 1)	8.6 kA	17.0 kA	18.0 kA
max. power loss, at $I_N$ , 45 °C, 400 V		10.418 kW	10.885 kW	12.495 kW
Required cooling air flow		450 l/s	450 l/s	450 l/s
Maximum connectable cross-section of t	he power	6 x 240 mm <sup>2</sup>	6 x 240 mm <sup>2</sup>	6 x 240 mm <sup>2</sup>
cable		6 x 500 kcmil	6 x 500 kcmil	6 x 500 kcmil
Maximum connectable cross-section of the	ne motor ca-	4 x 240 mm <sup>2</sup>	8 x 240 mm <sup>2</sup>	8 x 240 mm <sup>2</sup>
ble		4 x 500 kcmil	8 x 500 kcmil	8 x 500 kcmil
Maximum connectable cross-section of t	he DC link	4 x 240 mm <sup>2</sup>	4 x 240 mm <sup>2</sup>	4 x 240 mm <sup>2</sup>
cable		4 x 500 kcmil	4 x 500 kcmil	4 x 500 kcmil
Recommended cable cross-section for 38	30 V/400 V			
- line cable		4 x 185 mm <sup>2</sup>	4 x 185 mm <sup>2</sup>	4 x 240 mm <sup>2</sup>
- motor cable 3)		4 x 150 mm <sup>2</sup>	4 x 185 mm <sup>2</sup>	4 x 240 mm <sup>2</sup>

<sup>&</sup>lt;sup>3)</sup> When connecting a Braking Module with rated power 50 kW, P<sub>20</sub> power 200 kW.

Article No.	6SL3310-	1PE38-4AA0	1PE38-8AA0	1PE41-0AA0		
Recommended cable cross-sect	Recommended cable cross-section for 480 V					
- line cable		4 x 120 mm <sup>2</sup>	4 x 150 mm <sup>2</sup>	4 x 185 mm <sup>2</sup>		
- motor cable <sup>3)</sup>		4 x 120 mm <sup>2</sup>	4 x 150 mm <sup>2</sup>	4 x 150 mm <sup>2</sup>		
Recommended cable cross-sect	ion for 380 V/400 V					
- DC link infeed (2/3 converter p	oower)	4 x 120 mm <sup>2</sup>	4 x 150 mm <sup>2</sup>	4 x 185 mm <sup>2</sup>		
- Braking Module 4)		35 mm <sup>2</sup>	35 mm <sup>2</sup>	35 mm²		
Recommended cable cross-sect	ion for 480 V					
- DC link infeed (2/3 converter p	oower)	3 x 120 mm <sup>2</sup>	3 x 150 mm <sup>2</sup>	3 x 185 mm <sup>2</sup>		
- Braking Module 4)		35 mm <sup>2</sup>	35 mm <sup>2</sup>	35 mm²		
Tightening torque for line, moto cable	r, DC link, and ground	50 Nm / 443 lbf in	50 Nm / 443 lbf in	50 Nm / 443 lbf in		
Dimensions: Width x height x d	epth [mm]	801 x 1621 x 393	801 x 1621 x 393	801 x 1621 x 393		
Weight		235 kg	250 kg	250 kg		

The line supply must be capable of supplying the minimum short-circuit current so that the fuses trigger and consequential damage is avoided.

Table 11-33 PM330, frame size HX, 3-phase 500 ... 690 VAC, Part 1

Article No.	6SL3310-	1PG33-7AA0	1PG34-0AA0	1PG34-5AA0
Rated input current				
- at 500 V, 45 °C		383 A	416 A	471 A
- at 600 V, 45 °C		367 A	412 A	459 A
- at 690 V, 45 °C		354 A	409 A	447 A
- at 500 V, 55 °C		326 A	354 A	400 A
- at 600 V, 55 °C		312 A	350 A	390 A
- at 690 V, 55 °C		301 A	348 A	380 A
Rated input current DCP/DCN				
(for 2/3 of the converter power)				
- at 675 V <sub>DC</sub> , 45 °C		314 A	341 A	385 A
- at 810 V <sub>DC</sub> , 45 °C		301 A	337 A	376 A
- at 930 V <sub>DC</sub> , 45 °C		290 A	335 A	366 A
- at 675 V <sub>DC</sub> , 55 °C		267 A	290 A	328 A
- at 810 V <sub>DC</sub> , 55 °C		255 A	287 A	319 A
- at 930 V <sub>DC</sub> , 55 °C		246 A	284 A	311 A
Rated output current I <sub>N</sub>				
- at 500 V, 45 °C		368 A	400 A	453 A
- at 600 V, 45 °C		353 A	396 A	441 A
- at 690 V, 45 °C		340 A	393 A	430 A
- at 500 V, 55 °C		313 A	340 A	385 A
- at 600 V, 55 °C		300 A	337 A	375 A
- at 690 V, 55 °C		289 A	334 A	366 A
LO base load power		315 kW	355 kW	400 kW
LO base load input current at 690 V		343 A	401 A	437 A
LO base load output current at 690 V	/	330 A	385 A	420 A

Note: If the minimum short-circuit current is not reached, then the tripping time for the fuses increases, and this may result in consequential damage.

<sup>2)</sup> When semiconductor fuses are used, they must be mounted in the same higher construction as the converter.

<sup>3)</sup> The motor cables must be evenly distributed at both connection chambers.

<sup>&</sup>lt;sup>4)</sup> For connection of the Braking Module with rated power of 50 kW, P<sub>20</sub> power of 200 kW.

Article No.	6SL3310-	1PG33-7AA0	1PG34-0AA0	1PG34-5AA0
HO base load power		250 kW	315 kW	355 kW
HO base load input current	at 690 V	283 A	327 A	362 A
HO base load output curren	t at 690 V	272 A	314 A	348 A
Fuse according to IEC		3NE1333-2	3NE1334-2	3NE1435-2
-		(450 A/690 V)	(500 A/690 V)	(560 A/690 V)
manufacturer:		Siemens AG	Siemens AG	Siemens AG
Maximum permissible line s	hort-circuit current I <sub>kmax</sub>	≤ 100 kA	≤ 100 kA	≤ 100 kA
Minimum line short-circuit	current required I <sub>kmin</sub> 1)	> 3.5 kA	> 4.5 kA	> 7.0 kA
Fuse in compliance with UL	2)	3NE1333-2	3NE1334-2	3NE1435-2
		(450 A/690 V)	(500 A/690 V)	(560 A/690 V)
Manufacturer:		Siemens AG	Siemens AG	Siemens AG
Maximum permissible line s	hort-circuit current I <sub>kmax</sub>	≤ 100 kA	≤ 100 kA	≤ 100 kA
Minimum line short-circuit	current required I <sub>kmin</sub> 1)	> 3.5 kA	> 4.5 kA	> 7.0 kA
max. power loss, at I <sub>N</sub> , 45 °C	C, 690 V	5.402 kW	6.191 kW	6.884 kW
Required cooling air flow		360 l/s	360 l/s	360 l/s
Maximum connectable cros	s-section of the line, mo-	4 x 240 mm <sup>2</sup>	4 x 240 mm <sup>2</sup>	4 x 240 mm <sup>2</sup>
tor and DC-link cable		4 x 500 kcmil	4 x 500 kcmil	4 x 500 kcmil
Recommended cable cross-s	section for 500 V			'
- line cable		2 x 120 mm <sup>2</sup>	2 x 150 mm <sup>2</sup>	2 x 185 mm <sup>2</sup>
- motor cable		2 x 120 mm <sup>2</sup>	2 x 120 mm <sup>2</sup>	2 x 150 mm <sup>2</sup>
Recommended cable cross-s	section for 690 V			
- line cable		2 x 120 mm <sup>2</sup>	2 x 150 mm <sup>2</sup>	2 x 185 mm <sup>2</sup>
- motor cable		2 x 95 mm <sup>2</sup>	2 x 120 mm <sup>2</sup>	2 x 150 mm <sup>2</sup>
Recommended cable cross-s	section for 500 V			
- DC link infeed (2/3 convert	er power)	2 x 95 mm <sup>2</sup>	2 x 120 mm <sup>2</sup>	2 x 150 mm <sup>2</sup>
Recommended cable cross-s	section for 690 V			
- DC link infeed (2/3 convert	er power)	2 x 95 mm <sup>2</sup>	2 x 120 mm <sup>2</sup>	2 x 150 mm <sup>2</sup>
Tightening torque for line, m cable	otor, DC link, and ground	50 Nm / 443 lbf in	50 Nm / 443 lbf in	50 Nm / 443 lbf in
Dimensions: Width x height	x depth [mm]	548 x 1695 x 393	548 x 1695 x 393	548 x 1695 x 393
Weight		158 kg	158 kg	162 kg
Minimum control cabinet six Power Module (width x heig		800 mm x 2000 mm x 600 mm		

The line supply must be capable of supplying the minimum short-circuit current so that the fuses trigger and consequential damage is avoided.
Note: If the minimum short-circuit current is not reached, then the tripping time for the fuses increases, and this may result in consequential damage.

<sup>&</sup>lt;sup>2)</sup> When semiconductor fuses are used, they must be mounted in the same higher construction as the converter.

Table 11-34 PM330, frame size HX, 3-phase 500 ... 690 VAC, Part 2

	6SL3310-	1PG35-2AA0	
Rated input current			
- at 500 V, 45 °C		537 A	
- at 600 V, 45 °C		517 A	
- at 690 V, 45 °C		499 A	
- at 500 V, 55 °C		456 A	
- at 600 V, 55 °C		440 A	
- at 690 V, 55 °C		425 A	
Rated input current DCP/DCN			
(for 2/3 of the converter power)		422.4	
- at 675 V <sub>DC</sub> , 45 °C		439 A	
- at 810 V <sub>DC</sub> , 45 °C		423 A	
- at 930 V <sub>DC</sub> , 45 °C		409 A 373 A	
- at 675 V <sub>DC</sub> , 55 °C - at 810 V <sub>DC</sub> , 55 °C		360 A	
- at 930 V <sub>DC</sub> , 55 °C		347 A	
· · · · · · · · · · · · · · · · · · ·		J 7 / /	
Rated output current I <sub>N</sub>		516 A	
- at 500 V, 45 °C - at 600 V, 45 °C		497 A	
- at 690 V, 45 °C		480 A	
- at 500 V, 55 °C		438 A	
- at 600 V, 55 °C		422 A	
- at 690 V, 55 °C		408 A	
LO base load power		450 kW	
LO base load input current at 690 V		489 A	
LO base load output current at 690 V		470 A	
HO base load power		400 kW	
HO base load input current at 690 V		410 A	
HO base load output current at 690 V		394 A	
	<del></del>		
Fuse according to IEC		3NE1436-2	
manufacturer:		(630 A/690 V) Siemens AG	
Maximum permissible line short-circui		≤ 100 kA	
Minimum line short-circuit current req	uired I <sub>kmin</sub> 1)	> 8.5 kA	
Fuse in compliance with UL 2)		3NE1436-2	
		(630 A/690 V)	
Manufacturer:		Siemens AG	
Maximum permissible line short-circui	t current I <sub>kmax</sub>	≤ 100 kA	
Minimum line short-circuit current req	uired I <sub>kmin</sub> 1)	> 8.5 kA	
max. power loss, at I <sub>N</sub> , 45 °C, 690 V		7.716 kW	
Required cooling air flow	,	360 l/s	
Maximum connectable cross-section o	of the line mo-	4 x 240 mm <sup>2</sup>	
tor and DC-link cable	and mile, mo-	4 x 500 kcmil	
Recommended cable cross-section for	500 V		
- line cable		3 x 120 mm <sup>2</sup>	
- motor cable		3 x 95 mm <sup>2</sup>	
Recommended cable cross-section for	690 V		
- line cable		3 x 120 mm <sup>2</sup>	
- motor cable		3 x 95 mm <sup>2</sup>	

Article No.	6SL3310-	1PG35-2AA0
Recommended cable cross-section for 500 V - DC link infeed (2/3 converter power)		2 x 150 mm <sup>2</sup>
Recommended cable cross-section - - DC link infeed (2/3 converter power		2 x 150 mm <sup>2</sup>
Tightening torque for line, motor, DC cable	link, and ground	50 Nm / 443 lbf in
Dimensions: Width x height x depth	ı [mm]	548 x 1695 x 393
Weight	,	162 kg
Minimum control cabinet size for in Power Module (width x height x de		800 mm x 2000 mm x 600 mm

The line supply must be capable of supplying the minimum short-circuit current so that the fuses trigger and consequential damage is avoided.

Table 11-35 PM330, frame size JX, 3 AC 500 V ... 690 V

Article No.	6SL3310-	1PG35-8AA0	1PG36-5AA0	1PG37-2AA0
Rated input current				
- at 500 V, 45 °C		596 A	679 A	753 A
- at 600 V, 45 °C		578 A	647 A	720 A
- at 690 V, 45 °C		555 A	618 A	690 A
- at 500 V, 55 °C		506 A	577 A	640 A
- at 600 V, 55 °C		492 A	550 A	612 A
- at 690 V, 55 °C		472 A	525 A	587 A
Rated input current DCP/DCN				
(for 2/3 of the converter power)				
- at 675 $V_{DC}$ , 45 $^{\circ}C$		495 A	557 A	617 A
- at 810 V <sub>DC</sub> , 45 °C		474 A	531 A	590 A
- at 930 V <sub>DC</sub> , 45 °C		456 A	507 A	566 A
- at 675 V <sub>DC</sub> , 55 °C		420 A	473 A	525 A
- at 810 V <sub>DC</sub> , 55 °C		403 A	451 A	502 A
- at 930 V <sub>DC</sub> , 55 °C		387 A	431 A	481 A
Rated output current I <sub>N</sub>				
- at 500 V, 45 °C		581 A	654 A	725 A
- at 600 V, 45 °C		557 A	623 A	693 A
- at 690 V, 45 °C		535 A	595 A	665 A
- at 500 V, 55 °C		494 A	555 A	616 A
- at 600 V, 55 °C		473 A	530 A	589 A
- at 690 V, 55 °C		455 A	506 A	565 A
LO base load power		500 kW	560 kW	630 kW
LO base load input current at 690 V	/	540 A	602 A	675 A
LO base load output current at 690	V	520 A	580 A	650 A
HO base load power		450 kW	500 kW	560 kW
HO base load input current at 690 V	V	461 A	494 A	552 A
HO base load output current at 690	) V	444 A	476 A	532 A

Note: If the minimum short-circuit current is not reached, then the tripping time for the fuses increases, and this may result in consequential damage.

<sup>&</sup>lt;sup>2)</sup> When semiconductor fuses are used, they must be mounted in the same higher construction as the converter.

Article No. 6SL3310-	1PG35-8AA0	1PG36-5AA0	1PG37-2AA0
Fuse according to IEC	3NE1437-2 (710 A/690 V)	3NE1438-2 (800 A/690 V)	3NE1448-2 (850 A/690 V)
manufacturer:	Siemens AG	Siemens AG	Siemens AG
Maximum permissible line short-circuit current I <sub>kmax</sub>		≤ 100 kA	≤ 100 kA
Minimum line short-circuit current required $I_{kmin}$ 1)	> 10.0 kA	> 11.0 kA	> 13.0 kA
Fuse in compliance with UL <sup>2)</sup> Manufacturer:	3NE1437-2 (710 A/690 V) Siemens AG	3NE1438-2 (800 A/690 V) Siemens AG	3NE1448-2 (850 A/690 V) Siemens AG
Maximum permissible line short-circuit current $I_{kmax}$		≤ 100 kA	≤ 100 kA
Minimum line short-circuit current required $I_{kmin}$ <sup>1)</sup>	> 10.0 kA	> 11.0 kA	> 13.0 kA
max. power loss, at I <sub>N</sub> , 45 °C, 690 V	8.134 kW	8.828 kW	9.937 kW
Required cooling air flow	450 l/s	450 l/s	450 l/s
Maximum connectable cross-section of the power cable	6 x 240 mm <sup>2</sup> 6 x 500 kcmil	6 x 240 mm <sup>2</sup> 6 x 500 kcmil	6 x 240 mm <sup>2</sup> 6 x 500 kcmil
Maximum connectable cross-section of the motor cable	4 x 240 mm <sup>2</sup> 4 x 500 kcmil	4 x 240 mm <sup>2</sup> 4 x 500 kcmil	4 x 240 mm <sup>2</sup> 4 x 500 kcmil
Maximum connectable cross-section of the DC link cable	4 x 240 mm <sup>2</sup> 4 x 500 kcmil	4 x 240 mm <sup>2</sup> 4 x 500 kcmil	4 x 240 mm <sup>2</sup> 4 x 500 kcmil
Recommended cable cross-section for 500 V - line cable - motor cable <sup>3)</sup>	2 x 240 mm <sup>2</sup> 2 x 185 mm <sup>2</sup>	3 x 185 mm <sup>2</sup> 2 x 240 mm <sup>2</sup>	3 x 185 mm <sup>2</sup> 2 x 240 mm <sup>2</sup>
Recommended cable cross-section for 690 V - line cable - motor cable <sup>3)</sup>	2 x 240 mm <sup>2</sup> 2 x 185 mm <sup>2</sup>	3 x 150 mm <sup>2</sup> 2 x 240 mm <sup>2</sup>	3 x 185 mm <sup>2</sup> 2 x 240 mm <sup>2</sup>
Recommended cable cross-section for 500 V - DC link infeed (2/3 converter power)	2 x 185 mm <sup>2</sup>	2 x 185 mm²	2 x 240 mm <sup>2</sup>
Recommended cable cross-section for 690 V - DC link infeed (2/3 converter power)	2 x 150 mm <sup>2</sup>	2 x 185 mm <sup>2</sup>	2 x 185 mm <sup>2</sup>
Tightening torque for line, motor, DC link, and groun cable	d 50 Nm / 443 lbf in	50 Nm / 443 lbf in	50 Nm / 443 lbf in
Dimensions: Width x height x depth [mm]	801 x 1621 x 393	801 x 1621 x 393	801 x 1621 x 393
Weight	234 kg	234 kg	244 kg

The line supply must be capable of supplying the minimum short-circuit current so that the fuses trigger and consequential damage is avoided.

Note: If the minimum short circuit current is not reached, then the tripping time for the fuses increases, and this may recult

Note: If the minimum short-circuit current is not reached, then the tripping time for the fuses increases, and this may result in consequential damage.

<sup>&</sup>lt;sup>2)</sup> When semiconductor fuses are used, they must be mounted in the same higher construction as the converter.

<sup>&</sup>lt;sup>3)</sup> The motor cables must be evenly distributed at both connection chambers.

### Protective devices for the Power Module

The fuses listed in the following tables are examples of suitable fuses.

Additional components for branch protection are available in the Internet:

Branch protection and short-circuit strength according to UL and IEC (<a href="https://support.industry.siemens.com/cs/ww/en/view/109486009">https://support.industry.siemens.com/cs/ww/en/view/109486009</a>)

## Typical converter load cycles




Figure 11-5 "Low Overload" and "High Overload" load cycles

### 11.6.1 Ambient conditions

Property	Version
Ambient conditions for tra	nsport in the transport packaging
Air-conditioning	- 40 °C + 70 °C, according to Class 2K4 to EN 60721-3-2:1997 maximum humidity 95% at 40 °C
Mechanical system	Shocks and vibrations permissible according to 2M3 to IEC 60721-3-2:1997
Chemical substances	Protected according to Class 2C2 to IEC 60721-3-2:1997
Biological ambient conditions	Suitable according to Class 2B1 to IEC 60721-3-2:1997
Ambient conditions for lor	ng-term storage in the product packaging or in transport packaging
Air-conditioning	- 25 °C + 55 °C, according to Class 1K3 to IEC 60721-3-1:1997
Chemical substances	Protected according to Class 1C2 to IEC 60721-3-1:1997
Biological ambient conditions	Suitable according to Class 1B1 to IEC 60721-3-1:1997
Ambient conditions in ope	ration
Installation altitude	Up to 1000 m above sea level without limitations
	Restrictions for special ambient conditions (Page 562)

Property	Version	
Air-conditioning 1)	FSA FSC ambient operating temperature <sup>2)</sup>	
	– For operation according to Low Overload: -10 $^{\circ}$ C +40 $^{\circ}$ C	
	<ul> <li>For operation according to High Overload: -10 °C +50 °C</li> </ul>	
	<ul> <li>Restrictions for special ambient conditions (Page 562)</li> </ul>	
	FSD FSG ambient operating temperature <sup>2)</sup>	
	<ul> <li>For operation according to Low Overload: -20 °C +40 °C</li> </ul>	
	<ul> <li>For operation according to High Overload: -20 °C +50 °C</li> </ul>	
	<ul> <li>Restrictions for special ambient conditions (Page 562)</li> </ul>	
	Relative humidity: 5 95%, condensation not permitted	
	• Oil mist, ice formation, condensation, dripping water, spraying water, splashing water and water jets are not permitted	
Mechanical system	Vibration test during operation according to IEC 60068-2-6 Test Fc (sinusoidal)	
	• 0 57 Hz: 0.075 mm deflection amplitude	
	• 57 150 Hz: 1 g acceleration amplitude	
	10 frequency cycles per axis	
	Shock test according to IEC 60068-2-27 Test Ea (half-sine)	
	• 5 g peak acceleration	
	30 ms duration	
	<ul> <li>3 shocks in all three axes in both directions</li> </ul>	
Chemical substances	Protected according to 3C2 to IEC 60721-3-3:2002	
Biological ambient conditions	Suitable according to 3B1 to IEC 60721-3-3: 2002	
Pollution	Suitable for environments with degree of pollution 2 according to EN 61800-5-1	
Cooling	Forced air cooling AF, according to EN 60146	
Cooling air	Clean and dry air	
Noise emission	Maximum 75 db(A)	

<sup>1)</sup> Increased ruggedness regarding temperature range and relative humidity; therefore better than 3K3 according to IEC 60721-3-3: 2002

<sup>&</sup>lt;sup>2)</sup> Observe the permissible ambient operating temperatures for the Control Unit and the Operator Panel (IOP-2 or BOP-2).

# 11.6.2 General technical data, 200 V converters

Property	Version		
Line voltage	FSA FSC	200 V 240 V 1 AC ± 10%	0.55 kW 4 kW - LO 0.37 kW 3 kW - HO
		200 V 240 V 3 AC ± 10%	0.55 kW 7.5 kW - LO 0.37 kW 5.5 kW - HO
	FSD FSF	200 V 240 V 3 AC ± 10% (in operation -20% < 1 min)	11 kW 55 kW - LO 7.5 kW 45 kW - HO
Line supply configurations		TT line supplies or non-grounded IT li ecting the line supply and motor (Pag	
Line impedance	FSA FSC	$2\% \le Uk < 4\%$ . For Uk < 2%, we rewith the next higher power rating.	commend a line reactor, or a Power Module
	FSD FSF	No restrictions	
Power factor λ	FSA FSC	0.7 without line reactor for Uk $\geq$ 2° 0.85 with line reactor for Uk $<$ 2%	%
	FSD FSF	> 0.9	
Output voltage	0 V 3 AC 0.9	95 × input voltage	
Input frequency	50 Hz 60 Hz, ± 3 Hz		
Output frequency	0 550 Hz, depending on the control mode		
Inrush current	< LO base load input current		
Overvoltage category according to EN 61800-5-1	III for line supplies		
Pulse frequency	4 kHz (factory setting),		
	Adjustable in steps of 2 kHz.  Current reduction as a function of the pulse frequency (Page 539)		
	If you increase	the pulse frequency, the converter re	educes the maximum output current.
Short-circuit current (SCCR) and branch protection	Maximum permissible line short-circuit current ≤ 100 kA rms  Branch protection and short-circuit strength according to UL and IEC ( <a href="https://support.industry.siemens.com/cs/ww/en/view/109782705">https://support.industry.siemens.com/cs/ww/en/view/109782705</a> )		
Degree of protection ac-	IP20		
cording to EN 60529	IP55 PT devi	ces outside the control cabinet	
Protection class according to EN 61800-5-1	The converters are devices with protection class I		
Touch protection according to EN 50274	DGUV regulation 3 when used for the intended purpose		
Cooling in compliance with EN 60146	Forced air cod	oling AF	
Safety Integrated	See function n	nanual "Safety Integrated"	
	Overview	of the manuals (Page 581)	

# 11.6.3 Specific technical data, 200 V converters

Table 11-36 PM240-2, IP20, frame size A, 200 V ... 240 V 1 AC / 3 AC

Article No. without filter Article No. with filter	6SL3210-1PB13-0UL0 6SL3210-1PB13-0AL0	6SL3210-1PB13-8UL0 6SL3210-1PB13-8AL0	
LO base load power	0.55 kW	0.75 kW	
1 AC LO base load input current	7.5 A	9.6 A	
3 AC LO base load input current	4.2 A	5.5 A	
LO base load output current	3.2 A	4.2 A	
HO base load power	0.37 kW	0.55 kW	
1 AC HO base load input current	6.6 A	8.4 A	
3 AC HO base load input current	3.0 A	4.2 A	
HO base load output current	2.3 A	3.2 A	
Fuse according to IEC Fuse according to UL, class J	3NA3805 (16 A) 15 A	3NA3805 (16 A) 15 A	
Power loss	0.04 kW	0.04 kW	
Required cooling air flow	5 l/s	5 l/s	
Weight without filter	1.4 kg	1.4 kg	
Weight with filter	1.6 kg	1.6 kg	

Table 11-37 PM240-2, PT, frame size A, 200 V ... 240 V 1 AC / 3 AC

Article No. without filter Article No. with filter	6SL3211-1PB13-8UL0 6SL3211-1PB13-8AL0	
LO base load power	0.75 kW	
1 AC LO base load input current	9.6 A	
3 AC LO base load input current	5.5 A	'
LO base load output current	4.2 A	
HO base load power	0.55 kW	
1 AC HO base load input current	8.4 A	
3 AC HO base load input current	4.2 A	,
HO base load output current	3.2 A	'
Fuse according to IEC Fuse according to UL, class J	3NA3 805 (16 A) 15 A	
Power loss	0.04 kW	
Required cooling air flow	5 l/s	
Weight without filter	1.8 kg	
Weight with filter	2.0 kg	

Table 11-38 PM240-2, IP20, frame size B, 200 V ... 240 V 1 AC / 3 AC

Article No. without filter Article No. with filter	6SL3210-1PB15-5UL0 6SL3210-1PB15-5AL0	6SL3210-1PB17-4UL0 6SL3210-1PB17-4AL0	6SL3210-1PB21-0UL0 6SL3210-1PB21-0AL0
LO base load power	1.1 kW	1.5 kW	2.2 kW
1 AC LO base load input current	13.5 A	18.1 A	24.0 A
3 AC LO base load input current	7.8 A	9.7 A	13.6 A
LO base load output current	6 A	7.4 A	10.4 A
HO base load power	0.75 kW	1.1 kW	1.5 kW
1 AC HO base load input current	11.8 A	15.8 A	20.9 A
3 AC HO base load input current	5.5 A	7.8 A	9.7 A
HO base load output current	4.2 A	6 A	7.4 A
Fuse according to IEC Fuse according to UL, class J	3NA3812 (32 A) 35 A	3NA3812 (32 A) 35 A	3NA3812 (32 A) 35 A
Power loss	0.05 kW	0.07 kW	0.12 kW
Required cooling air flow	9.2 l/s	9.2 l/s	9.2 l/s
Weight without filter	2.8 kg	2.8 kg	2.8 kg
Weight with filter	3.1 kg	3.1 kg	3.1 kg

Table 11-39 PM240-2, PT, frame size B, 200 V ... 240 V 1 AC / 3 AC

Article No. without filter Article No. with filter	6SL3211-1PB21-0UL0 6SL3211-1PB21-0AL0	
LO base load power	2.2 kW	
1 AC LO base load input current	24.0 A	
3 AC LO base load input current	13.6 A	
LO base load output current	10.4 A	
HO base load power	1.5 kW	
1 AC HO base load input current	20.9 A	
3 AC HO base load input current	9.7 A	
HO base load output current	7.4 A	
Fuse according to IEC Fuse according to UL, class J	3NA3812 (32 A) 35 A	
Power loss	0.12 kW <sup>1)</sup>	
Required cooling air flow	9.2 l/s	
Weight without filter	3.4 kg	
Weight with filter	3.7 kg	

<sup>1)</sup> approx. 0.08 kW through the heat sink

Table 11-40 PM240-2, IP 20, frame size C, 200 V ... 240 V 1 AC / 3 AC

Article No. without filter Article No. with filter	6SL3210-1PB21-4UL0 6SL3210-1PB21-4AL0	6SL3210-1PB21-8UL0 6SL3210-1PB21-8AL0	
LO base load power	3 kW	4 kW	
1 AC LO base load input current	35.9 A	43.0 A	
3 AC LO base load input current	17.7 A	22.8 A	
LO base load output current	13.6 A	17.5 A	
HO base load power	2.2 kW	3 kW	
1 AC HO base load input current	31.3 A	37.5 A	
3 AC HO base load input current	13.6 A	17.7 A	
HO base load output current	10.4 A	13.6 A	
Fuse according to IEC Fuse according to UL, class J	3NA3820 (50 A) 50 A	3NA3820 (50 A) 50 A	
Power loss	0.14 kW	0.18 kW	
Required cooling air flow	18.5 l/s	18.5 l/s	
Weight without filter	5.0 kg	5.0 kg	
Weight with filter	5.2 kg	5.2 kg	

Table 11-41 PM240-2, PT, frame size C, 200 V ... 240 V 1 AC / 3 AC

Article No. without filter Article No. with filter	6SL3211-1PB21-8UL0 6SL3211-1PB21-8AL0	
LO base load power	4 kW	
1 AC LO base load input current	43.0 A	
3 AC LO base load input current	22.8 A	
LO base load output current	17.5 A	
HO base load power	3 kW	
1 AC HO base load input current	37.5 A	
3 AC HO base load input current	17.7 A	
HO base load output current	13.6 A	
Fuse according to IEC Fuse according to UL, class J	3NA3820 (50 A) 50 A	
Power loss	0.18 kW <sup>1)</sup>	
Required cooling air flow	18.5 l/s	
Weight without filter	5.9 kg	
Weight with filter	6.2 kg	

<sup>1)</sup> approx. 0.09 kW through the heat sink

Table 11-42 PM240-2, IP 20, frame size C, 200 V ... 240 V 3 AC

Article No. without filter Article No. with filter	6SL3210-1PC22-2UL0 6SL3210-1PC22-2AL0	6SL3210-1PC22-8UL0 6SL3210-1PC22-8AL0	
LO base load power	5.5 kW	7.5 kW	
LO base load input current	28.6 A	36.4 A	
LO base load output current	22.0 A	28.0 A	
HO base load power	4 kW	5.5 kW	
HO base load input current	22.8 A	28.6 A	
HO base load output current	17.5 A	22.0 A	
Fuse according to IEC Fuse according to UL, class J	3NA3820 (50 A) 50 A	3NA3820 (50 A) 50 A	
Power loss	0.2 kW	0.26 kW	
Required cooling air flow	18.5 l/s	18.5 l/s	
Weight without filter	5.0 kg	5.0 kg	
Weight with filter	5.2 kg	5.2 kg	

Table 11-43 PM240-2, PT, frame size C, 200 V ... 240 V 3 AC

Article No. without filter Article No. with filter	6SL3211-1PC22-2UL0 6SL3211-1PC22-2AL0	6SL3211-1PC22-8UL0 6SL3211-1PC22-8AL0	
LO base load power	5.5 kW	7.5 kW	_
LO base load input current	28.6 A	36.4 A	
LO base load output current	22.0 A	28.0 A	
HO base load power	4 kW	5.5 kW	
HO base load input current	22.8 A	28.6 A	
HO base load output current	17.5 A	22.0 A	
Fuse according to IEC Fuse according to UL, class J	3NA3820 (50 A) 50 A	3NA3820 (50 A) 50 A	
Power loss	0.2 kW <sup>1)</sup>	0.26 kW <sup>2)</sup>	
Required cooling air flow	18.5 l/s	18.5 l/s	
Weight without filter	5.9 kg	5.9 kg	
Weight with filter	6.2 kg	6.2 kg	

<sup>1)</sup> approx. 0.2 kW through the heatsink

Table 11-44 PM240-2, IP20, frame size D, 200 V ... 240 V 3 AC

Article No. without filter	6SL3210-1PC24-2UL0	6SL3210-1PC25-4UL0	6SL3210-1PC26-8UL0
LO base load power	11 kW	15 kW	18.5 kW
LO base load input current	40 A	51 A	64 A

<sup>&</sup>lt;sup>2)</sup> approx. 0.25 kW through the heatsink

Article No. without filter	6SL3210-1PC24-2UL0	6SL3210-1PC25-4UL0	6SL3210-1PC26-8UL0
LO base load output current	42 A	54 A	68 A
HO base load power	7.5 kW	11 kW	15 kW
HO base load input current	36 A	43 A	56 A
HO base load output current	35 A	42 A	54 A
Fuse according to IEC Fuse according to UL, class J	3NA3822 (63 A) 60 A	3NA3824 (80 A) 70 A	3NA3830 (100 A) 90 A
Power loss	0.45 kW	0.61 kW	0.82 kW
Required cooling air flow	55 l/s	55 l/s	55 l/s
Weight	18.3 kg	18.3 kg	18.3 kg

Table 11-45 PM240-2, PT, frame size D, 200 V ... 240 V 3 AC

Article No. without filter	6SL3211-1PC26-8UL0	
LO base load power	18.5 kW	
LO base load input current	64 A	
LO base load output current	68 A	
HO base load power	15 kW	
HO base load input current	56 A	
HO base load output current	54 A	
Fuse according to IEC Fuse according to UL, class J	3NA3830 (100 A) 90 A	
Power loss	0.82 kW <sup>1)</sup>	
Required cooling air flow	55 l/s	
Weight	19.5 kg	

<sup>1)</sup> approx. 0.72 kW through the heatsink

Table 11-46 PM240-2, IP20, frame size E, 200 V ... 240 V 3 AC

Article No. without filter	6SL3210-1PC28-0UL0	6SL3210-1PC31-1UL0	
LO base load power	22 kW	30 kW	
LO base load input current	76 A	98 A	
LO base load output current	80 A	104 A	
HO base load power	18.5 kW	22 kW	
HO base load input current	71 A	83 A	
IO base load output current	68 A	80 A	
use according to IEC use according to UL, class J	3NA3830 (100 A) 100 A	3NA3836 (160 A) 150 A	
Power loss	0.92 kW	1.28 kW	

Article No. without filter	6SL3210-1PC28-0UL0	6SL3210-1PC31-1UL0	
Required cooling air flow	83 l/s	83 l/s	
Weight	26.8 kg	26.8 kg	

Table 11-47 PM240-2, PT, frame size E, 200 V to 240 V 3 AC

Article No. without filter	6SL3211-1PC31-1UL0	
LO base load power	30 kW	
LO base load input current	98 A	
LO base load output current	104 A	
HO base load power	22 kW	
HO base load input current	83 A	
HO base load output current	80 A	
Fuse according to IEC Fuse according to UL, class J	3NA3836 (160 A) 150 A	
Power loss	1.28 kW <sup>1)</sup>	
Required cooling air flow	83 l/s	
Weight	29.5 kg	

<sup>1)</sup> approx. 1.1 kW through the heatsink

Table 11-48 PM240-2, IP20, frame size F, 200 V ... 240 V 3 AC

Article No. without filter	6SL3210-1PC31-3UL0	6SL3210-1PC31-6UL0	6SL3210-1PC31-8UL0
LO base load power	37 kW	45 kW	55 kW
LO base load input current	126 A	149 A	172 A
LO base load output current	130 A	154 A	178 A
HO base load power	30 kW	37 kW	45 kW
HO base load input current	110 A	138 A	164 A
HO base load output current	104 A	130 A	154 A
Fuse according to IEC Fuse according to UL, class J	3NA3140 (200 A) 175 A	3NA3140 (200 A) 200 A	3NA3142 (224 A) 250 A
Power loss	1.38 kW	1.72 kW	2.09 kW
Required cooling air flow	153 l/s	153 l/s	153 l/s
Weight	58 kg	58 kg	58 kg

Table 11-49 PM240-2, PT, frame size F, 200 V to 240 V 3 AC

Article No. without filter	6SL3211-1PC31-8UL0	
LO base load power	55 kW	'
LO base load input current	172 A	
LO base load output current	178 A	
HO base load power	45 kW	
HO base load input current	164 A	
HO base load output current	154 A	,
Fuse according to IEC Fuse according to UL, class J	3NA3142 (224 A) 250 A	
Power loss	2.09 kW <sup>1)</sup>	
Required cooling air flow	153 l/s	
Weight	60.5 kg	

<sup>1)</sup> approx. 1.9 kW through the heatsink

## 11.6.4 Current derating depending on the pulse frequency, 200 V converters

#### LO base load

Article number	LO			Pu	lse frequ	iency [k	Hz]		
	power	2	4 *)	6	8	10	12	14	16
	[kW]			LO base	load ou	tput cur	rent [A]		
6SL3210-1PB13-0 . L0	0.55	3.2	3.2	2.7	2.2	1.9	1.6	1.4	1.3
6SL3211PB13-8 . LO	0.75	4.2	4.2	3.6	2.9	2.5	2.1	1.9	1.7
6SL3210-1PB15-5 . L0	1.1	6	6	5.1	4.2	3.6	3	2.7	2.4
6SL3210-1PB17-4 . LO	1.5	7.4	7.4	6.3	5.2	4.4	3.7	3.3	3
6SL3211PB21-0 . LO	2.2	10.4	10.4	8.8	7.3	6.2	5.2	4.7	4.2
6SL3210-1PB21-4 . L0	3	13.6	13.6	11.6	9.5	8.2	6.8	6.1	5.4
6SL3211PB21-8 . LO	4	17.5	17.5	14.9	12.3	10.5	8.8	7.9	7
6SL3210-1PC22-2 . L0	5.5	22	22	18.7	15.4	13.2	11	9.9	8.8
6SL3210-1PC22-8 . L0	7.5	28	28	23.8	19.6	16.8	14	12.6	11.2
6SL3210-1PC24-2UL0	11	42	42	35.7	29.4	25.2	21	18.9	16.8
6SL3210-1PC25-4UL0	15	54	54	45.9	37.8	32.4	27	24.3	21.6
6SL3211PC26-8UL0	18.5	68	68	57.8	47.6	40.8	34	30.6	27.2
6SL3210-1PC28-0UL0	22	80	80	68	56	48	40	36	32
6SL3211PC31-1UL0	30	104	104	88.4	72.8	62.4	52	46.8	41.6
6SL3210-1PC31-3UL0	37	130	130	110.5	91				
6SL3210-1PC31-6UL0	45	154	154	130.9	107.8				
6SL3211PC31-8UL0	55	178	178	151.3	124.6				

<sup>\*)</sup> Factory setting

The permissible motor cable length depends on the particular cable type and the pulse frequency that has been selected.

## 11.6.5 General technical data, 400 V converters

Property	Version		
Line voltage	FSA FSC	380 V 480 V 3 AC ± 10%	
	FSD FSG	380 V (-20 %) 480 V 3 AC + 10%	
Line supply configurations		TT line supplies or non-grounded IT line supplies ting the line supply and motor (Page 90)	
Line impedance	FSA FSC	$1\% \le Uk < 4\%$ , for values smaller than 1%, we recommend a line reactor, or a Power Module with the next higher power rating.	
	FSD FSG	No restrictions	
Power factor λ	FSA FSC	0.7 without line reactor for $Uk \ge 1\%$ 0.85 with line reactor for $Uk < 1\%$	
	FSD FSG	> 0.9	
Output voltage	0 V 3 AC 0.9	95 x input voltage (max.)	
Input frequency	50 Hz 60 Hz	z, ± 3 Hz	
Output frequency	0 550 Hz, d	epending on the control mode	
Inrush current	< LO base load	input current	
Overvoltage category according to EN 61800-5-1	III for line supp	plies	
Pulse frequency	Factory setting	I	
	<ul> <li>4 kHz for devices with an LO base load power &lt; 110 kW</li> </ul>		
	• 2 kHz for d	evices with an LO base load power ≥ 110 kW	
	Can be adjuste	ed in 2 kHz steps as follows:	
	<ul> <li>2 kHz 16 kHz for devices with an LO base load power &lt; 55 kW</li> </ul>		
	• 2 kHz 8	kHz for devices with an LO base load output of 55 kW 250 kW	
	If you increase the pulse frequency, the converter reduces the maximum output current.		
	Current	reduction as a function of the pulse frequency (Page 549)	
Short-circuit current (SCCR)		missible line short-circuit current ≤ 100 kA rms	
and branch protection		rotection and short-circuit strength according to UL and IEC ( <a href="https://cry.siemens.com/cs/ww/en/view/109782705">https://cry.siemens.com/cs/ww/en/view/109782705</a> )	
Braking methods	DC braking, co	mpound braking, dynamic braking with integrated braking chopper	
Degree of protection accord-	IP20		
ing to EN 60529	IP55 PT devi	tes outside the control cabinet	
Protection class according to EN 61800-5-1	The converters are devices with protection class I		
Touch protection according to EN 50274	DGUV regulati	on 3 when used for the intended purpose	
Cooling in compliance with EN 60146	Forced air coc	ling AF	
Safety Integrated		nanual "Safety Integrated"	
	Overview	of the manuals (Page 581)	

## 11.6.6 Specific technical data, 400 V converters

Table 11-50 PM240-2, IP20, frame size A, 380 V ... 480 V 3 AC

Article No. without filter Article No. with filter	6SL3210-1PE11-8UL1 6SL3210-1PE11-8AL1	6SL3210-1PE12-3UL1 6SL3210-1PE12-3AL1	6SL3210-1PE13-2UL1 6SL3210-1PE13-2AL1
LO base load power	0.55 kW	0.75 kW	1.1 kW
LO base load input current	2.3 A	2.9 A	4.1 A
LO base load output current	1.7 A	2.2 A	3.1 A
HO base load power	0.37 kW	0.55 kW	0.75 kW
HO base load input current	2.0 A	2.6 A	3.3 A
HO base load output current	1.3 A	1.7 A	2.2 A
Fuse according to IEC Fuse according to UL, class J	3NA3803 (10 A) 10 A	3NA3803 (10 A) 10 A	3NA3805 (16 A) 15 A
Power loss	0.04 kW	0.04 kW	0.04 kW
Required cooling air flow	5 l/s	5 l/s	5 l/s
Weight without filter	1.3 kg	1.3 kg	1.3 kg
Weight with filter	1.5 kg	1.5 kg	1.5 kg

Table 11-51 PM240-2, IP20, frame size A, 380 V ... 480 V 3 AC

Article No. without filter Article No. with filter	6SL3210-1PE14-3UL1 6SL3210-1PE14-3AL1	6SL3210-1PE16-1UL1 6SL3210-1PE16-1AL1	6SL3210-1PE18-0UL1 6SL3210-1PE18-0AL1
LO base load power	1.5 kW	2.2 kW	3.0 kW
LO base load input current	5.5 A	7.7 A	10.1 A
LO base load output current	4.1 A	5.9 A	7.7 A
HO base load power	1.1 kW	1.5 kW	2.2 kW
HO base load input current	4.7 A	6.1 A	8.8 A
HO base load output current	3.1 A	4.1 A	5.9 A
Fuse according to IEC Fuse according to UL, class J	3NA3805 (16 A) 15 A	3NA3805 (16 A) 15 A	3NA3805 (16 A) 15 A
Power loss	0.07 kW	0.1 kW	0.12 kW
Required cooling air flow	5 l/s	5 l/s	5 l/s
Weight without filter	1.4 kg	1.4 kg	1.4 kg
Weight with filter	1.6 kg	1.6 kg	1.6 kg

Table 11-52 PM240-2, PT, frame size A, 380 V ... 480 V 3 AC

Article No. without filter Article No. with filter	6SL3211-1PE18-0UL1 6SL3211-1PE18-0AL1	
LO base load power	3.0 kW	
LO base load input current	10.1 A	
LO base load output current	7.7 A	
HO base load power	2.2 kW	
HO base load input current	8.8 A	
HO base load output current	5.9 A	
Fuse according to IEC Fuse according to UL, class J	3NA3805 (16 A) 15 A	
Power loss without filter	0.12 kW <sup>1)</sup>	
Required cooling air flow	7 l/s	
Weight without filter	1.8 kg	
Weight with filter	2.0 kg	

<sup>1)</sup> approx. 0.1 kW through the heatsink

Table 11-53 PM240-2, IP20, frame size B, 380 V ... 480 V 3 AC

Article No. without filter Article No. with filter	6SL3210-1PE21-1UL0 6SL3210-1PE21-1AL0	6SL3210-1PE21-4UL0 6SL3210-1PE21-4AL0	6SL3210-1PE21-8UL0 6SL3210-1PE21-8AL0
LO base load power	4.0 kW	5.5 kW	7.5 kW
LO base load input current	13.3 A	17.2 A	22.2 A
LO base load output current	10.2 A	13.2 A	18.0 A
HO base load power	3.0 kW	4.0 kW	5.5 kW
HO base load input current	11.6 A	15.3 A	19.8 A
HO base load output current	7.7 A	10.2 A	13.2 A
Fuse according to IEC Fuse according to UL, class J	3NA3812 (32 A) 35 A	3NA3812 (32 A) 35 A	3NA3812 (32 A) 35 A
Power loss	0.11 kW	0.15 kW	0.2 kW
Required cooling air flow	9.2 l/s	9.2 l/s	9.2 l/s
Weight without filter	2.9 kg	2.9 kg	3.0 kg
Weight with filter	3.1 kg	3.1 kg	3.2 kg

Table 11-54 PM240-2, PT, frame size B, 380 V ... 480 V 3 AC

Article No. without filter Article No. with filter	6SL3211-1PE21-8UL0 6SL3211-1PE21-8AL0	
LO base load power	7.5 kW	
LO base load input current	22.2 A	
LO base load output current	18.0 A	

Article No. without filter Article No. with filter	6SL3211-1PE21-8UL0 6SL3211-1PE21-8AL0	
HO base load power	5.5 kW	
HO base load input current	19.8 A	
HO base load output current	13.7 A	
Fuse according to IEC Fuse according to UL, class J	3NA3812 (32 A) 35 A	
Power loss	0.2 kW <sup>1)</sup>	
Required cooling air flow	9.2 l/s	
Weight without filter	3.6 kg	
Weight with filter	3.9 kg	

<sup>1)</sup> approx. 0.16 kW through the heatsink

Table 11-55 PM240-2, IP20, frame size C, 380 V ... 480 V 3 AC

Article No. without filter Article No. with filter	6SL3210-1PE22-7UL0 6SL3210-1PE22-7AL0	6SL3210-1PE23-3UL0 6SL3210-1PE23-3AL0	
LO base load power	11.0 kW	15.0 kW	
LO base load input current	32.6 A	39.9 A	
LO base load output current	26.0 A	32.0 A	
HO base load power	7.5 kW	11.0 kW	
HO base load input current	27.0 A	36.0 A	
HO base load output current	18.0 A	26.0 A	
Fuse according to IEC Fuse according to UL, class J	3NA3820 (50 A) 50 A	3NA3820 (50 A) 50 A	
Power loss	0.3 kW	0.37 kW	
Required cooling air flow	18.5 l/s	18.5 l/s	
Weight without filter	4.7 kg	4.8 kg	
Weight with filter	5.3 kg	5.4 kg	

Table 11-56 PM240-2, PT, frame size C, 380 V ... 480 V 3 AC

Article No. without filter Article No. with filter	6SL3211-1PE23-3UL0 6SL3211-1PE23-3AL0	
LO base load power	15.0 kW	
LO base load input current	39.9 A	
LO base load output current	32.0 A	
HO base load power	11.0 kW	
HO base load input current	36.0 A	
HO base load output current	26.0 A	

Article No. without filter Article No. with filter	6SL3211-1PE23-3UL0 6SL3211-1PE23-3AL0
Fuse according to IEC Fuse according to UL, class J	3NA3820 (50 A) 50 A
Power loss	0.37 kW <sup>1)</sup>
Required cooling air flow	18.5 l/s
Weight without filter	5.8 kg
Weight with filter	6.3 kg

<sup>1)</sup> approx. 0.3 kW through the heatsink

Table 11-57 PM240-2, IP20, frame size D, 380 V ... 480 V 3 AC

Article No. without filter Article No. with filter	6SL3210-1PE23-8UL0 6SL3210-1PE23-8AL0	6SL3210-1PE24-5UL0 6SL3210-1PE24-5AL0	6SL3210-1PE26-0UL0 6SL3210-1PE26-0AL0
LO base load power	18.5 kW	22 kW	30 kW
LO base load input current	36 A	42 A	57 A
LO base load output current	38 A	45 A	60 A
HO base load power	15 kW	18.5 kW	22 kW
HO base load input current	33 A	38 A	47 A
HO base load output current	32 A	38 A	45 A
Fuse according to IEC Fuse according to UL, class J	3NA3822 (63 A) 60 A	3NA3824 (80 A) 70 A	3NA3830 (100 A) 90 A
Power loss without filter	0.57 kW	0.70 kW	0.82 kW
Power loss with filter	0.58 kW	0.71 kW	0.83 kW
Required cooling air flow	55 l/s	55 l/s	55 l/s
Weight without filter	16.6 kg	16.6 kg	18.3 kg
Weight with filter	18.3 kg	18.3 kg	19 kg

Table 11-58 PM240-2, IP20, frame size D, 380 V ... 480 V 3 AC

Article No. without filter Article No. with filter	6SL3210-1PE27-5UL0 6SL3210-1PE27-5AL0	
LO base load power	37 kW	
LO base load input current	70 A	
LO base load output current	75 A	
HO base load power	30 kW	
HO base load input current	62 A	
HO base load output current	60 A	
Fuse according to IEC Fuse according to UL, class J	3NA3830 (100 A) 100 A	
Power loss without filter	1.09 kW	

Article No. without filter Article No. with filter	6SL3210-1PE27-5UL0 6SL3210-1PE27-5AL0	
Power loss with filter	1.10 kW	
Required cooling air flow	55 l/s	
Weight without filter	18.3 kg	
Weight with filter	19 kg	

Table 11-59 PM240-2, PT, frame size D, 380 V ... 480 V 3 AC

Article No. without filter Article No. with filter	6SL3211-1PE27-5UL0 6SL3211-1PE27-5AL0	
LO base load power	37 kW	
LO base load input current	70 A	
LO base load output current	75 A	
HO base load power	30 kW	
HO base load input current	62 A	
HO base load output current	60 A	
Fuse according to IEC Fuse according to UL, class J	3NA3830 (100 A) 100 A	
Power loss without filter	1.09 kW <sup>1)</sup>	
Power loss with filter	1.10 kW <sup>1)</sup>	
Required cooling air flow	55 l/s	
Weight without filter	20 kg	
Weight with filter	22 kg	

<sup>1)</sup> Approx. 1 kW through the heatsink

Table 11-60 PM240-2, IP20, frame size E, 380 V ... 480 V 3 AC

Article No. without filter Article No. with filter	6SL3210-1PE28-8UL0 6SL3210-1PE28-8AL0	6SL3210-1PE31-1UL0 6SL3210-1PE31-1AL0	
LO base load power	45 kW	55 kW	
LO base load input current	86 A	104 A	
LO base load output current	90 A	110 A	
HO base load power	37 kW	45 kW	
HO base load input current	78 A	94 A	
HO base load output current	75 A	90 A	
Fuse according to IEC Fuse according to UL, class J	3NA3832 (125 A) 125 A	3NA3836 (160 A) 150 A	
Power loss without filter	1.29 kW	1.65 kW	
Power loss with filter	1.30 kW	1.67 kW	
Required cooling air flow	83 l/s	83 l/s	

Article No. without filter Article No. with filter	6SL3210-1PE28-8UL0 6SL3210-1PE28-8AL0	6SL3210-1PE31-1UL0 6SL3210-1PE31-1AL0	
Weight without filter	26.4 kg	26.4 kg	
Weight with filter	28.4 kg	28.4 kg	

Table 11-61 PM240-2, PT, frame size E, 380 V ... 480 V 3 AC

Article No. without filter Article No. with filter	6SL3211-1PE31-1UL0 6SL3211-1PE31-1AL0	
LO base load power	55 kW	'
LO base load input current	104 A	
LO base load output current	110 A	
HO base load power	45 kW	
HO base load input current	94 A	
HO base load output current	90 A	
Fuse according to IEC Fuse according to UL, class J	3NA3836 (160 A) 150 A	
Power loss without filter	1.65 kW <sup>1)</sup>	
Power loss with filter	1.67 kW <sup>1)</sup>	
Required cooling air flow	83 l/s	
Weight without filter	30.5 kg	
Weight with filter	32 kg	

<sup>1)</sup> Approx. 1.4 kW through the heatsink

Table 11-62 PM240-2, IP20, frame size F, 380 V ... 480 V 3 AC

Article No. without filter Article No. with filter	6SL3210-1PE31-5UL0 6SL3210-1PE31-5AL0	6SL3210-1PE31-8UL0 6SL3210-1PE31-8AL0	6SL3210-1PE32-1UL0 6SL3210-1PE32-1AL0
LO base load power	75 kW	90 kW	110 kW
LO base load input current	140 A	172 A	198 A
LO base load output current	145 A	178 A	205 A
HO base load power	55 kW	75 kW	90 kW
HO base load input current	117 A	154 A	189 A
HO base load output current	110 A	145 A	178 A
Fuse according to IEC Fuse according to UL, class J	3NA3140 (200 A) 200 A	3NA3142 (224 A) 250 A	3NA3250 (300 A) 300 A
Power loss without filter	1.91 kW	2.46 kW	2.28 kW
Power loss with filter	1.93 kW	2.48 kW	2.30 kW
Required cooling air flow	153 l/s	153 l/s	153 l/s

Article No. without filter Article No. with filter	6SL3210-1PE31-5UL0 6SL3210-1PE31-5AL0	6SL3210-1PE31-8UL0 6SL3210-1PE31-8AL0	6SL3210-1PE32-1UL0 6SL3210-1PE32-1AL0
Weight without filter	58 kg	58 kg	62 kg
Weight with filter	64 kg	64 kg	66 kg

Table 11-63 PM240-2, IP20, frame size F, 380 V ... 480 V 3 AC

Article No. without filter Article No. with filter	6SL3210-1PE32-5UL0 6SL3210-1PE32-5AL0	
LO base load power	132 kW	
LO base load input current	242 A	
LO base load output current	250 A	
HO base load power	110 kW	
HO base load input current	218 A	
HO base load output current	205 A	
Fuse according to IEC Fuse according to UL, class J	3NA3252 (315 A) 350 A	
Power loss without filter	2.98 kW	
Power loss with filter	3.02 kW	
Required cooling air flow	153 l/s	
Weight without filter	62 kg	
Weight with filter	66 kg	

Table 11-64 PM240-2, PT, frame size F, 380 V ... 480 V 3 AC

Article No. without filter Article No. with filter	6SL3211-1PE32-5UL0 6SL3211-1PE32-5AL0	
LO base load power	132 kW	
LO base load input current	242 A	
LO base load output current	250 A	
HO base load power	110 kW	
HO base load input current	218 A	
HO base load output current	205 A	
Fuse according to IEC Fuse according to UL, class J	3NA3252 (315 A) 350 A	
Power loss without filter	2.98 kW <sup>1)</sup>	
Power loss with filter	3.02 kW <sup>1)</sup>	
Required cooling air flow	153 l/s	

Article No. without filter Article No. with filter	6SL3211-1PE32-5UL0 6SL3211-1PE32-5AL0	
Weight without filter	63.5 kg	
Weight with filter	68.5 kg	

<sup>1)</sup> Approx. 2.6 kW through the heatsink

Table 11-65 PM240-2, frame size G, 380 V ... 480 V 3 AC

Article No. with filter class C3 Article No. with filter class C2	6SL3210-1PE33-0CL0 6SL3210-1PE33-0AL0	6SL3210-1PE33-7CL0 6SL3210-1PE33-7AL0	6SL3210-1PE34-8CL0 6SL3210-1PE34-8AL0
LO base load power	160 kW	200 kW	250 kW
LO base load input current	300 A	365 A	470 A
LO base load output current	302 A	370 A	477 A
HO base load power	132 kW	160 kW	200 kW
HO base load input current	275 A	330 A	400 A
HO base load output current	250 A	302 A	370 A
Fuse according to IEC Fuse according to UL, class J Fuse according to IEC/UL	3NA3254 (355 A) 400 A 3NE1334-2 (500A)	3NA3260 (400 A) 500 A 3NE1334-2 (500A)	3NA3372 (630 A) 600 A 3NE1436-2 (630A)
Power loss with filter class C3 Power loss with filter class C2	3.67 kW 3.67 kW	4.62 kW 4.62 kW	6.18 kW 6.18 kW
Required cooling air flow	210 l/s	210 l/s	210 l/s
Weight with filter class C3 Weight with filter class C2	105 kg 107 kg	113 kg 114 kg	120 kg 122 kg

## 11.6.7 Current derating depending on the pulse frequency, 400 V converters

#### LO base load

Article number	LO			Pul	lse frequ	ency [k	Hz]		
	power	2	4 *)	6	8	10	12	14	16
	[kW]		•	LO base	load ou	tput cur	rent [A]	•	
6SL3210-1PE11-8 . L1	0.55	1.7	1.7	1.4	1.2	1	0.9	0.8	0.7
6SL3210-1PE12-3 . L1	0.75	2.2	2.2	1.9	1.5	1.3	1.1	1	0.9
6SL3210-1PE13-2 . L1	1.1	3.1	3.1	2.6	2.2	1.9	1.6	1.4	1.2
6SL3210-1PE14-3 . L1	1.5	4.1	4.1	3.5	2.9	2.5	2.1	1.8	1.6
6SL3210-1PE16-1 . L1	2.2	5.9	5.9	5	4.1	3.5	3	2.7	2.4
6SL3211PE18-0 . L1	3	7.7	7.7	6.5	5.4	4.6	3.9	3.5	3.1
6SL3210-1PE21-1 . L0	4	10.2	10.2	8.7	7.1	6.1	5.1	4.6	4.1
6SL3210-1PE21-4 . L0	5.5	13.2	13.2	11.2	9.2	7.9	6.6	5.9	5.3
6SL3211PE21-8 . LO	7.5	18	18	15.3	12.6	10.8	9	8.1	7.2
6SL3210-1PE22-7 . L0	11	26	26	22.1	18.2	15.6	13	11.7	10.4
6SL3211PE23-3 . L0	15	32	32	27.2	22.4	19.2	16	14.4	12.8
6SL3210-1PE23-8 . L0	18.5	38	38	32.3	26.6	22.8	19	17.1	15.2
6SL3210-1PE24-5 . L0	22	45	45	38.3	31.5	27	22.5	20.3	18
6SL3210-1PE26-0 . L0	30	60	60	51	42	36	30	27	24
6SL3211PE27-5 . L0	37	75	75	63.8	52.5	45	37.5	33.8	30
6SL3210-1PE28-8 . L0	45	90	90	76.5	63	54	45	40.5	36
6SL3211PE31-1 . L0	55	110	110	93.5	77				
6SL3210-1PE31-5 . L0	75	145	145	123.3	101.5				
6SL3210-1PE31-8 . L0	90	178	178	151.3	124.6				
Article number			_		lse frequ	ency [k	Hz]		
		2 *)	4	6 **)	8 **)	10	12	14	16
		LO base load output current [A]							
6SL3210-1PE32-1 . L0	110	205	143.5	102.5	82				
6SL3211PE32-5 . L0	132	250	175	125	100				
6SL3210-1PE33-0 .L0	160	302	211.4	151	120.8				
6SL3210-1PE33-7 .L0	200	370	259	185	148				
6SL3210-1PE34-8 .L0	250	477	333.9	238.5	190.8				

<sup>\*)</sup> Factory setting

The permissible motor cable length depends on the particular cable type and the pulse frequency that has been selected.

<sup>\*\*)</sup> Available from Functional State (FS) 12

# 11.6.8 General technical data, 690 V converters

Line voltage  • for systems according to IEC: 500 V 690 V 3 AC ± 10% (in operation -20% < 1 min)  • for systems according to UL 500 V 600 V 3 AC ± 10% (in operation -20% < 1 min) filtered devices only with Slash Rating (600Y/347V AC)  Line supply configurations  Connecting the line supplies or non-grounded IT line supplies rations  No restrictions  Power factor λ > 0.9  Output voltage 0 V 3 AC 0.95 x input voltage (max.)  Input frequency 50 Hz 60 Hz, ± 3 Hz  Output frequency 0 550 Hz, depending on the control mode  Inrush current < LO base load input current  Overvoltage category according to EN 61800-5-1  Pulse frequency 2 kHz (factory setting), can be adjusted to 4 kHz  Adjustable in steps of 2 kHz.  Current reduction as a function of the pulse frequency (Page 554) If you increase the pulse frequency, the converter reduces the maximum output current.  Short-circuit current  Maximum permissible line short-circuit current ≤ 100 kA rms	Property	Version
<ul> <li>&lt; 1 min)         filtered devices only with Slash Rating (600Y/347V AC)</li> <li>Line supply configurations</li> <li>Connecting the line supplies or non-grounded IT line supplies         Connecting the line supply and motor (Page 90)</li> <li>Line impedance</li> <li>No restrictions</li> <li>Power factor λ &gt; 0.9</li> <li>Output voltage</li> <li>O V 3 AC 0.95 x input voltage (max.)</li> <li>Input frequency</li> <li>Output frequency</li> <li>Output frequency</li> <li>0 550 Hz, depending on the control mode</li> <li>Inrush current</li> <li>&lt; LO base load input current</li> <li>Overvoltage category according to EN 61800-5-1</li> <li>Pulse frequency</li> <li>2 kHz (factory setting), can be adjusted to 4 kHz</li> <li>Adjustable in steps of 2 kHz.</li> <li>Current reduction as a function of the pulse frequency (Page 554)</li> <li>If you increase the pulse frequency, the converter reduces the maximum output current.</li> <li>Short-circuit current</li> <li>Maximum permissible line short-circuit current ≤ 100 kA rms</li> </ul>		
rationsConnecting the line supply and motor (Page 90)Line impedanceNo restrictionsPower factor λ> 0.9Output voltage0 V 3 AC 0.95 x input voltage (max.)Input frequency50 Hz 60 Hz, ± 3 HzOutput frequency0 550 Hz, depending on the control modeInrush current< LO base load input current		< 1 min)
Power factor λ       > 0.9         Output voltage       0 V 3 AC 0.95 x input voltage (max.)         Input frequency       50 Hz 60 Hz, ± 3 Hz         Output frequency       0 550 Hz, depending on the control mode         Inrush current       < LO base load input current		
Output voltage       0 V 3 AC 0.95 x input voltage (max.)         Input frequency       50 Hz 60 Hz, ± 3 Hz         Output frequency       0 550 Hz, depending on the control mode         Inrush current       < LO base load input current	Line impedance	No restrictions
Input frequency 50 Hz 60 Hz, ± 3 Hz  Output frequency 0 550 Hz, depending on the control mode  Inrush current < LO base load input current  Overvoltage category according to EN 61800-5-1  Pulse frequency 2 kHz (factory setting), can be adjusted to 4 kHz  Adjustable in steps of 2 kHz.  Current reduction as a function of the pulse frequency (Page 554)  If you increase the pulse frequency, the converter reduces the maximum output current.  Short-circuit current Maximum permissible line short-circuit current ≤ 100 kA rms	Power factor λ	> 0.9
Output frequency 0 550 Hz, depending on the control mode  Inrush current < LO base load input current  Overvoltage category according to EN 61800-5-1  Pulse frequency 2 kHz (factory setting), can be adjusted to 4 kHz  Adjustable in steps of 2 kHz.  Current reduction as a function of the pulse frequency (Page 554)  If you increase the pulse frequency, the converter reduces the maximum output current.  Short-circuit current Maximum permissible line short-circuit current ≤ 100 kA rms	Output voltage	0 V 3 AC 0.95 x input voltage (max.)
Inrush current  Overvoltage category according to EN 61800-5-1  Pulse frequency  2 kHz (factory setting), can be adjusted to 4 kHz  Adjustable in steps of 2 kHz.  Current reduction as a function of the pulse frequency (Page 554)  If you increase the pulse frequency, the converter reduces the maximum output current.  Short-circuit current  Maximum permissible line short-circuit current ≤ 100 kA rms	Input frequency	50 Hz 60 Hz, ± 3 Hz
Overvoltage category according to EN 61800-5-1  Pulse frequency  2 kHz (factory setting), can be adjusted to 4 kHz  Adjustable in steps of 2 kHz.  Current reduction as a function of the pulse frequency (Page 554)  If you increase the pulse frequency, the converter reduces the maximum output current.  Short-circuit current  Maximum permissible line short-circuit current ≤ 100 kA rms	Output frequency	0 550 Hz, depending on the control mode
ry according to EN 61800-5-1  Pulse frequency  2 kHz (factory setting), can be adjusted to 4 kHz  Adjustable in steps of 2 kHz.  Current reduction as a function of the pulse frequency (Page 554)  If you increase the pulse frequency, the converter reduces the maximum output current.  Short-circuit current  Maximum permissible line short-circuit current ≤ 100 kA rms	Inrush current	< LO base load input current
Adjustable in steps of 2 kHz.  Current reduction as a function of the pulse frequency (Page 554)  If you increase the pulse frequency, the converter reduces the maximum output current.  Short-circuit current  Maximum permissible line short-circuit current ≤ 100 kA rms	ry according to EN	III for line supplies
Current reduction as a function of the pulse frequency (Page 554)  If you increase the pulse frequency, the converter reduces the maximum output current.  Short-circuit current Maximum permissible line short-circuit current ≤ 100 kA rms	Pulse frequency	2 kHz (factory setting), can be adjusted to 4 kHz
output current.  Short-circuit current  Maximum permissible line short-circuit current ≤ 100 kA rms		
· ·		
		Maximum permissible line short-circuit current ≤ 100 kA rms
(SCCR) and branch protection and short-circuit strength according to UL and IEC ( <a href="https://support.industry.siemens.com/cs/ww/en/view/109782705">https://support.industry.siemens.com/cs/ww/en/view/109782705</a> )		
Braking methods DC braking, compound braking, dynamic braking with integrated braking chopper	Braking methods	
Degree of protection IP20; must be installed in a control cabinet according to EN 60529	according to EN	IP20; must be installed in a control cabinet
Protection class ac- cording to EN 61800-5-1  The converters are devices with protection class I	cording to EN	The converters are devices with protection class I
Touch protection ac- cording to EN 50274 DGUV regulation 3 when used for the intended purpose	•	DGUV regulation 3 when used for the intended purpose
Cooling in compliance with EN 60146  Forced air cooling AF		Forced air cooling AF
Safety Integrated See function manual "Safety Integrated"	Safety Integrated	See function manual "Safety Integrated"
Overview of the manuals (Page 581)		Overview of the manuals (Page 581)

## 11.6.9 Specific technical data, 690 V converters

Table 11-66 PM240-2, IP20, frame size D, 500 V ... 690 V 3 AC

Article No without filter Article No with filter	6SL3210-1PH21-4UL0 6SL3210-1PH21-4AL0	6SL3210-1PH22-0UL0 6SL3210-1PH22 -0AL0	6SL3210-1PH22-3UL0 6SL3210-1PH22 -3AL0
LO base load power	11 kW	15 kW	18.5 kW
LO base load input current	14 A	18 A	22 A
LO base load output current	14 A	19 A	23 A
HO base load power	7.5 kW	11 kW	15 kW
HO base load input current	11 A	14 A	20 A
HO base load output current	11 A	14 A	19 A
Fuse according to IEC Fuse according to UL, class J	3NA3807-6 (20 A) 20 A	3NA3810-6 (25 A) 25 A	3NA3812-6 (32 A) 30 A
Power loss without filter	0.35 kW	0.44 kW	0.52 kW
Power loss with filter	0.35 kW	0.45 kW	0.52 kW
Required cooling air flow	55 l/s	55 l/s	55 l/s
Weight without filter	17.4 kg	17.4 kg	17.4 kg
Weight with filter	18.9 kg	18.9 kg	18.9 kg

Table 11-67 PM240-2, IP20, frame size D, 500 V ... 690 V 3 AC

Article No without filter Article No with filter	6SL3210-1PH22-7UL0 6SL3210-1PH22-7AL0	6SL3210-1PH23-5UL0 6SL3210-1PH23 -5AL0	6SL3210-1PH24-2UL0 6SL3210-1PH24-2AL0
LO base load power	22 kW	30 kW	37 kW
LO base load input current	25 A	33 A	40 A
LO base load output current	27 A	35 A	42 A
HO base load power	18.5 kW	22 kW	30 kW
HO base load input current	24 A	28 A	36 A
HO base load output current	23 A	27 A	35 A
Siemens fuse according to IEC Fuse according to UL, class J	3NA3817-6KJ (40 A) 35 A	3NA3820-6KJ (50 A) 45 A	33NA3822-6 (63 A) 60 A
Power loss without filter	0.60 kW	0.77 kW	0.93 kW
Power loss with filter	0.60 kW	0.78 kW	0.94 kW
Required cooling air flow	55 l/s	55 l/s	55 l/s
Weight without filter	17.4 kg	17.4 kg	17.4 kg
Weight with filter	18.9 kg	18.9 kg	18.9 kg

Table 11-68 PM240-2, IP20, frame size E, 500 V ... 690 V 3 AC

Article No without filter Article No with filter	6SL3210-1PH25-2UL0 6SL3210-1PH25-2AL0	6SL3210-1PH26-2UL0 6SL3210-1PH26-2AL0	
LO base load power	45 kW	55 kW	
LO base load input current	50 A	59 A	
LO base load output current	52 A	62 A	
HO base load power	37 kW	45 kW	
HO base load input current	44 A	54 A	
HO base load output current	42 A	52 A	
Siemens fuse according to IEC Fuse according to UL, class J	3NA3824-6 (80A) 80 A	3NA3824-6 (80A) 80 A	
Power loss without filter	1.07 kW	1.30 kW	
Power loss with filter	1.08 kW	1.31 kW	
Required cooling air flow	83 l/s	83 l/s	
Weight without filter	27.1 kg	27.1 kg	
Weight with filter	28.5 kg	28.5 kg	

Table 11-69 PM240-2, IP20, frame size F, 500 V ... 690 V 3 AC

Article No without filter Article No with filter	6SL3210-1PH28-0UL0 6SL3210-1PH28-0AL0	6SL3210-1PH31-0UL0 6SL3210-1PH31-0AL0	6SL3210-1PH31-2UL0 6SL3210-1PH31-2AL0
LO base load power	75 kW	90 kW	110 kW
LO base load input current	78 A	97 A	111 A
LO base load output current	80 A	100 A	115 A
HO base load power	55 kW	75 kW	90 kW
HO base load input current	66 A	85 A	106 A
HO base load output current	62 A	80 A	100 A
Siemens fuse according to IEC Fuse according to UL, class J	3NA3830-6 (100 A) 100 A	3NA3132-6 (125 A) 125 A	3NA3136-6 (160 A) 150 A
Power loss without filter	1.37 kW	1.74 kW	1.95 kW
Power loss with filter	1.38 kW	1.76 kW	1.97 kW
Required cooling air flow	153 l/s	153 l/s	153 l/s
Weight without filter	61 kg	61 kg	61 kg
Weight with filter	65 kg	65 kg	65 kg

Table 11-70 PM240-2, IP20, frame size F, 500 V ... 690 V 3 AC

Article No without filter Article No with filter	6SL3210-1PH31-4UL0 6SL3210-1PH31-4AL0	
LO base load power	132 kW	
LO base load input current	137 A	

Article No without filter Article No with filter	6SL3210-1PH31-4UL0 6SL3210-1PH31-4AL0	
LO base load output current	142 A	
HO base load power	110 kW	
HO base load input current	122 A	'
HO base load output current	115 A	
Siemens fuse according to IEC Fuse according to UL, class J	3NA3140-6 (200 A) 200 A	
Power loss without filter	2.48 kW	
Power loss with filter	2.51 kW	
Required cooling air flow	153 l/s	
Weight without filter	61 kg	
Weight with filter	65 kg	

Table 11-71 PM240-2, frame size G, 500 V ... 690 V 3 AC

Article No. with filter	6SL3210-1PH31-7CL0	6SL3210-1PH32-1CL0	6SL3210-1PH32-5CL0
LO base load power	160 kW	200 kW	250 kW
LO base load input current	170 A	205 A	250 A
LO base load output current	171 A	208 A	250 A
HO base load power	132 kW	160 kW	200 kW
HO base load input current	160 A	185 A	225 A
HO base load output current	144 A	171 A	208 A
Fuse according to the IEC/UL	3NE1227-0 (250A)	3NE1230-0 (315A)	3NE1331-0 (350A)
Power loss	2.94 kW	3.70 kW	4.64 kW
Required cooling air flow	210 l/s	210 l/s	210 l/s
Weight	114 kg	114 kg	114 kg

# 11.6.10 Current derating depending on the pulse frequency, 690 V converters


#### LO base load

Article number	LO power [kW]	Pulse frequ	uency [kHz]
		2 *)	4
		LO base load ou	tput current [A]
6SL3210-1PH21-4 . L0	11	14	8.4
6SL3210-1PH22-0 . L0	15	19	11.4
6SL3210-1PH22-3 . L0	18.5	23	13.8
6SL3210-1PH22-7 . L0	22	27	16.2
6SL3210-1PH23-5 . L0	30	35	21
6SL3211PH24-2 . L0	37	42	25.2
6SL3210-1PH25-2 . L0	45	52	31.2
6SL3211PH26-2 . L0	55	62	37.2
6SL3210-1PH28-0 . L0	75	80	48
6SL3210-1PH31-0 . L0	90	100	60
6SL3210-1PH31-2 . L0	110	115	69
6SL3210-1PH31-4 . L0	132	142	85.2
6SL3210-1PH31-7CL0	160	171	102.6
6SL3210-1PH32-1CL0	200	208	124.8
6SL3210-1PH32-5CL0	250	250	150

<sup>\*)</sup> Factory setting

The permissible motor cable length depends on the particular cable type and the pulse frequency that has been selected

#### Typical converter load cycles



#### 11.7.1 Ambient conditions

#### **Ambient conditions during operation**

Property	Version			
Ambient conditions for transport in the transport packaging				
Climatic ambient conditions	- $40^{\circ}$ C + $70^{\circ}$ C, according to Class 2K4 to EN 60721-3-2 maximum humidity 95% at 40 °C			
Mechanical ambient condi-	FSC: Shock and vibration permissible according to 1M2 to EN 60721-3-2			
tions	FSD FSF: Shock and vibration permissible according to 2M3 to EN 60721-3-2			
Protection against chemical substances	Protected according to Class 2C2 to EN 60721-3-2			
Biological ambient conditions	Suitable according to Class 2B1 to EN 60721-3-2			
Ambient conditions for long	g-term storage in the product packaging			
Climatic ambient conditions	- 25 °C + 55 °C, according to Class 1K3 to EN 60721-3-1			
Protection against chemical substances	Protected according to Class 1C2 to EN 60721-3-1			
Biological ambient conditions	Suitable according to class 1B1 to EN 60721-3-1			
Ambient conditions in oper	Ambient conditions in operation			
Installation altitude	Up to 1000 m above sea level without limitations			
	Restrictions for special ambient conditions (Page 562)			

Property	Version	
Climatic ambient	Ambient operating temperature <sup>2)</sup>	
conditions 1)	– For operation according to Low Overload: $0^{\circ}$ C +40 $^{\circ}$ C	
	<ul> <li>For operation according to High Overload: 0° C +50° C</li> </ul>	
	<ul> <li>Restrictions for special ambient conditions (Page 562)</li> </ul>	
	Relative humidity: 5 95%, condensation not permitted	
	• Oil mist, salt mist, ice formation, condensation, dripping water, spraying water, splashing water and water jets are not permitted	
Mechanical ambient condi-	FSC FSF: Vibration levels permissible according to Class 3M1 to EN 60721-3-3	
tions	• FSC: Shock, permissible according to Class 3M2 to EN 60721-3-3	
	• FSD FSF: Shock permissible according to Class 3M1 to EN 60721-3-3	
Protection against chemical substances	Protected according to 3C2 to EN 60721-3-3	
Biological ambient conditions	Suitable according to 3C2 to EN 60721-3-3	
Pollution	Suitable for environments with degree of pollution 2 according to EN 61800-5-1, condensation not permitted	
Cooling	Forced air cooling AF, according to EN 60146	
Cooling air	Clean and dry air	

<sup>1)</sup> Increased ruggedness regarding temperature range and relative humidity; therefore better than 3K3 according to EN 60721-3-3

<sup>&</sup>lt;sup>2)</sup> Observe the permissible ambient temperatures for the Control Unit and possibly the operator panel (IOP-2 or BOP-2).

# 11.7.2 General technical data, PM250

Property	Version
Line voltage	380 480 V 3 AC ± 10%
Line impedance	Uk < 1% (RSC > 100), a line reactor is not permitted
Output voltage	3-phase 0 VAC input voltage x 0.87 (max.)
Input frequency	50 Hz 60 Hz, ± 3 Hz
Output frequency	0 550 Hz, depending on the control mode
Power factor λ	0.9
Inrush current	< LO base load input current
Pulse frequency (factory setting)	4 kHz The pulse frequency can be adjusted up to 16 kHz in 2 kHz steps. The higher the pulse frequency, the lower the available output current.  Restrictions for special ambient conditions (Page 562)
Electromagnetic compatibility	The devices comply with EN 61800-3: 2004 suitable for Category C2 and C3 environments.
Braking methods	<ul> <li>DC braking</li> <li>Regenerative feedback (energy recovery) max. with rated power based on high overload (HO)</li> </ul>
Degree of protection	IP20 chassis units

## 11.7.3 Specific technical specifications

#### Note

The values for Low Overload (LO) are identical with those of the rated values.

Table 11-72 PM250, IP20, Frame Size C, 3-ph. AC 380 V ... 480 V

Article No.	6SL3225-0BE25-5AA1	6SL3225-0BE27-5AA1	6SL3225-0BE31-1AA1
LO base load output	7.5 kW	11 kW	15 kW
LO base load input current	18 A	25 A	32 A
LO base load output current	18 A	25 A	32 A
HO base load output	5.5 kW	7.5 kW	11 kW
HO base load input current	13.2 A	19 A	26 A
HO base load output current	13.2 A	19 A	26 A
Fuse	20 A, Class J	32 A, Class J	35 A, Class J
Power loss	0.24 kW	0.30 kW	0.31 kW
Required cooling air flow	38 l/s	38 l/s	38 l/s
Sound pressure level L <sub>pA</sub> (1 m)	< 60 dB	< 60 dB	< 60 dB
Weight	7.5 kg	7.5 kg	7.5 kg

Table 11-73 PM250, IP20, Frame Size D, 3-ph. AC 380 V ... 480 V

Article No.	6SL3225-0BE31-5 . A0	6SL3225-0BE31-8. A0	6SL3225-0BE32-2.A0
LO base load output	18.5 kW	22 kW	30 kW
LO base load input current	36 A	42 A	56 A
LO base load output current	38 A	45 A	60 A
HO base load output	15 kW	18.5 kW	22 kW
HO base load input current	30 A	36 A	42 A
HO base load output current	32 A	38 A	45 A
Fuse according to IEC Fuse according to UL	3NA3820 50 A, Class J 3NE1817-0	3NA3822 63 A, Class J 3NE1818-0	3NA3824 80 A, Class J 3NE1820-0
Power loss	0.44 kW	0.55 kW	0.72 kW
Required cooling air flow	22 l/s	22 l/s	39 l/s
Sound pressure level L <sub>pA</sub> (1 m)	< 60 dB	< 60 dB	< 61 dB
Weight	15 kg	15 kg	16 kg

Table 11-74 PM250, IP20, Frame Size E, 3-ph. AC 380 V ... 480 V

Article No.	6SL3225-0BE33-0 . A0	6SL3225-0BE33-7 . A0	
LO base load output	37 kW	45 kW	
LO base load input current	70 A	84 A	
LO base load output current	75 A	90 A	
HO base load output	30 kW	37 kW	
HO base load input current	56 A	70 A	
HO base load output current	60 A	75 A	
Fuse according to IEC Fuse according to UL	3NA3830 100 A, Class J 3NE1821-0	3NA3832 125 A, Class J 3NE1822-0	
Power loss	1.04 kW	1.2 kW	
Required cooling air flow	22 l/s	39 l/s	
Sound pressure level L <sub>pA</sub> (1 m)	< 60 dB	< 62 dB	
Weight	21 kg	21 kg	

Table 11-75 PM250, IP20, Frame size F, 3-ph. AC 380 V ... 480 V

Article No.	6SL3225-0BE34-5 . A0	6SL3225-0BE35-5 . A0	6SL3225-0BE37-5 . A0
LO base load output	55 kW	75 kW	90 kW
LO base load input current	102 A	135 A	166 A
LO base load output current	110 A	145 A	178 A
HO base load output	45 kW	55 kW	75 kW
HO base load input current	84 A	102 A	135 A
HO base load output current	90 A	110 A	145 A
Fuse according to IEC Fuse according to UL	3NA3836 160 A, Class J 3NE1824-0	3NA3140 200 A, Class J 3NE1825-0	3NA3144 250 A, Class J 3NE1827-0
Power loss	1.5 kW	2.0 kW	2.4 kW
Required cooling air flow	94 l/s	94 l/s	117 l/s
Sound pressure level L <sub>pA</sub> (1 m)	< 60 dB	< 60 dB	< 65 dB
Weight	51 kg	51 kg	51 kg

# 11.7.4 Current reduction depending upon pulse frequency

## Relationship between pulse frequency and current reduction

Table 11-76 Current reduction depending on pulse frequency

Rated Power (LO)	Base load current (LO)	Base load	current (LO)	at pulse fre	quency of		
	4 kHz	6 kHz	8 kHz	10 kHz	12 kHz	14 kHz	16 kHz
kW	Α	Α	Α	Α	Α	Α	Α
0,55	1,7						
0,75	2,2						
1,1	3,1						
1,5	4,1						
2,2	5,9						
3	7,7						
4	10.2		,		,		
5,5	13.2						
7.5	18.0	12.5	11.9	10.6	9.20	7.90	6.60
11	25.0	18.1	17.1	15.2	13.3	11.4	9.50
15	32.0	24.7	23.4	20.8	18.2	15.6	12.8
18.5	38.0	32.3	26.6	22.8	19.0	17.1	15.2
22	45.0	38.3	31.5	27.0	22.5	20.3	18.0
30	60.0	51.0	42.0	36.0	30.0	27.0	24.0
37	75.0	63.8	52.5	45.0	37.5	33.8	30.0
45	90.0	76.5	63.0	54.0	45.0	40.5	36.0
55	110	93.5	77.0				
75	145	123	102				
90	178	151	125				

#### Data regarding the power loss in partial load operation 11.8

You can find data regarding power loss in partial load operation in the Internet:



Partial load operation (http://support.automation.siemens.com/WW/view/en/94059311)

## 11.9 Restrictions for special ambient conditions

#### 11.9.1 Permissible line supplies dependent on the installation altitude

#### Permissible line supplies dependent on the installation altitude

- For installation altitudes ≤ 2000 m above sea level, it is permissible to connect the converter to any of the line supplies that are specified for it.
- For installation altitudes 2000 m ... 4000 m above sea level, the following applies:
  - Connection to a TN line system with grounded neutral point is permissible.
  - TN systems with grounded line conductor are not permitted.
  - The TN line system with grounded neutral point can also be supplied using an isolation transformer.
  - The phase-to-phase voltage does not have to be reduced.

#### Note

Using Power Modules connected to TN line supplies with voltages ≥ 600 V for installation altitudes 2000 m ... 4000 m

For voltages  $\geq$  600 V, the TN line supply must have a grounded neutral point established using an isolating transformer.

#### Current derating as a function of the installation altitude

The permissible converter output current is reduced above an installation altitude of 1000 m.




Figure 11-6 Characteristic for PM230 Power Modules, PM250 Power Modules and PM330 Power Modules, HX and JX




Figure 11-7 Characteristic for the PM330 GX Power Module




Figure 11-8 Characteristic for PM240-2 Power Modules and PM240P-2 Power Modules

#### Current derating depending on the ambient air temperature

The Control Unit and Operator Panel can restrict the maximum permissible operating ambient temperature of the Power Module.




Figure 11-9 Characteristic for the PM230 Power Module




Figure 11-10 Characteristic for the PM330 Power Module




Figure 11-11 Characteristic for the PM250 Power Module

11.10 Protecting persons from electromagnetic fields

## 11.10 Protecting persons from electromagnetic fields

#### Overview

Protection of workers from electromagnetic fields is specified in the European EMF Directive 2013/35/EU. This directive is implemented in national law in the European Economic Area (EEA). Employers are obligated to design workplaces in such a way that workers are protected from impermissibly strong electromagnetic fields.

To this end, assessments and/or measurements must be performed for workplaces.

#### General conditions

The following general conditions apply for the evaluations and measurements:

- 1. The laws for protection from electromagnetic fields in force in individual EU member states can go beyond the minimum requirements of the EMF Directive 2013/35/EU and always take precedence.
- 2. The ICNIRP 2010 limits for the workplace are the basis for the assessment.
- 3. The 26th BImSchV (German Federal Emission Protection Regulation) defines 100  $\mu$ T (RMS) for the assessment of active implants. According to Directive 2013/35/EU, 500  $\mu$ T (RMS) at 50 Hz is applicable here.
- 4. The routing of power cables has a significant impact on the electromagnetic fields that occur. Install and operate the components inside metallic cabinets in compliance with the documentation and use shielded motor cables.
  - EMC-compliant setup of the machine or plant (Page 64)

#### Evaluation of the converter

The converters are normally used in machines. The assessment and testing is based on DIN EN 12198.

Compliance with the limit values was assessed for the following frequencies:

- Line frequency 47 ... 63 Hz
- Pulse frequency, for example 4/8/16 kHz and multiples thereof, assessed up to a maximum of 100 kHz

The indicated minimum distances apply to the head and complete torso of the human body. Shorter distances are possible for extremities.

Table 11-77 Minimum distances to the converter

Individuals witho	ut active implants	Individuals with active implants					
Control cabinet closed	Control cabinet open	Control cabinet closed	Control cabinet open				
0 cm	Forearm length (approx. 35 cm)	Must be separately assess tive in					

Appendix

## A.1 New and extended functions

#### A.1.1 Firmware version 4.7 SP14

Table A-1 New functions and function changes in firmware 4.7 SP14

	Function		SINAMICS						
					G1	G1:	20D		
		G115D	G120C	CU230P-2	CU240B-2	CU240E-2	CU250S-2	CU240D-2	CU250D-2
1	The G115D converter now supports the extended safety function 'Safety Limited Speed (SLS)' when using motors from SIEMENS and third-party manufacturers.	<b>\</b>	-	-	-	<b>✓</b>	-	1	-

#### A.1.2 Firmware version 4.7 SP13

Table A-2 New functions and function changes in firmware 4.7 SP13

	Function	SINAMICS									
						G1	20		G12	20D	
		G115D	G110M	G120C	CU230P-2	CU240B-2	CU240E-2	CU250S-2	CU240D-2	CU250D-2	
1	SIMOTICS 1FP1 and 1FP3 synchronous-reluctance motors have also been approved for operation with SINAMICS G120C.	-	1	1	1	1	1	-	1	-	
2	The extended safety functions SS1, SLS, SSM and SDI are approved when using synchronous-reluctance motors from Siemens and third-party manufacturers.	-	-	-	-	-	1	-	✓	-	
3	The converter transmits the state of the fail-safe digital input F-DI 0 via PROFIsafe when using the basic functions.	1	1	1	-	-	1	1	1	1	
	You can find more information in the "Safety Integrated" Function Manual.  "Safety Integrated" function manual ( <a href="https://support.industry.siemens.com/cs/ww/en/view/109751320">https://support.industry.siemens.com/cs/ww/en/view/109751320</a> )										

#### A.1 New and extended functions

	Function	SINAMICS								
						G1	20		G12	20D
4	Modbus RTU:	-	-	1	1	1	1	✓	-	-
	The converter supports the combination "1 stop bit" and "no parity".									
5	EtherNet/IP:	1	1	1	1	-	1	1	1	<b>\</b>
	When selecting the ODVA AC/DC drive profile, although telegram 1 is predefined, it can be extended to include additional process data.									
	The EDS file has been extended accordingly by a telegram with a length of 6 words.									
	More information is provided in the "Fieldbuses" Function Manual.									
	"Fieldbus" function manual (https://									
	support.industry.siemens.com/cs/ww/en/view/109751350)									
	EDS (https://support.industry.siemens.com/cs/ww/de/view/78026217)									

#### A.1.3 Firmware version 4.7 SP10

Table A-3 New functions and function changes in firmware 4.7 SP10

	Function SINAMICS									
					G1	20		G12	20D	
		G110M	G120C	CU230P-2	CU240B-2	CU240E-2	CU250S-2	CU240D-2	CU250D-2	ET 200pro FC-2
1	New parameter r7844 [1] for displaying the firmware version in plain text.	1	1	1	1	1	1	1	1	1
	"04070901" is equivalent to firmware version V4.7 SP9 HF1, for example									
2	<ul> <li>Modbus RTU:</li> <li>The factory setting of parameter p2040 was increased to provide more robust converter operation. Monitoring time for data failure at the Modbus interface: p2040 = 10 s</li> </ul>	•	•	•	•	•	•	-	-	-
_	r2057 indicates how the address switch on the converter is set									$\vdash$
3	<ul> <li>BACnet MS/TP:</li> <li>New factory setting for more robust converter operation: <ul> <li>Baud rate p2020 = 38.4 kBd</li> <li>Monitoring time for data failure at the BACnet interface was increased: p2040 = 10 s</li> <li>Factory setting for the maximum number of info frames p2025 [1] = 5</li> <li>Factory setting for the maximum number of manager addresses p2025 [3] = 32</li> </ul> </li> <li>r2057 indicates how the address switch on the converter is set</li> </ul>	-	-		-	-	-	-	-	-
4	Further technological unit kg/cm² for unit switchover	1	1	1	1	1	1	1	1	1
5	Further technological unit kg/cm² for additional technology controllers	_	-	1	_	_	-	_	_	-

	Function	SINAMICS								
				G120				G12	20D	
6	Commissioning with predefined motor data for SIMOTICS GP/SD synchronous-reluctance motors:	1	-	1	-	1)	-	1	-	-
	Second generation: 1FP1 . 04 → 1FP1 . 14									
	Further frame sizes:									
	- 1.1 kW 3 kW, 1500 1/min, 1800 1/min, 2810 1/min									
	- 0.75 kW 4 kW, 3000 1/min, 3600 1/min									
	In planning:									
	- 37 kW 45 kW, 1500 1/min, 1800 1/min, 2810 1/min									
	- 5.5 kW 18.5 kW, 3000 1/min, 3600 1/min									
	- 45 kW, 3000 1/min, 3600 1/min									
	The predefined motor data is already included in the firmware									
7	Extended setting option for evaluating the STOP cam in the "basic positioner" function	-	-	-	-	-	1	-	1	-
	Two different functions to evaluate STOP cams can be set:									
	Edge-triggered evaluation (factory setting)									
	Level-triggered evaluation									
	For more information, refer to the "Basic Positioner" Function Manual or the operating instructions for "SINAMICS G120D Converter with CU250D-2 Control Units".									
	"Basic positioner" function manual ( <a href="https://support.industry.siemens.com/cs/ww/en/view/109477922">https://support.industry.siemens.com/cs/ww/en/view/109477922</a> )									
	Operating instructions SINAMICS G120D with CU250D-2 (https://support.industry.siemens.com/cs/ww/en/view/109477365)									

<sup>1)</sup> Installation with PM240-2 or PM240P-2 Power Modules

## A.1.4 Firmware version 4.7 SP9

Table A-4 New functions and function changes in firmware 4.7 SP9

	Function		SINAMICS									
				G120 G120D								
		G110M	G120C	CU230P-2	CU240B-2	CU240E-2	CU250S-2	CU240D-2	CU250D-2	ET 200pro FC-2		
1	Support of PM240-2 FSG Power Modules	-	-	1	1	1	1	-	-	-		
2	Support of PM240-2 Power Modules in push-through technology, frame sizes FSD FSF, for the following voltages:  • 3 AC 200 V 240 V  • 3 AC 380 V 480 V  • 3 AC 500 V 690 V	-	-	•	<b>✓</b>	1	<b>✓</b>	-	-	-		
3	Shortened switch-on time for PM330 Power Modules	-	-	✓	-	-	-	-	-	-		
4	Expansion of the support for 1FP1 synchronous-reluctance motor with the following converters:  • SINAMICS G110M  • SINAMICS G120D  • SINAMICS G120 with CU240B-2 or CU240E-2 Control Unit A PM240-2 Power Module is required to operate a 1FP1 synchronous-reluctance motor with SINAMICS G120	•	-	<b>✓</b>	•	<b>✓</b>	-	<b>✓</b>	-	-		
5	Support of 1FP3 synchronous-reluctance motors	-	-	1	-	-	-	-	-	-		
	A PM240-2 Power Module is required to operate a 1FP3 synchronous-reluctance motor along with a selective release from SIEMENS											
6	Support of 1LE5 induction motors	-	✓	1	1	1	1	-	-	-		
7	The converter supports forming of the PM330 Power Module DC link capacitors	-	-	<b>✓</b>	-	-	-	-	-	-		
8	Setting option for two output reactors using parameter p0235 at the SI-NAMICS G120C and SINAMICS G120 with PM240-2 FSD FSF Power Module	-	✓	1	1	1	1	-	-	-		
9	Efficiency-optimized operation of induction motors Improved method "Efficiency optimization 2"	✓	✓	1	✓	1	<b>✓</b>	1	✓	<b>✓</b>		
10	New setting option for the "Technology application" p0500 = 5 during quick commissioning	1	•	1	1	<b>/</b>	<b>/</b>	<b>/</b>	1	1		
11	Expansion of the available PROFIdrive telegrams in the SINAMICS G120C to include telegram 350	-	1	1	1	1	1	-	-	-		
12	An SSI encoder can be parameterized as motor encoder	-	-	-	-	-	1	-	✓	-		
13	Expansion of the "Basic positioner" function to include the feedback signal from traversing blocks to the higher-level control system	-	-	-	-	-	1	-	1	-		
14	<ul> <li>Feedback signal supplemented to indicate that a memory card is not inserted in the converter:</li> <li>Parameter r9401 as BiCo parameter for the optional feedback signal to the higher-level control system.</li> <li>New alarm A01101</li> </ul>	•	•	•	•	•	<b>✓</b>	<b>✓</b>	•	•		

## A.1 New and extended functions

	Function		SINAMICS								
				G120				G12	20D		
15	Expansion of the "End stop control" function on the following converters:	1	✓	1	1	1	1	✓	1	-	
	SINAMICS G120										
	SINAMICS G120C										
	SINAMICS G120D										
16	Expansion of the technology controller to include the following functions:	-	-	1	-	1	-	-	-	-	
	• Gain $K_P$ and integral time $T_N$ can be adapted.										
	The system deviation can be used as adaptation signal										
17	Expansion to the torque limiting for SINAMICS G120 converters with CU230P-2 Control Unit	1	✓	1	1	1	1	1	1	<b>✓</b>	
18	The converter displays the state "PROFlenergy pause" as follows:	1	1	1	1	1	1	1	1	1	
	LED RDY "green on": 0.5 s										
	• LED RDY off: 3 s										

## A.1.5 Firmware version 4.7 SP6

Table A-5 New functions and function changes in firmware 4.7 SP6

	Function	SINAMICS																							
				G120			G120			G120			G120		G120		G120		G120		20		G120D		
		G110M	G120C	CU230P-2	CU240B-2	CU240E-2	CU250S-2	CU240D-2	CU250D-2	ET 200pro FC-2															
1	Support for the Power Module PM240-2, FSF frame sizes	-	-	1	1	1	1	-	-	-															
	Support of PM240P-2 Power Modules frame sizes FSD FSF	-	-	✓	<b>✓</b>	✓	-	-	-	-															
	Support of safety function Safe Torque Off (STO) via the terminals of the PM240-2 Power Module, frame size FSF and PM240P-2 Power Module FSD FSF	-	-	-	-	✓	✓	-	-	-															
2	Support for Power Module PM330 JX frame size	-	-	1	-	-	-	-	-	-															
3	Support for 1PC1 induction motors	✓	<b>✓</b>	✓	1	✓	✓	1	✓	1															
4	The control of synchronous reluctance takes into account the inductance of the output reactor.	-	-	1	-	-	-	-	-	-															
5	Support of motor temperature sensor Pt1000	1	1	1	1	1	1	1	1	1															
6	New p4621 parameter for disabling PTC short-circuit monitoring	-	-	-	-	-	-	1	1	1															
7	Revision of the thermal motor model for protecting the motor against damage due to overheating in the stator or rotor	1	1	1	1	1	<b>✓</b>	1	1	1															
8	Changing the quick commissioning in the "Standard Drive Control" application class:	-	<b>✓</b>	<b>✓</b>	1	1	✓	-	-	-															
	The motor data identification is no longer permanently set to p1900 = 12; instead, users select the appropriate motor data identification.																								
	Factory setting: p1900 = 2.																								
9	The free function blocks are also available in the SINAMICS G120C.	✓	✓	✓	1	1	✓	✓	-	-															

## A.1.6 Firmware version 4.7 SP3

Table A-6 New functions and function changes in firmware 4.7 SP3

	Function	SINAMICS										
			G120 G120D									
		G110M	G120C	CU230P-2	CU240B-2	CU240E-2	CU250S-2	CU240D-2	CU250D-2	ET 200pro FC-2		
1	PM240-2 Power Modules, frame sizes FSD and FSE are supported	-	-	1	1	1	1	-	-	-		
	The Safety Integrated Basic Function Safe Torque Off (STO) is supported via the terminals of the PM240-2 Power Module, frame sizes FSD and FSE	-	-	-	-	<b>✓</b>	<b>✓</b>	-	-	-		
2	Revised PM230 Power Module with new article numbers supported:	-	-	✓	✓	✓	-	-	-	-		
	IP55 degree of protection: 6SL3223-0DE <b>G</b> .											
	• IP20 degree of protection and Push Through: 6SL3211NE <b>G</b> .											
	The Safety Integrated Basic Function Safe Torque Off (STO) is supported with the revised PM230 Power Module	-	-	-	-	1	-	-	-	-		
3	PM330 Power Module, frame size HX is supported	-	-	1	-	-	-	-	-	-		
4	Support of 1FP1 synchronous-reluctance motors	-	-	1	-	-	-	-	-	-		
5	Encoderless 1FG1 geared synchronous motors are supported	-	-	-	-	-	-	1	-	-		
6	Selection list for 1PH8 induction motors in the STARTER and Startdrive commissioning wizard	-	<b>✓</b>	<b>✓</b>	1	1	<b>✓</b>	-	-	-		
7	Updated selection list for 1LE1 induction motors in the STARTER and Start- drive commissioning wizard	<b>✓</b>	1	1	1	1	1	1	1	1		
8	Motor support expanded with 1LE1, 1LG6, 1LA7 and 1LA9 induction motors	✓	-	-	-	-	-	-	-	-		
9	Speed and position control obtain their respective actual value from an SSI encoder with incremental tracks. The output signals of the encoder are available as encoder 2 for position control and timer 1 for speed control.	-	-	-	-	-	✓	-	✓	-		
10	Power Module with temperature-controlled fan	1	-	-	-	-	-	-	-	-		
11	SINAMICS "Standard Drive Control" and "Dynamic Drive Control" application classes to simplify commissioning and increase the degree of ruggedness of the closed-loop motor control.	-	1	1	1	✓	1	-	-	-		
	The SINAMICS application classes are available with the following converters:											
	SINAMICS G120C											
	SINAMICS G120 with PM240, PM240-2 and PM330 Power Modules											
12	Moment of inertia estimator with moment of inertia precontrol to optimize the speed controller in operation	1	<b>'</b>	-	<b>/</b>	1	<b>′</b>	<b>/</b>	1	<b>✓</b>		
13	Friction torque characteristic with automatic plotting to optimize the speed controller	<b>✓</b>	1	-	1	1	1	1	<b>✓</b>	<b>✓</b>		
14	Automatic optimization of the technology controller	-	-	1	1	1	-	-	-	-		
15	The sign of the system deviation for the additional, free technology controller can be switched over.	-	-	<b>1</b>	-	-	-	-		-		
	A new parameter defines the sign of the system deviation matching the particular application, e.g. for cooling or heating applications.											

## A.1 New and extended functions

	Function	SINAMICS								
				G120 G120D						
16	The technology controller output can be enabled and disabled during operation	-	1	1	1	1	1	-	-	-
17	Ramp-function generator remains active with enabled technology controller	-	-	1	-	-	-	-	-	-
18	Line contactor control using a digital output of the converter to save energy when the motor is switched off	✓	<b>✓</b>	1	1	1	1	1	1	-
19	Fast flying restart for PM330 Power Modules:	-	-	1	-	-	-	-	-	-
	The "Flying restart" function does not have to wait for the motor demagnetization time, and identifies the motor speed without requiring a search operation.									
20	Load torque monitoring extended to include the following functions:	✓	-	✓	✓	✓	-	-	-	-
	Protection against blocking, leakage and dry running operation in pump applications									
	Protection against blocking and broken belts in fan applications									
21	Automatic switchover of the real time clock from daylight saving time (summer time) to standard time (winter time).	-	-	1	-	-	-	-	-	-
22	New or revised default settings of the interfaces: p0015 macros 110, 112 and 120	-	-	1	-	-	-	-	-	-
23	Expansion of the temperature sensors to include DIN-Ni1000 for analog inputs AI 2 and AI 3	-	-	1	-	-	-	-	-	-
24	Communication via AS-Interface.	1	-	-	-	-	-	-	-	-
	Default setting of the communication via AS-i: p0015 macros 30, 31, 32 and 34									
25	Communication expansion via Modbus:	1	1	1	1	1	1	-	-	-
	Adjustable parity bit, access to parameters and analog inputs									
26	Extending communication via BACnet:	-	-	1	-	-	-	-	-	-
	Access to parameters and analog inputs									
27	The bus error LED for communication via USS and Modbus can be switched off	1	1	1	1	1	1	-	-	-
28	Default of the minimum speed to 20 % of the rated motor speed	-	-	1	-	-	-	-	-	-
29	For commissioning with an operator panel, the converter automatically backs up the measured data retentively in the ROM after identification of the motor data.	✓	1	1	✓	1	1	1	✓	1
30	The result of the energy savings calculation for flow machines is available as a connector	1	1	1	1	1	1	1	1	1
31	New "ppm" unit (parts per million) for unit switching	1	1	1	1	1	1	1	1	1
32	Displaying speeds during commissioning via operator panel in units of Hz instead of rpm. Conversion from Hz to rpm via p8552	-	-	1	-	-	-	-	-	-
33	Voltage-dependent current limit for 600V devices of Power Module PM330 and PM240-2	-	-	1	1	1	1	-	-	-

## A.1.7 Firmware version 4.7

Table A-7 New functions and function changes in Firmware 4.7

	Function				SINAMICS							
					G12	20D						
		G110M	G120C	CU230P-2	CU240B-2	CU240E-2	CU250S-2	CU240D-2	CU250D-2			
1 9	Supporting the identification & maintenance datasets (I&M1 4)	1	1	1	1	1	1	1	1			
2 I	Fall in pulse rate with increased drive power required by the motor	1	1	1	1	1	1	1	1			
	<ul> <li>The converter temporarily lowers the pulse frequency if required when the motor is started up, and simultaneously increases the current limit.</li> </ul>											
3 9	S7 communication	1	1	1	1	1	1	1	1			
	• Direct data exchange between the converter and human-machine interface (HMI).											
	<ul> <li>Increase in communication performance with the engineering tools and support of the S7 routing</li> </ul>											
	The basic functions of Safety Integrated are unrestrictedly available in all control types with 1FK7 encoderless permanent-field synchronous motors	-	-	-	-	-	-	1	-			
5 I	Encoderless 1FK7 synchronous motors are supported	-	-	-	-	-	-	1	-			
	<ul> <li>Direct motor selection based on the article number with associated code number</li> </ul>											
•	It is not necessary to input individual motor data											
6 I	Pulse input as source of setpoint value	-	-	-	-	-	✓	-	-			
	<ul> <li>The converter calculates its speed setpoint from a sequence of pulses at the digital input.</li> </ul>											
<b>I</b>	Dynamic IP address assignment (DHCP) and temporary device names for PROFI- NET	1	<b>✓</b>	✓	-	1	<b>✓</b>	<b>✓</b>	1			
8 I	PROFlenergy device profile 2 and 3	✓	1	✓	-	✓	✓	✓	1			
9 1	Uniform behavior for component replacement	1	1	-	-	1	1	1	1			
	<ul> <li>After a component is replaced, a converter with activated Safety Integrated will report what type of component has been replaced using a unique code.</li> </ul>											
10 I	Improved direct-component control in PM230	-	-	1	-	-	-	-	-			
•	Optimized efficiency for pump and fan applications											
11	Rounding down of BACnet and macros	-	-	1	-	-	-	-	- ]			

#### A.1 New and extended functions

## A.1.8 Firmware version 4.6 SP6

Table A-8 New functions and function changes in firmware 4.6 SP6

	Function		SINAMICS						
				G1	G1:	20D			
		G120C	CU230P-2	CU240B-2	CU240E-2	CU250S-2	CU240D-2	CU250D-2	
1	Support for the new Power Modules	-	1	-	-	-	-	-	
	• PM330 IP20 GX								

# A.1.9 Firmware version 4.6

Table A-9 New functions and function changes in Firmware 4.6

	Function	SINAMICS							
			G120			G12	G120D		
		G120C	CU230P-2	CU240B-2	CU240E-2	CU250S-2	CU240D-2	CU250D-2	
1	Support for the new Power Modules	-	1	1	1	1	-	-	
	• PM240-2 IP20 FSB FSC								
	PM240-2 in through-hole technology FSB FSC								
2	Support for the new Power Modules	-	1	1	1	-	-	-	
	PM230 in through-hole technology FSD FSF								
3	Motor data preassignment for the 1LA/1LE motors via code number	1	1	1	1	1	1	1	
	During quick commissioning with the operator panel, set the motor data using a code number								
4	Extension to communication via CANopen	1	1	-	-	1	-	-	
	CAN velocity, ProfilTorque, SDO channel for each axis, system test with CodeSys, suppression of ErrorPassiv alarm								
5	Extension to communication via BACnet	-	1	-	-	-	-	-	
	Multistate value objects for alarms, commandable AO objects, objects for configuring the PID controller								
6	Communication via EtherNet/IP	1	1	-	1	1	1	1	
7	Skip frequency band for analog input	✓	✓	✓	1	1	1	-	
	A symmetrical skip frequency band can be set for each analog input around the 0 V range.								
8	Changing the control of the motor holding brake	✓	-	✓	✓	<b>✓</b>	✓	-	
9	Safety function SBC (Safe Brake Control)	-	-	-	-	✓	-	-	
	Secure control of a motor holding brake when using the "Safe Brake Module" option								
10	Safety function SS1 (Safe Stop 1) without speed monitoring	-	-	-	-	1	-	-	
11	Straightforward selection of standard motors	1	1	✓	1	1	1	1	
	Selection of 1LA and 1LE motors with an operator panel using a list containing code numbers								
12	Firmware update via memory card	✓	✓	1	1	1	1	<b>✓</b>	
13	Safety info channel	-	-	-	1	1	1	<b>/</b>	
	BICO source r9734.014 for the status bits of the extended safety functions								
14	Diagnostic alarms for PROFIBUS	✓	1	✓	✓	1	✓	✓	

# A.1 New and extended functions

# A.1.10 Firmware version 4.5

Table A-10 New functions and function changes in Firmware 4.5

	Function			SINAMICS					
				G120			G120D		
		G120C	CU230P-2	CU240B-2	CU240E-2	CU240D-2	CU250D-2		
1	Support for the new Power Modules:	-	1	1	1	-	-		
	PM230 IP20 FSA FSF								
	PM230 in a push-through FSA FSC								
2	Support for the new Power Modules:	-	1	1	1	-	-		
	• PM240-2 IP20 FSA								
	PM240-2 in push-through FSA								
3	New Control Units with PROFINET support	1	1	-	1	1	1		
4	Support of the PROFlenergy profile	1	1	-	1	1	1		
5	Shared device support via PROFINET	<b>✓</b>	✓	-	1	1	<b>✓</b>		
6	Write protection	<b>✓</b>	<b>✓</b>	<b>✓</b>	1	1	✓		
7	Know-how protection	✓	<b>✓</b>	<b>✓</b>	<b>✓</b>	1	✓		
8	Adding a second command data set (CDS0 → CDS0 CDS1)	1	-	-	-	-	-		
	(All other converters have four command data sets)								
9	Position control and basic positioner	-	-	-	-	-	✓		
10	Support of an HTL encoder	-	-	-	-	1	1		
11	Support of an SSI encoder	-	-	-	-	-	1		
12	Failsafe digital output	-	-	-	-	1	<b>✓</b>		

# A.2 Interconnecting signals in the converter

#### A.2.1 Fundamentals

The following functions are implemented in the converter:

- Open-loop and closed-loop control functions
- Communication functions
- · Diagnosis and operating functions

Every function comprises one or several blocks that are interconnected with one another.




Figure A-1 Example of a block: Motorized potentiometer (MOP)

Most of the blocks can be adapted to specific applications using parameters.

You cannot change the signal interconnection within the block. However, the interconnection between blocks can be changed by interconnecting the inputs of a block with the appropriate outputs of another block.

The signal interconnection of the blocks is realized, contrary to electric circuitry, not using cables, but in the software.




Figure A-2 Example: Signal interconnection of two blocks for digital input 0

#### Binectors and connectors

Connectors and binectors are used to exchange signals between the individual blocks:

- Connectors are used to interconnect "analog" signals (e.g. MOP output speed)
- Binectors are used to interconnect digital signals (e.g. "Enable MOP up" command)




Figure A-3 Symbols for binector and connector inputs and outputs

Binector/connector outputs (CO/BO) are parameters that combine more than one binector output in a single word (e.g. r0052 CO/BO: status word 1). Each bit in the word represents a digital (binary) signal. This summary reduces the number of parameters and simplifies parameter assignment.

Binector or connector outputs (CO, BO or CO/BO) can be used more than once.

# Interconnecting signals

#### When must you interconnect signals in the converter?

If you change the signal interconnection in the converter, you can adapt the converter to a wide range of requirements. This does not necessarily have to involve highly complex functions.

Example 1: Assign a different function to a digital input.

Example 2: Switch the speed setpoint from the fixed speed to the analog input.

#### Principle when connecting BICO blocks using BICO technology

When interconnecting the signal, the following principle applies: Where does the signal come from?

An interconnection between two BICO blocks consists of a connector or a binector and a BICO parameter. The input of a block must be assigned the output of a different block: In the BICO parameters, enter the parameter numbers of the connector/binector that should supply its output signal to the BICO parameter.

# How much care is required when you change the signal interconnection?

Note which changes you make. A subsequent analysis of the set signal interconnections is possible only by evaluating the parameter list.

#### Where can you find additional information?

- All the binectors and connectors are located in the Parameter list.
- The function diagrams provide a complete overview of the factory setting for the signal interconnections and the setting options.

# A.2.2 Application example

# Shift the control logic into the converter

It is only permissible that a conveyor system starts when two signals are present simultaneously. These could be the following signals, for example:

- The oil pump is running (the required pressure level is not reached, however, until after 5 seconds)
- The protective door is closed

To implement this task, you must insert free function blocks between digital input 0 and the command to switch on the motor (ON/OFF1).




Figure A-4 Signal interconnection for control logic

The signal of digital input 0 (DI 0) is fed through a time block (PDE 0) and is interconnected with the input of a logic block (AND 0). The signal of digital input 1 (DI 1) is interconnected to the second input of the logic block. The logic block output issues the ON/OFF1 command to switch-on the motor.

#### Setting the control logic

Parameter	Description
p20161 = 5	The time block is enabled by assigning to runtime group 5 (time slice of 128 ms)
p20162 = 430	Run sequence of the time block within runtime group 5 (processing before the AND logic block)
p20032 = 5	The AND logic block is enabled by assigning to runtime group 5 (time slice of 128 ms)
p20033 = 440	Run sequence of the AND logic block within runtime group 5 (processing after the time block)
p20159 = 5000.00	Setting the delay time [ms] of the time module: 5 seconds
p20158 = 722.0	Connect the status of DI 0 to the input of the time block
	r0722.0 = Parameter that displays the status of digital input 0.
p20030[0] = 20160	Interconnecting the time block to the 1st AND input
p20030[1] = 722.1	Interconnecting the status of DI 1 to the 2nd AND input
	r0722.1 = Parameter that displays the status of digital input 1.
p0840 = 20031	Interconnect the AND output to ON/OFF1

# A.2 Interconnecting signals in the converter

# Explanation of the application example using the ON/OFF1 command

Parameter p0840[0] is the input of the "ON/OFF1" block of the converter. Parameter r20031 is the output of the AND block. To interconnect ON/OFF1 with the output of the AND block, set p0840 = 20031.




Figure A-5 Interconnecting blocks by setting p0840[0] = 20031

## A.3.1 Overview of the manuals

#### **Converter Manuals**

• CU230P-2 List Manual (<a href="https://support.industry.siemens.com/cs/ww/en/view/109782303">https://support.industry.siemens.com/cs/ww/en/view/109782303</a>)

Parameter list, alarms and faults. Graphic function diagrams



• CU230P-2 operating instructions (<a href="https://support.industry.siemens.com/cs/ww/en/view/109782866">https://support.industry.siemens.com/cs/ww/en/view/109782866</a>)

Installing, commissioning and maintaining the converter. Advanced commissioning (this manual)



# Supplementary manuals for converter

• "Fieldbus" function manual (<a href="https://support.industry.siemens.com/cs/ww/en/view/">https://support.industry.siemens.com/cs/ww/en/view/</a> 109751350)

Configuring fieldbuses.



• "Safety Integrated" function manual (<a href="https://support.industry.siemens.com/cs/ww/en/view/109751320">https://support.industry.siemens.com/cs/ww/en/view/109751320</a>)

Configuring PROFIsafe. Installing, commissioning and operating failsafe functions of the converter



• Power Module Installation Manual (<a href="https://support.industry.siemens.com/cs/ww/en/ps/13224/man">https://support.industry.siemens.com/cs/ww/en/ps/13224/man</a>)

Installing Power Modules, reactors and filters. Technical data, maintenance

• PM330 Hardware Installation Manual (<a href="https://support.industry.siemens.com/cs/ww/en/view/109748647">https://support.industry.siemens.com/cs/ww/en/view/109748647</a>)

Installing Power Modules, reactors and filters. Technical data, maintenance

• G120P Cabinet operating instructions (<a href="https://support.industry.siemens.com/cs/ww/en/view/109749009">https://support.industry.siemens.com/cs/ww/en/view/109749009</a>)
Installing, commissioning, operating and maintaining converter cabinet units

## Converter accessory manuals

BOP-2 operating instructions (<a href="https://support.industry.siemens.com/cs/ww/en/view/109483379">https://support.industry.siemens.com/cs/ww/en/view/109483379</a>)

Using the Operator Panel.

Operating instructions IOP-2 (<a href="https://support.industry.siemens.com/cs/ww/en/view/">https://support.industry.siemens.com/cs/ww/en/view/</a>
 109808456)

Using the operator panel, door mounting kit for mounting an IOP-2.

• Accessories manual (<a href="https://support.industry.siemens.com/cs/ww/en/ps/13225/man">https://support.industry.siemens.com/cs/ww/en/ps/13225/man</a>) Installation descriptions for converter components, e.g. line reactors and line filters. The printed installation descriptions are supplied together with the components.

## Additional information


EMC installation guideline (<a href="http://support.automation.siemens.com/WW/view/en/">http://support.automation.siemens.com/WW/view/en/</a> 60612658)

EMC-compliant control cabinet design, equipotential bonding and cable routing



# Finding the most recent edition of a manual

If there a multiple editions of a manual, select the latest edition:



## Configuring a manual

Further information about the configurability of manuals is available in the Internet:

MyDocumentationManager (<a href="https://www.industry.siemens.com/topics/global/en/planning-efficiency/documentation/Pages/default.aspx">https://www.industry.siemens.com/topics/global/en/planning-efficiency/documentation/Pages/default.aspx</a>).

Select "Display and configure" and add the manual to your "mySupport-documentation":



Not all manuals can be configured.

The configured manual can be exported in RTF, PDF or XML format.

# A.3.2 Configuring support

## Catalog

Ordering data and technical information for the converters SINAMICS G.



Catalogs for download or online catalog (Industry Mall):



#### **SIZER**

The configuration tool for SINAMICS, MICROMASTER and DYNAVERT T drives, motor starters, as well as SINUMERIK, SIMOTION controllers and SIMATIC technology



Article number: 6SL3070-0AA00-0AG0

Download SIZER (<a href="http://support.automation.siemens.com/WW/view/en/">http://support.automation.siemens.com/WW/view/en/</a> 10804987/130000)

# EMC (electromagnetic compatibility) technical overview

Standards and guidelines, EMC-compliant control cabinet design



EMC overview (https://support.industry.siemens.com/cs/ww/en/view/103704610)

## **EMC Guidelines configuration manual**

EMC-compliant control cabinet design, potential equalization and cable routing



EMC installation guideline (<a href="http://support.automation.siemens.com/WW/view/en/">http://support.automation.siemens.com/WW/view/en/</a> 60612658)

#### See also

All about SINAMICS G120C (www.siemens.com/sinamics-g120c)

Safety Integrated for novices (<a href="https://support.industry.siemens.com/cs/ww/en/view/80561520">https://support.industry.siemens.com/cs/ww/en/view/80561520</a>)

# A.3.3 Product Support

## Overview

You can find additional information about the product on the Internet:

Product support (<a href="https://support.industry.siemens.com/cs/ww/en/">https://support.industry.siemens.com/cs/ww/en/</a>)

This URL provides the following:

- Up-to-date product information (product announcements)
- FAQs
- Downloads
- The Newsletter contains the latest information on the products you use.
- The Knowledge Manager (Intelligent Search) helps you find the documents you need.
- Users and specialists from around the world share their experience and knowledge in the Forum.
- You can find your local representative for Automation & Drives via our contact database under "Contact & Partner".
- Information about local service, repair, spare parts and much more can be found under "Services".

If you have any technical questions, use the online form in the "Support Request" menu:



# Index

	Braking
	Regenerative, 391
3	Braking functions, 378
3RK3 (modular safety system), 149	Braking method, 378
	Braking module, 387
	Braking resistor, 387
8	Bus termination, 118, 119
87 Hz characteristic, 114	Bypass, 426
87 Hz characteristic, 114	
o, ne characteristic, nn	С
	Cable registance 264
A	Cascada control 357
Acyclic communication, 200	Catalog 584
Acyclic communication, 298 Additional technology controller 0, 320	Catalog, 584 CDS (Command Data Set), 313
Alarm, 361, 441, 447	Centrifuge, 380, 385, 387, 391
Alarm buffer, 361, 447	Characteristic
Alarm code, 447	Additional, 367
Alarm history, 448	Linear, 367, 370
Alarm time, 361, 447	parabolic, 367, 370
Alarm value, 447	square-law, 367, 370
Ambient temperature, 398, 399	Clockwise rotation, 266
Analog input, 122	Command data set, 313
Analog output, 122	Commissioning
Application example, 160, 162, 250, 259, 298, 329,	Guidelines, 165
332, 333, 579	Communication
Application example, 257	Acyclic, 298
Reading and writing parameters cyclically via	Compound braking, 385, 386
PROFIBUS, 298	Compressor, 39, 178, 183, 191, 199, 206
Arrangement of the mains and motor terminals, 98	Configuring support, 584
Article number, 32	Connectors, 578
Automatic mode, 314	Control terminals, 122
Automatic restart, 414	Control Units, 32
	Control word
D	Control word 1, 299, 307
В	Control word 3, 282 Control word 1, 280
Base load, 492	Control word 3 (STW3), 282
Base load input current, 492	Control word 3 (31W3), 282  Control word"; "Control word 1, 302
Base load output current, 492	Controlling the motor, 266
Base load power, 492	Converter
BF (Bus Fault), 442, 443, 444	does not respond, 486
BICO block, 577	Converter components, 32
Bimetallic switch, 396	Conveyor belt, 380
Binectors, 578	Conveyor systems, 204
Block, 577	Counter-clockwise rotation, 266
BOP-2	Current input, 255
Menu, 212 Symbols, 212	Current reduction, 506, 560
Jymbuls, 212	Cyclic communication, 295

	Fault, 361, 441
	Acknowledge, 451
D	Motor, 487
Data backup 210 229	Fault buffer, 361, 450
Data backup, 219, 228 Data transfer, 227	Fault case, 452
	Fault code, 450
Data set 47 (DS), 298	Fault history, 451
Date, 361	Fault time, 361, 450
Daylight saving time, 362	Received, 450
DC braking, 282, 380, 381, 382, 383	Removed, 450
DC link overvoltage, 401	Fault value, 450
DC link voltage, 401	FCC, 365
Deadband, 258	FCC (Flux Current Control), 367
Delta connection, 114	Field weakening, 114
Delta connection (Δ), 168, 169	Fieldbus interfaces, 118, 119, 157
Derating	Firmware, 32
Installation altitude, 562	Firmware downgrade, 483
Digital input, 122, 266	Firmware version, 565, 566, 567, 568, 569, 570, 571,
Digital output, 122	572, 573, 574, 575
Function, 253, 255, 259	Flow control, 340
DIP switch	Flux current control, 365
Analog input, 255	Flying restart, 412
Direct data exchange, 297	Formatting, 220
Direction of rotation, 331	Forming the DC-link capacitors, 170
Direction reversal, 266	Free function blocks, 315
Drive control, 241	Function Manual, 581
Drive Data Set, 438	Functions
Drive Data Set, DDS, 438	BOP-2, 212
DTC (Digital Time Clock), 363	Overview, 241
Dynamic braking, 387	Overview, 241
	G
E	
EMC, 64	Generator operation, 378
EMERGENCY STOP, 263	Grinding machine, 380, 385
EMERGENCY SWITCHING OFF, 263	
EN 60204-1, 263	
EN 61800-5-2, 262	Н
Energy recovery, 42	High Overload, 492
Energy recovery option, 391	Hoist drive, 391
Energy-saving display, 436	Hoisting gear, 387
ESM, 420	Horizontal conveyors, 385, 387
Essential service mode, 420	Hotline, 585
Extending the telegram, 296	110011110, 3003
Exterioring the telegram, 250	
	1
F	L
	I_max controller, 392
Factory assignment, 122	i2t monitoring, 395
Factory settings	Inclined conveyors, 387
Restoring the, 209, 210	IND (page index), 287, 291, 292
Fan, 38, 39, 40, 178, 183, 191, 199, 204, 206	Industry Mall, 584
Fans, 393	Installation altitude, 562

Installing, 71 Interfaces, 118 Interlock, 579	Motor code, 169 Motor control, 242 Motor data, 168 Identify, 180, 186, 188, 192, 376 Measure, 180, 186, 188, 192 Motor fault, 487
JOG function, 311	Motor holding brake, 262 Motor standard, 317 Motor temperature sensor, 122
K	Motorized potentiometer, 325 Multi-zone control, 354
Kinetic buffering, 417 Know-how protection, 220, 234 KTY84 sensor, 396	O
L  LED  BF, 442, 443, 444  LNK, 442  RDY, 442  LED (light emitting diode), 441  Level control, 340  License, 220  Line and motor connection, frame sizes  FSD FSF, 103, 113  Line contactor, 262  Line dip, 417  Line filter, 45  Linear characteristic, 367, 370  List Manual, 581  LNK (PROFINET Link), 442  Low Overload, 492	OFF1 command, 266 OFF3 ramp-down time, 338 ON command, 266 Operating instruction, 25 Operating Instructions, 581 Operation, 246 Operator panel BOP-2, 212 Menu, 212 Optimizing the closed-loop speed controller, 376 Output reactor, 364 Overload, 392 Overview Chapter, 26, 27 Overview of the functions, 241 Overvoltage, 401 Overvoltage protection, 154
	Parabolic characteristic, 367, 370
Manual mode, 314 Maximum cable length PROFIBUS, 161 PROFINET, 159 Maximum current controller, 392 Maximum speed, 173, 331 Memory cards, 220 Menu BOP-2, 212 Operator panel, 212 Minimum speed, 173, 331, 334 Modular Safety System, 149 MOP (motorized potentiometer), 325 MotID (motor data identification), 180, 186, 188, 192	Parameter channel, 285 IND, 287, 291, 292 Parameter index, 287, 291, 292 Parameter list, 581 Parameter number, 216, 287, 291, 292 Parameter value, 217 Parameters Overview, 244 Partial load operation, 561 PID controller, 340 PKW (parameter, ID value), 278 PLC functionality, 579 Power failure, 414 Power Module, 32 Pressure control, 340 Procedure, 25

PROFIBUS, 161 PROFIdrive, 157 PROFlenergy, 157 Protection functions, 242 Pt1000 sensor, 396 PTC sensor, 396 Pulse cancellation, 280, 299, 302, 308 Pulse enable, 280, 299, 302, 308 Pulse frequency, 394, 395, 506, 560 Pump, 38, 39, 40, 178, 183, 191, 199, 204, 206 PZD (process data), 278	Sine-wave filter, 55, 364 SIZER, 584 Skip frequency band, 331 Slip compensation, 365 Smart Access, 166 Speed change with BOP-2, 212 Limiting, 331 Speed control, 374 Square-law characteristic, 367, 370 Standards EN 61800-3, 33 Star connection (Y), 114
Q	Startdrive
Questions, 585	Download, 166 STARTER Download, 166
R	Starting behavior
Ramp-down time, 338 Ramp-function generator, 331 Ramp-up time, 338 RDY (Ready), 442 Ready, 246 Ready for switching on, 246 Real-time clock, 361 Real-Time Clock, 361 Regenerative feedback, 391 Reset Parameter, 209, 210 Reversing, 331 Rounding, 338 Rounding OFF3, 338 RTC (Real-Time Clock), 361, 363	Optimization, 372 Starting behavior"; "Optimization, 368 Starting current, 369 State overview, 245 Status word Status word 1, 280, 281, 300, 303, 309 Status word 3, 283 STO (Safe Torque Off), 262 select, 262 Stop Category 0, 263 Storage medium, 219 STW1 (control word 1), 280, 299, 302, 307 Subindex, 287, 291, 292 Support, 585 Switch off Motor, 246 OFF1 command, 246 OFF2 command, 246
S	OFF3 command, 246
S7 communication, 157 Saw, 380, 385 Scaling Analog input, 256 Analog output, 260 SD (memory card), 220 Formatting, 220	Switch on Motor, 246 ON command, 246 Switching on inhibited, 246, 281, 299, 302, 308 Symbols, 25 System runtime, 445
Sequence control, 245	Т
Series commissioning, 211 Setpoint processing, 242, 331 Setpoint source, 242 Selecting, 323, 324, 325 Settling time, 178, 183, 101, 100, 206	Technical data Control Unit, 489, 490, 491 General, 518 Task pology controller, 282, 210, 240
Settling time, 178, 183, 191, 199, 206 Short-circuit monitoring, 396, 397 Signal interconnection, 577	Technology controller, 282, 319, 340 Temperature calculation, 398 Temperature monitoring, 395, 398

Temperature sensor, 122
Temperature switch, 396
Terminal block, 248
Terminal strip, 154
Factory setting, 122
Three-wire control, 266
Time, 361
Time control, 363
Time switch, 363
Torque accuracy, 178, 183, 191, 199, 206
Two-wire control, 266
Type plate
Control Unit, 32
Power Module, 32

ZSW1 (status word 1), 280, 303, 309 ZWS3 (status word 3), 283 ZWST1 (status word 1), 300

## U

U/f characteristic, 365
Unit system, 317
Unwinders, 391
Upgrading the firmware, 481
Upload
Data transfer, 228
Download, 227
Use for the intended purpose, 29
User interfaces, 118
UTC (Universal Time Coordinated), 361

# ٧

Vdc\_min controller, 417
Vector control, 376
Sensorless, 374
Version
Control Unit, 32
Power Module, 32
Vertical conveyors, 387
Voltage boost, 365, 368, 369, 372
Voltage input, 255

#### W

Winders, 391 Wire-break monitoring, 257, 396, 397 Write protection, 231

## Ζ

Ziegler Nichols, 349 ZSW 1 (status word 1)", 281

# **Further information**

SINAMICS converters: www.siemens.com/sinamics

PROFINET

www.siemens.com/profinet

Siemens AG Digital Factory Motion Control Postfach 3180 91050 ERLANGEN Germany

